

TA298 indoor and outdoor temperature hygrometer manual

Uses:This product is suitable for,factories,warehouses, building air conditioning management,hospitals,aquaculture species,room,office,hotel,laboratory....Modern energy saving good helper.

The machine can be hung on the wall or on the table,on the back there is a hook and bracket

Measuring range:outdoor -40C~70(-40~158F)

degree of error:0.1c(0.1c)

Indoor0C-50(32F~122" F)

Humidity 10%~99%± 5%Resolution 1%

Function Test:Press MAX/MIN key once to display the previous maximum/minimum indoor and outdoor temperature and humidity values

When the MAX/MIN press the RESET button once to clear a previously memorized maximum or minimum Remeasure

When the MAX/MIN 8 seconds after the display returns to the current temperature and humidity display C/F key

Celsius and Fahrenheit Conversion

Time Debugging:

1 In the initial state,press and hold[MODE] for 2 seconds, the number of minutes the current time starts flashing,press the[ADJ] to adjust the hours,minutes.In normal time display mode,press the[ADJ]can be converted to 12/24 show.

2 In the current clock mode(clock and minutes between two blink once per second),press[MODE]once,switch the display to alarm mode(clock and minutes between two points is not flashing),press live[MODE]for 2 seconds,the alarm time flashes,press the [ADJ]can adjust the alarm time,minute. Alarm mode is displayed,press[ADJ] to set/cancel the alarm function.After setting press the[MODE]returns to normal time display.

This product uses 1.5v AAA batteries External 1.5 m water temperature sensors

*Fonts appear blurred,replace the battery.

中文

TA298 室内外温湿度计手册

用途：本产品适用于工厂、仓库、

楼宇空调管理、医院、水产养殖物种，房间，办公室，酒店，实验室…现代能源拯救好帮手。

机器可以挂在墙上或桌子上，后面是一个钩子和托架

测量范围：室外-40C~70(-40~158F)

错误程度： 0.1c (0.1c)

Indoor0C-50 (32F~122) “F)

湿度 10%~99%± 5%分辨率 1%

功能测试：按 MAX/MIN 键一次显示

室内外先前最高/最小值

温度和湿度值

当 MAX/MIN 按一次 RESET 按钮以清除

预先记忆的最大或最小量测

当显示后的 MAX/MIN 8 秒返回到

当前温湿度显示 C/F 键

摄氏和华氏温度转换

时间调试：

1 在初始状态下，按住[模式]2 秒，

当前时间开始闪烁的分钟数，按

调整小时、分钟的[ADJ]。在正常时间显示

模式下，按 [ADJ] 可以转换成 12/24 显示。

2 在当前时钟模式下（时钟和分钟之间）

每秒闪烁两次)，按[模式]一次，切换

显示到报警模式（时钟和两点之间的分钟数）

未闪烁)，按动[模式]2 秒，告警

时间闪烁，按 [ADJ]可以调整报警时间，分钟。

显示告警模式，按[ADJ]设置/取消警报

设置后按 [模式] 回到正常状态。

时间显示。

本产品使用 1.5v AAA 电池 External 1.5 m 水

温度传感器

字体看起来模糊了，替换电池。