DEVICE MENUS VERSION 73

THE POWERBOLT MENU

Hot Keys

up/down button press: e-give control power/down button press: hard reset

turn on/off the Bluetooth: press the up button and power button until a dark blue LED comes on

Power Button: turn device on/off (U)

- White: indicates battery charge level
- **Blue:** adjust eGive level (use 'up' and 'down' to control) (\(\right) \)
- Yellow: turn Bluetooth on/off
- Green: set voltage resolution from 0.1 to 0.5 voltage steps
- Orange: automatic LED brightness dimming (enable/disable)
- Light Blue: manual LED brightness control (use 'up' and 'down' to control) (^)
- Red: shipping mode

POWERBOLT +, LIGHTNINGBOLT, LIGHTNINGBOLT UNI, AIRBOLT, AIRBOLT MINI MENU

Hot Keys

up/down button press: e-give control

up/down button press/hold (for at least 3 seconds): footswitch pairing

power/down button press: hard reset

turn on/off the Bluetooth: press the up button and power button until a dark blue LED comes on

Power Button: turn device on/off (U)

- White: indicates battery charge level
- Blue: adjust eGive level (use 'up' and 'down' to control) (
- Green: set voltage resolution from 0.1 to 0.5 voltage steps
- Orange: automatic LED brightness dimming (enable/disable)
- Light Blue: manual LED brightness control (use 'up' and 'down' to control)
- **Pink:** sync or un-sync footswitch (for compatible devices)
- **Red:** shipping mode



















