

504 mm


70 mm

72 mm

Insta360 Link Controller


Tutorials 教学教程

User Manual 用户手册




<https://www.insta360.com/guide/link2pro>

Link 2 Pro | 摄像头结构




01

Magnetic Mount | 磁吸支架结构




02

Setup & Connection | 安装 & 连接




03

Setup & Connection | 安装 & 连接



04

Indicator Status | 指示灯状态



05

Insta360 Link Controller

Download Link Controller for More Features

Option 1: Connect the device and run the installer from the pop-up drive.

Option 2: Visit [insta360.com](https://www.insta360.com) and search "Link Controller" to download the latest software.


下载 Link Controller, 体验更多功能

方式一: 连接电脑, 运行自动弹出U盘内的安装程序

方式二: 访问官网 [insta360.com](https://www.insta360.com) 搜索下载

Insta360 Link 2 Pro

AI Tracking | AI 追踪



Lock on and track subjects in frame. Switch between single/multi-person mode right in the Controller. 可锁定画面中的人物并追踪; 可在客户端切换单人/多人跟踪方式

Turn On & Off | 开启 & 关闭方式


Gesture Control 手势识别

Link Controller 客户端操作

Tap the Touch Key 单击触摸按键

07

Whiteboard Mode | 白板模式



Recognize and optimize whiteboards for online viewing. If a whiteboard isn't detected, use the included recognition markers on 4 corners of the desired area. 智能识别标准白板, 画面自动校正; 若无标准白板, 亦可使用定位贴纸; 只需将其粘贴于识别区域的四个角即可


Turn On & Off | 开启 & 关闭方式

Gesture Control 手势识别

Link Controller 客户端操作


08

DeskView Mode | 桌面俯拍



Capture an overhead view of your desk. Automatically levels the image and fills the screen. 轻松俯拍桌面, 自动校正画面, 并全屏清晰展示

Turn On & Off | 开启 & 关闭方式




In the Controller, toggle **DeskView Mode**. Rotate the camera or mount to adjust the overhead view as needed. 在客户端内一键开关桌面俯拍; 可通过转动摄像头或调节磁吸支架调整俯拍角度

09

General Controls | 通用操作

Touch Key | 触摸按键



Reset the lens to initial state 摄像头自动回正

Gesture Zoom | 手势缩放

1 Hold the "L" gesture until green light flashes. 保持 L 手势直到绿灯闪烁


2 Gesture up: zoom in (One-time action) 手势上移: 放大 (无需持续移动)

Gesture down: zoom out (One-time action) 手势下移: 缩小 (无需持续移动)

10


Privacy & Standby Mode | 隐私 & 休眠模式

Privacy Mode | 隐私模式



Rotate the camera downward to enter Privacy Mode automatically. Lift up to exit. *The microphone is automatically muted in privacy mode. 摄像头朝下转动, 自动进入隐私模式; 抬起摄像头, 即可自动退出 *在隐私模式下, 麦克风将被关闭

Standby Mode | 休眠模式




When no platform is using the of Link 2 Pro's audio and video, the camera auto-rotates downward after 10s and enters Standby Mode. 当没有任何平台使用 Link 2 Pro 的摄像头时, 摄像头将在 10 秒后自动旋转朝下, 进入休眠模式

11

Insta360 Link 2 Pro

QuickStart Guide 快速入门指南



压线

绿色用专色印 PANTONE 7481C