







UniFi Travel Router




1






2



3



4



If you need further assistance, visit our [Help Center](#) or contact [Ubiquiti Support](#).

©2024 Ubiquiti. All rights reserved. Ubiquiti, the UniFi logo, and UniFi are trademarks of Ubiquiti Networks, Inc. or its subsidiaries. All other trademarks are the property of their respective owners. Apple, the Apple logo, and the Apple logo are trademarks of Apple Inc., registered in the U.S. and other countries. Google Play, the Google Play logo, and the Google Play logo are trademarks of Google LLC.