



Hyperion APR 16 Connection Diagram

XLR Cable ——— (red line)
HDMI Cable ——— (green line)
Speaker Wire ——— (white line)





Hyperion DPR 16 Connection Diagram

Category Cable ————
 HDMI Cable ————
 Speaker Wire ————
 RCA Cable ————






Hyperion DPR 16 Home Audio Distribution






TV eARC Dante Encoder Application Diagram


HDMI 
Cat 6a 
Speaker Wire 






Hyperion AXIS 10 Home Application Diagram


Coaxial Cable		Category 5e	
HDMI Cable		Speaker Wire	






Hyperion AXIS 16 Home Application Diagram

Coaxial Cable		Category 5e	
HDMI Cable		Speaker Wire	



Hyperion AXIS 16 Home Theater Application

Coaxial Cable		Category 5e	
HDMI Cable		Speaker Wire	



AXIS 16

Home Theater

Home Network

AV Rack

MXnet 1G Network Switch

Tetra - 4 Channel Amplifier

Height Channels

Tetra - 4 Channel Amplifier

Speaker Channels

Hepta - 7 Channel Amplifier

Speaker Channels

LFE Channel

RS 1000 - Subwoofer Amplifier

ACP-DANTE-D-POE Dante Decoder

Dante Port

HDMI eARC Input

Dante Audio Stream

HDMI Port (eARC)

Display

SFL

L

C

R

SFR

Subwoofer

SL

SBL

TL

TBL

TBR

TFL

TFR

TR

TBR

SBR

SR