

I PORT LAUNCH Rugged Case 10.2 | 10.5


Quick Start Guide

Compatible with:
LAUNCH Case 10.2 | 10.5

For


iPad 10.2-inch (7th gen)
iPad Air 10.5-inch (3rd gen)

1 Insert LAUNCH Case with the iPad into the bottom of Rugged Case.




For instructions on how to install your iPad into the LAUNCH Case, please refer to the install guide provided with your LAUNCH Case.


2 Pull the top of the Rugged Case over the top of the LAUNCH Case.




3 Adjust hand strap to a comfortable tightness around your hand.



4 We recommend wearing and supporting the Rugged Case as shown.



5 To remove the hand strap, detach the Velcro and pull through the open end of the loops.



NOTE: Rugged Case is compatible with LAUNCH BaseStation (70141, 70158) in **Landscape** only.

When using with a LAUNCH WallStation (70142, 70170), make sure the Velcro is tightened fully to allow for proper attachment to the WallStation.

When attaching the Rugged Case to a WallStation (70142, 70170) installed on a Universal Box (70348), there are no obstructions.

For more information and support please visit

www.iportproducts.com