

53525

LOCKING CLAMP FOR HOOD AND TRUNK OPENERS

TECHNICAL SPECIFICATIONS

Diameter	10mm
Weight	0,10Kg
Dimensions (LxWxH)	140x90x30mm

DETAILS

This lifting support clamp is used to hold the lifting bar in place and keep the hood or trunk open while working on the vehicle, to prevent the lifting bar from falling and causing damage.

Avoid the danger and discomfort of weak or faulty gas struts on hoods, trunks, and hatchbacks of SUVs, trucks, and cars.

