

Tools Needed: 8mm Hex Key, 17mm Wrench

..kuat..[®]
(koo-at)

1. Remove the 10mm bolt, nut, and washer with the 8mm hex key and 17mm wrench.
2. Remove the two 10mm bolts and lock washers .
3. Slide the rear cap out.

Note: When replacing bolts in step 2, tighten to 15ft-lbs (20Nm).
Alternating bolts between each turn.
Excessive tightening will damage the rack.

