


- 1. Loosen two 10mm bolts with the 8mm hex key and remove them from the rack.
- 2. Slide the front cap and tray off the rack.
- 3. Remove four 8mm bolts with the 6mm hex key.

Note: When replacing bolts in step 1, tighten to 15ft-lbs (20Nm).

Alternating bolts between each turn.

Excessive tightening will damage the rack.



For further assistance check out our video instructions.



1-877-822-5828 info@kuatracks.com