

Tool Needed: Hands

1. Remove the clap from the upright tube by turning the rear knob counterclockwise.

