

Tool Needed: 5mm Hex Key

1. Using the 5mm Hex Key, remove the 6mm bolt, lock washer, and the pivot handle.
2. Repeat these steps in reverse to install the new one.

