Küat

1 Using the 3mm Security Hex Key, loosen but do not fully remove the Lock Housing Screw. The old Lock Housing Assembly can now be removed.

2 Install the new Lock Housing Assembly by following step 1 in reverse.

