

Optional Tools Needed: Pliers

1. Open the Panel Door.
2. Firmly grip the Door Seal and pull up to begin removing the Door Seal. Pliers can be used to grip seal if needed.
3. Work the Door Seal loose around the perimeter of the Side Panel.
4. Unroll the new Door Seal and locate the welded seam. Starting with the seam at the bottom center, press the new Door Seal onto the Side Door perimeter. Make sure the Round Bulb is facing toward the outside of the vehicle.
5. Work the new Door Seal around the perimeter making sure it is fully seated.

