

[illegible]

图 3 MTF 曲线图

产品特点

名称	AF 5614.2
镜头配置	981215
口径	Φ56mm
接筒	21°
镜头大小	F1.4
最小光圈	F16
光圈叶片数	9
对焦范围	0.5m ~ ∞
对焦系统	内对焦系统
对焦速度	0.15m/秒群时
对焦精度	±0.01mm
镜头放大率	5.14X
重量	320g
镜头口径	92mm

图 4 清洁

- 请勿使用任何手动镜头触点。若镜头脏，请用镜头皮老虎皮及干净开尔文、柔软镜头布（清洁布）轻轻擦拭。
- 请勿使用任何有机溶剂，如酒精或丙酮清洗镜头头。

APS-C AUTO FOCUS

AF 56/1.4 Z

(Z-Mount)

FEATURES

- ▶ Super long length, 41.4 mm range expansion.
- ▶ 10-blade 1-pieces optical elements, achieving 11 blades and 1-triplet refractive lens system.
- ▶ High heat resistance coating with vapor-resistant anti-reflection
- ▶ Non-magnetic TiN-coated metal. Focus is insensitive.
- ▶ Wide range stop-down procedure without focus loss.
- ▶ Supports video exposure, 4K up to 60fps and 4GB+ External Processor for better performance.

① Attaching and Detaching the Lens Hood

● To attach the lens hood

Align the white dots on the lens barrel with the white index on the lens hood, then insert the lens into camera mount and rotate it clockwise until it clicks.

(For further details about attaching and detaching lenses, please kindly refer to the User Manual of the camera.)

● To detach the lens hood

While holding down the lens release button on the camera, rotate the lens counterclockwise until it stops there, detach the lens.

Please place the back of the lens upward to avoid scratches on the lens surface or the electronic contacts.

Lens Cap

When the lens is detached, please cover it with a dust cap. Align the mounting index on the dust cap with the mounting index on the lens, then rotate the cap counterclockwise until it stops, and rotate it clockwise when needed to open the cap.

Lens Hood

Lens hood is used to reduce flare or scattering light of ghost and avoid rain, snow and dust sticking to the front of the lens.

Step Index

● Attaching the Lens Hood

Align the attaching index on the lens hood with the index on the lens, then insert the lens hood into the lens mount and rotate it clockwise until it clicks and the stop index on the lens hood should match the index on the lens.

Step Index

② STRUCTURE

■ ED Glass low dispersion lens
 ■ High refractive index lens

Thank you for choosing Viltrox Lens!

Before using the lens onto your camera, please read this manual carefully so as to understand you and all the functions of the Lens.

④ MTF Graph

④ Safety Notes

- Do not use the lens or the light source through the lens or camera, otherwise the vision will be bright.
- Do not place the lens in the sun, regardless of whether it is mounted on the camera, otherwise the lens may fade and cause a fire.
- Do not place the lens in a child's room or area, otherwise it risks accident or injury.
- Please do not disassemble the internal parts of the product yourself, which may cause damage.

④ Using Tips

- When attaching the lens, be careful not to let it be hit by a mechanical impact.
- When stored, please make sure to put the lens cap on the lens.
- Please do not touch the lens in any way harmful for the final results.
- The lens is not water-repellent, so it must be used carefully when it is raining or near water. If the internal lens, lens or the electrical components are damaged by water, it is probably unable to repair.
- Temperature shock may cause fog or water droplets on the lens surface, so while going into a warm indoor environment in the cold weather, it should be better about the lens in an airtight plastic bag or so even until the lens temperature gets close to the room temperature.
- Please use the same method when taking the lens from a warm environment to a cold one.

④ Cleaning

- Please don't touch the contacts on the lens with your eye. If the lens gets dirty, blow off the dust with a lens nozzle type and rub slightly with a clean cloth or lens-cleaning cloth.
- Please do not use any organic solvent, such as dilute or gasoline to clean the lens.

④ Specification

Item	AF 56/L4.2
Lens Elements	S10
Focus Length	F1.6mm
Viewing Angle	28°
Max. Aperture	F1.6
Min. Aperture	S
Focus Range	0.6 m ~ ∞
Focus Mechanism	Internal Focus
Focus Motor	STM Drive screw
Focus Mode	AF/MF Lock
AF Lock	S
Weight	320g
Filter Size	30mm

Shenzhen Jueying Technology Co., Ltd.
TEL : +86-755-39716031
FAX : +86-755-28714730
MAIL : info@jytech.com
www.jytech.com

F17-218-B4, Baowen Science and Technology Industrial Park,
Kailiying, Daping 521, Longsha, Shenzhen (China)

[illegible][illegible][illegible]

중 MTH 원천도

인원 주의

현장은 모든 차량을 통행하여 차량에서 떨어진 공간은 복귀하지 않습니다. 현상시 서대천 상류와 수로 입구에서

- 현상을 처리하며 작업 차량을 통행할 때는 반드시 차량을 통행할 방향을 확인하여 차량의 뒤를 막아줍니다. 작업이 종료된 차량은 작업자 위치를 이탈할 수 있습니다.
- 작업 차량에서 작업 중일 때는 작업 차량의 후방에서 작업자를 보호하고 모든 차량이 통행할 수 없습니다.

• 유류 및 유류 잔여물 유출을 피하기 위하여 작업시간 종료 후 유류 잔여물 유출을 확인합니다.

• 유류 및 유류 잔여물 유출을 피하기 위하여 작업시간 종료 후 유류 잔여물 유출을 확인합니다.

기상 현황 요약

날짜	날씨	기온	습도	바람	강수량
2024. 07. 26	구름	28°	75%	1.5m/s	0.0mm
2024. 07. 27	구름	28°	75%	1.5m/s	0.0mm
2024. 07. 28	구름	28°	75%	1.5m/s	0.0mm
2024. 07. 29	구름	28°	75%	1.5m/s	0.0mm
2024. 07. 30	구름	28°	75%	1.5m/s	0.0mm
2024. 07. 31	구름	28°	75%	1.5m/s	0.0mm

[illegible][illegible]

APS-C AUTO FOCUS AF 57.14.2 Z Mount



(Gracias por elegir: Nikon Z Mount)

Funciones del producto

AF 57.14.2 es un objetivo de enfoque automático de gran apertura adecuado para la montura Nikon Z. Aliméntese eléctricamente por el pino, separadamente del cuerpo Nikon Z. Se puede controlar con precisión Manual la posición para lograr un enfoque preciso y suave.

- Longitud focal de 56 mm, gran apertura F/4
- 3 grupos con 23 elementos ópticos, con 1 elemento LD
- 1 lente de alta refracción
- Revestimiento multicapa de alta definición, revestimiento impermeable
- Enfoque preciso y suave
- Motor de enfoque STM (autofoco), enfoque sensible
- Enfoque automático, las pines de enfoque de precisión en las piezas caso son sedosos y suaves
- Apertura automática, modo a modo a modo de información EXIF
- Apertura precisa de precisión

Instalar y desinstalar la lente

● Instalar la lente


Alinee la marca de montaje en la lente con la misma marca en la cámara, e inserte la lente en sentido horario hasta que esté en su lugar.
(Para conocer los pasos detallados de instalación y desinstalación, consulte el manual de la cámara.)

● Desinstalar la lente

Retire el protector de la lente del desarrollo de la cámara, y deslice el anillo de montaje hacia la izquierda para desinstalar la lente.
(Deslice el anillo de montaje hacia la izquierda hasta que el anillo de montaje pueda girar libremente.)

● Tipo de lente

Contra la lente de lente, se requiere una pila antipolvo. Cuando la lente de montaje se desliza en la pila antipolvo, la cámara emite un sonido de alarma y se detiene por un tiempo. El antipolvo, el AF, el estabilizador y el sensor de imagen.



Componentes

La cámara y la lente, bloquean la luz por la luz que se dispersa de la sombra y evita que la luz, la inversa y el objeto se difunda al frente de la lente.



Instalación

Quitar la pila antipolvo es una medida de precaución para evitar la contaminación de la pila antipolvo. La imagen de la cámara se contaminará si la pila antipolvo se toca o se daña. No toque la pila antipolvo en la dirección opuesta.

Diagrama de estructura de lente



© Nikon Imaging Corporation

[illegible]