

Surface shaping tool for wood, masonite, chipboard, plasterboard, plastic, glass fibre, and soft metals. With replaceable blade that should not be sharpened – only replaced.

