

Tech Specs

What's in the box

Sensibo Air

WiFi controller for air conditioner

Power adapter

Double-sided adhesive

Room Sensor

Motion Sensor

Temperature and humidity sensor

Detachable stand

Detachable wall mount

2 x AAA batteries (included)

Double-sided adhesive

Compatibility

Any air conditioner with a remote control

Any heat pump with a remote control

Supported types of air conditioners:

Window
Split
Cassette
Portable
Central

Powering method

Sensibo Air

5V 1A micro USB adapter

Operating voltage – 110-240V

Room Sensor

2xAAA batteries

Bandwidth

15-20 MB/month



Connectivity and security

2 radios – WiFi, Bluetooth Low Energy (BLE)

WiFi 802.11 b/g/n @ 2.4GHz

DHCP or static IP addressing

SSL encryption

Green

Recyclable packaging

Mercury-free

Arsenic-free

PVC free

RoHS compliant

Temperature range

Operating: 0° to 55°C (32° to 130°F)

Sensitivity: $\pm 0.5^{\circ}\text{C}$ ($\pm 1^{\circ}\text{F}$)

Humidity range

Range: 5% to 95% RH

Sensitivity: $\pm 5\%$ RH

App Languages

Available in over 10 languages

Warranty

1-year warranty

Product Dimensions

Sensibo Air

Length: 65mm (2.56")

Width: 65mm (2.56")

Height: 17mm (0.67")

Room Sensor

Length: 57mm (2.24")

Width: 57mm (2.24")

Height: 14mm (0.55")

Sensors

Sensibo Air

Temperature

Humidity

2 Infrared receivers

Room Sensor

Motion

Temperature

Humidity

Apps

iOS

Android

Web (HTML5)

Voice Assistants

Amazon Echo (Alexa)

Google Home

Apple HomeKit

SmartThings

IFTTT

Open API

Learn more at sensibo.com
support@sensibo.com