



User Manual

Model: H6641

Govee Neon Rope Light for Wall Lining

Safety Instructions

Warning - Read and follow all the safety instructions:

- Use the product with the provided power adapter only.
- Be cautious of static electricity during installation and usage.
Keep the product away from sharp objects or strong corrosive chemicals.
- Remove nails, metal, or other conductive objects from the installation surface before attaching the strip light, as it may cause short-circuiting.
- Do not allow children to install the strip light alone.
- Avoid installing the strip light near potentially dangerous sources (e.g., candles, liquid-filled objects).
- Unroll the strip light before powering on.
- Please turn off the power and unplug the adapter when the strip light will not be used for a long time.
- The recommended working temperature is between 0-40 °C.
- The storage temperature should be between -20-60 °C.


Introduction

Thank you for choosing Neon Rope Light for Wall Lining. This 5m highly flexible neon strip can be perfectly mounted on right-angled wall positions with snap fasteners, and the RGBIC light effect provides a unique ambient light experience. It can be controlled by Govee Home App and voice assistants such as Alexa and Google Assistant.

What You Get

LED Rope Light	1
Mounting Clip	15
Internal Corner Bracket	2
Power Adapter	1
User Manual	1
Service Card	1
End Cap	1


Power-on Test



Before You Install

1. Unpack the box and check all items included.
 2. Power on the rope light and check whether it lights up.
- Caution: Do NOT power on before spreading the rope light.

Control Box Function Description




Installing Steps


1. Wipe the installation surface to ensure it is dry and clean.



2. Fix the mounting clips (via adhesives or screws) first. Then fix the rope light.




3. If there is an inner corner, install an internal angle cover (via adhesives or screws) first.



4. Peel off the protective film on the control box and stick it to a suitable location.



5. Power on the rope light and enjoy.



Pair Your Device with the Govee Home App

What You Need

- a. A Wi-Fi router supporting the 2.4GHz and 802.11 b/g/n bands. 5GHz is not supported.
- b. A smartphone or tablet running iOS 8.0 (or above) or Android 4.3 (or above).

Pairing Instructions

- a. Download Govee Home App from the App Store (iOS devices) or Google Play (Android devices).
- b. Turn on the Bluetooth on your smartphone.
- c. Open the app, tap the icon in the top right corner and search for "H6641."
- d. Tap the device icon and follow the on-screen instructions to complete pairing.

Controlling the Device with Your Voice

- a. Open Govee Home App, then tap the device icon to enter the details page.
- b. Tap the settings icon in the top right corner.
- c. Select "User Guide" and follow the on-screen instructions to control the device by using your voice.

Specifications

Power Input (Adapter)	AC 100-240V(US Plug) AC 200-240V (EU&BS Plug)
Power Input (LED Rope Light)	24VDC 2A
Light Displaying Technology	RGBIC
Length	16.4ft
Control Methods	App, Control Box, Voice Control

Specifications

- a. The rope light does not work/is malfunctioning.
- Check if the adapter used is the one provided.
 - Power the rope light off then on. Make sure the adapter and the control box have been powered on.
 - Long press and hold the power button on the control box and quickly press the middle button four times to restore factory settings.
- b. The rope light does not display the full selected color./Some light beads do not light up.
- Please contact Govee Support Team.
- c. Cannot connect to Govee Home App.
- Do not skip Bluetooth connection in the app.
 - Ensure Bluetooth on your smartphone has been turned on.
 - Your smartphone may be incompatible with Govee Home App. Try using a different smartphone.
 - Power the rope light and your smartphone's Bluetooth off then on, then try again.
 - Please ensure your smartphone is within 1m/3.28ft of the rope light when connecting.
 - Clear any obstructions that are between the rope light and your smartphone.


d. Cannot connect to Wi-Fi.

- Do not skip the Wi-Fi connection steps in the app.
- 5GHz network is not supported. Please set the router to 2.4GHz and then reset it.
- Connect your smartphone to Wi-Fi and check whether the network works well.
- Make sure that you have entered the correct Wi-Fi name and password.
- Change your Wi-Fi password to a brief one. 8 numbers and letters are suggested.
- Connect your smartphone's hotspot to the rope light and check whether the router works with the rope light.

e. Cannot connect to Alexa.

- Unplug every connective part of the rope light then firmly reconnect them.
- Reset your smartphone's Wi-Fi.
- Unplug the adapter port then re-plug it.

Disassembly Tip:



The product is divided into two parts: (1) a light source and (2) an adapter. By detaching the output terminal of the adapter, you can easily remove the light source or the adapter.

Customer Service

 Warranty: 12-Month Limited Warranty

 Support: Lifetime Technical Support

 Email: support@govee.com

 Official Website: www.govee.com

 @Govee  @govee_official  @govee.official

 @Goveeofficial  @Govee.smarthome



Points de collecte sur www.quefairedemesdechets.fr
Privilégiez la réparation ou le don de votre appareil !



Raccolta Carta

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Shenzhen Qianyan Technology LTD is under license.

The trademark Govee have been authorised to Shenzhen Qianyan Technology LTD.

Copyright ©2021 Shenzhen Qianyan Technology LTD.

All Rights Reserved.



Govee Home App

For FAQs and more information,
please visit: www.govee.com