


GERMAN SIGNALS

VR SIGNALS




HP SIGNALS





KS SIGNALS



SHUNTING SIGNALS



HL SIGNALS



GERMAN SIGNS & INDICATORS

SPEED SIGNS & INDICATORS




ADVANCED WARNING
OF LOWER SPEED LIMIT
REDUCE SPEED NOW




SPEED LIMIT AT
THIS SIGN

SPEED LIMIT APPLIES AT
THIS SIGNAL




SPEED LIMIT APPLIES AT
NEXT SIGNAL
REDUCE SPEED NOW




TIMES DIGIT BY 10 TO GET SPEED LIMIT


ROUTE INDICATORS



ROUTE DIRECTION
AT NEXT SIGNAL



ROUTE DIRECTION
AT THIS SIGNAL




ROUTE INTO
DEAD END

SIGNS



SIGNAL LOCATED
ON THE LEFT



DISTANT SIGNAL
APPROACHING



DANGER
OBTAIN PERMISSION &
OVERRIDE PZB TO PASS



DANGER
OBTAIN PERMISSION
TO PASS



STOPPING POINT
FOR PASSENGER
TRAINS



INDICATES WHICH
TRACK THIS SIGN
APPLIES TOO

SIGNAL IDENTIFIER POSTS



DISTANT























MAIN



MAIN &
DISTANT

GERMAN SAFETY SYSTEMS

PZB			
MODE	 PASSENGER	 FREIGHT	 H FREIGHT
			
			
			
			
MAX SPEED			
	OVER MAX SPEED EMERGENCY BRAKE WILL APPLY REDUCE SPEED NOW		
	EMERGENCY BRAKE APPLIED WAIT UNTIL TRAIN HAS STOPPED & RELEASE PZB TO RESTART		

SIFA



WHEN ILLUMINATED OR EMITTING SOUND
PZB ACKNOWLEDGE

LZB



LZB IS
ENABLED



IN
LZB ZONE



EXITING LZB ZONE
WHEN FLASHING
RELEASE PZB