







Facebook

Scan QR code to view detailed instruction

AUTO BED LEVELING SENSOR FOR 3D PRINTER

This guidebook is for Creality V2 mainboard.It include but not limited to the following 3d printer:

CR-10S/CR-10 S4/CR-10 S5/CR20.

File download: https://www.creality3d.cn/download/

SHENZHEN CREALITY 3D TECHNOLOGY CO., LTD.

12/F, Block 3, JinChengYuan, Huafan Road, Tongsheng Community, Dalang, Longhua District, Shenzhen, China, 518109 Official Website: www.creality3d.cn

Tel: +86 755-2103 4006

E-mail: info@creality3d.cn cs@creality3d.cn











