



Installation instructions for part LC-GMRC-04

LC-GMRC-04 GM data bus interface 2000-2005

INTERFACE FEATURES

- Provides accessory power (12-volt 10-amp)
- Retains R.A.P. (retained accessory power)
- Provides NAV outputs (parking brake, reverse, and speed sense)
- Used in non-amplified models, or when bypassing a factory amplifier
- Used in models without OnStar
- Retains all warning chimes
- High level speaker input
- Retains balance and fade
- Micro "B" USB updatable

INTERFACE COMPONENTS

- LC-GMRC-04 interface • LC-GMRC-04 harness

APPLICATIONS

BUICK	OLDSMOBILE	PONTIAC
LeSabre 2000-2005	Aurora 2001-2003	Bonneville 2000-2005

Table of Contents

Connections to be made.....	2
Installing the LC-GMRC-04.....	3
Initializing the LC-GMRC-04.....	3

TOOLS REQUIRED

- Cutting tool • Crimp tool • Tape
- Connectors (example: butt-connectors, bell caps, etc.)

CAUTION! All accessories, switches, climate controls panels, and especially air bag indicator lights must be connected before cycling the ignition. Also, do not remove the factory radio with the key in the on position, or while the vehicle is running.

REV.9/16/2016 INSTLC-GMRC-04



Connections to be made

From the LC-GMRC-04 harness to the aftermarket radio:

- Connect the **Black** wire to the ground wire.
- Connect the **Yellow** wire to the battery wire.
- Connect the **Red** wire to the accessory wire.
- Connect the **Blue** wire to the power antenna wire.
- If the aftermarket radio has an illumination wire, connect the **Orange** wire to it.

Note: There are (2) **Orange** wires. If the **Orange** wire on the 32-pin harness is populated on the factory side, use that wire. Otherwise, use the other **Orange** wire.

- Connect the **Gray** wire to the right front positive speaker output.
- Connect the **Gray/Black** wire to the right front negative speaker output.
- Connect the **White** wire to the left front positive speaker output.
- Connect the **White/Black** wire to the left front negative speaker output.
- Connect the **Green** wire to the left rear positive speaker output.
- Connect the **Green/Black** wire to the left rear negative speaker output.

- Connect the **Purple** wire to the right rear positive speaker output.
- Connect the **Purple/Black** wire to the right rear negative speaker output.

The following (3) wires are only for multimedia/navigation radios that require these wires.

- Connect the **Blue/Pink** wire to the VSS/speed sense wire.
- Connect the **Green/Purple** wire to the reverse wire.
- Connect the **Light Green** wire to the parking brake wire.

Installing the LC-GMRC-04

With the key in the off position:

- Connect the LC-GMRC-04 harness into the interface.
- Connect the LC-GMRC-04 harness to the vehicle.

Initializing the LC-GMRC-04

Attention: *If the interface loses power for any reason, the following steps will need to be performed again.*

- Turn the key (or push-to-start button) to the ignition position and wait until the radio comes on.

Note: *If the radio does not come on within 60 seconds, turn the key to the off position, disconnect the interface, check all connections, reconnect the interface, and then try again.*

- Turn the key to the off position, and then to the accessory position. Test all functions of the installation for proper operation, before reassembling the dash.



Installation instructions for part LC-GMRC-04



IMPORTANT

If you are having difficulties with the installation of this product, please call our Tech Support line at **1-800-253-TECH**. Before doing so, look over the instructions a second time, and make sure the installation was performed exactly as the instructions are stated. Please have the vehicle apart and ready to perform troubleshooting steps before calling.



KNOWLEDGE IS POWER

Enhance your installation and fabrication skills by enrolling in the most recognized and respected mobile electronics school in our industry. Log onto www.installerinstitute.com or call 800-354-6782 for more information and take steps toward a better tomorrow.



Metra recommends MECP certified technicians

REV. 9/16/2016 INSTLC-GMRC-04



Axxess Integrate

axxessinterfaces.com • metraonline.com

© COPYRIGHT 2004-2016 METRA ELECTRONICS CORPORATION



Instrucciones de instalación para la pieza LC-GMRC-04

LC-GMRC-04 GM Interfase de Bus de Datos 2000-2005

CARACTERÍSTICAS DE LA INTERFASE

- Provee corriente de accesorios (12 voltios 10 amperes)
- Retiene R.A.P. (corriente de accesorio retenida)
- Proporciona salidas de NAV (freno de mano, reversa y sensor de velocidad)
- Utilizados en los modelos no amplificados, o cuando sin pasar por un amplificador de fábrica
- Se utiliza en los modelos sin OnStar
- Retiene todas las campanillas de advertencia
- Entrada de bocina de alto nivel
- Retiene el balance y la intensidad
- Actualizable por micro "B" USB

COMPONENTES DE LA INTERFASE

- Interfase LC-GMRC-04 • Arnés LC-GMRC-04

APLICACIONES

BUICK	OLDSMOBILE	PONTIAC
LeSabre 2000-2005	Aurora 2001-2003	Bonneville 2000-2005

Indice

Conexiones que se deben hacer	2
Instalación del LC-GMRC-04	3
Inicialización del LC-GMRC-04	3

HERRAMIENTAS REQUERIDAS

- Cortacables • Ponchadora • Cinta • Conectores (ejemplo: conectores de extremo, de campana, etc.)

¡PRECAUCIÓN! Todos los accesorios, interruptores, paneles de controles de clima y especialmente las luces del indicador de las bolsas de aire deben estar conectados antes ciclar la ignición. Además, no quite el radio de fábrica con la llave en la posición o de encendido ni con el vehículo funcionando.



Conexiones que se deben hacer

Desde el arnés LC-GMRC-04 al radio de mercado secundario:

- Conecte el cable **negro** al cable de tierra.
 - Conecte el cable **amarillo** al cable de la batería.
 - Conecte el cable **rojo** con el cable de accesorios.
 - Conecte el cable **azul** al cable de encendido del amplificador.
 - Si el radio de mercado secundario tiene un cable de iluminación, conecte el cable **anaranjado** a ella.
- Nota:** Hay (2) cables de **naranja**. Si el cable **naranja** en el arnés de 32 clavijas está poblado en el lado de la fábrica, utilice ese cable. De lo contrario, utilice el otro cable de **naranja**.
- Conecte el cable **gris** con la salida positiva de la bocina derecha delantera.
 - Conecte el cable **gris/negro** con la salida negativa de la bocina derecha delantera.
 - Conecte el cable **blanco** con la salida positiva de la bocina izquierda delantera.
 - Conecte el cable **blanco/negro** con la salida negativa de la bocina izquierda delantera.
 - Conecte el cable **verde** con la salida positiva de la bocina izquierda trasera.

- Conecte el cable **verde/negro** con la salida negativa de la bocina izquierda trasera.
- Conecte el cable **púrpura** con la salida positiva de la bocina derecha trasera.
- Conecte el cable **púrpura/negro** con la salida negativa de la bocina derecha trasera.

Los siguientes (3) cables son para radios de mercado secundario con multimedia/navegación que tienen estos cables.

- Conecte el cable **azul/rosa** al cable VSS o de detección de velocidad.
- Conecte el cable **verde/púrpura** al cable de reversa.
- Conecte el cable **verde claro** al cable de freno de mano.



Instalación del LC-GMRC-04

Con la llave en la posición de apagado:

- Conecte el arnés LC-GMRC-04 a la interfase.
- Conecte el arnés LC-GMRC-04 al vehículo.

Initializing the LC-GMRC-04

Atención: *Si la interfase pierde energía por cualquier razón, tendrán que volverse a ejecutar los siguientes pasos.*

- Gire la llave (o pulsar para botón de inicio) a la posición de encendido and y esperar hasta que la radio se enciende.

Nota: *Si la radio no se enciende dentro de 60 segundos, gire la llave a la posición de apagado, desconecte la interfase, compruebe todas las conexiones, vuelva a conectar la interfase, y vuelva a intentarlo.*

- Gire la llave a la posición de apagado, y luego a la posición de accesorios. Pruebe todas las funciones de la instalación para su correcto funcionamiento, antes de volver a montar el tablero.



Instrucciones de instalación para la pieza LC-GMRC-04



IMPORTANT

If you are having difficulties with the installation of this product, please call our Tech Support line at **1-800-253-TECH**. Before doing so, look over the instructions a second time, and make sure the installation was performed exactly as the instructions are stated. Please have the vehicle apart and ready to perform troubleshooting steps before calling.



KNOWLEDGE IS POWER

Enhance your installation and fabrication skills by enrolling in the most recognized and respected mobile electronics school in our industry. Log onto www.installerinstitute.com or call 800-354-6782 for more information and take steps toward a better tomorrow.



Metra recommends MECP certified technicians

REV. 9/16/2016 INSTLC-GMRC-04



Axxess Integrate

axxessinterfaces.com • metraonline.com

© COPYRIGHT 2004-2016 METRA ELECTRONICS CORPORATION