


RJ2BLOCK

DMX RJ45 to Terminal Block Connector




Overview

The RJ2BLOCK makes connecting the POWER + DMX port on a STICK controller to the DMX and power wires a simple task.


Simply connect a CAT5 cable to the POWER + DMX port and the other end to the RJ2BLOCK. Now you can connect your DC power-in and DMX universe 1 and universe 2 (if available) with screw terminals.

When connected to a Stick2+, DMX2- and DMX2+ provide Port1 and Port2 triggering.

Please check your STICK datasheet for RJ2BLOCK compatibility.



POWER+DMX RJ45 PIN ORDER



****CHECK PIN CONFIGURATIONS CAREFULLY. APPLYING POWER TO THE DMX INPUT WILL DAMAGE THE CONTROLLER****

* with Stick2+
DMX2- = Port 1
DMX2+ = Port 2

** Connect optional Power4M
7v power adapter