
Dear Friend :

Thank you very much for choosing us!


We will always be at your service in the following time, the pursuit of high quality products is our goal of production all the time, the products are strictly checked by us before sending, if you encounter any problems in the process of use, you can contact us at any time, we provide you with a lifetime maintenance service.

The following is the installation diagram of the product, any questions can always contact us!







1. Determine the location, Slide Stop Tube Onto Valve



1. Pass D(Esctcheon) Through A(Stop Tube),
Install the Panel, and Fix It with E (Escutcheon Screws)



1. Make Sure Cartridge Stem is Positioned with Notch Facing Dow
2. Insert B (Key Stop) & C (Adjustable Limit Stop) into Stop Tube.
3. Install F (Handle Adapter) Onto Cartridge Stem.
4. Secure with G (Handle Adapter Screw).



1. Place H (Handle) on F (Handle Adapter)
2. And Fix It with I (Set Screw)
3. Finally, Add J (Rubber Stopper) to Keep it Looking Good and Prevent the Parts from Rusting