

Chair / Row Spacing


Technical Bulletin - 03/010 #2 Date: March 2010




These measurements are provided for your information and reference ONLY. ComforTek Seating does not recommend or suggest spacing for any project.

Please consult with your local builder, architect or building code to determine spacing requirements for your jurisdiction.











Frame Floor Width Foot Print

Layout 1 (Side Step)

20" @ 36" = 5.0 sq ft

22" @ 36" = 5.5 sq ft







Layout 2 (Walk)

20" @ 38" = 5.27 sq ft

22" @ 38" = 5.80 sq ft





Layout 3 (Pass By)

20" @ 40" = 5.55 sq ft

22" @ 40" = 6.11 sq ft

