

ActiveStart

By Active Controls

Quick Start ACS30P Guide


Instructions:

1. Plug Unit into approved 120/30A NEMA TT-30R RV Power Receptacle.
2. Verify LED's indicate "Correct Wiring". If not, correct issue.
 - a. Generators have Ground and Neutral floating so unit will indicate reverse polarity. Please use the available bonding plug (available on our website) to correct the issue when using a generator.
3. Plug RV Power Cord into the ActiveStart. There is a delay before output LED is Green.
4. Operate RV or Boat normally.

Download our app from the Apple or Android app stores. Search for ActiveStart and follow steps below:

1. Select "Add New Device" from the connections tab at the bottom once the unit is powered ON.
2. App will search for available devices.
3. Select the device from list of found devices which is shown as a mac address.
4. The device has a unique pass key on the sticker on the back of the unit. **Ex of Key: WX5ja8**
 - a. **We highly suggest to use a QR reader app to read the label and do a copy paste of the key into the app to eliminate any mistakes in reading the letters or numbers.**
5. Once the pass key is entered the device will show voltage and other information on the main screen. Visit our website for complete instructions if needed: Active-Controlsllc.com

App Images:



Caution:

Fully insert all Plugs
Keep away from children and pets Do
not repair or modify
For outdoor use only
Store indoors when not in use

Scan to
download app
and visit
website:

