

REMOTE CONTROL FUNCTION INTRODUCTION



On/Off:
This button starts/stops the massage system.



MENU:
Click this button to choose auto mode, manual mode, air pressure massage, heat, vibration, and setting menu.



Direction adjustment:
under menu, press the button to adjust direction. when program is determined, press the middle OK button to confirm it and enjoy the chosen function.



Backrest Rise:
Press this button, the backrest will be moved up to the original position, press again to stop.



Backrest Down:
Press this button, the backrest will be moved down to the lowest position, press again to stop.



Zero gravity:
one-button zero gravity, press this button to zero gravity position

AUTO

AUTO:
when massage chair is working, press auto button to switch 4 auto programs.



Heat:
press this button to on/off the heater



Vibration:
press this button to on/off the vibrator

REMOTE CONTROL FUNCTION INTRODUCTION



On/Off:
This button starts/stops the massage system.



MENU:
Click this button to choose auto mode, manual mode, air pressure massage, heat, vibration, and setting menu.



Direction adjustment:
under menu, press the button to adjust direction. when program is determined, press the middle OK button to confirm it and enjoy the chosen function.



Backrest Rise:
Press this button, the backrest will be moved up to the original position, press again to stop.



Backrest Down:
Press this button, the backrest will be moved down to the lowest position, press again to stop.



Zero gravity:
one-button zero gravity, press this button to zero gravity position

AUTO

AUTO:
when massage chair is working, press auto button to switch 4 auto programs.



Heat:
press this button to on/off the heater




Vibration:
press this button to on/off the vibrator

CUSTOM MESSAGE MODE

- By selecting a single massage area, auto massage will stop
You can turn on a single massage area, or multiple areas.
- This allows you to give yourself a complete customizable massage.
- You can also adjust the strength of the air bags and intensity of the rollers.

ABOUT THE REMOTE CONTROL PANEL



Press  Into Custom Massage Mode
Into The Main Menu, you Can See:

Auto: Select 4 Auto mode

Airbag: Turn on/off the airbags and adjust air pressure.

Manual: Turn on/off the rollers and adjust speed.

Other: Turn on/off the foot rollers heater and vibrator.

Setting: Timer control.



Vibrate: Press "VIBRATE" To Turn On Or Off Seat Vibration.



Heat: To turn on/off the seat heating.



Back Rise/back Down: Press To Lower Or Raise Backrest And Feet.



- 1 TFT Display
- 2 Power Button
- 3 Menu Button
- 4 Direction Buttons
- 5 OK Button
- 6 Backrest Rise
- 7 Backrest Down
- 8 Auto Mode Selection Button
- 9 One-Button Zero Gravity
- 10 Heater Button
- 11 Seat Vibrate Button

