

CLEANING INSTRUCTIONS

.....



Like anything else, if it is taken care of, it will last.

Cooley recommend the following to ensure fabric longevity and cleanliness:

1. Gently rinse the fabric with clean lukewarm water to loosen or remove large dirt particles. Do not use power washers or high pressure sprays. These can abrade the surface of the fabric beyond repair.
2. Using a soft sponge or brush and the recommended cleaning solution, wash an area of the fabric by wiping from bottom to top. Do not let the soap dry on the fabric. To prevent this, wash a predetermined area and then rinse it with clean water making sure that no soap is left behind. Then, proceed to the next area. Manufacturers of cleaning products recommend cleaning 10 square feet at a time followed by rinsing. Leaving the cleaning solution behind could result in major staining of the fabric.
3. Repeat step (2) until the entire fabric is cleaned.
4. Ensure the canopy is completely dry before storing.

Recommended cleaning solutions:

- Simple Green or similar neutral pH cleaner – can be used frequently for general cleaning
- Cooley Clean – use sparingly for stubborn dirt/stains
- Cooley Deep Clean – use very sparingly for the most stubborn dirt/stains