

This picture shows the Air Line Schematic looking down from the top and through the LM-5 valves located on the sides of the feeder.

When mounting on the rear of the press...switch the lines connected to ports 2 and 4 on the right side LM-5 Valve.

