



## Parts List for DC551KA Type 1

Item Number	Part Number	Description	Qty Required
1	623246-14	CLAMSHELL SET	1
2	624703-14	MOTOR ASSEMBLY	1
3	389461-00	COMP. SPRING	1
4	623263-00	COLLET LOCK	1
5	392448-00	COMP. SPRING	1
6	623315-00	COLLET GRIP	1
7	389458-00	COLL.GRP.COV.	1
8	330019-02	SCREW,PLASTITE	2
9	389243-00	1/8 COLLET	1
9	389244-00	1/4 COLLET	1
10	389245-00	COLLET NUT	1
11	330019-13	SCREW,M4X19	6
12	145312-00	PLUG,RUBBER	2
13	623986-00	SWITCH ASSY.	1
14	623258-00	SWITCH ACTUATOR	1
15	389459-00	GUIDE	1
16	633513-00	NAMEPLATE	1
17	625060-00	WARNING LABEL	1
18	624162-00	IDENT. LABEL	1
19	389460-00	GUIDE BASE	1
20	396992-01	KNOB	1
21	045687-00	STAR WASHER	1
22	625759-00	BOOT	1
856	391023-00	DRYWALL BIT	1
856	DW6601	GENERAL PURPOSE BIT	1
861	N043199	KITBOX	1
866	DC9091	BATTERY PACK	2

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit [www.dewaltservicenet.com](http://www.dewaltservicenet.com) for current parts information.

## Parts List for DC551KA Type 1

Item Number	Part Number	Description	Qty Required
867	645221-00	BATTERY CAP	1
871	388683-12	1 HOUR CHARGER	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit [www.dewaltservicenet.com](http://www.dewaltservicenet.com) for current parts information.