



Parts List for DW430 Type 4

Item Number	Part Number	Description	Qty Required
1	248420-01	ARMATURE	1
2	760969-00	FIELD	1
3	760999-00	SWITCH	1
4	248447-01	BRUSH & HOLDER	2
5	330072-97	CORD/10 FT/18-2	1
6	770235	CORD PROTECTOR	1
7	324595-02	CASE,FIELD	1
8	324593-02	COVER	1
9	330004-19	BEARING,NEEDLE	1
11	248479-01	HOUSING	1
14	860073-03	WASHER	1
15	248428-00	KNOB	1
16	720945-00	SCREW	1
17	860079-03	CIRCLIP	1
18	720947-00	SPINDLE	1
19	000000-00	No Longer Available	1
20	283513-00	SPRING	1
21	720950-00	FORK	1
22	760261-00	WASHER	1
23	720952-00	SPACER	1
24	720953-00	LEVER	1
25	720954-00	SPRING	1
26	325024-00	PLATE	1
27	720956-00	PLATE,CORK	1
28	720957-00	ROLLER	1
29	000000-00	No Longer Available	1
30	248426-00	NUT	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.

Parts List for DW430 Type 4

Item Number	Part Number	Description	Qty Required
31	000000-00	No Longer Available	1
32	720961-00	WASHER	1
33	248423-00	COVER	1
34	283516-00	BEARING	2
35	742289-00	NUT	1
36	720965-00	WASHER	1
37	575217-00	GEAR & ROLLER	1
38	330003-17	BEARING,BALL	2
40	325021-00	PINION	1
41	720970-00	HOUSING,R.H.	1
42	325017-00	PULLEY	1
44	000000-00	No Longer Available	1
45	325016-00	FAN	1
46	325018-00	BELT	1
47	720975-00	ROLLER,FRONT	1
48	248421-05	COVER,FAN	1
49	325026-00	FAN	1
50	248422-05	COVER	1
51	720979-00	BEARING,BALL	1
52	720980-00	LEAD,FIELD	2
53	760975-00	LEAD,BRUSH	2
54	248427-00	BAG DUST	1
55	949896-11	SCREW	7
56	249437-00	SCREW	7
59	720984-00	STONE	2
60	720985-00	GASKET	1
61	720986-00	SPRING	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.

Parts List for DW430 Type 4

Item Number	Part Number	Description	Qty Required
65	379684	CABLE CLAMP	1
69	330019-18	SCREW,PLASTITE	2
70	000000-00	No Longer Available	2
71	249416-04	SCREW	1
73	249118-01	KNOB	1
74	000000-00	No Longer Available	1
75	247600-00	GASKET	1
76	247601-00	GASKET	1
78	249221-00	WASHER	1
83	249415-00	SCREW	2
84	248425-00	SUPPORT	1
85	325019-00	PULLEY	1
86	248354-00	NUT	1
87	247650-00	WASHER	1
91	249411-00	NUT	1
92	760219-00	SCREW	1
93	720990-00	BRACKET,EXT.	1
94	720989-00	WASHER	1
95	000000-00	No Longer Available	1
96	000000-00	No Longer Available	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.