





Power Supply

Your order contains an outdoor power supply that is compatible with our sensors and rated for outdoor use.

The power supply should be installed such that the included USB plug is orientated down and the power plug oriented in a downward angle as shown. **Please see the example images:**



Air Quality Sensor - Quick Start Guide

Thank you for supporting PurpleAir and helping to monitor the air we breathe. Your sensor has been built and tested by PurpleAir. Every PurpleAir sensor has successfully passed a chamber test prior to shipping.

1) Mount your PurpleAir sensor close to WiFi and power.

For tips: www.purpleair.com/install

2) Configure your sensor's WiFi connection with a phone, tablet or PC.
Read all steps before starting!

- a) Open www.purpleair.com/configure, leave open for step C.
- b) On the same device, open WiFi preferences and connect to 'AirMonitor_XXXX'
- c) **Within 5 seconds**, click "Connect to sensor" on the configuration page from step A.
- If this connection fails, repeat steps B and C.
- d) Select your WiFi access point from the list, enter your WiFi password and press save.
- e) Once successfully connected, data will begin to upload and the 'AirMonitor_XXXX' network will disappear.

3) Register your sensor at www.purpleair.com/register

Check out the PurpleAir Live Map

www.purpleair.com/map

Questions or comments?

Email us at contact@purpleair.com