






0117
0116
0101
0117
0116
0102
0102
0102
0113
0112
0114
0115
0115
0111
0112
0112
0113
0110
0111
0105
0103
0104
0103
0104
0108
0108
0105
0103
0104
0104
0104
0199
0107
0103
0104
0104
0108
0106
0103
0104
0104
0108
0109



0201
0205
0205
0206
0202
0207
0204
0203


0308
0308
0308
0308
0308
0301
0313
0314
0307
0306
0306
0304
0302
0307
0306
0305
0303
0311
0309
0310
0302
0303


0410
0410
0410
0410
0410
0409
0402
0407
0405
0408
0408
0407
0406
0403
0404


0524
0507
0508
0511
0509
0510
0509
0510
0505
0506
0506
0513
0514
0512
0519
0520
0515
0520
0520
0517
0518
0516
0521
0521
0521
0523
0504
0504
0504
0504
0504
0503


0601



Item Number	Material Number	Material Shorttext	Infotext	Substitute Material Number
0102	10019974	Screw	Screw - TRUSS 4 TS - POINTED - BLACK	
0103	12041658	Screw	Screw for shelf supports, back wall	
0104	10019974	Screw	Screw - TRUSS 4 TS - POINTED - BLACK	
0106	20003758	Rack guide rail	Rack glide, lower LH for UC Wine cellar	
0107	20003759	Rack guide rail	Rack support, lower RH side, UC RH	
0108	23002022	Wire rack	Wire Rack Assembly	23002983
0109	23002023	Wire rack	Wire Rack Assembly	
0110	20003014	Panel-base	Kick Plate	
0111	00638086	Screw	Kick Plate Screw	
0112	00637970	Foot	Leg	
0113	12037622	Mounting bracket	Bracket Kick Plate	
0114	12041324	Switchbox	Box, Door switch - - Switch # 10024572	
0115	10019977	Screw	Screw - TRUSS 4 TS - POINTED - WHITE	
0116	00638141	Mounting bracket	Fixation Bracket Assembly, includes adhesive strip.	
0117	00638142	Screw	Self-Tapping Screw	
0150	10024572	Switch-door	Door switch	
0201	23002021	Shelf plate	Seperator Assembly	

Item Number	Material Number	Material Shorttext	Infotext	Substitute Material Number
0202	11048548	Display module	Display PCB assembly, UI	
0203	12037621	LED cover	Cover, LED	
0204	12037620	LED-Light bar	LED Assembly	
0205	10019974	Screw	Screw - TRUSS 4 TS - POINTED - BLACK	
0206	10019974	Screw	Screw - TRUSS 4 TS - POINTED - BLACK	
0207	11048547	Sealing strip	Divider, SEALING STRIP, for UC wine cellar	
0303	10019975	Screw	Screw - TRUSS 4 TS 16	
0304	23002030	Cover	Evaporator Cover Service Kit	
0305	20003790	Fan	Evaporator Fan Assembly - Wine Cellar	
0306	10019985	Washer	Washer	
0307	10019974	Screw	Screw - TRUSS 4 TS - POINTED - BLACK	
0308	10019974	Screw	Screw - TRUSS 4 TS - POINTED - BLACK	
0309	12037619	Temperature sensor	Sensor, Defrost	
0310	10019976	Fuse-thermal	Temp Fuse	
0311	11045023	Heater-defrost	Defrost Heater Kit	
0313	12037630	Sensor-PTC	Sensor PCC	
0314	12037631	Adhesive tape	Tape PE-F B	
0401	11045280	Labels	Label, energy	

Item Number	Material Number	Material Shorttext	Infotext	Substitute Material Number
0402	23002064	Door	Complete door assembly, RH Handle, Masterpiece	
0403	12037752	Plate	Switch Push Plate	
0404	10019977	Screw	Screw - TRUSS 4 TS - POINTED - WHITE	
0405	12037754	Hinge-cover	Hinge Cover, BOTTOM	
0406	12037753	Hinge-cover	Hinge Cover, TOP	
0409	11045283	Seal-door	Door Gasket	
0410	10007320	Screw	M5X22 no head markings screw	
0503	10019978	Clamp	Clamp, Cord	
0504	10019977	Screw	Screw - TRUSS 4 TS - POINTED - WHITE	
0505	11045033	Pan	Pan Water EVA	
0506	10019977	Screw	Screw - TRUSS 4 TS - POINTED - WHITE	
0507	11045034	Control module	Main control PCB assembly with housing	
0508	10019979	Screw	TRUSS 4 TS 18 - POINTED WHITE	
0509	10019977	Screw	Screw - TRUSS 4 TS - POINTED - WHITE	
0510	00637999	Washer	Washer	
0511	11045035	Box	Cover Box PCB	

Item Number	Material Number	Material Shorttext	Infotext	Substitute Material Number
0512	11045036	Fan motor	Fan Motor Assembly - Service Kit	
0513	12011018	Dryer	Dryer, Filter	
0514	12037624	Clamp	Clamp Dryer	
0515	23002026	Compressor	Compressor	
0516	12037625	Relay	PTC Relay	
0517	12037626	Motor-protection	Motor Protector	
0518	12037627	Cover	Cover	
0519	11045037	Cover	Compressor Noise Suppressor	
0520	00637977	Bolt	Compressor Bolt	
0521	00637978	Grommet	Grommet, Comressor Mount	
0523	11012709	Cover	Rear Cover	
0524	12047624	Power cord	Power Cord.	
0601	00715143	Insulation mat	Cabinet Insulation (Only when 2 units installed S x S)	