




Mar 2, 2025

Bill-of-material

1

Item Number	Material Number	Material Shorttext	Infotext	Substitute Material Number
0101	00743991	Hob top	Teppan-Yaki- plate	11053647
0108	10009213	Holder	Holder for iService connector.	
0109	10013301	Housing part	Lid for iService plug.	
0111	00748237	Fixing kit	spring fix , New 400 Vario fastening devices	
0115	11031858	Insulating part	Insulation parts set (quantity: 3 parts)	
0116	00627968	Sealing strip	VP-Seal 5x4 cut	
0126	00751002	Heating element	heating assembly flat heating	
0128	00627993	Connection	Connector for flat heating	
0130	10011156	Limiter-temperature	250°C	
0132	10011155	Temperature sensor	PT1000	
0134	12027541	Control module not programmed	Encoding required with "iService" Customer Service software.	12036831
0134	12027552	Control module programmed	VC: 102, VP414-US. , Module not programmed: 12027541.	
0136	00552829	Part not included in this appliance	552829 Part not included in this appliance	
0141	12029003	Cable	iService cable, UL. , 500 mm, for appliances with UL requirements.	

Mar 2, 2025

Bill-of-material

2

Item Number	Material Number	Material Shorttext	Infotext	Substitute Material Number
0142	10011161	Cable harness	V400 E-knob internal cable	
0143	00552829	Part not included in this appliance	552829 Part not included in this appliance	
0145	00552829	Part not included in this appliance	552829 Part not included in this appliance	
0146	12031297	Cable harness	Power supply cable US, UL.	
0147	12031868	Connection piece	1/2" Steel Conduit , Length: 1524mm (60")	
0148	00414692	Connection	CONNECTOR, 1/2" x 90DEG	
0149	00416289	Insert	ANTI-SHORT BUSHING	
0150	00415812	Retaining washer	PROTECTOR, KNOCKOUT	
0151	10013302	Cable harness	Front zone cable, UL.	
0152	10013303	Cable harness	Rear zone cable, UL.	
0153	00552829	Part not included in this appliance	552829 Part not included in this appliance	
0154	00552829	Part not included in this appliance	552829 Part not included in this appliance	
0161	10020328	Sign	Marking ring Vario 400 , "Temperature" stainless steel	
0161	12031296	Rotary knob	VP414-US, electronic knob , VC 0066, SW4	

Mar 2, 2025

Bill-of-material

3

Item Number	Material Number	Material Shorttext	Infotext	Substitute Material Number
0162	10020329	Sign	Marking ring Vario 400 , "Teppan Yaki Zone" stainless steel	
0162	12027540	Rotary knob	VP414, Selector, electronic knob , VC 0049, SW4	
0166	00628211	Ring	O-Ring User Interface knob , Vario400	
0167	10001572	Nut	Knob nut	
0168	12013604	Connection cable	Cable for knob Vario 400 , 0,3 m	
0170	12013606	Connection cable	Cable for knob Vario 400 , 1,0 m	
0171	12014046	Mounting bracket	Mounting plate, 2 knobs	
0186	00445808	Scraper	Putty, stainless steel	
0198	10020190	Screw-set	4 screws PT4x16	
0199	10001573	Tools	For tightening of knob nut.	10016840
8461	18028334	Installation Instructions Gaggenau	en-us,fr-ca,es-mx	
8461	18045509	Installation Instructions Gaggenau	en-us,es-mx,fr-ca	
8476	18045508	Instruction Manual Gaggenau	en-us,es-mx,fr-ca	