

IMPORTANT SAFETY INSTRUCTIONS

PROPER ATTACHMENT TO SURFACES:

Attach BLO & GO™ to a flat, smooth, dry surface only. BLO & GO™ will attach best to glass windows, mirrors and most counter tops. The security of BLO & GO™ depends on proper attachment. Attaching to any other surface will interfere with the pressure-grip lock system. BLO & GO™ should not be attached to walls, painted surfaces, drywall or porous surfaces as it may leave a mark.

BLOW DRYER CORDS:

The cord of the blow dryer must be away from water to avoid electric shock or electrocution, and needs to be positioned to the side to avoid tripping over it.

PROPER ATTACHMENT OF BLOW DRYER:

Be sure the blow dryer is attached securely with the bungee cord and placed within the hooks provided on the sides of the holder BEFORE use.

AFTER USE:

Unplug and remove the blow dryer from the BLO & GO™. BLO & GO™ may become hot after extended hair styling. Allow the unit to cool before handling. After the unit is cool to the touch, remove the BLO & GO™ immediately from the attached surface. Do not leave BLO & GO™ attached to surfaces for extended periods of time as it may leave a mark.

BLO & GO™ INSTRUCTIONAL MANUAL



Welcome and congratulations on your purchase of BLO & GO™! We are excited that you have chosen BLO & GO™ to help make your hair styling a whole lot easier.

With your purchase of the BLO & GO™, you can get professional salon results in the convenience of your home, for just a fraction of the price. Everyone can use an extra pair of hands. BLO & GO™ will help you blow dry and style your hair faster and easier. You'll be blown away by the results!

IMPORTANT SAFETY INSTRUCTIONS

WARNING: TO REDUCE THE RISK OF SERIOUS INJURY, READ ALL INSTRUCTIONS AND WARNINGS COMPLETELY BEFORE USING THIS PRODUCT.

SAVE THESE INSTRUCTIONS. KEEP THIS MANUAL IN A SAFE PLACE FOR FUTURE REFERENCE AND MAKE SURE ANYONE WHO USES THIS PRODUCT ALSO READS THIS MANUAL.

BLO & GO™ has been carefully engineered for both effectiveness and safety. However, basic safety precautions should always be followed when using any product, especially when children are present.

WARNING: BLO & GO™ IS NOT INTENDED FOR USE BY CHILDREN.

KEEP AWAY FROM WATER — DANGER

BLO & GO™ is used with a blow dryer. UNPLUG IT AFTER USE. As with most electrical appliances, electrical parts in a blow dryer are electrically live even when switch is off.

WARNING: TO REDUCE THE RISK OF DEATH OR INJURY BY ELECTRICAL SHOCK:

1. ALWAYS UNPLUG the blow dryer after using the BLO & GO™.
2. ALWAYS remove the blow dryer from the BLO & GO™ after use.
3. DO NOT place or store BLO & GO™ or the blow dryer where they can fall or be pulled into tub, toilet, sink, or any other water.
4. DO NOT use the BLO & GO™ or the blow dryer while bathing or showering.
5. DO NOT use the BLO & GO™ or the blow dryer near water.
6. DO NOT place or drop the BLO & GO™ or the blow dryer into water or other liquid.
7. If the BLO & GO™ or the blow dryer falls into water, DO NOT REACH INTO WATER. Unplug the blow dryer immediately.

TO REDUCE THE RISK OF BURNS, FIRE, ELECTRICAL SHOCK, DEATH, INJURY OR DAMAGE TO PROPERTY:

1. Use this product only for its intended use as described in this Instructional Manual.
2. Do not use attachments not recommended by the manufacturer.
3. Never operate a blow dryer with this product if it has a damaged cord or plug, if it is not working properly, if it has been dropped or damaged, or if it has been dropped into water.
4. Keep this product and the blow dryer cord away from water and heated surfaces.
5. This product has moving parts. Please keep children and pets away from this product when in use or when unattended.
6. This product is designed for hair styling. Do not use for any other purpose.
7. This product is a personal care device and is not intended for commercial use.
8. Do not use this product if any parts become damaged. Inspect this product prior to beginning hair styling to ensure all parts are secure in their place.
9. Do not subject this product to excessive force or shock that may result in malfunction, shorter life span or distorted parts.
10. Do not tamper with this product's components. Doing so may cause unnecessary damage. This product contains no user-serviceable parts.
11. Do not use liquid cleaners, aerosol cleaners, or any cleaner containing alcohol, detergent, abrasive or corrosive materials.
12. Do not hang or pull on this product.
13. Do not insert anything heavier than a blow dryer within the holder on this product.

INSTRUCTIONS — NO ASSEMBLY REQUIRED



STEP 1

Place your BLO & GO™ on a flat, dry surface with the suction lever in the up position



STEP 2

While using one hand to firmly hold your BLO & GO™ against the flat, dry surface, place your other hand on the suction lever



STEP 3

Press down on the suction lever to activate the pressure-grip lock system



STEP 4

Place the cord of your blow dryer all the way through the opening of the holder at the top of your BLO & GO™



STEP 5

Place the arm of your blow dryer within the holder at the top of your BLO & GO™



STEP 6

Hold the arm of your blow dryer with one hand and use the other hand to wrap the bungee cord around the top of your blow dryer



STEP 7

Place the bungee cord within the hook provided on the side of the holder



STEP 8

Style your hair — BLO AND GO!

IMPORTANT
SEE REVERSE SIDE
FOR ADDITIONAL
SAFETY
INSTRUCTIONS

