

User Manual- TF 500

Special Features

- Ringer with LED Indication
- 3-Step Ringer Volume Control (OFF / LOW / HI) Switchable
- 3-Step Handset Receive Volume Control (L / M / H) Switchable
- Tone / Pulse Dialing Mode Switchable
- Flash Function
- Pause Function
- Mute Function
- Last Number Redial
- Dynamic Changeover from Pulse to Tone
- Desktop / Wall Mountable

Contents

Contents	Page No.
Precaution	1
Installation	1
Feature Layout	2
Initial settings	2-3
Operations	3-4
- Making a call	3
- Last Number Redial	3

- Flash Function	3
- Pause Function	3
- Mute Function	3
- Dynamic change over from Pulse to Tone	4
- Ring Indicator	4

Contents in retail package

- Base Unit --- 1Nos
- Handset --- 1Nos
- Line cord --- 1Nos
- Coil Cord --- 1Nos
- User Manual -- 1Nos

Precautions

- Install the phone in a dust free and non-corrosive environment.
- Do not drop the phone on hard surfaces.
- Wipe the telephone with a soft cloth. don't use harsh chemicals, cleaning solvents or strong detergents to clean your phone.
- Do not twist or pull the telephone cord too hard.
- Do not use electrical plug so as not to have connection accidentally to AC mains, connection to AC Mains will severely damage the telephone.

Installation

- Connect the base and handset with coiled cord.

- Insert one end of the line cord to the line jack on the base (marked as LINE) & connect the other end to the rosette/Wall jack.

Setting the dial mode to correct mode according to the directions from your local telecom company

- | | |
|----------------|----------------|
| 1. Receiver | 6. FLASH key |
| 2. Hook-Switch | 7. Pause key |
| 3. Number Key | 8. Mute key |
| 4. REDIAL key | 9. Coiled Cord |
| 5. RING LED | |

Initial Settings

Dial Mode Setting

- Dial mode can be set by using the P/T (Pulse/Tone) switch mounted on the rear side of the base unit
- In on hook condition slide the P/T switch knob from T (Tone) to P (Pulse) as desired.
- The default dial mode setting is Tone. **Ringer Volume setting**
- Ringer volume can be adjusted by using the Ringer switch mounted on rear side of the base unit.
- Set the ringer volume switch knob from high to Low or Off position as desired.
- The default ringer setting is High

2

Handset Receive Volume setting

- Handset receive volume can be adjusted by using the handset receive volume switch mounted on rear side of the base unit.
- Set the handset receive volume switch knob from low to medium or high position as desired
- The default handset receive volume setting is Low.


Operations

Making a call:

- Pick up the handset and hear the dial tone.
- Press the desired number & speak to the other end.
- After the conversation finished, place the handset on the base.

1

Feature layout



Layout Base

Receiving a call

- The unit will ring when you have an incoming call, •
When the unit rings, pick up the handset and speak to the caller.
- When conversation finished, place the handset to the base.

Last Number Redial

- Pick up the handset.
- After hearing the dial tone, Press Redial key.
- The last dialed number will be dialed out.

Flash Function

- Pick up the handset.
- Press FLASH key the telephone line will break for 300 m Sec. (This feature is provided in the telephone to access the facility offered by some EPBAX such as line transfer or network service by telephone companies such as Call Waiting, etc.)

Pause Function

- We recommend you to press the PAUSE key if a pause is required for dialing with a PABX or to access a Long Distance Code. On pressing the PAUSE key

the unit will introduce a 3.6 seconds delay between the two digits dialed before and after the pause.

Mute Function

- When making a phone call, if you need a temporary talk with some one else and you don't want the phone receiver hear your speaking, keep press "MUTE" key to mute your voice sending, release "MUTE" key to return to conversation mode.

Dynamic change over from Pulse to Tone

- When phone is set in Pulse Dialing Mode
- Pick up the handset
- Press * key to change the dialing mode from Pulse to Tone temporarily.
- Dial the desired number from key pad and talk to the other end.
- After finishing the conversation, place the handset on the base.

Note: - The phone will return to the original pulse dialing mode automatically after finishing the Conversation

Ring Indicator

- The Ring Indicator shows the incoming call.