
WARM CUP

55 degrees is just right


Product introduction




Product usage



① Place the base on a flat table top and turn on the power.



② Place the cup filled with water on the heating device of the heat preservation dish, the base senses the weight of the Cup, the power is automatically switched on, the indicator light is on, and the work starts.



③ Remove the cup and the gravity switch will pop up automatically, disconnecting the power supply.

Points to note

① The base can not be immersed in water to clean, you can wait for the cooling of the base with a wring dry soft wet cloth wipe (wipe before you must disconnect the power);

② The base heating device and the heat conduction device at the bottom of the cup body are in working condition, the surface is high temperature, be careful of scalding;

③ Please use in the open indoor environment, do not use blanket objects cover the base heating, so as not to affect the performance of heat dissipation, causing damage;

④ This product can not be connected to external timer or independent remote control system in the way of Operation;

⑤ Children and capacity persons are advised to use the product under the supervision of their guardians;

⑥ Please use the supporting cup body with bottom heat conduction device

⑦ If the product needs to replace electrical components or other electrical performance problems, please contact our The ADJUSTER staff to guide maintenance;

⑧ If the power cord is damaged, in order to avoid danger, it must be replaced by the manufacturer, its Maintenance Department or similar professionals.

Product parameters

Product name: Vacuum Flask PRODUCT MODEL: JYY-01

RATED POWER SUPPLY:220V~50Hz Rated Power: 16W

NOMINAL CAPACITY: 350 ~ 400 ML

Implementation Standard: GB4706.1-2005 GB4706.55-2008

Warranty information

—、Warranty clause

Products sold from the date, the normal use of quality problems, can enjoy 1 year free warranty service.

In the case of the following factors, the company will charge a maintenance fee as appropriate;

1.Damage caused by force majeure factors (earthquake, fire, flood, etc.);

2.Product damage caused by human factors (mistake/careless use, etc.);

3.Damage caused by disassembly or alteration;

4.Exceeding the warranty period.

Please keep this information and present it when you need maintenance services.

User name: Telephone number:

PLACE OF PURCHASE: PURCHASE DATE:

Delivery Address: