

Girls Button Set Item Top

All Mesurment are in CMS

TOP

ITEM	45	50	55	60	65	70	75	80	85	90
Chest	28.00	29.00	30.50	32.50	33.50	34.50	36.00	38.00	41.00	44.00
Length	38.50	41.00	43.50	46.00	48.50	51.00	54.50	58.50	62.50	66.00
Sleeve Length	9.00	9.50	10.00	10.50	11.00	12.00	12.50	13.00	13.50	14.00
Sleeve Open	8.50	9.00	9.50	10.00	10.50	11.50	12.00	12.50	13.00	13.50
Arm Hole	12.00	12.50	13.00	14.00	14.50	15.00	16.00	17.00	18.00	19.00
Wasit	26.00	27.00	29.00	30.00	32.00	33.00	34.00	36.00	38.00	40.00
Bottom	29.00	30.00	32.00	34.00	36.00	37.50	39.00	41.00	43.50	46.00
Shoulder	24.00	25.00	27.00	28.00	29.00	30.00	31.00	33.00	35.00	37.00
Neck Open	15.00	15.00	15.00	15.00	16.00	16.00	16.00	17.00	17.00	17.00
Neck Drop	7.00	7.00	7.00	7.00	8.00	8.00	8.00	8.00	8.00	8.00

Bottom Full Pant

ITEM	45	50	55	60	65	70	75	80	85	90
Wrist Band Width	18.00	19.00	20.00	22.00	23.00	24.00	25.00	27.00	28.00	29.00
Wrist Band Hight	2.50	2.50	2.50	2.50	2.50	2.50	2.50	2.50	2.50	2.50
HIP	29.00	30.50	32.00	34.00	36.50	38.50	41.00	43.00	46.00	48.50
Length	52.00	57.00	62.00	66.00	71.00	76.00	81.00	87.00	91.00	95.00
THIGH	17.50	19.00	20.00	20.50	21.50	22.50	24.00	25.00	26.50	27.50
INSEAM	34.00	38.50	42.00	46.50	50.50	55.50	58.50	62.50	66.50	70.00
LEG OPEN	12.50	13.00	13.00	13.50	13.50	14.00	14.00	15.00	15.00	16.00