## **HOW MUCH PER TIRE?**

<b>6</b>	MOTORCYCLE	8 oz. (237 mL)
هل	SCOOTER	8 oz. (237 mL)
	CAR/TRAILER	16 oz. (473 mL)
<b></b>	TRUCK/SUV	20 oz. (592 mL)

## **HOW DO I INSTALL SLIME?**





upper half of tire.

core with tool in cap.



4. Remove object

(if possible).



squeeze in Slime.



6. Replace valve core.



7. Inflate tire.



8. Drive. Stop. Verify seal and check pressure.