



## ***VALVE FISHING TOOL***

1. Use tool to install the valve.
2. Use tool to remove valve core.
3. Use tool to deflate and clean threads.

©Accessories Marketing, Inc.

800 Farroll Road Grover Beach, CA 93433 USA

P.O. Box 197, Oaklands Park, SA 5046 Australia

**[www.slime.com](http://www.slime.com)**

**PART# 20075**

**09.08**



Made in China