


Size	Width (cm)	Length (cm)
104 (3-4 year)	33	43
110 (4-5 year)	35.5	46
116/128 (6-8 year)	38	48
140/152 (9-12 year)	41	52
164 (13-14 year)	43	56



To wash graphic tees without cracking the print or having the colors deteriorate after a wash, follow these washing advices:

1. Turn the tee inside out to protect the graphic from friction
2. Use cold water (30°C) and gentle cycle to prevent color fading and stretching
3. Avoid using harsh detergents or bleach, which can damage the fabric and graphics
4. Air-dry the tee instead of using a dryer to prevent heat damage
5. If needed, iron the tee inside out on a low setting By following these steps, you can ensure your graphic tees stay vibrant and crack-free