

Brinsea

Brinsea Products Ltd, Station Road, Sandford,
North Somerset, BS25 5RA.
Tel: 0845 226 0120 Fax: (01934) 820250
e-mail: sales@brinsea.co.uk,
website: www.Brinsea.co.uk

OvaView High-Intensity

Egg Candling Lamp

User Instructions

The *OvaView* is a scientifically designed, purpose made lamp for inspecting the embryo development during incubation.

A non-replaceable, high power LED is used for greatest efficiency, reliability and cool operation.


**CAUTION – Never look directly into the light source.
Switch off when not in use to maximise battery and LED life.**

Instructions for use.


1. Eggs may be examined for fertility after about 7 days. Infertile eggs will appear clear and can be rejected.
2. Air space estimation can be made using the chart. If the airspace is too small reduce humidity and vice versa.
3. The *OvaView* may be used directly in a darkened room or the *OvaScope* may be used in other situations.

Battery Replacement

- Observe correct polarity to prevent leakage or risk of fire
- Do not mix old and new batteries
- Do not use different types of battery at the same time
- For best results use rechargeable batteries in the *OvaView* High Intensity. A suitable charger and batteries are available from Brinsea Products
- Remove the batteries if you do not intend to use the *OvaView* for a long period



Hen Egg 58g



Turkey Egg 85g

Dimensions: 128 x 83 x 33mm (5" x 3.3" x 1.3")
Weight: 85g (3 oz)