

**Datenblatt zu Notebook Akku VIS-53-T430L9**Vistaport-Artikel-Nr. **VIS-53-T430L9**Für Notebook-Marke **IBM / Lenovo**Techn. Spezifikation **9 cells, 10.8V, 7800mAh, Lilon**Anzahl Zellen **9 cells**Gewicht **400g**Garantie **18 months**Kann diese Original-Hersteller-Teile ersetzen **45N1011, 45N1010,70++, 0A36303,45N1013,42T4739,42T4799,42T4801,42T4803**

## Modelle

IBM / Lenovo	<b>LENOVO - IBM 0A36303</b>
IBM / Lenovo	<b>LENOVO - IBM 42T4710</b>
IBM / Lenovo	<b>LENOVO - IBM 42T4712</b>
IBM / Lenovo	<b>LENOVO - IBM 42T4714</b>
IBM / Lenovo	<b>LENOVO - IBM 42T4739</b>
IBM / Lenovo	<b>LENOVO - IBM 42T4799</b>
IBM / Lenovo	<b>LENOVO - IBM 42T4801</b>
IBM / Lenovo	<b>LENOVO - IBM 42T4803</b>
IBM / Lenovo	<b>LENOVO - IBM 42T4912</b>
IBM / Lenovo	<b>LENOVO - IBM 45N1007</b>
IBM / Lenovo	<b>LENOVO - IBM 45N1010</b>
IBM / Lenovo	<b>LENOVO - IBM 45N1011</b>
IBM / Lenovo	<b>LENOVO - IBM 45N1013</b>
IBM / Lenovo	<b>LENOVO - IBM 70 PLUS PLUS</b>

**Datenblatt zu Notebook Akku VIS-53-T430L9**

IBM / Lenovo	<b>LENOVO - IBM 70++</b>
IBM / Lenovo	<b>LENOVO - IBM BATTERY 70++</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD 0578-26U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD 057826U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD 2842-7PU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD E520</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD E525</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD EDGE 14</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD EDGE 14 0199</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD EDGE 14 0578</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD EDGE 14 0579</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD EDGE 14 0579-22U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD EDGE 140579-53U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD EDGE 140579-54U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD EDGE 140579-66U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD EDGE 140579-6AU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD EDGE 15</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD EDGE 15 0301</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD EDGE 15 0302</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD EDGE 15 0319</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD EDGE 15 0319-22U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD EDGE 15 0319-23U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD EDGE 15 0319-24U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD EDGE 15 0319-25U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD EDGE 15 0319-26U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD EDGE 15 0319-3NU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD EDGE 15 0319-3PU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD EDGE 15 0319-3QU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD EDGE 15 0319-3RU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD EDGE 15 0319-3SU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD EDGE 15 0319-42U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD EDGE 15 0319-46U</b>

**Datenblatt zu Notebook Akku VIS-53-T430L9**

IBM / Lenovo	<b>LENOVO - IBM THINKPAD EDGE 40</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD EDGE 40 0199</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD EDGE 40 0578</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD EDGE 50</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD EDGE 50 0301</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD EDGE 50 0302</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD EDGE E420 1141-55U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD EDGE E420 1141-56U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD EDGE E420 1141-57U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD EDGE E420 1141-58U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD EDGE E420 1141-9BU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD EDGE E420 1141-BTU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD EDGE E420 1141-BUU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD EDGE E420 1141-D9U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD EDGE E420 1141-GCU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD EDGE E425 1198-3EU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD EDGE E425 1198-3FU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD EDGE E520 1143-3BU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD EDGE E520 1143-3CU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD EDGE E520 1143-3DU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD EDGE E520 1143-3EU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD EDGE E520 1143-3FU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD EDGE E520 1143-3GU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD EDGE E520 1143-7RU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD EDGE E520 1143-ADU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD EDGE E520 1143-AEU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD EDGE E520 1143-AFU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD EDGE E520 1143-BNU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD EDGE E520 1143-D7U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD EDGE E520 1143-D8U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD EDGE E520 1143-EHU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD EDGE E520 1143-GWU</b>

**Datenblatt zu Notebook Akku VIS-53-T430L9**

IBM / Lenovo	<b>LENOVO - IBM THINKPAD EDGE E520 1143-KEU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD EDGE E520 1143-KFU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD EDGE E520 1143-KGU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD EDGE E525 1200-2LU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD EDGE E525 1200-2MU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD EDGE E525 1200-38U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD EDGE E525 1200-39U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD EDGE E525 1200-3JU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L410</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L410 0616</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L410 2931</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L412</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L412 0530</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L412 0553</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L412 0585</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L412 0591</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L412 4403</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L412 4404</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L420</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L420 7826</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L420 7827</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L420 782732U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L420 782733U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L420 782734U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L420 782742U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L420 782743U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L420 782744U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L420 782745U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L420 782746U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L420 782747U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L420 782748U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L420 78275DU</b>

**Datenblatt zu Notebook Akku VIS-53-T430L9**

IBM / Lenovo	<b>LENOVO - IBM THINKPAD L420 78275EU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L420 78275FU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L420 78275GU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L420 78275HU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L420 78275WU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L420 7829</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L420 782932U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L420 782933U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L420 782934U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L420 782942U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L420 782943U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L420 782944U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L420 782945U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L420 782946U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L420 782947U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L420 782948U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L420 78294QU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L420 78294RU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L420 78294SU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L420 78294TU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L420 78294UU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L420 7854</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L420 785434U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L420 785437U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L420 785438U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L420 78545FU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L420 78545GU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L420 7856</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L420 785634U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L420 785637U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L420 785638U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L421</b>

**Datenblatt zu Notebook Akku VIS-53-T430L9**

IBM / Lenovo	<b>LENOVO - IBM THINKPAD L421 7826</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L421 7827</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L421 7829</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L421 7854</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L421 7856</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L430</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L430 2464</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L430 2465</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L430 246527U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L430 246528U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L430 246529U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L430 24652AU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L430 24652BU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L430 24652CU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L430 24652DU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L430 24652EU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L430 24652FU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L430 24652GU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L430 24652HU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L430 24652JU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L430 24652KU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L430 246532U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L430 246533U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L430 2466</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L430 246632U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L430 246633U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L430 246639U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L430 24663AU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L430 24663BU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L430 24663CU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L430 24663DU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L430 24663EU</b>

**Datenblatt zu Notebook Akku VIS-53-T430L9**

IBM / Lenovo	<b>LENOVO - IBM THINKPAD L430 24663FU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L430 24663GU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L430 24663HU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L430 24663JU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L430 24663KU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L430 2468</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L430 24682AU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L430 24683AU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L430 2469</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L430 246924U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L430 246925U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L430 246926U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L430 246927U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L430 246928U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L510</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L510 2873</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L512</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L512 2550</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L512 2597</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L512 2598</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L512 2599</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L512 4444</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L512 4447</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L520</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L520 5015</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L520 5016</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L520 501632U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L520 501633U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L520 501642U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L520 501643U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L520 501644U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L520 501645U</b>

**Datenblatt zu Notebook Akku VIS-53-T430L9**

IBM / Lenovo	<b>LENOVO - IBM THINKPAD L520 501646U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L520 501647U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L520 501648U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L520 501649U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L520 50165ZU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L520 5017</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L520 501732U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L520 501733U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L520 501742U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L520 501743U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L520 501744U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L520 501745U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L520 501746U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L520 501747U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L520 501748U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L520 501749U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L520 5860</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L520 7859</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L520 785935U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L520 785936U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L520 785938U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L520 785968U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L520 785969U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L520 7860</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L520 786035U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L520 786036U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L520 786038U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L530</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L530 2475</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L530 2478</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L530 247823U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L530 247824U</b>



**Datenblatt zu Notebook Akku VIS-53-T430L9**

IBM / Lenovo	<b>LENOVO - IBM THINKPAD L530 247825U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L530 247826U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L530 247827U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L530 247828U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L530 247829U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L530 24782AU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L530 24782BU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L530 24782CU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L530 24782DU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L530 24782FU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L530 24782GU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L530 24782HU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L530 24782XU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L530 24782YU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L530 247832U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L530 247833U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L530 2479</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L530 247932U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L530 247933U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L530 247939U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L530 24793AU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L530 24793BU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L530 24793CU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L530 24793DU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L530 24793EU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L530 24793GU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L530 24793MU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L530 24793PU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L530 247944U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L530 247945U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L530 247953U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L530 2481</b>

**Datenblatt zu Notebook Akku VIS-53-T430L9**

IBM / Lenovo	<b>LENOVO - IBM THINKPAD L530 248126U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L530 248134U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L530 2485</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L530 248522U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L530 248523U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L530 248524U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L530 248525U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD L530 248526U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD SL410</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD SL410 2842</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD SL410 2874</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD SL410 2931</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD SL410-2842</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD SL510</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD SL510 2847</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD SL510 2875</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD SL510 5072</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T410</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T410 2516</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T410 2518</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T410 2519</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T410 2522</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T410 2537</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T410 2538</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T410 2539</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T410I</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T410I 2516</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T410I 2518</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T410I 2537</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T420</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T420 4177</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T420 4177Q2U</b>

**Datenblatt zu Notebook Akku VIS-53-T430L9**

IBM / Lenovo	<b>LENOVO - IBM THINKPAD T420 4177Q5U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T420 4177Q8U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T420 4177QJU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T420 4177QKU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T420 4177QLU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T420 4177R3U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T420 4177RVU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T420 4178</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T420 417856U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T420 417857U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T420 417858U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T420 417859U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T420 41786UU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T420 41786VU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T420 41786WU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T420 41789RU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T420 4178ACU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T420 4178AFU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T420 4178APU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T420 4178ATU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T420 4178AWU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T420 4178B7U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T420 4178C9U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T420 4178CAU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T420 4178CUU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T420 4179</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T420 4180</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T420 418062U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T420 418063U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T420 418064U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T420 418065U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T420 4180KHU</b>

**Datenblatt zu Notebook Akku VIS-53-T430L9**

IBM / Lenovo	<b>LENOVO - IBM THINKPAD T420 4180MBU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T420 4180MMU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T420 4180MNU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T420 4180N2U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T420 4180NCU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T420 4180NDU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T420 4180NEU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T420 4180PAU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T420 4180PFU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T420 4180PRU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T420 4180Q3U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T420 4180QAU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T420 4180QCU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T420 4180QFU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T420 4236</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T420 423662U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T420 423663U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T420 423664U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T420 423665U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T420 4236MBU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T420 4236NHU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T420 4236NUU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T420 4236NVU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T420 4236PAU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T420 4236PRU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T420 4236QFU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T420 4237</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T420 4238</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T420I</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T420I 4177</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T420I 4177QGU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T420I 4177R2U</b>

**Datenblatt zu Notebook Akku VIS-53-T430L9**

IBM / Lenovo	<b>LENOVO - IBM THINKPAD T420I 4178</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T420I 4179</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T420I 4180</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T420I 4236</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T430</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T430 2342</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T430 2344</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T430 2345</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T430 2347</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T430 2349</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T430 2350</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T430 2351</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T430I</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T430I 2342</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T430I 2344</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T430I 2347</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T430I 2349</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T510</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T510 4313</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T510 4314</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T510 4339</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T510 4349</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T510 4349CJ3</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T510 4384</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T510 4384HP3</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T510 4384ZKS</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T510 4484</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T510 4873</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T510 5584</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T510 8787</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T510I</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T510I 4313</b>

**Datenblatt zu Notebook Akku VIS-53-T430L9**

IBM / Lenovo	<b>LENOVO - IBM THINKPAD T510I 4314</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T510I 4339</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T520</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T520 4239</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T520 423923U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T520 423924U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T520 423926U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T520 423946U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T520 42394CU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T520 42394DU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T520 42394EU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T520 42394MU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T520 42395CU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T520 42395GU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T520 4240</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T520 42402FU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T520 42402GU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T520 42402HU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T520 424048U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T520 424049U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T520 42404AU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T520 42404EU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T520 42404RU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T520 424053U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T520 424057U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T520 424066U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T520 42406MU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T520 42406NU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T520 4241</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T520 424126U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T520 4242</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T520 424227U</b>

**Datenblatt zu Notebook Akku VIS-53-T430L9**

IBM / Lenovo	<b>LENOVO - IBM THINKPAD T520 424228U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T520 424229U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T520 424239U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T520 42424UU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T520 42424VU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T520 42424WU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T520 424258U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T520 424259U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T520 42425UU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T520 42425YU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T520 42425ZU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T520 424262U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T520 4243</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T520 424327U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T520 424328U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T520 424329U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T520 42434UU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T520 42434VU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T520 42434WU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T520 42435UU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T520 42435ZU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T520 4244</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T520 4246</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T520I</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T520I 4239</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T520I 423947U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T520I 42394LU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T520I 4240</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T520I 4241</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T520I 4242</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T530</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T530 2359</b>

**Datenblatt zu Notebook Akku VIS-53-T430L9**

IBM / Lenovo	<b>LENOVO - IBM THINKPAD T530 2392</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T530 2393</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T530 2394</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T530 2429</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T530 2430</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T530 2434</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T530I</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T530I 2359</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T530I 2392</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T530I 2429</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T530I 2436</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T530I 2438</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T530I 2439</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T530I 2441</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T530I 2447</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T530I 2449</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD T530I 2463</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD W510</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD W510 4318</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD W510 4319</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD W510 4387</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD W510 4389</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD W510 4391</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD W510 4875</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD W510 4876</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD W520</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD W520 4249</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD W520 4260</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD W520 4270</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD W520 4276</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD W520 42763JU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD W520 42763KU</b>



**Datenblatt zu Notebook Akku VIS-53-T430L9**

IBM / Lenovo	<b>LENOVO - IBM THINKPAD W520 42763LU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD W520 42763MU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD W520 42763NU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD W520 4281</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD W520 4282</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD W520 428223U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD W520 428224U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD W520 428225U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD W520 428226U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD W520 42823RU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD W520 42823SU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD W520 428245U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD W520 42824BU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD W520 42824CU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD W520 42824EU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD W520 42824GU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD W520 42824UU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD W520 42824YU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD W520 42824ZU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD W520 42825BU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD W520 42825CU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD W520 4284</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD W520 428423U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD W520 428424U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD W520 428425U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD W520 428426U</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD W520 42844BU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD W520 42844CU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD W520 42844EU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD W520 42844YU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD W520 42844ZU</b>
IBM / Lenovo	<b>LENOVO - IBM THINKPAD W520 42845CU</b>

## Datenblatt zu Notebook Akku VIS-53-T430L9

IBM / Lenovo

**LENOVO - IBM THINKPAD W520 42845DU**

IBM / Lenovo

**LENOVO - IBM THINKPAD W530**