



User Guide

Thank you for purchasing the Go-tcha Evolve for Pokémon GO!

Enjoy Pokémon GO on the move without looking at your smartphone!

What's In The Box?


In your Go-tcha Evolve for Pokémon Go box you should receive:

- x1 Go-tcha Evolve Smartwatch
- x1 Charging Instruction Card



Charging Your Go-tcha

The Go-tcha Evolve has a built-in USB charging connector accessed by removing the buckle end of strap. Connect the built-in USB charging unit into a power source - fully charged and ready to use in 1 1/2 hours.



IMPORTANT: Check that the Go-tcha Evolve is inserted into the USB port of the power source the correct way up. Even though it goes into the USB port both ways - the animation screen will only appear when inserted in the correct orientation. Only when the charging animation is displayed, is your Go-tcha Evolve actually charging.

Before You Start - Ensure that your Go-tcha Evolve has the latest firmware

Download the Go-tcha Evolve App for even more features like checking your stats and changing your smartwatch settings to enhance the Go-tcha experience. Simply scan the QR code to take you to Go-tcha Evolve on the Apple or Android App Store page or search 'Go-tcha Evolve' in the App store.

To connect your Go-tcha Evolve to the Go-tcha Evolve App, you must close the Pokémon Go App. Press the button on the Go-tcha Evolve to wake the screen and it will connect automatically to the open Go-tcha Evolve App. Updates will download automatically.

Note: The Go-tcha Evolve cannot connect to more than one App at a time so the Pokémon Go App cannot be running in the background. If you tried to connect with the Pokémon Go App running, close both Apps and then open the Go-tcha Evolve App again.



***Time Setting:** The Go-tcha Evolve App will automatically update the time on your Go-tcha Evolve when you connect your watch to the app. The App will also enable the Logo/Time setting screen to allow you to choose which you would like as your default screen setting.

Connecting Your Go-tcha Evolve

To connect your Go-tcha Evolve to the Pokémon App:

- 🕒 Open the Pokémon GO App
 - 🕒 Touch the Main Menu
 - 🕒 Touch Settings
 - 🕒 Touch 'Pokémon GO Plus'
 - 🕒 Press the red button on the Go-tcha Evolve to make it discoverable to the Pokémon Go App
 - 🕒 Touch your 'Pokémon GO Plus' under Available Devices list to connect
 - 🕒 Accept the Bluetooth pairing message on your smartphone to complete the connection
-

Using Go-tcha Evolve - Manually Catch Pokémon and Collect at Pokéstops

- 🕒 Go-tcha Evolve will vibrate and animate the screen to show a new/duplicate Pokémon is near.
- 🕒 Press the red Go-tcha Evolve button to catch the Pokémon.
- 🕒 Go-tcha Evolve will vibrate and animate the screen to show a successful/unsuccessful catch.

- 🕒 Go-tcha Evolve will vibrate and animate the screen to show when a Pokéstop is in range.
- 🕒 Press the red Go-tcha Evolve button to retrieve items from a Pokéstop.
- 🕒 Go-tcha Evolve will vibrate and animate the screen to show it has successfully/unsuccessfully collected the items and how many items it has collected.

See 'Go-tcha Evolve Animation Screens' on pages 2-3 of this User Guide for a complete guide to the colour screen animation alerts.

Using Your Go-tcha - Auto-catch Pokémon and Collect at Pokéstops

To turn the 'Auto-catch' function on, press the Go-tcha Evolve button until the auto-catch symbol changes as below.

Auto-catch
off



Auto-catch
on

If you have Auto Catch on:

- Go-tcha Evolve will vibrate and animate the screen to show a successful/unsuccessful catch.
- Go-tcha Evolve will vibrate and animate the screen to show it has successfully/unsuccessfully collected the items and how many items it has collected at a Pokéstop.


To turn 'Auto-catch' off, press and hold the Go-tcha button until the  appears in the box.

Go-tcha Evolve Animation Screens

The Go-tcha Evolve has many colour animations to alert you. On the next page of the manual you will find a full list of animation screens and their functions.



Auto-catch
on




Auto-catch
off



Unknown
Pokémon



Pokémon
Caught



Pokémon
Ran Away



Out of
Pokéballs



Auto-catch
Unknown
on



Auto-catch
Unknown
off



Mystery
Item



Catch
Pokémon
Unknown



Catch
Pokémon
Duplicate



Bag
Full



Auto-Pokéstop
on



Auto-Pokéstop
off



Pokéstop
In Range



Pokéstop
Out Of
Range



Pedometer



Charging



Watch Paired?
Yes



Watch Paired?
No



Vibrate Watch?
Yes



Vibrate Watch?
No



Silence Watch Alerts?
Yes



Silence Watch Alerts?
No



Update Ready




Updating



Update Complete



Switch logo to clock screen
on*



Switch logo to clock screen
off*



Flip Screen

(Your Go-tcha Evolve may or may not have this function depending on its region)



Available in...



GLOBETROTTER GREEN



DYNAMIC GREY



TRAILBLAZER BLUE



DAREDEVIL RED

Visit www.go-tcha-evolve.co.uk for updates



THIS PRODUCT IS NOT SPONSORED, ENDORSED, OR APPROVED BY THE POKÉMON COMPANY OR Niantic.

Compatible with iPhone 5s, iPhone 6, iPhone 6 Plus, iPhone 6S, iPhone 6S Plus, iPhone SE, iPhone 7, iPhone 7 Plus, iPhone 8, iPhone 8 Plus, iPhone X, iPhone XS, iPhone XS Max, iPhone XR, iPhone 11, iPhone 11 Pro and iPhone 11 Pro Max devices with iOS 10.0 or later installed. Compatible with Android devices with 2 GB RAM or more, Bluetooth Smart (Bluetooth Ver. 4.0 or higher) capability, and Android Ver. 5.0 or higher installed.

Technical Support

Before contacting Datel's customer service department, please ensure that you have read through and understood the information in this manual/guide. If you contact support, please ensure that you have information on when and where you purchased this product to hand.

Web: <http://support.codejunkies.com/>

Datel Customer Services Europe
Customers Services, Datel Ltd,
Stafford Road,
Stone,
Staffordshire,
ST15 0DG.
UNITED KINGDOM



© 2019 Datel Ltd. Go-tcha Evolve is a trademark of Datel Ltd. Pokémon is a trademark or registered Trademark of the POKÉMON COMPANY. All other trademarks are the property of their respective owners. Go-tcha Evolve for Pokémon Go is a 100% unofficial product and is NOT sponsored, endorsed or approved by NINTENDO, nor any games developer or publisher.