

Supported Devices

Retail Branding	Marketing Name	Device	Model
		FJL21	FJL21
		Luno	Luno
		T31	Panasonic T31
		hws7721g	MediaPad 7 Youth 2
3Q	OC1020A	OC1020A	OC1020A
7Eleven	IN265	IN265	IN265
A.O.I. ELECTRONICS FACTORY	A.O.I.	TR10CS1_11	TR10CS1
AMTC	AMTC MD1001 Tablet	MD1001	MD1001
AMTC	AMTC MD7008	MD7008A	MD7008
AMTC	AMTC MD7081	MD7081A	MD7081
AOC	A2272PWHT	AOC_WW	G2SMNT
AOC	AOC-A2272PW4T	AOC_WW	G3SMNTA22
AOC	AOC-A2272PW4T	AOC_WW	G3SMNTA24
AOC	AOC-A2472PW4T	G3SMNTA24	G3SMNTA24
AV	AV10	RCT6203W46	AV10
AV	AV7	RCT6773W22	AV7
AZBox	AZDroid	AZDroid	AZDroid
AZPEN	AZPEN A720	wing-inet	A720
AZPEN	AZPEN A920	wing-ibt	A920
Abocom	AboCom A08SM	A08	A08S
Acer		B1-A71	B1-A71
Acer		C10	V360
Acer		C4R	E310
Acer		C6	Acer E320
Acer		C6	Acer E320-orange
Acer		C7	E330
Acer		C8	AK330
Acer		C8	E350
Acer		C8n	E350

Supported Devices

Acer		K3	E130
Acer		T2	AT390
Acer		T603T	TD600
Acer		Z1	Z110
Acer		Z2	Z120
Acer		a110	A110
Acer		a3	Stream
Acer		a4	Acer Liquid Metal
Acer		a4	Liquid MT
Acer		a4	Liquid Metal
Acer		a5	S300
Acer		a9	S500
Acer		c4	E310
Acer		k4	E140
Acer		k5	E210
Acer		maya	G100W
Acer		maya	TPA60W
Acer		picasso	A500
Acer		picasso	A501
Acer		picasso_e	A200
Acer		picasso_e2	A210
Acer		picasso_e2	A211
Acer		picasso_m	A510
Acer		picasso_m	A511
Acer		picasso_mf	A700
Acer		picasso_mf	A701
Acer		vangogh	A100
Acer		vangogh	A101
Acer	A1-713	acer_aprilia	A1-713
Acer	A1-810	mango	A1-810

Supported Devices

Acer	A1-811	mango	A1-811
Acer	A1-830	ducati	A1-830
Acer	A100	vangogh	A100
Acer	A110	a110	A110
Acer	A211	picasso_e2	A211
Acer	A3-A10	zara	A3-A10
Acer	A3-A11	zara	A3-A11
Acer	A3-A20	acer_harley	A3-A20
Acer	A3-A20FHD	acer_harleyfhd	A3-A20FHD
Acer	A500	picasso	A500
Acer	A511	picasso_m	A511
Acer	A700	picasso_mf	A700
Acer	A700/A701	picasso_mf	A700
Acer	AK330s	C8n	AK330S
Acer	Aspire A3	aa3-600	AA3-600
Acer	B1-710	B1-710	B1-710
Acer	B1-711	B1-711	B1-711
Acer	B1-720	b1-720	b1-720
Acer	B1-721	b1-721	b1-721
Acer	B1-730	vespatn	B1-730
Acer	B1-730HD	vespa	B1-730HD
Acer	B1-A71	B1-A71	B1-A71
Acer	CloudMobile S500	a9	S500
Acer	DA220HQL	DA220HQL	DA220HQL
Acer	DA221HQL	da1	DA221HQL
Acer	DA222HQL	da2	DA222HQL
Acer	DA222HQLA	da2	DA222HQLA
Acer	DA222HQLA	da222hqla	DA222HQLA
Acer	DA223HQL	da3	DA223HQL
Acer	DA241HL	DA241HL	DA241HL

Supported Devices

Acer	DA245HQL	da245hql	DA245HQL
Acer	E380	acer_e3n	E380
Acer	G1-715	G1-715	G1-715
Acer	I110	I1	I110
Acer	Icona One 7	vespa	B1-730HD
Acer	Iconia One 7	G1-725	G1-725
Acer	Iconia One 7	vespa	B1-730HD
Acer	Iconia One 7	vespa2	B1-750
Acer	Iconia One 7	vespatn	B1-730
Acer	Iconia One 8	vespa8	A1-850
Acer	Iconia One 8	vespa8	B1-810
Acer	Iconia Tab 10	acer_harley	A3-A20
Acer	Iconia Tab 10	acer_harleyfhd	A3-A20FHD
Acer	Iconia Tab 7	acer_aprilia	A1-713
Acer	Iconia Tab 7	acer_apriliahd	A1-713HD
Acer	Iconia Tab 8	ducati2fhd	A1-840FHD
Acer	Iconia Tab 8	ducati2hd	A1-840
Acer	Iconia Tab 8	ducati2hd3g	A1-841
Acer	Iconia Tab A100 (VanGogh)	vangogh	A100
Acer	Iconia Tab A100 (VanGogh)	vangogh	A101
Acer	Iconia TalkTab 7	acer_a1_724	A1-724
Acer	Liquid	a1	Acer Liquid
Acer	Liquid	a1	Acer S100
Acer	Liquid	a1	Liquid
Acer	Liquid C1	I1	I110
Acer	Liquid E2	C11	V370
Acer	Liquid E3	acer_e3	E380
Acer	Liquid E3	acer_e3n	E380
Acer	Liquid E3S	acer_ZXR	Z130
Acer	Liquid E600	e600	E600

Supported Devices

Acer	Liquid E700	acer_e39	E39
Acer	Liquid Jade	acer_S55	S55
Acer	Liquid Jade S	acer_S56	S56
Acer	Liquid S1	a10	S510
Acer	Liquid S2	a12	S520
Acer	Liquid S3	s3	S53
Acer	Liquid X1	s3	S53
Acer	Liquid Z200	acer_z200	Z200
Acer	Liquid Z205	acer_z205	Z205
Acer	Liquid Z205	acer_z205p	Z205
Acer	Liquid Z205	acer_z205p	Z205P
Acer	Liquid Z3	ZX	Z130
Acer	Liquid Z3	acer_ZXR	Z130
Acer	Liquid Z4	acer_Z6	Z160
Acer	Liquid Z410	acer_z410	Z410
Acer	Liquid Z5	acer_ZXL	Z150
Acer	Liquid Z500	acer_Z500	Z500
Acer	M3-2200	da2	M3-2200
Acer	N3-2200	da2	N3-2200
Acer	Picasso	picasso	A500
Acer	Picasso	picasso	A501
Acer	Picasso	ventana	A500
Acer	Picasso	ventana	G100W
Acer	Picasso	ventana	TPA60W
Acer	TA2	ta2	TA272HUL
Acer	TA272HUL	ta2	TA272HUL
Acer	Tab 7	td070va1	TD070VA1
Acer	Z110	Z1	Z110
Acer	Z120	Z2	Z120
Allfine	Allfine M721	86S	M721

Supported Devices

Allfine	Allfine PC1038Q	fine10_Joy	PC1038Q
Alphascan	SAT2242 WorkTab	ADP_WW	G2SMNT
Amplify	TR10CD3	TR10CD3_1	TR10CD3
Amplify	TR10CD3	TR10CD3_2	TR10CD3
Anydata		ASP320Q_GSM	ASP320Q_ANDi
Anydata	Aquaris I8	bq_Aquaris	bq Aquaris
Anydata	Auchan MID7317CP Tablet	MID7317CP	MID7317CP
Anydata	COBY MID7055	MID7055	MID7055
Anydata	Carrefour CT710	M755ND	CT710
Anydata	Carrefour CT720 / Emdoor EM63 Tablet	EM63	EM63
Anydata	Coby MID1065	MID1065	MID1065
Anydata	Coby MID7065	MID7065	MID7065
Anydata	Coby MID8065	MID8065	MID8065
Anydata	D2-721G	D2-721G	D2-721G
Anydata	D2-727G	D2-727	D2-727
Anydata	DOPO GMS-718 Tablet / Discovery	DT088	GS-718
Anydata	DOTPAD DP3D8 / Gadmei	E8-3D	DP3D8
Anydata	Digix TAB-840_G	TAB-840_G	TAB-840_G
Anydata	Eviant MT8000	PDM829MD	MT8000
Anydata	Garmin nuvi3590	scorpio	nuvi 3590
Anydata	Garmin nuvi3595	scorpio	nuvi 3595
Anydata	Grundig GR-TB10S Tablet	GR-TB10S	GR-TB10S
Anydata	HCL ME TABLET PC U2	M712MC	U2
Anydata	HKC P771A	P771A_WIFI	P771A
Anydata	HKC P774A	P774A	P774A
Anydata	HKC P776A	P776A	P776A
Anydata	HKC P778A	HKCP778A	P778A
Anydata	HKC P886A	P886A	P886A
Anydata	HS_7DTB14	HS_7DTB14	HS_7DTB14

Supported Devices

Anydata	Insignia NS-13T001 Tablet	oracle	NS-13T001
Anydata	Jiateng JT1241	JT1241	JT1241
Anydata	Lazer MD7305 Tablet / AMTC	MD7305	MD7305
Anydata	Le Pan S	oracle	Le Pan S
Anydata	LePanII	LePanII_wifi	LePanII
Anydata	Leader I10A-LE	I10A-LE	I10A-LE
Anydata	Mach_Speed Trio G2 Tablet	Trio_Stealth_G2	G2
Anydata	Marquis Tablet	marquis_tablet	Marquis_MP977
Anydata	Matsunichi M97	oracle	M97
Anydata	Monster M7 Tablet	MONSTERM7	M7
Anydata	Nextbook NX007HD Tablet	M7000ND	NX007HD
Anydata	Nextbook NX008HD8G Tablet	M8000ND	NX008HD8G
Anydata	Nextbook NX008HI Tablet / Carrefour CT810	M909NP	NX008HI
Anydata	Nextbook Next7D12 Tablet	M757ND	Next7D12
Anydata	Nextbook Next7P12	M727MC	Next7P12
Anydata	Pendo PNDPP48GP	PNDPP48GP	PNDPP48GP
Anydata	Philips W336	Crane	Philips W336
Anydata	Philips W536	Philips_WG-MANTO-RU_B	Philips W536
Anydata	Philips W626	sangfei73_gb	W626
Anydata	Philips W632	robot	Philips W632
Anydata	Philips W832	Philips_WG-ROVER-RU_A	Philips W832
Anydata	Proscan PLT7223G	PLT7223G	PLT7223G
Anydata	Proscan PLT7777	AMLMID710K	PLT7777
Anydata	Proscan PLT8223G	PLT8223G	PLT8223G
Anydata	RCA RCT6078W2	AMLEM62	RCT6078W2
Anydata	RCA RCT6078W2	EM62	RCT6078W2
Anydata	TecToy TT-2500	AML757ND	TECTOYTT2500
Anydata	Visual Land Prestige 7D	PRO7D	PRO7D
Anydata	Vivitar Camelio Tablet	PI070H04CA	Camelio Family tablet

Supported Devices

Anydata	Vivitar XO Tablet	PI070H08XO	XO Learning tablet
Anydata	Zeki TBDG773	TBDG773	TBDG773
Anydata	ematic EGP008	EGP008	EGP008
Anydata	ematic EGP010	EGP010	EGP010
Anydata	ematic EGS004	EGS004	EGS004
Anydata	ematic EGS102	EGS102	EGS102
Anydata	essentielb ST8003/FT8001 Tablet	M805ND	Smart\TAB 8003
Anydata	iCraig CMP748	CMP748	CMP748
Anydata	iCraig CMP749	CMP749	CMP749
Apex	TM785CH	tm785ch	TM785CH
Archos		A101S	ARCHOS 101G9
Archos		A101S	Archos 101 Internet Tablet
Archos		A80S	ARCHOS 80G9
Archos		A80S	Archos 80 Internet Tablet
Archos	101 Childpad	A101CHP	ARCHOS 101 CHILDPAD
Archos	101 Cobalt	AC101CO	Archos 101 Cobalt
Archos	101 G9	A101	ARCHOS 101G9
Archos	101 Neon	A101NE	Archos 101 Neon
Archos	101 Platinum	A101PL	ARCHOS 101 PLATINUM
Archos	101 Titanium	A101TI	ARCHOS 101 Titanium
Archos	101 XS	A101XS	ARCHOS 101G10
Archos	101 Xenon	a101xe	Archos 101 Xenon
Archos	101XS2	AC101XS2	ARCHOS 101 XS 2
Archos	101b XS2	ac101bxs2	ARCHOS 101b XS2
Archos	40 Titanium	a40ti	Archos 40 Titanium
Archos	40b Titanium	a40btisr	Archos 40b Titanium Surround
Archos	40c Titanium	ac40cti	Archos 40c Titanium
Archos	45 Helium 4G	a45he	Archos 45 Helium 4G
Archos	45 Platinum	msm8625	Archos 45 Platinum
Archos	45 Titanium	a45ti	Archos 45 Titanium

Supported Devices

Archos	45c Platinum	ac45cpl	Archos 45c Platinum
Archos	50 Helium 4G	a50he	Archos 50 Helium 4G
Archos	50 Neon	a50ne	Archos 50 Neon
Archos	50 Oxygen	a50ox	Archos 50 Oxygen
Archos	50 Platinum	msm8625	Archos 50 Platinum
Archos	50 Titanium	a50ti	Archos 50 Titanium
Archos	50b Platinum	ac50bpl	Archos 50b Platinum
Archos	53 Platinum	msm8625	Archos 53 Platinum
Archos	53 Titanium	a53ti	Archos 53 Titanium
Archos	70 Cobalt	AC70CO	ARCHOS 70 Cobalt
Archos	70 Neon	ac70ne	Archos 70 Neon
Archos	70 Titanium	A70TI	ARCHOS 70 Titanium
Archos	70 Xenon	a70xe	Archos 70 Xenon
Archos	70b Titanium	A70BTI	ARCHOS 70b TITANIUM
Archos	79 Neon	a79ne	Archos 79 Neon
Archos	79 Platinum	AC79PL	ARCHOS 79 Platinum
Archos	79 Xenon	a79xe	Archos 79 Xenon
Archos	80 Carbon	AC80CA	ARCHOS 80 Carbon
Archos	80 Childpad	A80CHP	ARCHOS 80 CHILDPAD
Archos	80 Cobalt	A80CO	ARCHOS 80 COBALT
Archos	80 G9	A80	ARCHOS 80G9
Archos	80 Platinum	A80PL	ARCHOS 80 Platinum
Archos	80 Titanium	A80TI	ARCHOS 80 TITANIUM
Archos	80 XS	A80XSK	ARCHOS 80XSK
Archos	80 Xenon	A80XE	Archos 80 Xenon
Archos	80b Platinum	A80BPL	ARCHOS 80b PLATINUM
Archos	90 Neon	a90ne	Archos 90 Neon
Archos	90b Neon	ac90bne	Archos 90b Neon
Archos	97 Carbon	A97C	ARCHOS 97 CARBON
Archos	97 Cobalt	AC97CO	Archos 97 Cobalt

Supported Devices

Archos	97 Platinum	A97PL	ARCHOS 97 Platinum
Archos	97 Titanium HD	A97TIHD	ARCHOS 97 TITANIUMHD
Archos	97 Xenon	A97XE	ARCHOS 97 XENON
Archos	97b Platinum	AC97BPL	ARCHOS 97b PLATINUM
Archos	97b Titanium	A97BTI	ARCHOS 97B TITANIUM
Archos	ARCHOS 90 Copper	ac90cv	Archos 90 Copper
Archos	Archos 101 Copper	ac101cv	Archos 101 Copper
Archos	Archos 101 Xenon	ac101cxe	Archos 101c Xenon
Archos	Archos 101b Neon	ac101bne	Archos 101b Neon
Archos	Archos 101b Platinum	ac101bpl	Archos 101b Platinum
Archos	Archos 59 Titanium	ac59ti	Archos 59 Titanium
Archos	Archos 64 Xenon	ac64xe	Archos 64 Xenon
Archos	Archos 70 Copper	ac70cv	Archos 70 Copper
Archos	Archos 70b Cobalt	a70bco	Archos 70b Cobalt
Archos	Archos 70b Xenon	ac70bx	Archos 70b Xenon
Archos	Archos 70c Cobalt	ac70cco	Archos 70c Cobalt
Archos	Archos 70it 2	A70it2	ARCHOS 70it2
Archos	Archos 70it 2	A70it2	ARCHOS 70it2G8
Archos	Archos 79 Cobalt	ac79co	Archos 79 Cobalt
Archos	Archos 80 Helium	ac80he	Archos 80 Helium 4G
Archos	Archos 80b xenon	ac80bx	Archos 80b Xenon
Archos	Archos ArcBook	a101db	Archos 101 DB
Archos	Auchan QiLive 45	ql45	Qilive 45
Archos	Auchan QiLive 50	ql50	Qilive 50
Archos	Auchan Qilive 40	ql40	Qilive 40
Archos	Auchan Qilive8	QiLive8	QiLive 8
Archos	Auchan Qilive8QC	QiLive8QC	QiLive 8QC
Archos	Auchan Qilive97	QiLive97	QiLive 97
Archos	Auchan Qilive97R	QiLive97R	QiLive 97R
Archos	Auchan Selecline 10	SELECLINE10	Selecline 10

Supported Devices

Archos	Bush MyTablet 7	ac70bu	BUSH 7.0 TABLET
Archos	Bush Mytablet 2	a80bu	Bush Mytablet 2
Archos	ChefPad	A97CFP	Archos Chefpad
Archos	FamilyPad 2	A133FP2	ARCHOS FAMILYPAD 2
Archos	GamePad	A70GP	ARCHOS GAMEPAD
Archos	GamePad 2	A70GP2	ARCHOS GAMEPAD2
Archos	HomeSmartphone d800	d800	BT Home SmartPhone S II
Archos	KUNO 4+	kuno4p	KUNO 4+
Archos	Kuno	KUNO4	KUNO4
Archos	My Tablet 101	ac101bu	BUSH 10.1 TABLET
Archos	QiLive 101	aqilive101	QILIVE 101
Archos	Qilive 53	msm8625	Qilive 53
Archos	Qilive 7	qilive7	Qilive 7
Archos	Qilive 97R2	qilive97r2	Qilive 97R-2
Archos	Qilive79	Qilive79	Qilive 79
Archos	Qilive7V2	ql70v2	Qilive 70v2
Archos	Quechua Phone 5	A50RG11	Quechua Phone 5
Archos	Quechua Tablet 8	A80RG11	A80RG11
Archos	Smart Home Tablet	hometablet	Archos Smart Home Tablet
Archos	TV Connect	LUDO	ARCHOS LUDOG10
Astak	NEOS	Wenu	NEOS
Astro Queo	A712	A712	A712
AstroQueo	polaris_wifionly	polaris-wifionly	A912
Asus		EP71	ME171
Asus		TF300T	ASUS Pad TF300T
Asus		TF300T	ASUS Transformer 300
Asus		TF300T	ASUS Transformer Pad TF300T
Asus		a10	Asus A10
Asus		a10	Garmin-Asus A10
Asus		ventana	Transformer TF101

Supported Devices

Asus	ASUS ETBW11AA	ETBW11AA	ETBW11AA
Asus	ASUS ETBW11AA	TF101G	ETBW11AA
Asus	ASUS Fonepad	K00G	K00G
Asus	ASUS Fonepad 7	K01F	K01F
Asus	ASUS Fonepad 7 LTE	K00Y	K00Y
Asus	ASUS Fonepad 8	K016_2	K016
Asus	ASUS Fonepad 8	K016_3	K016
Asus	ASUS Fonepad 8	K016_4	K016
Asus	ASUS Fonepad 8(FE380CG)	K016_1	K016
Asus	ASUS Fonepad ME371MG	ME371MG	ME371MG
Asus	ASUS MeMO Pad 7 (ME572CL)	K00R	K00R
Asus	ASUS MeMO Pad FHD 10	ME302KL	ME302KL
Asus	ASUS MeMO Pad HD7 Dual SIM	ASUS-K00S	ASUS K00S
Asus	ASUS MeMO Pad Smart 10	ME301T	ME301T
Asus	ASUS MeMo Pad ME302C	ME302C	ME302C
Asus	ASUS MeMo Pad ME302CASUS MeMo Pad ME302C	ME302C	ME302C
Asus	ASUS Pad	K010	K010
Asus	ASUS Trans AiO P1801	P1801-T	ASUS Tablet P1801-T
Asus	ASUS TransBook Trio	TX201LA	TX201LA
Asus	ASUS Transformer AiO P1801	P1801-T	ASUS Tablet P1801-T
Asus	ASUS Transformer AiO P1802	P1802-T	ASUS Tablet P1802-T
Asus	ASUS Transformer Book Trio	TX201LA	TX201LA
Asus	ASUS Transformer Pad	K010	K010
Asus	ASUS Transformer Pad	K010_1	K010
Asus	ASUS Transformer Pad Infinity	TF700KL	ASUS Transformer Pad TF700KL
Asus	ASUS Transformer Pad TF300TG	TF300TG	ASUS Transformer Pad TF300TG
Asus	ASUS Transformer Pad TF300TL	TF300TL	ASUS Transformer Pad TF300TL
Asus	ASUS Transformer Pad TF502T	TF502T	ASUS Transformer Pad TF502T
Asus	ASUS Transformer Pad TF600T	TF600T	ASUS Transformer Pad TF600T

Supported Devices

Asus	ASUS ZenWatch	anthias	ASUS ZenWatch
Asus	Asus Fonepad Note 6	K00G	K00G
Asus	Asus MeMo Pad 7	K012_2	K012_2
Asus	Asus Pad TF303CL	K014	K014
Asus	Asus Transformer Pad	K018	K018
Asus	Asus Transformer Pad TF303CL	K014	K014
Asus	Cube	asus_google_cube	asus_google_cube
Asus	Eee Pad	EeePad	Transformer TF101
Asus	Eee Pad	EeePad	Transformer TF101G
Asus	Eee Pad Slider	SL101	Slider SL101
Asus	Eee Pad TF101	TF101	TF101
Asus	Eee Pad TF101	TF101	Transformer TF101
Asus	Eee Pad TF101-WiMAX	TF101-WiMAX	TF101-WiMAX
Asus	Eee Pad Transformer	TF101	Transformer TF101
Asus	Eee Pad Transformer Prime	TF201	TF201
Asus	Eee Pad Transformer Prime	TF201	Transformer Prime TF201
Asus	Eee Pad Transformer Prime	TF201	Transformer TF201
Asus	EeePad Slider SL101	SL101	Slider SL101
Asus	Fonepad 7	K00Z	K00Z
Asus	Fonepad 7	K012	K012
Asus	Fonepad 7	K01N_1	K01N
Asus	Fonepad 7	K01N_2	K01N
Asus	Fonepad 7 (FE375CG)	K019_1	K019
Asus	Fonepad 7 (FE375CXG)	K019_3	K019
Asus	Fonepad 7 (FE375CXG)	K019_4	K019
Asus	Fonepad 7(FE375CXG)	K019_2	K019
Asus	Fonepad HD7	K00E	K00E
Asus	K00F	K00F	K00F
Asus	K00L	K00L	K00L
Asus	ME173X	ME173X	ME173X

Supported Devices

Asus	ME302KL	ME302KL	ME302KL
Asus	MeMO PAD	me172v	ME172V
Asus	MeMO Pad 7	K013	K013
Asus	MeMO Pad 7	K013_1	K013
Asus	MeMO Pad 7	K017	K017
Asus	MeMO Pad 7	K01A	K01A
Asus	MeMO Pad 7 LTE	K00X	ASUS MeMO Pad 7
Asus	MeMO Pad 7 ME572C	K007	K007
Asus	MeMO Pad 8	K011	K011
Asus	MeMO Pad 8	K011_1	K011
Asus	MeMO Pad ME103K	K01E_1	K01E
Asus	MeMO Pad ME103K	K01E_2	K01E
Asus	MeMO pad 8 AST21	K015	AST21
Asus	MeMO pad 8 ME581C	K01H	K01H
Asus	MeMO pad 8 ME581CL	K015	K015
Asus	MeMo Pad HD 7	K00U	K00U
Asus	Memo Pad 7	K01U_1	K01U
Asus	Memo Pad 7	K01U_2	K01U
Asus	Memo Pad HD7 Dual SIM	ASUS-K00S	ASUS K00S
Asus	Nexus 7 (2012)	grouper	Nexus 7
Asus	Nexus 7 (2012)	tilapia	Nexus 7
Asus	Nexus 7 (2013)	deb	Nexus 7
Asus	Nexus 7 (2013)	flo	Nexus 7
Asus	Nexus Player	fugu	Nexus Player
Asus	Nuvifone	a50	Garmin-Asus A50
Asus	PadFone	PadFone	PadFone
Asus	PadFone 2	A68	PadFone 2
Asus	PadFone E	ASUS-T008	PadFone T008
Asus	PadFone Infinity	A80	PadFone Infinity
Asus	PadFone Infinity	ASUS-A80	PadFone Infinity

Supported Devices

Asus	PadFone Infinity Lite	ASUS-A80	PadFone Infinity
Asus	PadFone Mini	ASUS-T00C	PadFone T00C
Asus	PadFone S	ASUS_T00N	ASUS_T00N
Asus	PadFone T004	ASUS-A86	PadFone T004
Asus	PadFone Xmini	ASUS-T00S	ASUS PadFone X mini
Asus	PadFone mini	ASUS-T00C	PadFone T00C
Asus	PadFone mini	ASUS_T00E	ASUS_T00E
Asus	PadFone-T004	ASUS-A86	PadFone T004
Asus	Padfone S	ASUS_T00N	ASUS_T00N
Asus	Padfone X	ASUS-T00D	ASUS PadFone X
Asus	Padfone mini	ASUS-T00S	ASUS_T00T
Asus	T101TA	T10xTA	T10xTA
Asus	TF700T	TF700T	ASUS Pad TF700T
Asus	TF700T	TF700T	ASUS Transformer Pad TF700T
Asus	TX201LAF	TX201LAF	TX201LAF
Asus	Trans Pad Infinity	K00C	K00C
Asus	Transformer 10(TF103CE)	K010E	K010E
Asus	Transformer Pad	K00C	K00C
Asus	Transformer Pad	K010_3	K010
Asus	Transformer Pad Infinity	K00C	K00C
Asus	Transformer Pad TF303K	K01B	K01B
Asus	Transformer TF101G	TF101G	Transformer TF101G
Asus	ZenFone 4	ASUS_T00I	ASUS_T00I
Asus	ZenFone 4	ASUS_T00Q	ASUS_T00Q
Asus	ZenFone 5	ASUS_T00F	ASUS_T00F
Asus	ZenFone 5	ASUS_T00F1	ASUS_T00F
Asus	ZenFone 5	ASUS_T00J	ASUS_T00J
Asus	ZenFone 5	ASUS_T00J1	ASUS_T00J
Asus	ZenFone 5	ASUS_T00K	ASUS_T00K
Asus	ZenFone 5 LTE	ASUS_T00P	ASUS_T00P

Supported Devices

Asus	ZenFone 6	ASUS_T00G	ASUS_T00G
Asus	ZenFone 6	ASUS_Z002	ASUS_Z002
Asus	ZenFone C	ASUS_Z007	ASUS_Z007
AtGames-zooti	ZOOTI PAD ZT-701	ZT-701	ZT-701
Auchan	Selecline X35T	X35T	X35T
Audiovox	Audiovox T752 Tablet	AD7L	T752
Audiovox	Audiovox T852 Tablet	MID30801	T852
Avoca	STB7012	STB7012	STB7012
Avoca	STB7013	AVOCA	STB7013
Avoca	STB8098	STB8098	STB8098
Avoca	STB9097	STB9097	STB9097
BYD	DynaVox T10	T10	T10
BYD	FarEastone Smart 502	Smart502	Smart 502
BYD	INHON G3	G3	G3
BYD	K-Touch E815	E815	E815
BYD	M601	M601	M601
BYD	Moi E996+	E996plus	moii E996+
BYD	PT452E	PT452E	Digma Linx 4.5 PT452E
BYD	Prestigio PAP5430	PAP5430	PAP5430
BYD	SI4301	SI4301	SI4301
BYD	SOLO S450	S450	S450
BYD	SP355AWG	msm7627a_sku3	SP355AWG
BYD	Smart 401	tianyu72_wet_jb3	Smart 401
BYD	Smart 402	hawaii_garnet_c_w68tk	Smart402
BYD	Solo S350	S350	S350
BYD	WISKY W032I	W032I	W032I
BYD	X910	X910	XOLO X910
BYD	Zippers	Zippers	Vexia Zippers
Barnes and Noble	NOOK\\® HD	hummingbird	BNTV400
Barnes and Noble	NOOK\\® HD+	ovation	BNTV600

Supported Devices

Beeline	Beeline Tab	Beeline_Tab	Beeline Tab
Beeline	Beeline Tab 2	Tab_2	Tab_2
BenQ	A3	A3	A3
BenQ	Agora 4G	Agora_4G	Agora 4G
BenQ	BenQ A3	A3	A3
BenQ	BenQ A3c	BenQ_A3c	BenQ A3c
BenQ	BenQ B50	B50	B50
BenQ	BenQ B502	B502	B502
BenQ	BenQ F3	F3	F3
BenQ	BenQ F4	benq_a3s	BenQ A3s
BenQ	BenQ F5	BENQ_F5	BenQ F5
BenQ	BenQ F5	F5	BenQ F5
BenQ	BenQ F5_06	F5	F5_06
BenQ	BenQ F5_13	F5	F5_13
BenQ	BenQ F5_15	F5	F5_15
BenQ	BenQ F5_16	F5	F5_16
BenQ	BenQ T3_08	T3_17A	BenQ T3
BenQ	JM-250	JM-250	JM-250
BenQ	Kogan 4G+	Agora_4G_PLUS	Agora 4G+
BenQ	PT2200	PT2200	PT2200
BenQ	T3	T3	BenQ T3
Best Buy	MG103	K010	K010
Bigben	BB8252	Bigben-TAB	BB8252
Bigben	GAMETAB-ONE	GAMETAB-ONE	GAMETAB-ONE
Binatone	SMART64	SMART64	SMART64
Binatone	Smart 63	SMART63	SMART63
Binatone	Smart 66	SMART66	SMART66
Bitmore	Bitmore Tab870	Tab870	Tab870
Bitmore	GTAB700	GTAB700	NID_7010
Bitmore	GTAB900	GTAB900	S952

Supported Devices

Bitmore	LUXYA MID704DC Tablet / Bitmore Tab770	MY7317P	Tab770
Blaupunkt	Endeavour101	Blaupunkt	Endeavour101
Bluedot	BLUEDOT BNT-700K	BNT-700K	BNT-700K
Booken	Cybook Tablet	cybtt10_bk	Cybook-Tablet
Borqs	Falcon	falcon	falcon
Bouygues Telecom	Bouygues Telecom Bs 451	Bs_451	Bs 451
Brightstar	M8046IU	M8047IU	M8047IU
Bunbungame	MiSS	MiSS	MiSS
Bungbungame	KALOS	FG6Q_N	KALOS
Bush	MyTablet 79	ac79bu	BUSH 7.85 TABLET
C&M	Smart TV II	stb_catv_cnm	SX930C-CC
CAT	CAT B15	TOUGH	B15
CAT	CAT B15Q	B15Q	B15Q
CHN TELECOM	CHN-UCAN MJ	lefhd	CHN-UCAN MJ
CJ HelloVision	Hello TV Smart	SX930C_CJ	SX930C_CJ
CMCC	M811	m811	M811
CMCC	M811	m811hk	M811
COMIO	AD7003	AD7003	AD7003
Camelus	Camelus L10	TR-10HBT	L10
Camelus	Camelus L7	TR-7U	L7
Candor	PHS-601	phs601	PHS-601
Carrefour	CT1000	Carrefour	CT1000
Carrefour	Carrefour CT1020W	M1010FP	CT1020W
Carrefour	Carrefour CT820	M878LP	CT820
Casper	TA80CA2	TA80CA2_1	TA80CA2
Casper	VIA_T41	VIA_T41	VIA_T41
Cat	B15Q	CatB15Q	B15Q
Cat	S50	CatS50	S50
Cellon	A27	C8680	A27

Supported Devices

Cellon	A5801	C8680	A5801
Cellon	Alpha Ice	M8047	Alpha Ice
Cellon	C3668	C3668	C3668
Cellon	CI	Dream-C1	CI
Cellon	CJ-1984	C8690	C8690
Cellon	CJ-1984	C8690	CJ-1984
Cellon	CJ-1984	C8690	ELITE 4.7 HD
Cellon	EI	Dream-E1	EI
Cellon	EIII	Dream-E3	EIII
Cellon	EK-8680	C8680	EK-8680
Cellon	Explosion	C8690	Explosion
Cellon	HW-W900	C8690	HW-W900
Cellon	HWW820	C8680	HW-W820
Cellon	Houston	C8680	Houston
Cellon	ICON	ICON	ICON
Cellon	IQ 1.1	IQ1-1	i-mobile IQ1-1
Cellon	Linx PS474S	C8690	Linx PS474S
Cellon	MTC SMART Run	SMART_Run	MTC SMART Run
Cellon	Mach	C8680	Mach
Cellon	Newman N2	C8690	Newman N2
Cellon	Q	M8047XT	Q
Cellon	S21	S21	Q-Smart S21
Cellon	SI	Dream-S1	SI
Cellon	SM55	C8660	C8660
Cellon	SM55	C8660	SM55
Cellon	Starmobile KNIGHT	KNIGHT	Starmobile KNIGHT
Cellon	VEON_C8680	C8680	VEON_C8680
Cellon	i-STYLE7	c8669SA	i-mobile i-STYLE 7
Cellon	i-STYLE7A	c8669SA	i-mobile i-STYLE 7A
Cellon	i-mobile IQ X	M8047SA	i-mobile IQ X

Supported Devices

Cellon	i-mobile IQ X	M8047SA	i-mobile IQ XA
Cellon	i-mobile IQ X2A	M8050SA	i-mobile IQ X2
Cellon	i-mobile IQ X2A	M8050SA	i-mobile IQ X2A
Cellon	iris pro 30	pro30	iris pro 30
Cellon	starTIM1	starTIM1	starTIM1
Cherry Mobile	Cherry W900 LTE	al7	W900 LTE
Cisco	Cisco CP-DX650	CP-DX650	CP-DX650
Cisco	Cisco Desktop Collaboration Experience DX70	CP-DX70	CP-DX70
Cisco	Cisco Desktop Collaboration Experience DX80	CP-DX80	CP-DX80
Clementoni	Clempad 4.4 Basic Special	Clempad2_special	Clempad2_special
Clementoni	Clempad 4.4 Plus	Clempad2_plus	Clempad2_plus
Clementoni	Clempad 4.4 XL	Clempad2_XL	Clempad2_XL
Clementoni	My first Clempad 4.4 Basic Special	MFC2_Special	MFC2_Special
Clementoni	My first Clempad 4.4 Plus	MFC2_Plus	MFC2_Plus
ClickN Kids	ClickN Kids	g04e	CK07T
Compal		CA22	COSMO DUO
Compal		CAP5	A600
Compal		CAP6	A600
Compal		CAP7	A300
Compal		CAP7	A8
Compal		CAP7	W12
Compal		cap2	Andy
Compal		penguin	AX 8.6
Compal	TANK 4.5	ka09	TANK 4.5
Condor	C1+	C1Plus	C1+
Condor	C_5	u970_5	C-6
Condor	HS-U939	u939e_6	HS-U939
Coolpad		7019_msm7627a	Coolpad 7019

Supported Devices

Coolpad		7560U	Nivo
Coolpad		801E	801E
Coolpad		8710	8710
Coolpad		9960	YL-Coolpad 9960
Coolpad		CP5832	5832
Coolpad		CP5880	5880
Coolpad		CP7728	Coolpad7728
Coolpad		CP8870	8870
Coolpad		CP9130	N930
Coolpad		Coolpad7290	Coolpad 7290
Coolpad		Coolpad9080W	Coolpad 9080W
Coolpad		dkb	8150
Coolpad		dkb	8180
Coolpad		dkb	8810
Coolpad		msm7627_5820	Coolpad 5820
Coolpad		msm7627_SP150	MTS-SP150
Coolpad		msm7627_surf	5860
Coolpad		msm7627_surf	7260
Coolpad		msm7627_w706	Coolpad W706+
Coolpad		msm7627_w706T	Coolpad W706+
Coolpad		msm7627_w708	Coolpad W708
Coolpad		msm7627a_5860S	5860S
Coolpad		msm7627a_5870	5870
Coolpad		msm7627a_7230	7230
Coolpad		msm7627a_7266	7266
Coolpad		msm7627a_9120	9120
Coolpad		msm7627a_PAP4000	PAP4000
Coolpad		msm7627a_cp5910	5910
Coolpad		msm7627a_ea58	Coolpad 5010
Coolpad		msm7627a_ea92	Coolpad 5210

Supported Devices

Coolpad		msm7627a_sku3	5110
Coolpad		msm7627a_sku3	5860A
Coolpad		msm7627a_sku3	7260A
Coolpad		msm8660_9900	9900
Coolpad		msm8660_CP8950	8950
Coolpad	5860E	CP5860E	5860E
Coolpad	801EM	801EM	801EM
Coolpad	8970L	8970L	Coolpad 8970L
Coolpad	Bs501	cp8870u	Bs 501
Coolpad	CM001	CoolpadCM001	Coolpad CM001
Coolpad	CP5108	msm7627a_a8_5108_new	Coolpad 5108
Coolpad	CP5210A	msm7627a_d7_5210a	Coolpad 5210A
Coolpad	CP5310	cp5310	Coolpad 5310
Coolpad	CP5660S	5560S	5560S
Coolpad	CP5952	Coolpad5952	Coolpad 5952
Coolpad	CP8021	Coolpad8021	Coolpad 8021
Coolpad	CP8089	CP8089	Coolpad 8089
Coolpad	CP8089Q	CP8089Q	Coolpad 8089Q
Coolpad	CP8295M	8295M	Coolpad8295M
Coolpad	CP8735	8735	Coolpad 8735
Coolpad	CP8750	8750	Coolpad8750
Coolpad	CP9190L	Coolpad9190L	Coolpad 9190L
Coolpad	CP9250L	Coolpad9250L	Coolpad 9250L
Coolpad	CP9970	9970	Coolpad 9970
Coolpad	CPA520	CoolpadA520	Coolpad A520
Coolpad	CPT1	CoolpadT1	Coolpad T1
Coolpad	Coolmini	Coolmini	Coolmini
Coolpad	Coolpad 3700A	3700A	CP3700A
Coolpad	Coolpad 5109	Coolpad5109	Coolpad 5109
Coolpad	Coolpad 5200	Coolpad5200	Coolpad 5200

Supported Devices

Coolpad	Coolpad 5216D	5216D	Coolpad 5216D
Coolpad	Coolpad 5217	msm8610	Coolpad 5217
Coolpad	Coolpad 5218S	msm8x25q_a5y_5218s	Coolpad 5218S
Coolpad	Coolpad 5219	5219	Coolpad 5219
Coolpad	Coolpad 5219_C00	5219_C00	Coolpad 5219_C00
Coolpad	Coolpad 5891	Coolpad5891	Coolpad 5891
Coolpad	Coolpad 5891S	Coolpad5891S	Coolpad 5891S
Coolpad	Coolpad 5951	Coolpad5951	Coolpad 5951
Coolpad	Coolpad 7061	CP7061	Coolpad 7061
Coolpad	Coolpad 7230S	Coolpad7230S	Coolpad 7230S
Coolpad	Coolpad 7232	CP7232	Coolpad 7232
Coolpad	Coolpad 7251	Coolpad7251	Coolpad 7251
Coolpad	Coolpad 7270	Coolpad7270	Coolpad 7270
Coolpad	Coolpad 7270I	7270I	Idea ULTRA Pro
Coolpad	Coolpad 7275	CP7275	Coolpad 7275
Coolpad	Coolpad 7295A	Coolpad7295A	Coolpad 7295+
Coolpad	Coolpad 7295A	Coolpad7295A	Coolpad 7295A
Coolpad	Coolpad 7296	Coolpad7296	Coolpad 7296
Coolpad	Coolpad 7620L	Coolpad7620L	Coolpad 7620L
Coolpad	Coolpad 8079	Coolpad8079	Coolpad 8079
Coolpad	Coolpad 8122	Coolpad8122	Coolpad 8122
Coolpad	Coolpad 8198W	Coolpad8198W	Coolpad 8198W
Coolpad	Coolpad 8297D	Coolpad8297D	Coolpad 8297D
Coolpad	Coolpad 8670	Coolpad8670	Coolpad 8670
Coolpad	Coolpad 8702	Coolpad8702	Coolpad 8702
Coolpad	Coolpad 8729	Coolpad8729	Coolpad 8729
Coolpad	Coolpad 8730L	Coolpad8730L	Coolpad 8730L
Coolpad	Coolpad 8732	Coolpad8732	Coolpad 8732
Coolpad	Coolpad 8736	8736	Coolpad 8736
Coolpad	Coolpad 8971	8971	Coolpad 8971

Supported Devices

Coolpad	Coolpad 9150W	Coolpad9150W	Coolpad 9150W
Coolpad	Coolpad 9190_T00	Coolpad9190_T00	Coolpad 9190_T00
Coolpad	Coolpad 9970L	9970L	Coolpad 9970L
Coolpad	Coolpad 9976A	Coolpad9976A	Coolpad 9976A
Coolpad	Coolpad 9976T	Coolpad9976T	Coolpad 9976T
Coolpad	Coolpad Flo	7560T	Coolpad Flo
Coolpad	Coolpad5218D	msm7627a_a5y_5218d	Coolpad_5218D
Coolpad	Coolpad5315	msm8610_s10_cp5315	Coolpad 5315
Coolpad	Coolpad5872	Coolpad5872	Coolpad 5872
Coolpad	Coolpad5879T	Coolpad5879T	Coolpad 5879T
Coolpad	Coolpad5891Q	Coolpad5891Q	Coolpad 5891Q
Coolpad	Coolpad5892	Coolpad5892	Coolpad 5892
Coolpad	Coolpad5950	Coolpad5950	Coolpad 5950
Coolpad	Coolpad5950T	Coolpad5950T	Coolpad 5950T
Coolpad	Coolpad7270_W00	Coolpad7270_W00	Coolpad 7270_W00
Coolpad	Coolpad7295C	Coolpad7295C	Coolpad 7295C
Coolpad	Coolpad7295C_C00	Coolpad7295C_C00	Coolpad 7295C_C00
Coolpad	Coolpad7295I	Coolpad7295I	Spice Mi-515
Coolpad	Coolpad7295T	Coolpad7295T	Coolpad 7295T
Coolpad	Coolpad7296S	Coolpad7296S	Coolpad 7296S
Coolpad	Coolpad7298A	Coolpad7298A	Coolpad 7298A
Coolpad	Coolpad7298D	Coolpad7298D	Coolpad 7298D
Coolpad	Coolpad7320	Coolpad7320	Coolpad 7320
Coolpad	Coolpad7920	7920	Coolpad7920
Coolpad	Coolpad801ES	801ES	801ES
Coolpad	Coolpad8085Q	Coolpad8085Q	Coolpad8085Q
Coolpad	Coolpad8198T	8198T	Coolpad8198T
Coolpad	Coolpad8297	Coolpad8297	Coolpad 8297
Coolpad	Coolpad8297W	Coolpad8297W	Coolpad 8297W
Coolpad	Coolpad8705	Coolpad8705	Coolpad 8705

Supported Devices

Coolpad	Coolpad8720L	Coolpad8720L	Coolpad 8720L
Coolpad	Coolpad8908	8908	Coolpad8908
Coolpad	Forward_EVOLVE	Forward_EVOLVE	Forward_EVOLVE
Coolpad	Idea ULTRA	Coolpad7295S	Idea ULTRA
Coolpad	Karbons Titanium S5 Plus	Karbons	Karbons Titanium S5 Plus
Coolpad	MEDION P5001	MEDION	MEDION P5001
Coolpad	MEDION P5001	P5001	MEDION P5001
Coolpad	Mtag 353	msm7627a_ea92_mts	Mtag 353
Coolpad	STARADDICT III	cp8861u	STARADDICT III
Coolpad	Spice Mi-496	Coolpad7268I	Spice Mi-496
Coolpad	Vodafone Smart 4G	cp8860u	Vodafone Smart 4G
Coolpad	VodafoneSmart4	VodafoneSmart4	Vodafone Smart 4
Coolpad	VodafoneSmart4turbo	VodafoneSmart4turbo	Vodafone Smart 4 turbo
Coolpad	cp7236	msm8610_w7_cp7236	Coolpad 7236
Crosscall	ODYSSEY	ODYSSEY3G	ODYSSEY
DEA Factory	KTAB	KTAB	KTAB
DIFRNCE	DIT702201	DIT702201	NID_7010
Danew	DANEW Dslide971DC	Dslide971DC	Dslide971DC
Danew	DSlide 710	Dslide710	Dslide710
Danew	Danew DSlide 750	Danew_DSslide750	DSlide750
Danew	Danew Dslide 1013	DSlide1013	DSlide 1013
Dell		Dell_Grappa	Dell Aero
Dell		Dell_Grappa	Mini_3iG
Dell		Streak10Pro	Dell Streak 10 Pro
Dell		qsd8250_surf	Dell Mini 5
Dell		qsd8250_surf	Dell Streak
Dell		streak7	Dell Streak 7
Dell		streak7	streak7
Dell		streakpro	101DL
Dell		streakpro	Dell V04B

Supported Devices

Dell		streakpro	GS01
Dell		venue	BizSmartPhone
Dell		venue	Dell Venue
Dell	Cloud Connect	capri_wyse	CS-1A13
Dell	Streak	streak	001DL
Dell	Streak	streak	Dell M01M
Dell	Streak	streak	Dell Streak
Dell	Venue 7	LW	Venue 7 3741
Dell	Venue 7	Venue7	Venue 7 3740
Dell	Venue 7	Venue7	Venue7 3740
Dell	Venue 7	Venue7	Venue7 3740 LTE
Dell	Venue 7	thunderbird	Venue 7 3730
Dell	Venue 7	thunderbird	Venue 7 HSPA+
Dell	Venue 8	BB	Venue 8 7840
Dell	Venue 8	Venue8	Venue 8 3840
Dell	Venue 8	Venue8	Venue8 3840
Dell	Venue 8	Venue8	Venue8 3840 LTE
Dell	Venue 8	yellowtail	Venue 8 3830
Dell	Venue 8	yellowtail	Venue 8 HSPA+
DigiLand	DL1010Q	DL1010Q	DL1010Q
DigiLand	DL700D	DL700D	DL700D
DigiLand	DL701Q	DL701Q	DL701Q
DigiLand	DL785D	DL785D	PLT7803G
Digilite	TA70CA1	TA70CA1	TA70CA1
Digilite	TA70CA2	TA70CA2_1	TA70CA2
Digilite	TA70CA3	TA70CA3_1	TA70CA3
Digilite	TR10CD1	TR10CD1_5	TR10CD1
Digilite	TR10CS1	TR10CS1_3	TR10CS1
Diginnos	Diginnos DG-D07S/GP	DG-D07SGP	DG-D07SGP
Digital2	Digital2 Deluxe	nuclear-D2_Deluxe	Digital2-Deluxe

Supported Devices

Digital2	Digital2 Platinum	D2-963G	Digital2 Platinum
Digital2	Digital2 Plus	Digital2Plus	Digital2 Plus
DigitalStream	DigitalStream DWA1015D Tablet	DWA1015D	DWA1015D
Digitron	i-Buddie	TR10CD1_10	TR10CD1
Digitron	i_Buddie	TR10CS1_12	TR10CS1
Digix	TAB-740_G	TAB-740_G	TAB-740_G
Ditigron	i-Buddie	TR10CD1_11	TR10CD1
Dopo	DOPO EM63 Tablet	EM63	EM63
Dopo	DOPO GS-918	GS_918	GS-918
Dopo	DP7856K	DP7856K	DP7856K
Dopo	DPA23D	polaris-wifionly	DPA23D
Dopo	DPM1081	RCT6203W46	DPM1081
Dopo	DPM7827	RCT6773W22	DPM7827
Doro	Doro Liberto 820 Mini	820Mini	Doro Liberto 820 Mini
Doro	Liberto 810	Liberto810	Doro Liberto 810
Doro	Liberto 810	Liberto810	Doro Liberto 810-orange
Doro	Liberto 810	Liberto810_S12	Doro Liberto 810
Doro	Liberto 820	Liberto820	Doro Liberto 820
Doro	Liberto 820 Mini	820Mini	Doro Liberto 820 Mini
Dreamax	DMX-ST7A	DMX-ST7A	DMX-ST7A
EBN	NEBUPOS3	UY3A	NEBUPOS3
ECS	RealPad MA7BX2	RealPad_MA7BX2_1	RealPad MA7BX2
ECS	TC69CA2	TC69CA2_1	TC69CA2
ECS	TR10CS1	TR10CS1_8	TR10CS1
ECS	TR10RS1	TR10RS1_2	TR10RS1
EG936D	Hisense	EG936D	HS-EG936D
EMTEC	EMTEC F400	f400	f400
ENTITY	GDENTMY7317	GDENTMY7317	GDENTMY7317
ENVIZEN DIGITAL	ENVIZEN DIGITAL V917G	GK-MID9022	V917G
ENVIZEN DIGITAL	V100MD	V100MD	V100MD

Supported Devices

Edcon	Platiumm vp.1	VerssedVP1	Verssed VP1
Edcon	Platiumm vp.2	VerssedVP2	Verssed VP2
Ematic	EGD078	EGD078	EGD078
Ematic	EGD170	EGD170	Ematic EGD170
Ematic	EGD172	EGD172	EGD172
Ematic	EGD213	EGD213	EGD213
Ematic	EGQ337	EGQ337	EGQ337
Ematic	EGQ780	EGQ780	EGQ780
Ematic	EMATICEGS109	EGS109	EGS109
Ematic	Ematic EGD103	EGD103	EGD103
Ematic	Ematic EGQ307	EGQ307	EGQ307
Ematic	Ematic EGQ327M	EGQ327M	EGQ327M
Ematic	Ematic EGS017	EGS017	EGS017
Ematic	Ematic ETH102	ETH102	ETH102
Ematic	FunTab 2	FunTab2	FunTab2
Ematic	Sprout Channel Cubby	Cubby	SproutChannelCubby
Emdoor	EM_i8180	em_i8180	em_i8180
Emerson	Emerson EM749/748	EM749_748	EM749_748
Enspert		E-TAB	E-TAB
Enspert		ESP_E301	ESP_E301BK
Enspert		ESP_E301	ESP_E301V
Enspert		ESP_E301	ESP_E301VD
Enspert		ESP_E301	ESP_E301VE
Enspert		e201	ESP_E201V7
Enspert		e201	enspert_e201
Enspert		illuminus	ITP-S100WD
Enspert		s8073	Miracle
Enspert	CINK KING	s9081	CINK KING
Enspert	CINK KING	s9081	Cynus T2
Enspert	CINK KING	s9081	IMD501

Supported Devices

Enspert	CINK KING	s9081	freebit PandaA
Enspert	CINK SLIM	s8073	CINK SLIM
Enspert	CINK SLIM	s8073	Fly_IQ442
Enspert	CINK SLIM	s8073	WIKO-CINK SLIM
Enspert	Carrefour CT1010	Carrefour	CT1010
Enspert	Cynus F3	s7511	Cynus F3
Enspert	DARKSIDE	s9301	Cinema
Enspert	DARKSIDE	s9301	DARKSIDE
Enspert	Lazer X40E	X40E	X40E
Enspert	MG	MGA930	A930
Enspert	STAIRWAY	s9111	STAIRWAY
Enspert	WIKO CINK PEAX	s9091	CINK PEAX
Enspert	WIKO CINK PEAX	s9091	EverClassic
Enspert	WIKO CINK+	s7505	CINKPLUS
Enspert	WIKO SUBLIM	s9070	SUBLIM
Enspert	Wiko CINK FIVE	s9201	CINK FIVE
Enspert	Wiko CINK FIVE	s9201	Cynus T5
Enspert	orion	orion	NGM Orion
Enspert	vanitysmart	vanitysmart	NGM Vanity Smart
EssentielB	EssentielB Smart\TAB 7800	fiber-785q6	Smart\Tab_7800
EssentielB	EssentielB Smart\TAB 9001	fiber-smart	Smart\TAB 9001
Etuline	ETL-S4521	u939e_2	ETL-S4521
Etuline	ETL-S5042	u970_4	ETL-S5042
EveryPad2	Lenovo	A3500F	EveryPad2
Explay	4Game	4Game	4Game
Explay	ATV	ATV	ATV
Explay	Air	Air	Air
Explay	Atom	Atom	Atom
Explay	Bit	Bit	Bit
Explay	Cosmic	Cosmic	Cosmic

Supported Devices

Explay	Craft	Craft	Craft
Explay	Easy	Easy	Easy
Explay	Favorite	Favorite	Favorite
Explay	Fog	Fog	Fog
Explay	Fresh	Fresh	Fresh
Explay	Gravity	T4728	Gravity
Explay	Hit	Hit	Hit
Explay	Indigo	Indigo	Indigo
Explay	Joy TV	Joy_TV	Joy_TV
Explay	Light	Light	Light
Explay	M1 Plus	Fog	M1_Plus
Explay	Onyx	Onyx	Onyx
Explay	Phantom	Phantom	Phantom
Explay	Prime	Prime	Prime
Explay	Pulsar	Pulsar	Pulsar
Explay	Rio Play	RioPlay	RioPlay
Explay	Shine	T5246	Shine
Explay	Tornado	Tornado	Tornado
Explay	Tornado 3G	Tornado3G	Tornado3G
Explay	Vega	Vega	Vega
FBC	M24IS810	MX24	TDA02
FBC	M24IS820	fst01ms	M24IS820
FaceVSION	FaceVSION OC1020A	OC1020A	FV-FG6
FarEasTone	Smart 403	msm8226	Smart 403
FarEasTone	Smart 505	Smart505	Smart 505
FarEasTone	Smart501	Smart501	Smart501
FarEasTone	Smart503	MC2	Smart503
Fly	Fly ERA Nano 7	Fly_IQ4407	IQ4407
Fly	Fly EVO Chic 1	IQ4405_Quad	Fly IQ4405_Quad
Fly	Fly Ego Art 2	Fly_Ego_Art_2	Fly Ego Art 2

Supported Devices

Fly	Fly Era Energy 1	IQ4502_Quad	IQ4502 Quad
Fly	Fly Era Life 2	IQ456	IQ456
Fly	Fly Era Nano 6	Era_Nano_6	IQ4406
Fly	Fly Era Nano 8	IQ4400	IQ4400
Fly	Fly Era Nano 9	IQ436i	IQ436i
Fly	Fly Era Style 3	IQ4415_Quad	IQ4415 Quad
Fly	Fly Evo Chic 2	IQ459	IQ459
Fly	Fly Evo Chic 2	IQ459	IQ459 Quad
Fly	Fly Evo Energy4	IQ4501	Evo Energy4
Fly	Fly Evo Tech 3	IQ4414_Quad	IQ4414 Quad
Fly	Fly IQ434	IQ434	IQ434
Fly	Fly IQ4490i	IQ4490i	IQ4490i
Fly	Fly IQ4503	IQ4503	FLY IQ4503
Fly	Fly IQ4503 Quad	IQ4503_Quad	IQ4503 Quad
Fly	Fly IQ4504 Quad	IQ4504_Quad	IQ4504 Quad
Fly	Fly IQ4505	IQ4505	Fly IQ4505
Fly	Fly IQ4505 Quad	IQ4505_Quad	IQ4505 Quad
Fly	Fly IQ4512 Quad	IQ4512_Quad	IQ4512 Quad
Fly	Fly IQ4513	IQ4513	IQ4513
Fly	Fly IQ4513 Octa	IQ4513_Octa	IQ4513 Octa
Fly	Fly IQ4514 Quad	IQ4514_Quad	Fly IQ4514
Fly	Fly IQ4514 Quad	IQ4514_Quad	Fly IQ4514 AF
Fly	Fly IQ4514 Quad	IQ4514_Quad	IQ4514 Quad
Fly	Fly IQ4515 Quad	IQ4515_Quad	IQ4515 Quad
Fly	Fly IQ4516 Octa	IQ4516_Octa	IQ4516
Fly	Fly IQ4516 Octa	IQ4516_Octa	IQ4516 Octa
Fly	Fly IQ458 Quad Evo Tech 2	IQ458	IQ458 Quad
Fly	Fly IQ4602	Fly_IQ4602	Fly IQ4602
Fly	Fly IQ4602	IQ4602_Quad	IQ4602 Quad
Fly	Fly Iris	FLY_IQ4400	FLY_IQ4400_AF

Supported Devices

Fly	Fly Phoenix 2	IQ4410i	Phoenix 2
Fly	Flylife Connect 10.1	Flylife_Connect_101_3G_2	Flylife Connect 10.1 3G 2
Fly	Flylife Connect 7 3G 2	Flylife7	Flylife Connect 7 3G 2
Fly	Flylife Connect 7.85 3G 2	Flylife	Flylife Connect 7.85 3G 2
Fly	IQ4401	IQ4401	IQ4401
Fly	IQ4409 Quad	IQ4409_Quad	IQ4409 Quad
Fly	IQ4413 Quad	IQ4413_Quad	IQ4413_Quad
Fly	IQ4415	IQ4415	IQ4415
Fly	IQ4416	IQ4416	IQ4416
Fly	IQ4417 Quad	IQ4417_Quad	IQ4417 Quad
Fly	IQ4418	IQ4418	Fly IQ4418 AF
Fly	IQ4418	IQ4418	IQ4418
Fly	IQ4601	IQ4601	IQ4601
Fly	Tornado One	IQ4511_Octa	FLY IQ4511
Fly	Tornado One	IQ4511_Octa	IQ4511 Octa
Fly	Tornado One	IQ4511_Octa	IQ4511 TR
Foxconn		A1	MUCHTEL A1
Foxconn		A800	WellcoM-A800
Foxconn		Boston	Boston
Foxconn		Boston	Orange_Boston
Foxconn		FE6	FE6
Foxconn		G1305	GSmart-G1305
Foxconn		K2	E120
Foxconn		K3	E130
Foxconn		SF4Y6	SF4Y6
Foxconn		a1	Rstream-A1
Foxconn		a800	WellcoM-A800
Foxconn		a89	WellcoM-A89
Foxconn		a99	WellcoM-A99
Foxconn		axioo	PICOpad-QGN

Supported Devices

Foxconn		fb0	FIH-FB0
Foxconn		fm600	Camangi-FM600
Foxconn		hd710	Commtiva-HD710
Foxconn		m500	MUSN-M500
Foxconn		magnumhd	cherry-MagnumHD
Foxconn		mangrove7	Camangi-Mangrove7
Foxconn		mi410	CSL-MI410
Foxconn		msm7627_surf	EV-S110
Foxconn		msm7627_surf	FIH-F0X
Foxconn		msm7627_surf	FIH-FM6
Foxconn		msm7627_surf	KT-F100
Foxconn		msm7627_surf	KT-S110
Foxconn		muchtela2	MUCHTEL-A2
Foxconn		musn-t800	Cherry-MUSN-T800
Foxconn		superion	cherry mobile-SUPERION
Foxconn		t800	MUSN-T800
Foxconn		vigo410	Axioo-VIGO410
Foxconn		vt100	V-T100
Foxconn	A5	A5	A5
Foxconn	CSL Spice MI700	mi700	CSL_Spice_MI700
Foxconn	CSL Spice MI700	mi700	Spice_MI700
Foxconn	Casper_VIA_A6108	SI1	Casper_VIA_A6108
Foxconn	Commtiva N700	n700	Commtiva-N700
Foxconn	Dolphin 70e Black	dblack	Dolphin 70e Black
Foxconn	InFocus IN260	IN260	IN260
Foxconn	MUSN COUPLE	couple	COUPLE
Foxconn	SH530U	sh530u	SH530U
Foxconn	SH930W	FCN	SH930W
Foxconn	SHARP SH837W	S1U	SH837W
Foxconn	SHARP SH630E	SAE	SHP-SH630E

Supported Devices

Foxconn	SHARP SH631W	S2U	SH631W
Foxconn	SHARP SH837W	S1U	SH837W
Foxconn	ViewPhone3	viewphone3	ViewPhone3
Foxconn	XOLO	AZ510	X900
Foxconn	XOLO_X1000	SI1	XOLO_X1000
Foxconn	vizio VP700	S1U	VP700
Foxconn	vizio VP800	FCN	VP800
Fujitsu	ARROWS A SoftBank 101F	SBM101F	101F
Fujitsu	ARROWS A SoftBank 201F	SBM201F	201F
Fujitsu	ARROWS A SoftBank 202F	SBM202F	202F
Fujitsu	ARROWS A SoftBank 301F	SBM301F	301F
Fujitsu	ARROWS ES IS12F	FJI12	IS12F
Fujitsu	ARROWS Kiss F-03D	f11sky	F-03D
Fujitsu	ARROWS Kiss F-03E	F03E	F-03E
Fujitsu	ARROWS Me F-11D	F11D	F-11D
Fujitsu	ARROWS NX F-06E	F06E	F-06E
Fujitsu	ARROWS S EM01F	EM01F	EM01F
Fujitsu	ARROWS Tab F-05E	F05E	F-05E
Fujitsu	ARROWS Tab FJT21	FJT21_jp_kdi	FJT21
Fujitsu	ARROWS Tab LTE F-01D	blaze_tablet	F-01D
Fujitsu	ARROWS Tab Wi-Fi FAR70B	FAR70B	FAR70B
Fujitsu	ARROWS Tab Wi-Fi FAR75A/70A	blaze_tablet	FAR7
Fujitsu	ARROWS V F-04E	F04E	F-04E
Fujitsu	ARROWS X F-02E	F02E	F-02E
Fujitsu	ARROWS X F-10D	F10D	F-10D
Fujitsu	ARROWS X LTE F-05D	blaze	F-05D
Fujitsu	ARROWS Z FJL22	FJL22_jp_kdi	FJL22
Fujitsu	ARROWS Z ISW11F	FJI11	ISW11F
Fujitsu	ARROWS Z ISW13F	FJI13	ISW13F
Fujitsu	ARROWS ef FJL21	FJL21	FJL21

Supported Devices

Fujitsu	ARROWS mu F-07D	f11apo	F-074
Fujitsu	ARROWS mu F-07D	f11apo	F-07D
Fujitsu	ARROWS mu F-07D	f11apo	FJJB091
Fujitsu	Disney Mobile on docomo F-07E	F07E	F-07E
Fujitsu	Disney Mobile on docomo F-08D	blaze	F-08D
Fujitsu	F-01F	F01F	F-01F
Fujitsu	F-02F	F02F	F-02F
Fujitsu	F-02G	F02G	F-02G
Fujitsu	F-03F	F03F	F-03F
Fujitsu	F-03G	F03G	F-03G
Fujitsu	F-04F	F04F	F-04F
Fujitsu	F-05F	F05F	F-05F
Fujitsu	F-06F	F06F	F-06F
Fujitsu	F-09D ANTEPRIMA	F09D	F-09D
Fujitsu	F-09E	F09E	F-09E
Fujitsu	F-12C	f11eif	F-12C
Fujitsu	FARTM9334P1	FARTM9334	FARTM9334P1
Fujitsu	FARTM933KZ	FARTM933KZ	FARTM933KZ
Fujitsu	M01	M01	M01
Fujitsu	M305	M305	M305
Fujitsu	M363/P	UY1	M363/P
Fujitsu	REGZA Phone IS11T	TSI11	IS11T
Fujitsu	REGZA Phone T-01C	tg03	IS04
Fujitsu	REGZA Phone T-01C	tg03	T-01C
Fujitsu	REGZA Phone T-01D	blaze	T-01D
Fujitsu	REGZA Phone T-02D	T02D	T-02D
Fujitsu	Raku-Raku SMART PHONE F-12D	F12D	F-12D
Fujitsu	Raku-Raku SMART PHONE2 F-08E	F08E	F-08E
Fujitsu	STYLISTIC M350/CA2	M350	M350

Supported Devices

Fujitsu	STYLISTIC M532	mx532	M532
Fujitsu	STYLISTIC M702	M702	M702
Fujitsu	STYLISTIC MH350	MH350	MH350
Fujitsu	STYLISTIC S01	S01	S01-orange
Fujitsu	SZJ-JS101	SZJ101	SZJ-JS101
Funai Electric		smdkv210	ALM-001J
G53	TA71CA3	TA71CA3_1	TA71CA3
GD Classbook	TA80CA1	TA80CA1_2	TA80CA1
GENERAL MOBILE	General Mobile E-tab 4	mehmet	e-tab4
GOCLEVER	QUANTUM_700S/QUANTUM 700S	QUANTUM_700S	QUANTUM_700S
GOCLEVER	TQ700/QUANTUM 700/TAB	TQ700	TQ700
GSmart	Arty A3	Arty_A3	GSmart Arty A3
GSmart	GSmart Aku A1	Aku_A1	GSmart Aku A1
GSmart	GSmart Alto A2	Alto_A2	GSmart Alto A2
GSmart	GSmart GS202+	GSmart_GS202	GSmart GS202+
GSmart	GSmart GSmart SX1	GBC_bravo	GSmart SX1
GSmart	GSmart Guru G1	Guru_G1	GSmart Guru G1
GSmart	GSmart Maya M1	MayaM1	GSmart Maya M1
GSmart	GSmart Maya M1 v2	Maya_M1_v2	GSmart Maya M1 v2
GSmart	GSmart Rey R3	Rey_R3	GSmart Rey R3
GSmart	GSmart Rio R1	Rio_R1	GSmart Rio R1
GSmart	GSmart Roma R2	Roma_R2	GSmart Roma R2
GSmart	GSmart SX1	bravo	GSmart SX1
GSmart	GSmart Sierra S1	GSmart_Sierra_S1	GSmart Sierra S1
GSmart	GSmart T4	GSmart_T4	GSmart T4
GSmart	GSmart Tuku T2	Tuku_T2	GSmart Tuku T2
GSmart	GX2	GBC_ares	GX2
GSmart	Mika M2	Mika_M2	GSmart Mika M2
GSmart	Mika M3	Mika_M3	GSmart Mika M3

Supported Devices

GSmart	Saga_S3	Saga_S3	GSmart Saga S3
GSmart	Simba SX1	GBC_bravo	Simba SX1
GSmart	Simba SX1	bravo	Simba SX1
Galapad	Galapad S6	GALAPAD_S6	GALAPAD_S6
Garmin		a10	Garmin-Asus A10
Garmin	Monterra	monterra	Monterra
Garmin	Nuvi 3595	scorpio	nuvi 3595
Garmin	Nuvifone	a50	Garmin-Asus A50
Garmin	Nuvifone	a50	Garminfone
Garmin	Nuvifone	a50	nuvifone A50
Garmin	Nuvifone	a50	n\xc3\xbcvifone A50
Garmin	nuvi 3590	scorpio	nuvi 3590
Garmin	nuvi 3592	scorpio	nuvi 3592
Garmin	nuvi 3595	scorpio	nuvi 3595
GeneralMobile	E-Tab10	blue_eye	E-Tab10
Geniatech	Enjoy TV Quad-Core Box	ATV581	Enjoy TV Quad-Core Box
Getac	Getac Z710	z710	Getac Z710
Gigabyte		G1317S	GSmart G1317S
Gigabyte	9788	9788	9788
Gigabyte	Boston 4G	boston_4g	Boston 4G
Gigabyte	E9771	E9771	E9771
Gigabyte	GSmart G1310	G1310	GSmart G1310
Gigabyte	GSmart G1315	G1315	GSmart G1315
Gigabyte	GSmart G1317	G1317D	GSmart G1317D
Gigabyte	GSmart G1342	m7627a	GSmart G1342
Gigabyte	GSmart G1345	m7627_sku2	GSmart G1345
Gigabyte	GSmart G1355	G1355	GSmart G1355
Gigabyte	GSmart G1362	G1362	GSmart G1362
Gigabyte	GSmart GS202	GS202	GSmart GS202
Gigabyte	Gigabyte SB506	SB506	SB506

Supported Devices

Gigabyte	Gigabyte SB510 / IBT-102	SB510	SB510
Gigabyte	Hipstreet 9DTB7 / Lazer MY9308P	AMLMY9308P	9DTB7
Gigabyte	Hipstreet 9DTB7 / Lazer MY9308P	AMLMY9308P	MY9308P
Gigabyte	P102g	P102g	P102G
Gigabyte	PAPILIO G1	inhon77_cidals	INHON PAPILIO G1
Gigabyte	PROSCAN PLT1066 / MAG MAGPAD / TEAC TEACTAB / DOPO GS-1008	MID1005_K	GS-1008
Gigabyte	PROSCAN PLT1066 / MAG MAGPAD / TEAC TEACTAB / DOPO GS-1008	MID1005_K	MAGPAD
Gigabyte	PROSCAN PLT1066 / MAG MAGPAD / TEAC TEACTAB / DOPO GS-1008	MID1005_K	PLT1066
Gigabyte	PROSCAN PLT1066 / MAG MAGPAD / TEAC TEACTAB / DOPO GS-1008	MID1005_K	TEACTAB
Gigabyte	SAF3011	SAF3011	SAF3011
Gigabyte	TB100	TB100	Gigabyte TB100
Gigabyte	TB100	TB100	TB100
Gigabyte	TECNO P3S	P3S	TECNO P3S
Gigabyte	TM105	TM105	TM105
Gigabyte	TM105A	TM105A	Aero1021/P1021HCBA4C1VXX
Gigabyte	TM105A	TM105A	Glacier
Gigabyte	TM105A	TM105A	Qrypton1010
Gigabyte	TM105A	TM105A	TM105A
Gigabyte	TM75A	TM75A	GSmart7Tab
Gigabyte	TM75A	TM75A	Qrypton7
Gigabyte	TM75A	TM75A	TM75A
Gigabyte	TM75A	TM75A	Voyager
Gigabyte	TM75A-V	TM75A-V	TM75A-V
Gigabyte	W5510	W5510	W5510
Gigabyte	W6360	W6360	W6360

Supported Devices

Gigabyte	mexico	Lanix	iliumPAD
Gigaset	Gigaset QV1030	FG6Q	Gigaset QV1030
Gigaset	Gigaset QV830	UY8	Gigaset QV830
Gigaset	Gigaset QV831	UY8	Gigaset QV831
Gigaset	Maxwell 10	maxwell_10	80-1
Gigaset	SL930	lion_s	SL930
Gionee	M3	M3	M3
Gionee	P4S	P4S	P4S
Gionee	P6	P6	P6
Gionee	S5.1	S5_1	S5.1
Gionee	S5.5	S5_5	S5.5
Gionee	V4S	V4S	V4S
Gionee	V5	V5	V5
Google	Galaxy S4 Google Play edition	jgedlte	GT-I9505G
Google	Project Tango Tablet Development Kit	yellowstone	Yellowstone
Gradiente	iphone C600	GBC_bravo	iphone C600
Gradiente	iphone C600	bravo	iphone C600
Grundig	GTB1030	TA10CA2	TA10CA2
Grundig	TC69CA2	GTB801	GTB 801
HANNSpree	HANNSpree HSG1279	HANNSpad	HSG1279
Hlsense	HS-EG916	EG916	HS-EG916
HKC	HKC A79 Tablet	EM62	A79
HKT	eye3	UY3-PCW	eye3
HP	10	spruce	HP 10
HP	10 Plus	torsa	HP 10 Plus
HP	7 G2	redwood	HP 7 G2
HP	7 Plus	llex	HP 7 Plus
HP	7 Plus G2	deschutes	HP 7 Plus G2
HP	7 Tablet	Mesquite	HP 7

Supported Devices

HP	7 Voice Tab	klondike	HP 7 VoiceTab
HP	7 VoiceTab	yukon	HP 7 VoiceTab
HP	7.1	Holly	HP 7.1
HP	8	Fir	HP 8
HP	8 G2	maple	HP 8 G2
HP	Bonsai 10 HD	bonsai10	HP Slate 10 HD
HP	HP Slate 7	pine	HP Slate 7
HP	HP SlateBook 10 x2 PC	3645	HP SlateBook 10 x2 PC
HP	Pro Slate 12	dane	HP Pro Slate 12
HP	Slate 10 HD	bonsai10	HP Slate 10 HD
HP	Slate 10 Plus	linkplus	HP Slate 10 Plus
HP	Slate 17	franky	HP Slate 17
HP	Slate 21 Pro	ranger	Slate 21 Pro
HP	Slate 6 Voice Tab	pomegranate	HP Slate 6 Voice Tab
HP	Slate 6 Voice Tab II	avocado	HP Slate 6 Voice Tab II
HP	Slate 6 VoiceTab Plus	mekong	HP Slate 6 VoiceTab Plus
HP	Slate 7 Beats Special Edition	fairfax	HP Slate 7 Beats Special Edition
HP	Slate 7 Beats Special Edition	fairfax	HP Slate7 Beats Special Edition
HP	Slate 7 Extreme	olive	HP Slate7 Extreme
HP	Slate 7 HD	bonsai10	HP Slate 10 HD
HP	Slate 7 HD	bonsai7	HP Slate 7 HD
HP	Slate 7 Voice Tab	almond	HP Slate 7 Voice Tab
HP	Slate 7 VoiceTab Ultra	charm	HP Slate 7 VoiceTab Ultra
HP	Slate 8 Plus	vogue	HP Slate 8 Plus
HP	Slate 8 Pro	dogwood	HP Slate 8 Pro
HP	Slate21	phobos	Slate 21
HP	Slate7 Plus	birch	HP Slate 7 Plus
HP	Slate8 Pro	fig	HP Slate 8 Pro
HP	SlateBook 14	200a	HP SlateBook 14 PC
HP	Tablet 10	balsa	HP_10_Tablet

Supported Devices

HP	Voice Tab 7	almond	HP Slate 7 Voice Tab
HTC		express	HTC Flyer
HTC		express	PG41200
HTC		expresskt	HTC_P515E
HTC		rider	HTC_X515E
HTC		tagh	HTC Incredible E S715e
HTC	\tADR6325	lexikon	ADR6325
HTC	ADR6330VW	blissc	ADR6330VW
HTC	ADR6425LVW	vigor	ADR6425LVW
HTC	AT&T HTC One X+	evitareul	HTC EVARE_UL
HTC	AT&T HTC One X+	evitareul	HTC One X+
HTC	Aria	liberty	HTC Aria
HTC	Aria	liberty	HTC Aria A6380
HTC	Aria	liberty	HTC Gratia A6380
HTC	Aria	liberty	HTC Liberty
HTC	Butterfly S	dlxpul	HTC Butterfly s
HTC	Butterfly S	dlxpul	HTC_Butterfly_s_901s
HTC	Chacha	chacha	HTC ChaCha A810b
HTC	Chacha	chacha	HTC ChaCha A810e
HTC	Chacha	chacha	HTC ChaChaCha A810e
HTC	Chacha	chacha	HTC Status
HTC	Desire	bravo	HTC Desire
HTC	Desire	bravo	X06HT
HTC	Desire	bravoc	PB99400
HTC	Desire 320	htc_v01_u	HTC Desire 320
HTC	Desire 510	htc_a11ul8x26	HTC Desire 510
HTC	Desire 516 dual sim	htc_v2_dcg	HTC Desire 516 dual sim
HTC	Desire 516 dual sim	htc_v2_dug	HTC Desire 516 dual sim
HTC	Desire 516 dual sim	htc_v2_dug	HTC V2
HTC	Desire 620 dual sim	htc_a31dtul	HTC_D620u

Supported Devices

HTC	Desire 820	htc_a51ul	HTC 0PFJ4
HTC	Desire 820	htc_a51ul	HTC Desire 820
HTC	Desire D820mini	htc_a31dtul	HTC D820mt
HTC	Desire D820mini	htc_a31dtul	HTC D820mu
HTC	Desire HD	ace	001HT
HTC	Desire HD	ace	Desire HD
HTC	Desire HD	ace	HTC Desire HD A9191
HTC	Desire HD	ace	Inspire HD
HTC	Desire L by HTC	cp2u	Desire L by HTC
HTC	Desire S	saga	HTC Desire S
HTC	Desire VC	primodd	HTC Desire VC
HTC	Desire VC	primodd	HTC Desire VC T328d
HTC	Desire VC	primodd	HTC PRO_DD
HTC	Droid DNA	dlx	HTC6435LRA
HTC	Droid DNA	dlx	HTC6435LVW
HTC	Droid Eris	desirec	Eris
HTC	Droid Eris	desirec	Pulse
HTC	Droid Incredible	inc	ADR6300
HTC	EVO 3D	shooter	HTCEVOV4G
HTC	EVO 3D	shooter	PG86100
HTC	EVO LTE 4G	jewel	EVO
HTC	EVO Shift 4G	speedy	PG06100
HTC	Evo 4G	supersonic	PC36100
HTC	Flyer	flyer	HTC Flyer
HTC	Flyer	flyer	HTC Flyer P510e
HTC	Flyer	flyer	HTC Flyer P511e
HTC	Flyer	flyer	HTC Flyer P512
HTC	Flyer	flyer	HTC_Flyer_P512_NA
HTC	G1	dream	HTC Dream
HTC	G2	vision	HTC Vision

Supported Devices

HTC	G2	vision	T-Mobile G2
HTC	HTC 5060 dual sim	z4dug	HTC Desire 500 dual sim
HTC	HTC 601e	m4	HTC 601e
HTC	HTC 606w	cp3dug	HTC 606w
HTC	HTC 606w	cp3dug	HTC Desire 600
HTC	HTC 606w	cp3dug	HTC Desire 600 dual sim
HTC	HTC 606w	cp3dug	HTC PO49120
HTC	HTC 608t	cp3dtg	HTC 608t
HTC	HTC 609d	cp3dcg	HTC 609d
HTC	HTC 6160	zaradug	HTC 6160
HTC	HTC 619d	zarawl	HTC 619d
HTC	HTC 7060	cp5dug	HTC_7060
HTC	HTC 710C	htc_a5chl	710C
HTC	HTC 802d	m7cdwg	HTC 802d
HTC	HTC 803e	t6ul	HTC 803e
HTC	HTC 8060	t6dug	HTC 8060
HTC	HTC 8088	t6tl	HTC 8088
HTC	HTC 809d	t6dwg	HTC 809d
HTC	HTC 8160	t6uhl	HTC 8160
HTC	HTC 9060	dlxpul	HTC 901e
HTC	HTC 9060	m7	HTC 801e
HTC	HTC 9060	m7cdug	HTC 802w
HTC	HTC 9088	dlpdtu	HTC 9088
HTC	HTC 919d	dlpdwg	HTC 919d
HTC	HTC Butterfly	dlxu	HTC Butterfly
HTC	HTC Butterfly	dlxu	HTC DLX_U
HTC	HTC Butterfly	dlxu	HTC X920e
HTC	HTC Butterfly	dlxub1	HTC Butterfly
HTC	HTC Butterfly	dlxub1	HTC DLXUB1
HTC	HTC Butterfly 2	htc_b2ul	HTC Butterfly 2

Supported Devices

HTC	HTC Butterfly 2	htc_b2ul	HTC_B810x
HTC	HTC Butterfly s 9060	dlpdug	HTC 9060
HTC	HTC D316d	htc_v2_c	HTC D316d
HTC	HTC D610t	htc_a3tl	HTC D610t
HTC	HTC D816d	htc_a5dwg	HTC D816d
HTC	HTC D816d	htc_a5dwg	HTC_D816d
HTC	HTC D816e	htc_a5dugl	HTC D816e
HTC	HTC D816h	htc_a5mgrp_dug	HTC D816h
HTC	HTC D816t	htc_a5tl	HTC D816t
HTC	HTC D816v	htc_a5dwgl	HTC D816v
HTC	HTC D816w	htc_a5dug	HTC D816w
HTC	HTC D820 Mini	htc_a31dtul	HTC D820mt
HTC	HTC D820t	htc_a51dtul	HTC D820t
HTC	HTC D820u	htc_a51dtul	HTC D820u
HTC	HTC DROID DNA	dlx	HTC6435LRA
HTC	HTC DROID Incredible 4G LTE	fireball	ADR6410LRA
HTC	HTC DROID Incredible 4G LTE	fireball	ADR6410LVW
HTC	HTC DROID Incredible 4G LTE	fireball	ADR6410OM
HTC	HTC Desire 200	gtou	HTC Desire 200
HTC	HTC Desire 200	gtou	HTC_Desire_200
HTC	HTC Desire 210 dual sim	htc_v0_dug	HTC Desire 210 dual sim
HTC	HTC Desire 300	g3u	HTC 301e
HTC	HTC Desire 300	g3u	HTC Desire 300
HTC	HTC Desire 300	g3u	HTC_0P6A1
HTC	HTC Desire 300	g3u	HTC_Desire_300
HTC	HTC Desire 310	htc_v1_dug	HTC D310w
HTC	HTC Desire 310	htc_v1_dug	HTC Desire 310 dual sim
HTC	HTC Desire 310	htc_v1_u	HTC Desire 310
HTC	HTC Desire 310	htc_v1_u	HTC_D310n
HTC	HTC Desire 310	htc_v1_u	HTC_V1

Supported Devices

HTC	HTC Desire 320	htc_v01_u	HTC 0PF120
HTC	HTC Desire 320	htc_v01_u	HTC Desire 320
HTC	HTC Desire 500	z4u	HTC Desire 500
HTC	HTC Desire 500	z4u	HTC_Desire_500
HTC	HTC Desire 500 dual sim	z4dug	HTC 5060
HTC	HTC Desire 500 dual sim	z4dug	HTC Desire 500 dual sim
HTC	HTC Desire 501	htc_csnu	HTC Desire 501
HTC	HTC Desire 501	htc_csnu	HTC_603h
HTC	HTC Desire 501 dual sim	csndug	HTC Desire 501 dual sim
HTC	HTC Desire 5088	z4td	HTC 5088
HTC	HTC Desire 510	htc_a11chl	0PCV1
HTC	HTC Desire 510	htc_a11ul	HTC 0PCV20
HTC	HTC Desire 510	htc_a11ul	HTC Desire 510
HTC	HTC Desire 510	htc_a11ul	HTC_0PCV2
HTC	HTC Desire 516	htc_v2_dcg	HTC D516d
HTC	HTC Desire 516	htc_v2_dtg	HTC D516t
HTC	HTC Desire 516	htc_v2_dug	HTC C2
HTC	HTC Desire 516	htc_v2_dug	HTC D516w
HTC	HTC Desire 516	htc_v2_dug	HTC V2
HTC	HTC Desire 516 dual sim	htc_v2_dug	HTC Desire 516 dual sim
HTC	HTC Desire 526G+ dual sim	htc_v02_dug	HTC 0PL41
HTC	HTC Desire 526G+ dual sim	htc_v02_dug	HTC 0PL4100
HTC	HTC Desire 526G+ dual sim	htc_v02_dug	HTC Desire 526GPLUS dual sim
HTC	HTC Desire 526G+ dual sim	htc_v02_dug	HTC_D526h
HTC	HTC Desire 600	cp3dug	HTC Desire 600
HTC	HTC Desire 600 Dual SIM	cp3dug	HTC Desire 600 dual sim
HTC	HTC Desire 600c Dual SIM	cp3dcg	HTC 609d
HTC	HTC Desire 600c Dual SIM	cp3dcg	HTC Desire 600c dual sim
HTC	HTC Desire 601	zara	HTC Desire 601
HTC	HTC Desire 601	zara	HTC_0P4E2

Supported Devices

HTC	HTC Desire 601	zaracl	HTC Desire 601
HTC	HTC Desire 601	zaracl	HTC0P4E1
HTC	HTC Desire 601 dual sim	zaradug	HTC Desire 601 dual sim
HTC	HTC Desire 606w	cp3dug	HTC 606w
HTC	HTC Desire 609d	cp3dcg	HTC 609d
HTC	HTC Desire 610	htc_a3qhdul	HTC Desire 610
HTC	HTC Desire 610	htc_a3qhdul	HTC_0P9O2
HTC	HTC Desire 610	htc_a3qhdul	HTC_D610x
HTC	HTC Desire 610	htc_a3ul	HTC Desire 610
HTC	HTC Desire 616 dual sim	htc_v3_dug	HTC D616w
HTC	HTC Desire 616 dual sim	htc_v3_dug	HTC Desire 616 dual sim
HTC	HTC Desire 616 dual sim	htc_v3_dug	HTC V3
HTC	HTC Desire 620	htc_a31ul	HTC 0PE64
HTC	HTC Desire 620	htc_a31ul	HTC Desire 620
HTC	HTC Desire 620G dual sim	htc_a31mg_dug	HTC 0PE65
HTC	HTC Desire 620G dual sim	htc_a31mg_dug	HTC Desire 620G dual sim
HTC	HTC Desire 620G dual sim	htc_a31mg_dug	HTC_D620h
HTC	HTC Desire 700 dual sim	cp5dug	HTC Desire 700 dual sim
HTC	HTC Desire 700 dual sim	cp5dwg	HTC Desire 700 dual sim
HTC	HTC Desire 700 dual sim	cp5dwg	HTC_709d
HTC	HTC Desire 7060	cp5dug	HTC_7060
HTC	HTC Desire 7088	cp5dtu	HTC 7088
HTC	HTC Desire 709d	cp5dwg	HTC 709d
HTC	HTC Desire 816	htc_a5chl	HTC Desire 816
HTC	HTC Desire 816	htc_a5ul	HTC Desire 816
HTC	HTC Desire 816	htc_a5ul	HTC_0P9C2
HTC	HTC Desire 816	htc_a5ul	HTC_D816x
HTC	HTC Desire 816 dual sim	htc_a5dug	HTC Desire 816 dual sim
HTC	HTC Desire 816 dual sim	htc_a5dwg	HTC Desire 816 dual sim
HTC	HTC Desire 816G dual	htc_a5mgp_dug	HTC Desire 816G dual sim

Supported Devices

HTC	HTC Desire 816G dual SIM	htc_a5mgrp_dug	HTC Desire 816G dual sim
HTC	HTC Desire 816G dual sim	htc_a5mg_dug	HTC Desire 816G dual sim
HTC	HTC Desire 816G dual sim	htc_a5mgrp_dug	HTC Desire 816G dual sim
HTC	HTC Desire 820 dual sim	htc_a51dtul	HTC Desire 820 dual sim
HTC	HTC Desire 820s	htc_a50ml_dtul	HTC D820ts
HTC	HTC Desire 820s	htc_a50ml_dtul	HTC D820us
HTC	HTC Desire 820s	htc_a50ml_dtul	HTC Desire 820s dual sim
HTC	HTC Desire C	golfc	HTC Desire C
HTC	HTC Desire C	golfu	HTC Desire C
HTC	HTC Desire EYE	htc_eyetuhl	HTC 0PFH2
HTC	HTC Desire EYE	htc_eyetuhl	HTC Desire EYE
HTC	HTC Desire EYE	htc_eyetuhl	HTC_M910x
HTC	HTC Desire EYE	htc_eyeu1	HTC 0PFH11
HTC	HTC Desire EYE	htc_eyeu1	HTC Desire EYE
HTC	HTC Desire Eye	htc_eyeu1_att	HTC Desire Eye
HTC	HTC Desire L dual sim	cp2dug	HTC Desire L dual sim
HTC	HTC Desire P	magniu	HTC Desire P
HTC	HTC Desire SV	magnids	HTC Desire SV
HTC	HTC Desire V	primods	HTC Desire Q
HTC	HTC Desire V	primods	HTC Desire U
HTC	HTC Desire V	primods	HTC Desire U dual sim
HTC	HTC Desire V	primods	HTC Desire V
HTC	HTC Desire V	primods	HTC PROMIN_U
HTC	HTC Desire V	primods	HTC PRO_DS
HTC	HTC Desire V	primods	HTC T327w
HTC	HTC Desire X	protou	HTC Desire X
HTC	HTC Desire X	protou	HTC POO_U
HTC	HTC Desire X dual sim	protodug	HTC Desire X dual sim
HTC	HTC Desire XC dual sim	protodcg	HTC Desire XC dual sim
HTC	HTC EVO 3D ISW12HT	shooterk	ISW12HT

Supported Devices

HTC	HTC EVO 3D X515m	shooteru	HTC EVO 3D X515a
HTC	HTC EVO 3D X515m	shooteru	HTC EVO 3D X515m
HTC	HTC EVO 3D X515m	shooteru	HTC Inspire 3D
HTC	HTC EVO 4G LTE	jewel	EVO
HTC	HTC Explorer A310e	pico	HTC Explorer
HTC	HTC Explorer A310e	pico	HTC Explorer A310b
HTC	HTC Explorer A310e	pico	HTC Explorer A310e
HTC	HTC Hero	hero	ERA G2 Touch
HTC	HTC Hero	hero	HTC Hero
HTC	HTC Hero	hero	T-Mobile G2 Touch
HTC	HTC Hero	hero	T-Mobile_G2_Touch
HTC	HTC Hero	hero	dopod A6288
HTC	HTC J Butterfly	dlxj	HTL21
HTC	HTC J One	m7wj	HTL22
HTC	HTC J Z321e	valentewxc9	HTC J Z321e
HTC	HTC M8t	htc_m8tl	HTC M8t
HTC	HTC ONE S	ville	HTC One S
HTC	HTC ONE SV	k2u	HTC K2_U
HTC	HTC ONE SV	k2u	HTC One SV
HTC	HTC ONE SV	k2ul	HTC One SV
HTC	HTC One	m7	HTC 801e
HTC	HTC One	m7	HTC One
HTC	HTC One	m7	HTC One 801e
HTC	HTC One	m7	HTC_PN071
HTC	HTC One	m7cdtu	HTC 802t
HTC	HTC One	m7cdtu	HTC 802t 16GB
HTC	HTC One	m7cdug	HTC 802w
HTC	HTC One	m7cdug	HTC One dual sim
HTC	HTC One	m7cdwg	HTC 802d
HTC	HTC One	m7cdwg	HTC One dual 802d

Supported Devices

HTC	HTC One	m7cdwg	HTC One dual sim
HTC	HTC One	m7wls	HTC One
HTC	HTC One	m7wls	HTCONE
HTC	HTC One	m7wlv	HTC One
HTC	HTC One	m7wlv	HTC6500LVW
HTC	HTC One (E8)	htc_mecdwg	HTC M8Sd
HTC	HTC One (E8)	htc_mectl	HTC M8St
HTC	HTC One (E8)	htc_mectl	HTC One_E8
HTC	HTC One (E8)	htc_mecul	HTC One_E8
HTC	HTC One (E8)	htc_mecul	HTC_M8Sx
HTC	HTC One (E8)	htc_mecwhl	0PAJ5
HTC	HTC One (E8) dual sim	htc_mecdug	HTC One_E8 dual sim
HTC	HTC One (E8) dual sim	htc_mecdwg	HTC 0PAJ4
HTC	HTC One (E8) dual sim	htc_mecdwg	HTC One_E8 dual sim
HTC	HTC One (E8) \xe6\x97\xb6\xe5\xb0\x9a\xe7\x89\x88	htc_mectl	HTC M8St
HTC	HTC One (E8) \xe6\x97\xb6\xe5\xb0\x9a\xe7\x89\x88 4G LTE\xe5\x8f\x8c\xe5\x8d\xa1\xe5\x8f\x8c\xe5\xbe\x85\xe8\x81\x94\xe9\x80\x9a\xe7\x89\x88	htc_mecdug	HTC M8Sw
HTC	HTC One (E8) \xe6\x99\x82\xe5\xb0\x9a\xe7\x89\x884G LTE xe7\xa7\xbb\xe5\x8a\xa8\xe7\x89\x88	htc_mectl	HTC M8Ss
HTC	HTC One (M8)	htc_m8	HTC M8w
HTC	HTC One (M8)	htc_m8	HTC One_M8
HTC	HTC One (M8)	htc_m8	HTC_0P6B
HTC	HTC One (M8)	htc_m8	HTC_0P6B6
HTC	HTC One (M8)	htc_m8	HTC_M8x
HTC	HTC One (M8)	htc_m8dug	HTC One_M8 dual sim
HTC	HTC One (M8)	htc_m8dwg	HTC M8d

Supported Devices

HTC	HTC One V	primou	HTC ONE V
HTC	HTC One V	primou	HTC One V
HTC	HTC One VX	totemc2	HTC One VX
HTC	HTC One X	endeavoru	HTC One X
HTC	HTC One X	evita	HTC One X
HTC	HTC One X+	enrc2b	HTC One X+
HTC	HTC One X+	evitareul	HTC One X+
HTC	HTC One XL	evita	HTC One X
HTC	HTC One XL	evita	HTC One XL
HTC	HTC One XL	evita	HTC_One_XL
HTC	HTC One XL	evitautl	HTC EVA_UTL
HTC	HTC One max	t6ul	HTC One max
HTC	HTC One max	t6ul	HTC_One_max
HTC	HTC One max	t6whl	HTC0P3P7
HTC	HTC One mini	htc_m4	HTC One mini
HTC	HTC One mini	m4	HTC One mini
HTC	HTC One mini	m4	HTC_One_mini_601e
HTC	HTC One mini	m4	HTC_PO582
HTC	HTC One mini 2	htc_memul	HTC One mini 2
HTC	HTC One mini 2	htc_memul	HTC_M8MINx
HTC	HTC One mini 2	htc_memul	HTC_One_mini_2
HTC	HTC One mini 601E	m4	HTC_One_mini_601e
HTC	HTC One mini2	htc_memul	HTC One mini 2
HTC	HTC One remix	htc_memwl	HTC6515LVW
HTC	HTC One_E8	htc_mecul_emea	HTC One_E8
HTC	HTC Onex X	endeavoru	HTC One X
HTC	HTC PO091	csndug	HTC PO091
HTC	HTC Rhyme S510b	bliss	HTC Rhyme S510b
HTC	HTC S720e	endeavoru	HTC S720e
HTC	HTC Salsa C510e	icong	HTC Salsa C510b

Supported Devices

HTC	HTC Salsa C510e	icong	HTC Salsa C510e
HTC	HTC Sensation XL with Beats Audio X315e	runnymede	HTC Sensation XL with Beats Audio X315b
HTC	HTC Sensation XL with Beats Audio X315e	runnymede	HTC Sensation XL with Beats Audio X315e
HTC	HTC Sensation XL with Beats Audio X315e	runnymede	HTC-X315E
HTC	HTC Sensation XL with Beats Audio X315e	runnymede	Sensation XL with Beats Audio
HTC	HTC T329d	protodcg	HTC T329d
HTC	HTC T528w	cp2dug	HTC Desire L dual sim
HTC	HTC Velocity 4G	holiday	HTC PH39100
HTC	HTC Velocity 4G	holiday	HTC Raider X710e
HTC	HTC Velocity 4G	holiday	HTC Velocity 4G
HTC	HTC Velocity 4G	holiday	HTC Velocity 4G X710s
HTC	HTC Velocity 4G	holiday	HTC-X710a
HTC	HTC Wildfire S A515c	marvelc	HTC Wildfire S A515c
HTC	HTC Wildfire S A515c	marvelc	HTC-PG762
HTC	HTC Wildfire S A515c	marvelc	USCCADR6230US
HTC	HTC desire 608t	cp3dtg	HTC 608t
HTC	HTC first	mystul	HTC first
HTC	HTC6435LVW	dlx	HTC6435LVW
HTC	HTC909d	dlpdwg	HTC 919d
HTC	HTCDesire612VZW	htc_a3qhdcl	HTC331ZLVW
HTC	HTCDesire612VZW	htc_a3qhdcl	HTC331ZLVWPP
HTC	HTCEVODesign4G	kingdom	HTC Acquire
HTC	HTCEVODesign4G	kingdom	HTC EVO Design C715e
HTC	HTCEVODesign4G	kingdom	HTC Hero S
HTC	HTCEVODesign4G	kingdom	HTC Kingdom
HTC	HTCEVODesign4G	kingdom	HTCEVODesign4G
HTC	HTCEVODesign4G	kingdom	PH44100
HTC	HTCOneMaxVZW	t6wl	HTC6600LVW

Supported Devices

HTC	HTC_0P3P5	t6ul	HTC_0P3P5
HTC	HTC_0P4E2	zara	HTC_0P4E2
HTC	HTC_A510c	marvelc	HTC_A510c
HTC	HTC_Amaze_4G	ruby	HTC Amaze 4G
HTC	HTC_Amaze_4G	ruby	HTC Ruby
HTC	HTC_Amaze_4G	ruby	HTC_Amaze_4G
HTC	HTC_D820u	htc_a51dtul	HTC_D820u
HTC	HTL23	htc_b2wlj	HTL23
HTC	Hero	heroc	HERO200
HTC	ISW13HT	valentewx	ISW13HT
HTC	Incredible 2	vivow	ADR6350
HTC	Incredible 2	vivow	HTC IncredibleS S710d
HTC	Incredible S	vivo	HTC Incredible S
HTC	Incredible S	vivo	HTC_S710E
HTC	KDDI Infobar A02	imnj	HTX21
HTC	Legend	legend	HTC Legend
HTC	Nexus 9	flounder	Nexus 9
HTC	Nexus One	passion	Nexus One
HTC	One XL	evita	HTC One XL
HTC	Puccini	puccinilte	HTC PG09410
HTC	Puccini	puccinilte	HTC-P715a
HTC	Sensation 4G	pyramid	HTC Sensation
HTC	Sensation 4G	pyramid	HTC Sensation 4G
HTC	Sensation 4G	pyramid	HTC Sensation XE with Beats Audio
HTC	Sensation 4G	pyramid	HTC Sensation XE with Beats Audio Z715a
HTC	Sensation 4G	pyramid	HTC Sensation XE with Beats Audio Z715e
HTC	Sensation 4G	pyramid	HTC Sensation Z710a
HTC	Sensation 4G	pyramid	HTC Sensation Z710e
HTC	Sensation 4G	pyramid	HTC-Z710a
HTC	Thunderbolt	mecha	ADR6400L

Supported Devices

HTC	Thunderbolt	mecha	HTC Mecha
HTC	Wildfire	buzz	HTC Wildfire
HTC	Wildfire CDMA	bee	HTC Bee
HTC	Wildfire CDMA	bee	HTC Wildfire
HTC	Wildfire S	marvel	HTC Wildfire S
HTC	Wildfire S	marvel	HTC Wildfire S A510b
HTC	Wildfire S	marvel	HTC Wildfire S A510e
HTC	Wildfire S	marvel	HTC-A510a
HTC	hTC Desire 601	zara	HTC Desire 601
HTC	htc desire 400 dual sim	cp2dug	HTC Desire 400 dual sim
HTC	htc desire 610	htc_a3qhdul	HTC Desire 610
HTC	htc desire x	protou	HTC Desire X
HTC	myTouch 3G	sapphire	HTC Magic
HTC	myTouch 3G	sapphire	T-Mobile myTouch 3G
HTC	myTouch 3G Slide	espresso	T-Mobile myTouch 3G Slide
HTC	myTouch 4G	glacier	HTC Glacier
HTC	myTouch 4G	glacier	HTC Panache
HTC	myTouch 4G Slide	doubleshot	myTouch_4G_Slide
Haier	A-TT00	A-TT00	A-TT00
Haier	AD6B1H	AD6B1H	Smartfren Andromax AD6B1H
Haier	AT7003	AT7003	AT7003
Haier	Beeline Smart 3	Beeline_Smart3	Beeline Smart 3
Haier	CDP7TAB4C8	CDP7TAB4C8	CDP7TAB4C8
Haier	CETAB10KML9	CETAB10KML9	CETAB10KML9
Haier	CETAB7ML9	CETAB7ML9	CETAB7ML9
Haier	CETAB9ML9	CETAB9ML9	CETAB9ML9
Haier	CMP_765	CMP_765	CMP_765
Haier	CT1030	CT1030	CT1030
Haier	CT301_W818	msm7627a	CT301_W818
Haier	CT825	fiber-a31stm	CT825

Supported Devices

Haier	CYCLONE_ODYSSEY	CYCLONE_ODYSSEY	CYCLONE_ODYSSEY
Haier	D2-721	D2-721G	D2-721G
Haier	D2-751G	d2PAD	D2-751G
Haier	D2-927G	D2-927G	D2-927G
Haier	D2-961G	D2-961G	D2-961G
Haier	GF88	I7A-LE	I7A-LE
Haier	HG-9041	HG-9041	HG-9041
Haier	HS-10DTB4	HS-10DTB4	HS-10DTB4
Haier	HS-7DTB25	HS-7DTB25	HS-7DTB25
Haier	HS-7DTB29-8GB	HS-7DTB29-8GB	HS-7DTB29-8GB
Haier	HS-9DTB37	HS_9DTB37	HS_9DTB37
Haier	HT-I860	HT-I860	HT-I860
Haier	Haier	Homesurf744	Binatone Homesurf744 / Hubble Smart7 (Homesurf744)
Haier	Haier	PAD69H	PAD69H
Haier	Haier	PAD_D85	pad_d85
Haier	HomeSurf742_AT7003	HomeSurf742_AT7003	HomeSurf742_AT7003
Haier	Homesurf844	Homesurf844	Binatone Homesurf844 / Hubble Smart8 (Homesurf844)
Haier	INGO-TAB	INGO-TAB	INGO-TAB
Haier	Konnect_350	Konnect_350	Konnect_350
Haier	LE39M7000CF	LE39M7000CF	LE39M7000CF
Haier	LE48M7000CF	LE48M7000CF	LE48M7000CF
Haier	LE55M7000CF	LE55M7000CF	LE55M7000CF
Haier	Logicom S9782	Logicom-S9782	Logicom-S9782
Haier	MD210	MD210	MD210
Haier	MEGAFON MS3A	Megafon	MS3A
Haier	MT-700	MT-700	MT-700
Haier	NEO10-1	NEO10-1	NEO10-1
Haier	NEO7-1	NEO7-1	NEO7-1
Haier	NEO7-2	NEO7-2	NEO7-2

Supported Devices

Haier	NEO8-1	NEO8-1	NEO8-1
Haier	P2	P2	P2
Haier	PAD1021	PAD1021	PAD1021
Haier	PAD1042	PAD1042	PAD1042
Haier	PAD712	PAD712	PAD712
Haier	PAD722	PAD722	PAD722
Haier	PAD841	PAD841	PAD841
Haier	PADCT1010W	PADCT1010W	PADCT1010W
Haier	PAD_1042	PAD_1042	PAD_1042
Haier	PNDPP410GP	PNDPP410GP	PNDPP410GP
Haier	PNDPP44Q7GPBLK	PNDPP44Q7GPBLK	PNDPP44Q7GPBLK
Haier	PNDPP47GP	PNDPP47GP	PNDPP47GP
Haier	SP-5100	SP-5100	SP-5100
Haier	Skill	Skill	Skill
Haier	Smartfren Andromax AD681H	AD681H	Smartfren Andromax AD681H
Haier	Smartfren Andromax AD9A1H	AD9A1H	Smartfren Andromax AD9A1H
Haier	StarQ_Q5002	StarQ_Q5002	Q5002
Haier	T785B	T785B	T785B
Haier	TAB-700	TAB_700	TAB-700
Haier	TAB-700	TAB_700	TAB700MPG
Haier	W757	W757	W757
Haier	W860	W860	W860
Harris	Harris 12131-1000	msm8660_cougar	Harris 12131-1000
Hipstreet	7DTB25	7DTB25	7DTB25
Hipstreet	HS-10DTB12	Hipstreet	HS-10DTB12
Hipstreet	HS-10DTB12A	RCT6203W46	HS_10DTB12A
Hipstreet	HS-7DTB27	HS-7DTB27	HS-7DTB27
Hipstreet	HS-7DTB35	RCT6773W22	HS_7DTB35
Hipstreet	HS-7DTB39	HS-7DTB39	HS-7DTB39
Hipstreet	HS-9DTB7A	HS-9DTB7A	HS-9DTB7A

Supported Devices

Hipstreet	Hipstreet HS-10DTB8	HS-10DTB8	HS-10DTB8
Hisense		AD683G	AD683G
Hisense		AD685G	New Andromax-i
Hisense		E820	HS-E820
Hisense		E910	E910
Hisense		E910	HS-E910
Hisense		E912	HS-E912
Hisense		E912S	HS-E912S
Hisense		E920	HS-E920
Hisense		E926	E926
Hisense		E930	HS-E930
Hisense		E956	HS-E956
Hisense		E956Q	HS-E956Q
Hisense		EG870	HS-EG870
Hisense		EG876	HS-EG876
Hisense		EG901	HS-EG901
Hisense		EG909	HS-EG909
Hisense		EG950	HS-EG950
Hisense		EG970	HS-EG970
Hisense		P4013	MEDION-P4013
Hisense		SIMPlus	MegaFon SIM+
Hisense		T818	HS-T818
Hisense		TP9101	HS-M170AT
Hisense		TP9102	M1101AT
Hisense		U2	U2
Hisense		U8	HS-U8
Hisense		U820	HS-U820
Hisense		U820A	HS-U820
Hisense		U820A	U1+
Hisense		U820AVN	HS-U820

Supported Devices

Hisense		U860	HS-U860
Hisense		U909	HS-U909
Hisense		U909B	HS-U909B
Hisense		U909B_6	HS-U909
Hisense		U909B_MN	U2S
Hisense		U912	HS-U912
Hisense		U950	HS-U950
Hisense		U950_6	HS-U950
Hisense		U950_MN	U3
Hisense		U950_ae	HS-U950
Hisense		U958	HS-U958
Hisense		U960Q	HS-U960Q
Hisense		W2400	W2400
Hisense		m3101	M3101BW
Hisense		m370	M370BW
Hisense		t909	HS-T909
Hisense		t950	HS-T950
Hisense		t958	HS-T958
Hisense		t960	HS-T960
Hisense	55H6SG	Vision	Vision
Hisense	Andromax-c	AD686G	Andromax-c
Hisense	C-4	C_4	C-4
Hisense	CMB405	L690AE	CMB405
Hisense	CMB501	u970_carrefour	CMB501
Hisense	CMB510	L696	CMB510
Hisense	E100T	E100T	Hisense E100T
Hisense	E200T	E200T	HS-E200T
Hisense	E2070	mt8312	E2070
Hisense	E2371CH	rk3026	E2371CH
Hisense	E260T	E260T	HS-E260T

Supported Devices

Hisense	E260U	E260U	Hisense E260U
Hisense	E270BSA	E270BSA	E270BSA
Hisense	E600MH02	E600MH02	HS-E600M
Hisense	E601M	E601M	E601M
Hisense	E860	E860	E860
Hisense	EG680	eg980ae	EG680
Hisense	EG68AE	EG668AE	LT668
Hisense	EG929	EG929_TW	EG929
Hisense	EG950	EG950TW	EG950
Hisense	EG970	EG970TW	EG970
Hisense	EG978	EG978	HS-EG978
Hisense	EG98	EG98	EG98
Hisense	EG98	EG98TW	EG98
Hisense	EG981	EG981	HS-EG981
Hisense	F270BW	F270BW	F270BW
Hisense	F5070	mt8389	F5070
Hisense	F5180	f5180	F5180
Hisense	F5281CH	rk3288	F5281CH
Hisense	G1	G1	G1
Hisense	G2-3GP	G2-3GP	G2-3GP
Hisense	H800T	H800T	HS-H800T
Hisense	HS-E600M	E600M	HS-E600M
Hisense	HS-E620M	E620M	HS-E620M
Hisense	HS-E917	E917	HS-E917
Hisense	HS-E936	E936	HS-E936
Hisense	HS-E968	E968	HS-E968
Hisense	HS-EG929	EG929	msm8625
Hisense	HS-EG939	EG939	HS-EG939
Hisense	HS-EG958	EG958	HS-EG958
Hisense	HS-EG966	EG966	HS-EG966

Supported Devices

Hisense	HS-EG971	EG971	HS-EG971
Hisense	HS-EG980	eg980	HS-EG980
Hisense	HS-EG98C	EG98C	HS-EG98C
Hisense	HS-I630M	msm8226	HS-I630M
Hisense	HS-I630T	msm8226	HS-I630T
Hisense	HS-T9	T9	HS-T9
Hisense	HS-T926	t926	HS-T926
Hisense	HS-T928	t928	HS-T928
Hisense	HS-T939	HS-T939	HS-T939
Hisense	HS-T959	t959	HS-T959
Hisense	HS-T959S	t959s	HS-T959S
Hisense	HS-T966	HS-T966	HS-T966
Hisense	HS-T967	HS-T967	HS-T967
Hisense	HS-T968	t968	HS-T968
Hisense	HS-T968S	t968s	HS-T968S
Hisense	HS-T970	t970	HS-T970
Hisense	HS-T978	t978	HS-T978
Hisense	HS-T980	t980	HS-T980
Hisense	HS-U820	U820B	HS-U820
Hisense	HS-U9	U9	HS-U9
Hisense	HS-U912	U912A_1	HS-U912
Hisense	HS-U912	U912B	HS-U912
Hisense	HS-U912	U912C	HS-U912
Hisense	HS-U929	u929de	HS-U929
Hisense	HS-U929	u929de_3	HS-U929
Hisense	HS-U936	U936	HS-U936
Hisense	HS-U939	u939	HS-U939
Hisense	HS-U939	u939e_1	HS-U939
Hisense	HS-U939	u939e_3	HS-U939
Hisense	HS-U939	u939e_4	HS-U939

Supported Devices

Hisense	HS-U939	u939e_5	HS-U939
Hisense	HS-U950	U950_5	HS-U950
Hisense	HS-U966	u966	HS-U966
Hisense	HS-U966	u966ae	HS-U966
Hisense	HS-U970	u970e_6	HS-U970
Hisense	HS-U970	u970s_export	HS-U970
Hisense	HS-U971	U971AE	HS-U971
Hisense	HS-U978	u978	HS-U978
Hisense	HS-U98	U98	U98
Hisense	HS-U98	U98_FR	HS-U98
Hisense	HS-U980	u980	HS-U980
Hisense	HS-U980	u980be	HS-U980
Hisense	HS-U980	u980be_1	HS-U980
Hisense	HS-U980	u980be_2	HS-U980
Hisense	HS-U980	u980ce_1	HS-U980
Hisense	HS-U980	u980ce_3	HS-U980
Hisense	HS-U980	u980ce_4	HS-U980
Hisense	HS-U980	u980ce_5	HS-U980
Hisense	HS-X5T	X5T	HS-X5T
Hisense	HS-X68T	x68t	HS-X68T
Hisense	HS-X6T	X6T	HS-X6T
Hisense	HS-X8C	x8c	HS-X8C
Hisense	HS-X8T	X8T	HS-X8T
Hisense	HS-X8U	x8u	HS-X8U
Hisense	Hisense E360M	e360m	Hisense E360M
Hisense	Hisense E613M	E613M	Hisense E613M
Hisense	Hisense E620M	E602M	Hisense E602M
Hisense	Hisense E621T	E621T	Hisense E621T
Hisense	Hisense EG606	EG606_TW	EG606
Hisense	Hisense I631M	i631m	Hisense I631M

Supported Devices

Hisense	Hisense I632M	I632M	Hisense I632M
Hisense	Hisense I632T	I632T	Hisense I632T
Hisense	Hisense I639M	I639M	Hisense I639M
Hisense	Hisense I639T	I639T	Hisense I639T
Hisense	Hisense I639T	I639TA1	Hisense I639T
Hisense	Hisense TV	hisense_gx1200v	hisense_gx1200v
Hisense	I300T	I300T	Hisense I300T
Hisense	I630U	I630U	Hisense I630U
Hisense	K220_FHD	mst628	K220_FHD
Hisense	L691	I691	HS-L691
Hisense	L691	I691e_2	HS-L691
Hisense	LED32G180	hisenseLED32G180	LED32G180
Hisense	LED32K220	mst628	LED32K220
Hisense	LED32K280J3D	mt5880	LED32K280J3D
Hisense	LED32K360	mt5880	LED32K360
Hisense	LED32K360J	mt5880	LED32K360J
Hisense	LED32K360J3D	mt5880	LED32K360J3D
Hisense	LED32K360X3D	mt5880	LED32K360X3D
Hisense	LED32K370	mt5880	LED32K370
Hisense	LED32K600J	mt5880	LED32K600J
Hisense	LED32K600X3D	mt5880	LED32K600X3D
Hisense	LED32K610X3D	mt5880	LED32K610X3D
Hisense	LED32L288	mt5880	LED32L288
Hisense	LED39K280J3D	mt5880	LED39K280J3D
Hisense	LED39K360J	mt5880	LED39K360J
Hisense	LED39K360X3D	mt5880	LED39K360X3D
Hisense	LED39K600X3D	mt5880	LED39K600X3D
Hisense	LED39K600X3DU	mst901	LED39K600X3DU
Hisense	LED39K610X3D	mt5880	LED39K610X3D
Hisense	LED39K680X3DU	mt5327	LED39K680X3DU

Supported Devices

Hisense	LED40K260X3D	mt5880	LED40K260X3D
Hisense	LED40K360J	mt5880	LED40K360J
Hisense	LED40K360X3D	mt5880	LED40K360X3D
Hisense	LED40K370	mt5880	LED40K370
Hisense	LED40K681X3DU	msd6a918	LED40K681X3DU
Hisense	LED40L288	mt5880	LED40L288
Hisense	LED42G200	hisenseLED42G200	LED42G200
Hisense	LED42K280J3D	mt5880	LED42K280J3D
Hisense	LED42K330X3D	mt5880	LED42K330X3D
Hisense	LED42K360J	mt5880	LED42K360J
Hisense	LED42K360X3D	mt5880	LED42K360X3D
Hisense	LED42K370	mt5880	LED42K370
Hisense	LED42K380U	msd6a918	LED42K380U
Hisense	LED42K560X3D	hisenseLED42K560X3D	LED42K560X3D
Hisense	LED42K600A3D	mt5880	LED42K600A3D
Hisense	LED42K600X3D	mt5880	LED42K600X3D
Hisense	LED42K610J3DP	mt5880	LED42K610J3DP
Hisense	LED42K610X3D	mt5880	LED42K610X3D
Hisense	LED42K660X3D	hisenseLED42K660X3D	LED42K660X3D
Hisense	LED42K680X3DU	mt5327	LED42K680X3DU
Hisense	LED42L288	mt5880	LED42L288
Hisense	LED46K260X3D	mt5880	LED46K260X3D
Hisense	LED46K280J3D	mt5880	LED46K280J3D
Hisense	LED46K330X3D	mt5880	LED46K330X3D
Hisense	LED46K360J	mt5880	LED46K360J
Hisense	LED46K360X3D	mt5880	LED46K360X3D
Hisense	LED46K660X3D	hisense6a801	LED46K660X3D
Hisense	LED47K560J3D	hisenseLED47K560J3D	LED47K560J3D
Hisense	LED47K600X3D	mt5880	LED47K600X3D
Hisense	LED47K610J3DP	mt5880	LED47K610J3DP

Supported Devices

Hisense	LED48K360X3D	mt5880	LED48K360X3D
Hisense	LED48K370	mt5880	LED48K370
Hisense	LED48K380U	msd6a918	LED48K380U
Hisense	LED48K681X3DU	msd6a918	LED48K681X3DU
Hisense	LED48L288	mt5880	LED48L288
Hisense	LED50G05	hisenseLED50G05	LED50G05
Hisense	LED50K260X3D	mt5880	LED50K260X3D
Hisense	LED50K360J	mt5880	LED50K360J
Hisense	LED50K360X3D	mt5880	LED50K360X3D
Hisense	LED50K370	mt5880	LED50K370
Hisense	LED50K380U	msd6a918	LED50K380U
Hisense	LED50K610X3D	mt5880	LED50K610X3D
Hisense	LED50K660X3D	hisenseLED50K660X3D	LED50K660X3D
Hisense	LED50K680X3DU	mt5327	LED50K680X3DU
Hisense	LED50L288	mt5880	LED50L288
Hisense	LED50XT880G3D	hisenseLED50XT880G3D	LED50XT880G3D
Hisense	LED50XT880G3DU	mst901	LED50XT880G3DU
Hisense	LED50XT900X3DU	mt5327	LED50XT900X3DU
Hisense	LED55K260X3D	mt5880	LED55K260X3D
Hisense	LED55K360X3D	mt5880	Hisense LED55K360X3D
Hisense	LED55K370	mt5880	LED55K370
Hisense	LED55K380U	msd6a918	LED55K380U
Hisense	LED55K600A3D	mt5880	LED55K600A3D
Hisense	LED55K600X3D	mt5880	LED55K600X3D
Hisense	LED55K610X3D	mt5880	LED55K610X3D
Hisense	LED55K680X3DU	mt5327	LED55K680X3DU
Hisense	LED55L288	mt5880	LED55L288
Hisense	LED55XT780G3D	hisenseLED55XT780G3D	LED55XT780G3D
Hisense	LED55XT810X3DU	msd6a918	LED55XT810X3DU
Hisense	LED55XT880G3DU	mst901	LED55XT880G3DU

Supported Devices

Hisense	LED55XT900X3DU	mt5327	LED55XT900X3DU
Hisense	LED58K280J	mt5880	LED58K280J
Hisense	LED58K280U	mt5327	LED58K280U
Hisense	LED58K610X3D	mt5880	LED58K610X3D
Hisense	LED58K680X3DU	mt5327	LED58K680X3DU
Hisense	LED58XT880G3D	hisenseLED58XT880G3D	LED58XT880G3D
Hisense	LED58XT880J3DU	mst901	LED58XT880J3DU
Hisense	LED60K380	mt5327	LED60K380
Hisense	LED65K560J3DTB	hisenseLED65K560J3DTB	LED65K560J3DTB
Hisense	LED65K560J3DTR	hisenseLED65K560J3DTR	LED65K560J3DTR
Hisense	LED65K600X3D	mt5880	LED65K600X3D
Hisense	LED65K680X3DU	mt5327	LED65K680X3DU
Hisense	LED65XT780G3D	hisenseLED65XT780G3D	LED65XT780G3D
Hisense	LED65XT800X3DU	mt5327	LED65XT800X3DU
Hisense	LED65XT810X3DU	msd6a918	LED65XT810X3DU
Hisense	LED65XT880G3D	hisenseLED65XT880G3D	LED65XT880G3D
Hisense	LED65XT880G3DF	hisenseLED65XT880G3DF	LED65XT880G3DF
Hisense	LED65XT880G3DU	mst901	LED65XT880G3DU
Hisense	LED65XT890G3D	hisenseLED65XT890G3D	LED65XT890G3D
Hisense	LED65XT900G3DU	mst901	LED65XT900G3DU
Hisense	LED65XT900X3DU	mt5327	LED65XT900X3DU
Hisense	LED75XT890G3D	mst901	LED75XT890G3D
Hisense	LED75XT910G3DU	mt5327	LED75XT910G3DU
Hisense	LED84XT900G3D	hisenseLED84XT900G3D	LED84XT900G3D
Hisense	LED85XT910G3DU	mt5327	Vision20
Hisense	LT100K6900A	mt5327	LT100K6900A
Hisense	M3101BCD	m3101bcd	M3101BCD
Hisense	M470BSA	m470	M470BSA
Hisense	M470BSD	m470bsd	M470BSD
Hisense	M470BSE	m470bse	M470BSE

Supported Devices

Hisense	M470BSG	m470bsg	M470BSG
Hisense	M470BSS	m470bss	M470BSS
Hisense	M701	M701	M701
Hisense	MEDION E4001	E4001	MEDION E4001
Hisense	MEDION X4701	x4701	MEDION X4701
Hisense	Oysters Pacific 800	x4701ae	Oysters Pacific 800
Hisense	PX1900	atm7039c	PX1900
Hisense	PX2000	hisensepx2000	PX2000
Hisense	PX2700	g18ref	PX2700
Hisense	PX2800	hisensepx2800	PX2800
Hisense	PX3000	mt5880	Hisense PX3000
Hisense	PX3000	mt5880	PX3000
Hisense	PX3100	mt5880	PX3100
Hisense	SKi630t	msm8226	SKi630t
Hisense	Sero 7	rk3168	E2171CA
Hisense	Sero 7	rk3168	E2171MX
Hisense	Sero 7	rk3168	E2171TK
Hisense	Sero 8	rk3188	E2281
Hisense	Sero 8	rk3188	E2281CA
Hisense	Sero 8	rk3188	E2281TK
Hisense	Sero 8	rk3188	E2281UK
Hisense	Sero 8 pro	rk3288	F5281
Hisense	Sero7	rk3168	E2171SS
Hisense	Sero7 LE	rk3026	E2371
Hisense	Sero8	rk3188	E2281SS
Hisense	SoundTab MA-317	rk3028a	Hisense SoundTab MA-317
Hisense	U606AE	U606AE	HS-U606
Hisense	U606AE	U606AE	PHS-402
Hisense	U607	U607	Bouygues Telecom Bs 403
Hisense	U609	U609	HS-U609

Supported Devices

Hisense	U610	U610	HS-U610
Hisense	U966	u966e_1	U966
Hisense	U970	u970e_8	U970
Hisense	U988	U988	HS-U988
Hisense	U988E-1	U988E_1	HS-U988
Hisense	U988E-2	U988E_2	HS-U988
Hisense	Vidaa	helium3	H7
Hisense	Vision	Vision	Vision
Hisense	Vision 2.5	vision2_5	vision2_5
Hisense	W270BD	W270BD	W270BD
Hisense	WA912	U912ATW	WA912
Hisense	WA960	U960Q_1	WA960
Hisense	WM8	wm8980s	WM8
Hisense	XOLO	us9230e1	XOLO T1000
Hisense	I691	msm8226	HS-L691
Hisense	vision2_1	vision2_1	vision2_1
Hon Hai Precision Industry Co., Ltd.		EP10_wifi	PocketBook A10
Hon Hai Precision Industry Co., Ltd.		EP5A_wifi	PocketBook A7
Hon Hai Precision Industry Co., Ltd.	Germany	S9714	LIFETAB_S9714
Hon Hai Precision Industry Co., Ltd.	nabi_XD	XD	NABIXD-NV10C
Honda	A-DA	e1853	14A-DA
Honda	A-DA	e1853	MY15ADA
Honda	MY15ADA	koelsch	MY15ADA
Honeywell	Honeywell Dolphin 70e Black	dblack_gn	Dolphin 70e Black
Honeywell	Honeywell Dolphin 70e Black	dblack_go	Dolphin 70e Black
Honeywell	Honeywell Dolphin 70e Black	dblack_wn	Dolphin 70e Black
Honeywell	Honeywell Dolphin 70e Black	dblack_wo	Dolphin 70e Black
Huawei		C8600	C8600
Huawei		CHT8000	CHT8000
Huawei		HuaweiU8180	Huawei Ideos X1

Supported Devices

Huawei		HuaweiU8180	HuaweiU8180
Huawei		HuaweiU8180	IDEOS X1
Huawei		HuaweiU8180	Kyivstar Terra
Huawei		HuaweiU8180	Starshine
Huawei		HuaweiU8180	Stockholm
Huawei		HuaweiU8180	U8180
Huawei		Pulse	Pulse
Huawei		T8300	HUAWEI T8300
Huawei		T8600	HUAWEI T8600
Huawei		T8828	HUAWEI T8828
Huawei		U8110	EQ U8110
Huawei		U8110	Huawei
Huawei		U8110	Huawei U8110
Huawei		U8110	MTC_A
Huawei		U8110	Pulse Mini
Huawei		U8110	TSP21
Huawei		U8110	Turkcell T10
Huawei		U8110	U8110
Huawei		U8110	life:) Android
Huawei		U8300	U8300
Huawei		U8500	HUAWEI IDEOS U8500
Huawei		U8500	MTC_EVO
Huawei		dtab01	dtab01
Huawei		hwC8813Q	HUAWEI C8813Q
Huawei		hwC8860E	HUAWEI C8860E
Huawei		hwD2-2010	HUAWEI D2-2010
Huawei		hwG510-0200	HUAWEI Ascend G510
Huawei		hwG510-0200	HUAWEI G510-0200
Huawei		hwG510-0200	Orange Daytona
Huawei		hwG510-0251	HUAWEI G510-0251

Supported Devices

Huawei		hwG520-T10	HUAWEI G520-T10
Huawei		hwG525-U00	HUAWEI Ascend G525
Huawei		hwG525-U00	HUAWEI G525-U00
Huawei		hwS42HW	S42HW
Huawei		hwS7-901w	A01HW
Huawei		hwT8808D	HUAWEI T8808D
Huawei		hwT8830Pro	T8830Pro
Huawei		hwU9202L	U9202L-1
Huawei		hwU9202L	U9202L-3
Huawei		hwc8500	C8500
Huawei		hwc8511	C8511
Huawei		hwc8511	MTS-SP101
Huawei		hwc8512	C8512
Huawei		hwc8600	C8600
Huawei		hwc8650	C8650
Huawei		hwc8650e	HUAWEI C8650+
Huawei		hwc8655	HUAWEI C8655
Huawei		hwc8800	C8800
Huawei		hwc8800	MTS-SP140
Huawei		hwc8810	HUAWEI C8810
Huawei		hwc8812E	HUAWEI C8812E
Huawei		hwc8813	HUAWEI C8813
Huawei		hwc8825D	HUAWEI C8825D
Huawei		hwc8826D	HUAWEI C8826D
Huawei		hwc8850	HUAWEI-C8850
Huawei		hwc8860E	HUAWEI C8860E
Huawei		hwc8860V	C8860V
Huawei		hwc8950D	HUAWEI C8950D
Huawei		hwcm980	CM980
Huawei		hwes8100	ES8100

Supported Devices

Huawei		hwes8500	HuaweiES8500
Huawei		hwh866c	H866C
Huawei		hwh866c	HUAWEI H866C
Huawei		hwh867g	Huawei-H867G
Huawei		hwh868c	HUAWEI H868C
Huawei		hwh881c	HUAWEI H881C
Huawei		hwm650	Express
Huawei		hwm650	M650
Huawei		hwm660	M660
Huawei		hwm860	HUAWEI-M860
Huawei		hwm865c	M865C
Huawei		hwm866	HUAWEI M866
Huawei		hwm866	M866
Huawei		hwm866	USCCADR3310
Huawei		hwm886	M886
Huawei		hwm920	HUAWEI-M920
Huawei		hwm931	HUAWEI-M931
Huawei		hwmt1-u06	HUAWEI MT1-U06
Huawei		hwp2-0000	HUAWEI P2-0000
Huawei		hwp2-6011	HUAWEI P2-6011
Huawei		hwp2-6011	HUAWEI P2-6011-orange
Huawei		hws10101u	MediaPad 10 FHD
Huawei		hws10101w	GT01
Huawei		hws10101w	MediaPad 10 FHD
Huawei		hws10201u	MediaPad 10 LINK
Huawei		hws7300c	HUAWEI MediaPad
Huawei		hws7300u	HUAWEI MediaPad
Huawei		hws7300u	Huawei S7-312u
Huawei		hws7300u	MediaPad
Huawei		hws7300u	SpringBoard

Supported Devices

Huawei		hws7300w	HUAWEI MediaPad
Huawei		hws7930u	MediaPad 7 Lite
Huawei		hws7930w	MediaPad 7 Lite
Huawei		hwt8620	T8620
Huawei		hwt8830	T8830
Huawei		hwt8833	HUAWEI T8833
Huawei		hwt8950	HUAWEI T8950
Huawei		hwt8950N	HUAWEI T8950N
Huawei		hwt8951	HUAWEI T8951
Huawei		hwt9200	T9200
Huawei		hwt9510e	T9510E
Huawei		hwu8180	Netphone 501
Huawei		hwu8180	U8180
Huawei		hwu8185	U8185
Huawei		hwu8186	U8186
Huawei		hwu8230	U8230
Huawei		hwu8350	Barcelona
Huawei		hwu8350	GM FOX
Huawei		hwu8350	HuaweiU8350
Huawei		hwu8350	MTC Pro
Huawei		hwu8350	Personal U8350
Huawei		hwu8350	Temptation
Huawei		hwu8350	U8350
Huawei		hwu8350	U8350-51
Huawei		hwu8500	Grameenphone Crystal
Huawei		hwu8500	HUAWEI_IDEOS_U8500
Huawei		hwu8500	HuaweiU8500
Huawei		hwu8500	ICE
Huawei		hwu8500	MF8503
Huawei		hwu8500	MTC Evo

Supported Devices

Huawei		hwu8500	MegaFon U8500
Huawei		hwu8500	U8500
Huawei		hwu8510	Beeline_E500
Huawei		hwu8510	GM Ultimate Slim
Huawei		hwu8510	Huawei IDEOS X3
Huawei		hwu8510	HuaweiU8510
Huawei		hwu8510	MTC Bravo
Huawei		hwu8510	S41HW
Huawei		hwu8510	U8510
Huawei		hwu8520	U8520
Huawei		hwu8600	U8600
Huawei		hwu8650	HUAWEI SONIC
Huawei		hwu8650	HUAWEI_IDEOS_U8650
Huawei		hwu8650	HuaweiU8650
Huawei		hwu8650	Kyivstar Aqua
Huawei		hwu8650	MTC 955
Huawei		hwu8650	SONIC
Huawei		hwu8650	Turkcell T20
Huawei		hwu8650	U8650
Huawei		hwu8650	U8650-1
Huawei		hwu8651	Astro
Huawei		hwu8651	Prism
Huawei		hwu8651	U8651
Huawei		hwu8651	U8651T
Huawei		hwu8652	Huawei-U8652
Huawei		hwu8652	U8652
Huawei		hwu8652-51	U8652-51
Huawei		hwu8655	Etisalat
Huawei		hwu8655	HUAWEI IDEOS Y 200
Huawei		hwu8655	Personal U8655-51

Supported Devices

Huawei		hwu8655	STARTRAIL II
Huawei		hwu8655	U8655
Huawei		hwu8655	U8655-1
Huawei		hwu8655	U8655-51
Huawei		hwu8660	SONIC
Huawei		hwu8661	HUAWEI U8661
Huawei		hwu8665	Huawei-U8665
Huawei		hwu8666	MTC Fit
Huawei		hwu8666	U8666-1
Huawei		hwu8666	U8666-51
Huawei		hwu8666-51	U8666-51
Huawei		hwu8666e	HUAWEI U8666E
Huawei		hwu8666e	MegaFon SP-A3
Huawei		hwu8666e-51	HUAWEI U8666E
Huawei		hwu8666e-51	HUAWEI U8666E-51
Huawei		hwu8666n	HUAWEI U8666N
Huawei		hwu8667	U8667
Huawei		hwu8680	T-Mobile myTouch
Huawei		hwu8681	HUAWEI U8681
Huawei		hwu8730	T-Mobile myTouch Q
Huawei		hwu8800	IDEOS X5
Huawei		hwu8800	MTC Neo
Huawei		hwu8800	U8800
Huawei		hwu8800	Ucell
Huawei		hwu8800	u8800
Huawei		hwu8800-51	Huawei U8800-51
Huawei		hwu8800-51	IDEOS X5
Huawei		hwu8800-51	U8800
Huawei		hwu8800-51	U8800-51
Huawei		hwu8800Pro	HUAWEI_IDEOS_X5

Supported Devices

Huawei		hwu8800Pro	HuaweiU8800Pro
Huawei		hwu8800Pro	IDEOS X5
Huawei		hwu8800Pro	MTC Neo
Huawei		hwu8800Pro	RBM_HD
Huawei		hwu8800Pro	U8800 Pro
Huawei		hwu8800Pro	U8800Pro
Huawei		hwu8812D	U8812D
Huawei		hwu8815	HUAWEI Ascend G 300
Huawei		hwu8815	HUAWEI U8815
Huawei		hwu8815	HUAWEI_Ascend G 300
Huawei		hwu8815	Personal U8815-51
Huawei		hwu8815	U8815
Huawei		hwu8815	U8815-51
Huawei		hwu8815n	HUAWEI U8815N
Huawei		hwu8815n	U8815N
Huawei		hwu8816	MTC Viva
Huawei		hwu8816	U8816
Huawei		hwu8818	HUAWEI U8818
Huawei		hwu8818	U8818
Huawei		hwu8820	U8820
Huawei		hwu8825-1	Bs 401
Huawei		hwu8825-1	HUAWEI Ascend G 330
Huawei		hwu8825-1	HUAWEI U8825-1
Huawei		hwu8825D	HUAWEI U8825D
Huawei		hwu8832D	U8832D
Huawei		hwu8836D	U8836D
Huawei		hwu8850	007HW
Huawei		hwu8850	HUAWEI-U8850
Huawei		hwu8860	GS02
Huawei		hwu8860	HUAWEI_U8860

Supported Devices

Huawei		hwu8860	TURKCELL MaxiPRO5
Huawei		hwu8860	U8860
Huawei		hwu8860	U8860-51
Huawei		hwu8867Z	U8867Z
Huawei		hwu8950-1	HUAWEI U8950-1
Huawei		hwu8950-51	HUAWEI U8950-51
Huawei		hwu8950D	HUAWEI U8950D
Huawei		hwu8950N-1	HUAWEI U8950N-1
Huawei		hwu8950N-51	HUAWEI U8950N-51
Huawei		hwu9000	HUAWEI-U9000
Huawei		hwu9200	U9200
Huawei		hwu9200	U9200E
Huawei		hwu9200-92	GS03
Huawei		hwu9200-92	U9200
Huawei		hwu9200E	U9200E
Huawei		hwu9201L	201HW
Huawei		hwu9500	U9500E
Huawei		hwu9501L	HW-01E
Huawei		hwu9508	HUAWEI U9508
Huawei		hwu9510	HUAWEI U9510
Huawei		hwu9510	U9510
Huawei		hwu9510e	HUAWEI U9510E
Huawei		hwu9700L	GL07S
Huawei		hwum840	UM840
Huawei		hwy210-0010	HUAWEI Y210-0010
Huawei		hwy210-0100	HUAWEI Ascend Y 210
Huawei		hwy210-0100	HUAWEI Y210-0100
Huawei		hwy210-0151	HUAWEI Y210-0151
Huawei		hwy210-0200	HUAWEI Ascend Y 210D
Huawei		hwy210-0200	HUAWEI Asend Y 210D

Supported Devices

Huawei		hwy210-0200	HUAWEI Y210-0200
Huawei		hwy210-0200	Leopard MF808
Huawei		hwy210-0200	NATCOM N8302
Huawei		hwy210-0200	VIETTEL V8404
Huawei		hwy210-0251	HUAWEI Y210-0251
Huawei		hwy210-2010	HUAWEI Y210-2010
Huawei		hwy220t	HUAWEI Y 220T
Huawei		msm7201a	Pulse
Huawei		msm7201a	U8230
Huawei		msm7225	Beeline_E300
Huawei		msm7225	Grameenphone Crystal
Huawei		msm7225	HUAWEI IDEOS U8500
Huawei		msm7225	HUAWEI_IDEOS_U8500
Huawei		msm7225	Huawei
Huawei		msm7225	HuaweiU8300
Huawei		msm7225	Ideos
Huawei		msm7225	MTC Evo
Huawei		msm7225	Pulse Mini
Huawei		msm7225	RBM C
Huawei		msm7225	S31HW
Huawei		msm7225	Smile
Huawei		msm7225	Tactile internet
Huawei		msm7225	Turkcell T10
Huawei		msm7225	U8110
Huawei		msm7225	U8300
Huawei		msm7225	U8500
Huawei		msm7225	Vodafone 845
Huawei		msm7227	004HW
Huawei		msm7230	IDEOS X5
Huawei		msm7230	u8800

Supported Devices

Huawei		msm7625	C8600
Huawei		msm7625	HUAWEI-M860
Huawei		msm7625	Ideos
Huawei		msm7625	M860
Huawei		msm7625	U8180
Huawei		orinoquiac8688V	ORINOQUIA C8688V
Huawei		qsd8k_s7	HUAWEI-S7
Huawei		qsd8k_s7	IDEOS S7
Huawei		qsd8k_s7	Ideos S7
Huawei		qsd8k_s7	Oysters SmaKit S7
Huawei		qsd8k_s7	S7
Huawei		qsd8k_slim	IDEOS S7 Slim
Huawei		u8800	u8800
Huawei	A199	hwa199	HUAWEI A199
Huawei	Ascend D	hwu9500	U9500
Huawei	B199	hwB199	HUAWEI B199
Huawei	C8812	hwc8812	HUAWEI C8812
Huawei	C8813DQ	hwC8813DQ	HUAWEI C8813DQ
Huawei	C8815	hwC8815	HUAWEI C8815
Huawei	C8816	hwC8816	HUAWEI C8816
Huawei	C8816D	hwC8816D	HUAWEI C8816D
Huawei	C8817D	hwC8817D	C8817D
Huawei	C8817E	hwC8817E	HUAWEI C8817E
Huawei	C8817L	hwC8817L	HUAWEI C8817L
Huawei	CM990	hwCM990	CM990
Huawei	Che1-CL10	Che1	Che1-CL10
Huawei	Che1-CL20	Che1	Che1-CL20
Huawei	Che2-TL00	hwChe2	Che2-TL00
Huawei	Che2-TL00H	hwChe2	Che2-TL00H
Huawei	Che2-TL00M	hwChe2	Che2-TL00M

Supported Devices

Huawei	Che2-UL00	hwChe2	Che2-UL00
Huawei	D2	hwD2-6070	HUAWEI D2-6070
Huawei	G350	HWG350	HUAWEI G350-U20
Huawei	G350	hwg350	HUAWEI G350
Huawei	G350	hwg350	HUAWEI G350-U00
Huawei	G506	hwG506-U151	HUAWEI G506-U151
Huawei	G510	hwG510-0010	HUAWEI G510-0010
Huawei	G510	hwG510-0100	HUAWEI G510-0100
Huawei	G510	hwG510-0100	HuaweiG510-0100
Huawei	G510	hwG510-0100	HuaweiG510-0100-orange
Huawei	G520	hwG520-5000	HUAWEI G520-5000
Huawei	G521-L076	HWG521-L	HUAWEI G521-L076
Huawei	G521-L176	HWG521-L	HUAWEI G521-L176
Huawei	G526	hwG526-L11	G526-L11
Huawei	G526	hwG526-L22	G526-L22
Huawei	G526	hwG526-L33	G526-L33
Huawei	G527	hwG527-U081	G527-U081
Huawei	G535-L11	hwG535-L11	HUAWEI G535-L11
Huawei	G535-L11	hwG535-L11	Kestrel
Huawei	G535-L11	hwG535-L11	Orange Gova
Huawei	G535-L11	hwG535-L11	Speedsurfer
Huawei	G535-L11	hwG535-L11	Ultym5
Huawei	G6	hwG6-T00	HUAWEI G6-T00
Huawei	G6-C00	hwG6-C00	HUAWEI G6-C00
Huawei	G6-L11	hwG6-L11	HUAWEI G6-L11
Huawei	G6-L22	hwG6-L22	HUAWEI G6-L22
Huawei	G6-L33	hwG6-L33	HUAWEI G6-L33
Huawei	G6-U00	hwG6-U00	HUAWEI G6-U00
Huawei	G6-U10	hwG6-U10	HUAWEI G6-U10
Huawei	G6-U251	hwG6-U251	HUAWEI G6-U251

Supported Devices

Huawei	G6-U34	hwG6-U34	HUAWEI G6-U34
Huawei	G606	HWG606	HUAWEI G606-T00
Huawei	G610	hwG610-T00	HUAWEI G610-T00
Huawei	G610	hwG610-U00	G610-U00
Huawei	G610	hwG610-U00	HUAWEI G610-U00
Huawei	G610	hwG610-U30	HUAWEI G610-U30
Huawei	G610-T01	hwG610-T01	HUAWEI G610-T01
Huawei	G610-T11	hwG610-T11	HUAWEI G610-T11
Huawei	G610-U15	hwG610-U15	HUAWEI G610-U15
Huawei	G610-U20	hwG610-U20	HUAWEI G610-U20
Huawei	G610C	hwG610-C00	HUAWEI G610-C00
Huawei	G615-U10	hwG615-U10	G615-U10
Huawei	G615-U10	hwG615-U10	HUAWEI G615-U10
Huawei	G616-L076	HWG616-L	HUAWEI G616-L076
Huawei	G620-L72	hwG620-L72	HUAWEI G620-L72
Huawei	G620-L75	hwG620-L75	G620-L75
Huawei	G620S-L01	hwG620S-L01	G620S-L01
Huawei	G620S-L02	hwG620S-L02	G620S-L02
Huawei	G620S-L03	hwG620S-L03	G620S-L03
Huawei	G620S-L03	hwG620S-L03	HUAWEI G620
Huawei	G620S-L03	hwG620S-L03	Personal Huawei G620S
Huawei	G620S-UL00	hwG620S-UL00	G620S-UL00
Huawei	G621-TL00	hwG621-TL00	G621-TL00
Huawei	G621-TL00M	hwG621-TL00	G621-TL00M
Huawei	G628-TL00	HWG628-TL	HUAWEI G628-TL00
Huawei	G630-U00	hwG630-U00	HUAWEI G630-U00
Huawei	G630-U10	hwG630-U10	G630-U10
Huawei	G630-U20	hwG630-U20	G630-U20
Huawei	G630-U251	hwG630-U251	G630-U251
Huawei	G630-U251	hwG630-U251	HUAWEI G630-U251

Supported Devices

Huawei	G660-L075	hwG660-L075	HUAWEI G660-L075
Huawei	G7-L03	hwG7-L03	G7-L03
Huawei	G7-L03	hwG7-L03	HUAWEI G7
Huawei	G7-L03	hwG7-L03	HUAWEI G7-L03
Huawei	G7-TL00	hwG7-TL00	G7-TL00
Huawei	G7-TL00	hwG7-TL00	HUAWEI G7-TL00
Huawei	G700	hwG700-T00	HUAWEI G700-T00
Huawei	G700	hwG700-U00	HUAWEI G700-U00
Huawei	G700-T01	hwG700-T01	HUAWEI G700-T01
Huawei	G700-U10	hwG700-U10	HUAWEI G700-U10
Huawei	G700-U20	hwG700-U20	HUAWEI G700-U20
Huawei	G716	hwG716-L070	HUAWEI G716-L070
Huawei	G718	hwg718	HUAWEI G718
Huawei	G730	hwG730-C00	HUAWEI G730-C00
Huawei	G730	hwG730-T00	HUAWEI G730-T00
Huawei	G730	hwG730-U00	HUAWEI G730-U00
Huawei	G730-L075	hwG730-L075	HUAWEI G730-L075
Huawei	G730-U10	hwG730-U10	HUAWEI G730-U10
Huawei	G730-U251	hwG730-U251	HUAWEI G730-U251
Huawei	G730-U27	hwG730-U27	HUAWEI G730-U27
Huawei	G730-U30	hwG730-U30	HUAWEI G730-U30
Huawei	G740	hwG740-L00	G740-L00
Huawei	G740	hwG740-L00	Orange Yumo
Huawei	G750-T00	hwG750-T00	HUAWEI G750-T00
Huawei	G750-T01	hwG750-T01	HUAWEI G750-T01
Huawei	G750-T01M	hwG750-T01M	HUAWEI G750-T01M
Huawei	G750-T20	hwG750-T20	HUAWEI G750-T20
Huawei	G750-U10	hwG750-U10	HUAWEI G750-U10
Huawei	G7500	HWG7500	HUAWEI G7500
Huawei	Gran_Roraima	hws7721u	Orinoquia Gran Roraima + S7-722u

Supported Devices

Huawei	H30-C00	hwH30-C00	H30-C00
Huawei	H30-L01	hwH30	HONOR H30-L01
Huawei	H30-L01M	hwH30	HONOR H30-L01M
Huawei	H30-L02	hwH30	H30-L02
Huawei	H30-L02	hwH30	HONOR H30-L02
Huawei	H30-T00	hwH30-T00	H30-T00
Huawei	H60	hwH60	H60-L01
Huawei	H60-J1	hwH60	HW-H60-J1
Huawei	H60-L01	hwH60	H60-L01
Huawei	H60-L02	hwH60	H60-L02
Huawei	H60-L03	hwH60	H60-L03
Huawei	H60-L04	hwH60	H60-L04
Huawei	H60-L11	hwH60	H60-L11
Huawei	H60-L12	hwH60	H60-L12
Huawei	H60-L21	hwH60	H60-L21
Huawei	H60-L21	hwH60-L21	H60-L21
Huawei	H882L	hwh882l	H882L
Huawei	HUAWEI C199	hwC199	HUAWEI C199
Huawei	HUAWEI G630	hwG630-T00	HUAWEI G630-T00
Huawei	HUAWEI G7-L01	hwG7-L01	G7-L01
Huawei	HUAWEI G7-UL20	hwG7-UL20	HUAWEI G7-UL20
Huawei	HUAWEI H871G	hwh871g	HUAWEI H871G
Huawei	HUAWEI MT7-J1	hwmt7	HUAWEI MT7-J1
Huawei	HUAWEI MT7-L09	hwmt7	HUAWEI MT7-L09
Huawei	HUAWEI MediaPad 10 Link+	hws10231l	402HW
Huawei	HUAWEI MediaPad 10 Link+	hws10231l	MediaPad 10 Link+
Huawei	HUAWEI MediaPad 10 Link+	hws10231l	S10-232L
Huawei	HUAWEI MediaPad 10 Link+	hws10231l	SpeedTAB
Huawei	HUAWEI MediaPad 7 Youth2	hws7721u	MediaPad 7 Youth 2
Huawei	HUAWEI MediaPad 7 Youth2	hws7721u	S7-721u

Supported Devices

Huawei	HUAWEI MediaPad M1 8.0	hws8301l	403HW
Huawei	HUAWEI MediaPad M1 8.0	hws8301l	CNPC Security Pad S1
Huawei	HUAWEI MediaPad M1 8.0	hws8301l	MediaPad M1 8.0
Huawei	HUAWEI MediaPad M1 8.0	hws8301l	MediaPad M1 8.0 (LTE)
Huawei	HUAWEI MediaPad M1 8.0	hws8301l	MediaPad M1 8.0 (WIFI)
Huawei	HUAWEI MediaPad M1 8.0	hws8301l	S8-303L
Huawei	HUAWEI MediaPad M1 8.0	hws8301l	S8-306L
Huawei	HUAWEI MediaPad X1 7.0	hw7d501l	7D-501u
Huawei	HUAWEI MediaPad X1 7.0	hw7d501l	MediaPad X1
Huawei	HUAWEI MediaPad X1 7.0	hw7d501l	MediaPad X1 7.0
Huawei	HUAWEI MediaPad X1 7.0	hw7d501l	X1 7.0
Huawei	HUAWEI P6	hwp6-u06	HUAWEI Ascend P6
Huawei	HUAWEI P6	hwp6-u06	HUAWEI P6-U06
Huawei	HUAWEI P6	hwp6-u06	HUAWEI P6-U06-orange
Huawei	HUAWEI P7-L11	hwp7	HUAWEI P7-L11
Huawei	HUAWEI Y536-A1	hwY536A1	HUAWEI Y536A1
Huawei	HUAWEI Y610	HWY610-U	HUAWEI Y610-U00
Huawei	HUAWEI Y618	HWY618-T	HUAWEI Y618-T00
Huawei	HW-03E	HW-03E	HW-03E
Huawei	Hol-T00	HWHol-T	Hol-T00
Huawei	Hol-U10	HWHol-U	Hol-U10
Huawei	Hol-U19	HWHol-U	Hol-U19
Huawei	Honor3	hwH30-T10	H30-T10
Huawei	Honor3	hwH30-U10	H30-U10
Huawei	Honor3	hwHn3-u00	HUAWEI HN3-U00
Huawei	Honor3	hwHn3-u01	HUAWEI HN3-U01
Huawei	IDEOS	U8150	Comet
Huawei	IDEOS	U8150	Ideos
Huawei	IDEOS	u8150	Ideos
Huawei	Ice-Twist	Ice-Twist	Ice-Twist

Supported Devices

Huawei	M220	hwmediaqm220	M220
Huawei	M220	hwmediaqm220	M220c
Huawei	M310	hwsingleboxm310w	M310
Huawei	M620	M620	M620
Huawei	M620	M620	TB01
Huawei	M835	hwm835	HUAWEI-M835
Huawei	M860	M860	M860
Huawei	M865	hwm865	M865
Huawei	M865	hwm865	USCCADR3305
Huawei	M868	hwm868	HUAWEI M868
Huawei	MS4C	hwMS4C	MS4C
Huawei	MT2-L01	hwmt2-l01	HUAWEI MT2-L01
Huawei	MT2-L02	hwmt2-l02	HUAWEI MT2-L02
Huawei	MT2-L03	hwMT2L03	MT2L03
Huawei	MT2-L05	hwmt2-l05	HUAWEI MT2-L05
Huawei	MT2L03LITE	hwMT2L03LITE	MT2L03
Huawei	MT7-CL00	hwmt7	HUAWEI MT7-CL00
Huawei	MT7-TL00	hwmt7	HUAWEI MT7-TL00
Huawei	MT7-TL10	hwmt7	HUAWEI MT7-TL10
Huawei	MT7-UL00	hwmt7	HUAWEI MT7-UL00
Huawei	Mate	hwmt1-t00	HUAWEI MT1-T00
Huawei	Mate2	hwmt2-c00	HUAWEI MT2-C00
Huawei	MediaPad Vogue	hws7601u	MediaPad 7 Lite II
Huawei	MediaPad Vogue	hws7601u	MediaPad 7 Vogue
Huawei	MediaPad Youth	hws7701w	MediaPad 7 Youth
Huawei	MediaPad7	hws7601us	MediaPad 7 Vogue
Huawei	MediaPad7	hws7601w	MediaPad 7 Vogue
Huawei	P2	hwp2-6070	HUAWEI P2-6070
Huawei	P6	hwp6-c00	HUAWEI P6-C00
Huawei	P6	hwp6-t00	HUAWEI P6-T00

Supported Devices

Huawei	P6	hwp6-t00	HUAWEI P6-T00V
Huawei	P6S	hwP6s-l04	P6 S-L04
Huawei	P6S-L04	hwp6s-l04	302HW
Huawei	P6S-U06	hwp6s-u06	HUAWEI P6 S-U06
Huawei	P7 mini	hwP7Mini	HUAWEI P7 mini
Huawei	P7-L00	hwp7	HUAWEI P7-L00
Huawei	P7-L05	hwp7	HUAWEI P7-L05
Huawei	P7-L07	hwp7	HUAWEI P7-L07
Huawei	P7-L09	hwp7	HUAWEI P7-L09
Huawei	P7-L10	hwp7	HUAWEI P7-L10
Huawei	P7-L12	hwp7	HUAWEI P7-L12
Huawei	Prism II	hwu8686	Prism II
Huawei	S10	hws10103l	MediaPad 10 FHD
Huawei	S10	hws10201l	MediaPad 10 LINK
Huawei	S7	hws7601c	MediaPad 7 Vogue
Huawei	S7	hws7601w	MediaPad 7 Vogue
Huawei	S7	hws7701u	MediaPad 7 Youth
Huawei	S7	hws7930u	Orinoquia Roraima S7-932u
Huawei	S7	hws7951w	MediaPad 7 Lite+
Huawei	S7	hws7951w	Telpad Dual S
Huawei	S7	hws7961w	Telpad QS
Huawei	S7	hws7961w	Telpad Quad S
Huawei	SC-CL00	HWSC-CL00	HUAWEI SC-CL00
Huawei	T-Mobile Pulse	U8100	Huawei_8100-9
Huawei	T-Mobile Pulse	U8100	Tactile internet
Huawei	T-Mobile Pulse	U8100	U8100
Huawei	T-Mobile Pulse	U8100	Videocon_V7400
Huawei	T101	hwt101	T-101
Huawei	T101	hwt101	T101 PAD
Huawei	T102	hwt102	QH-10

Supported Devices

Huawei	T102	hwt102	T102 PAD
Huawei	T801	hwt801	T801 PAD
Huawei	T802	hwt802	MT-803G
Huawei	T802	hwt802	T802 PAD
Huawei	U8120	U8120	Vodafone 845
Huawei	U8220	U8220	Pulse
Huawei	U8220	U8220	U8220
Huawei	U8220	U8220	U8220PLUS
Huawei	U8230	U8230	U8230
Huawei	U8687	hwu8687	Huawei-U8687
Huawei	V858	hwu8160	Huawei 858
Huawei	V858	hwu8160	MTC 950
Huawei	V858	hwu8160	MTC Mini
Huawei	V858	hwu8160	Vodafone 858
Huawei	Vogue7	hws7601u	MediaPad 7 Classic
Huawei	Vogue7	hws7601u	MediaPad 7 Lite II
Huawei	Vogue7	hws7601u	MediaPad 7 Vogue
Huawei	Y210	oay210	Orinoquia Auyantepui Y210
Huawei	Y220	HWY220-U	Y220-U00
Huawei	Y220	HWY220-U	Y220-U05
Huawei	Y220	HWY220-U	Y220-U17
Huawei	Y220-T10	hwy220-t10	HUAWEI Y220-T10
Huawei	Y220-U10	HWY220-U	Y220-U10
Huawei	Y221-U03	HWY221-U	HUAWEI Y221-U03
Huawei	Y221-U12	HWY221-U	HUAWEI Y221-U12
Huawei	Y221-U22	HWY221-U	HUAWEI Y221-U22
Huawei	Y221-U33	HWY221-U	HUAWEI Y221-U33
Huawei	Y221-U43	HWY221-U	HUAWEI Y221-U43
Huawei	Y221-U53	HWY221-U	HUAWEI Y221-U53
Huawei	Y300	hwY300-0100	HUAWEI Ascend Y300

Supported Devices

Huawei	Y300	hwY300-0100	HUAWEI Y300-0100
Huawei	Y300	hwY300-0151	HUAWEI Y300-0151
Huawei	Y300	hwY300-0151	Pelephone-Y300-
Huawei	Y300-0000	hwY300-0000	HUAWEI Y300-0000
Huawei	Y301A1	hwY301A1	Huawei Y301A1
Huawei	Y301A2	hwY301A2	Huawei Y301A2
Huawei	Y320	hwy320-c00	HUAWEI Y320-C00
Huawei	Y320-T00	HWY320-T00	HUAWEI Y320-T00
Huawei	Y320-U01	HWY320	HUAWEI Y320-U01
Huawei	Y320-U01	HWY320	Y320-U01
Huawei	Y320-U10	HWY320-U	HUAWEI Y320-U10
Huawei	Y320-U151	HWY320-U	HUAWEI Y320-U151
Huawei	Y320-U30	HWY320-U	HUAWEI Y320-U30
Huawei	Y320-U351	HWY320-U	HUAWEI Y320-U351
Huawei	Y321	HWY321-U	HUAWEI Y321-U051
Huawei	Y321	hwy321-c00	HUAWEI Y321-C00
Huawei	Y325-T00	HWY325-T	HUAWEI Y325-T00
Huawei	Y330	hwY330-U05	Bucare Y330-U05
Huawei	Y330	hwY330-U05	HUAWEI Y330-U05
Huawei	Y330	hwY330-U21	HUAWEI Y330-U21
Huawei	Y330-C00	hwY330-C00	HUAWEI Y330-C00
Huawei	Y330-U01	hwY330-U01	HUAWEI Y330-U01
Huawei	Y330-U01	hwY330-U01	Luno
Huawei	Y330-U07	hwY330-U07	HUAWEI Y330-U07
Huawei	Y330-U08	hwY330-U08	HUAWEI Y330-U08
Huawei	Y330-U11	hwY330-U11	HUAWEI Y330-U11
Huawei	Y330-U11	hwY330-U11	V8510
Huawei	Y330-U15	hwY330-U15	HUAWEI Y330-U15
Huawei	Y330-U17	hwY330-U17	HUAWEI Y330-U17
Huawei	Y336-A1	hwY336-A1	HUAWEI Y336-A1

Supported Devices

Huawei	Y340-U081	hwY340-U081	Y340-U081
Huawei	Y511-T00	HWY511-T	HUAWEI Y511-T00
Huawei	Y511-T00	HWY511-T	Y511-T00
Huawei	Y511-U00	HWY511-U	Y511-U00
Huawei	Y511-U10	HWY511-U	HUAWEI Y511-U10
Huawei	Y511-U251	HWY511-U	HUAWEI Y511-U251
Huawei	Y511-U30	HWY511-U	HUAWEI Y511-U30
Huawei	Y511-U30	HWY511-U	VIETTEL V8506
Huawei	Y516-	HWY516-T	HUAWEI Y516-T00
Huawei	Y518-T00	HWY518-T	HUAWEI Y518-T00
Huawei	Y520-U03	HWY520-U	HUAWEI Y520-U03
Huawei	Y520-U12	HWY520-U	HUAWEI Y520-U12
Huawei	Y520-U22	HWY520-U	HUAWEI Y520-U22
Huawei	Y520-U33	HWY520-U	HUAWEI Y520-U33
Huawei	Y523-L076	HWY523	HUAWEI Y523-L076
Huawei	Y523-L176	HWY523	HUAWEI Y523-L176
Huawei	Y530	hwY530-U00	HUAWEI Y530-U00
Huawei	Y530-U051	hwY530-U051	HUAWEI Y530
Huawei	Y530-U051	hwY530-U051	HUAWEI Y530-U051
Huawei	Y535	HWY535-C00	HUAWEI Y535-C00
Huawei	Y535D-C00	HWY535D-C00	HUAWEI Y535D-C00
Huawei	Y540-U01	HWY540-U	HUAWEI Y540-U01
Huawei	Y550-L01	hwY550-L01	HUAWEI Y550-L01
Huawei	Y550-L02	hwY550-L02	HUAWEI Y550-L02
Huawei	Y550-L02	hwY550-L02	Y550-L02
Huawei	Y550-L03	hwY550-L03	HUAWEI Y550
Huawei	Y550-L03	hwY550-L03	HUAWEI Y550-L03
Huawei	Y550-L03	hwY550-L03	Personal Huawei Y550
Huawei	Y550-L03	hwY550-L03	Y550-L03
Huawei	Y600	HWY600-U	HUAWEI Y600-U00

Supported Devices

Huawei	Y600	HWY600-U	HUAWEI Y600-U151
Huawei	Y600	HWY600-U	HUAWEI Y600-U20
Huawei	Y600-U351	HWY600-U	HUAWEI Y600-U351
Huawei	Y600-U40	HWY600-U	HUAWEI Y600-U40
Huawei	Y600D-C00	HWY600D-C00	HUAWEI Y600D-C00
Huawei	Y625-U03	KVY625-U	Kavak Y625-U03
Huawei	Y625-U43	HWY625-U	HUAWEI Y625-U43
Huawei	Youth	hws7701u	Orinoquia Gran Roraima S7-702u
Huawei	eH811	hweH811	eH811
Huawei	hw204HW	hw204HW	204HW
Huawei	m881	hwm881	HUAWEI M881
Huawei	t1_8p0	hws8701	MediaPad T1 8.0
Huawei	t1_8p0	hws8701	S8-701u
Huawei	t1_8p0	hws8701	S8-701w
ICL-KME CS OJSC	TR10CD1	TR10CD1_7	TR10CD1
ICRAIG	ICRAIG CMP 756	Omega9	CMP 756
ICRAIG	ICRAIG CMP 759	Omega7	CMP 759
IDEA	i4901	i4901	i4901
INQ Mobile		camden	Camden
INQ Mobile		camden	INQ Cloud Touch
INQ Mobile		camden	INQ Cloud Touch -parrot
INQ Mobile		msm7627_surf	INQ Mayfair (EU)
IPRODA	T1144	T1144	T1144
Ice Phone	Ice Phone Mini	ice_phone_mini	Ice-Phone Mini
Impecca	ET7050D	ET7050D	ET7050D
Inet-Tablet	D711HC_PG	D711HC_PG	D711HC_PG
Inet-Tablet	D7911L3BC_OGS	D7911L3BC_OGS	D7911L3BC_OGS
Infinix	Infinix X505	X505	Infinix X505
Infinix	X405	up09_infinix_x405_gms	Infinix X405
Infocus	Amazing A8	D78	Amazing A8

Supported Devices

Infocus	CS1 8.0	cs180	CS180
Infocus	IN610	MG2	IN610
Infocus	IN810	VKY	IN810
Infocus	IN815	VK3	IN815
Infocus	InFocus FP-U320-INF-WLW	U320-WF	FP-U320-INF-WLW
Infocus	InFocus IN260	IN260	IN260
Infocus	InFocus IN335	IVM	IN335
Infocus	InFocus M2	LSO	InFocus M2
Infocus	InFocus M2+	LSC	InFocus M2PLUS
Infocus	InFocus M210	M210	M210
Infocus	InFocus M310	H1W	InFocus M310
Infocus	InFocus M320	M320	InFocus M320
Infocus	InFocus M320e	M320e	InFocus M320e
Infocus	InFocus M510t	TID	InFocus M510t
Infocus	InFocus M810	VNA	InFocus M810
Infocus	InFocus M810t	VNA	InFocus M810t
Infocus	InFocus NewTab F1	f1	NewTab F1
Infocus	Infocus M320e	M320e	InFocus M320e
Infocus	M210	M210	M210
Infocus	M2_3G	G10	InFocus M2_3G
Infocus	M310	H1W	InFocus M310
Infocus	M320	M320	InFocus M320
Infocus	M320e	M320e	InFocus M320e
Infocus	M320m	M320m	InFocus M320m
Infocus	M320u	M320	InFocus M320u
Infocus	M330	D77	InFocus M330
Infocus	M510	TID_CHT	M510
Infocus	M510t	TID	InFocus M510t
Infocus	M511	TID_CHT	M510
Infocus	M511	TID_TWN	M511

Supported Devices

Infocus	M512	MC2_CN	InFocus M512
Infocus	M512	MC2_CN	M512
Infocus	M518	MC2_APT	M518
Infocus	Smart503	MC2	Smart503
Infocus	T3000	P7M	T3000
Inhon	L55	L55	L55
Insignia	INSIGNIA FLEX 8\xe2\x80\x99\xe2\x80\x99 LTE Android Tablet	ns_15t8lte	NS-15T8LTE
Insignia	INSIGNIA NS-14T002	ns_14t002	NS-14T002
Insignia	Insignia Flex 10.1	ns_14t004	NS-14T004
Insignia	Insignia Flex 8"	ns_15at08	NS-15AT08
Insignia	NS-15AT07	NS-15AT07	NS-15AT07
Insignia	NS-15AT10	TA120	NS-15AT10
Intel		SP-A20i	SP-A20i
Intel		blackbay	Xolo_X900
Intel		noonhill	AZ210A
Intel		noonhill	AZ210B
Intel		noonhill	SP-A20i
Intel	AQ710A	Salitpa	AQ710A
Intel	Etisalat E-20	zeeyabeach	BT230
Intel	Orange San Diego	AZ210A	AZ210A
Intel	Orange avec Intel Inside	AZ210B	AZ210B
Intel	TR10CD1(PVT2)	TR10CD1_4	TR10CD1
Intel	TR10CD1(PVT2)	TR10CD1_6	TR10CD1
Intel	TR10CS1 (PVT2)	TR10CS1_4	TR10CS1
Intel	Xolo X500	zeeyabeach	Xolo_X500
Intel	Yolo	zeeyabeach	BT210
Intenso	Intenso Tab814S	Tab814S	Tab814S
Intenso	Tab734	Tab734	Tab734
Intermec	CN51	CN51_NC0	CN51 NC0

Supported Devices

Intermec	CN51	CN51_NCF	CN51 NCF
Intermec	CN51	CN51_NCU	CN51 NCU
Intermec	CN51	CN51_NN0	CN51 NN0
Intermec	CN51	CN51_QC0	CN51 QC0
Intermec	CN51	CN51_QCF	CN51 QCF
Intermec	CN51	CN51_QCU	CN51 QCU
Intermec	CN51	CN51_QN0	CN51 QN0
Itworks	TM705	TM705	NID_7010
JLab	JLab_PRO-7	polaris-p1gms	JLab PRO-7
JVC	DM65UXR\DM65USR\DM85UXR	mstarnapoli_atsc	DM65UXR
JVC KENWOOD Holdings, Inc.		gener	RY-AP1
K-Touch		whistler	W808
KAZAM	KAZAM TV 4.5	KOT49H	KAZAM TV 45
KAZAM	KAZAM TV 4.5	TV_45	KAZAM TV 45
KAZAM	KAZAM Thunder 345	Thunder_345	KAZAM Thunder 345
KAZAM	KAZAM Thunder 345 LTE	Thunder_345_LTE	KAZAM Thunder 345 LTE
KAZAM	KAZAM Thunder 345 LTE	Thunder_345_LTE	Thunder3 45 LTE
KAZAM	KAZAM Thunder 345L	Thunder_345L	KAZAM Thunder 345L
KAZAM	KAZAM Thunder 347	Thunder_347	Thunder 347
KAZAM	KAZAM Thunder 350L	Thunder_350L	KAZAM Thunder 350L
KAZAM	KAZAM Thunder2 45L	Thunder2_45	KAZAM THUNDER2 45L
KAZAM	KAZAM Thunder2 50	Thunder2_50	KAZAM Thunder2 50
KAZAM	KAZAM Tornado 348	Tornado_348	Tornado 348
KAZAM	KAZAM Tornado 350	KAZAM_Tornado_350	KAZAM Tornado 350
KAZAM	KAZAM Tornado2 50	Tornado2_50	KAZAM Tornado2 50
KAZAM	KAZAM Trooper 450	KAZAM_Trooper_450	KAZAM Trooper 450
KAZAM	KAZAM Trooper 451	Trooper_451	KAZAM Trooper 451
KAZAM	KAZAM Trooper2 40	Trooper2_40	KAZAM Trooper2 40
KAZAM	KAZAM Trooper2 45	Trooper2_45	Trooper2 45

Supported Devices

KAZAM	KAZAM Trooper2 50	Trooper2_50	KAZAM Trooper2 50
KAZAM	KAZAM Trooper2 60	Trooper2_60	Kazam Trooper2 60
KAZAM	TROOPER X3.5	KAZAM	Trooper_X35
KAZAM	TROOPER X4.0	KAZAM	Trooper_X40
KAZAM	TROOPER X5.5	KAZAM	Trooper_X55
KD Interactive	KD Interactive Kurio10S	C13300A	Kurio10S
KD Interactive	KD Interactive Kurio4S	C13200A	Kurio4S
KD Interactive	KD Interactive Kurio7S	C13000A	Kurio7S
KD Interactive	Kurio Phone	C14500	KurioPhone
KD Interactive	Kurio Tab - Extrem	g03k	C14100
KLIPAD	KLIPAD_SMART_D71	KLIPAD_SMART_D71	KLIPAD_SMART_D71
KLIPAD	KLIPAD_SMART_D791	KLIPAD_SMART_D791	KLIPAD_SMART_D791
KOOOK	C600	GBC_bravo	C600
KT Tech		s120	KM-S120
KT Tech		s200	KM-S200
KT Tech		s220	KM-S220
KT Tech		s220H	KM-S220H
KT Tech		s300	KM-S300
KT Tech		s330	KM-S330
KT Tech	EV-S100	s100	EV-S100
KT Tech	TAKE SUIT	e100	KM-E100
Karbons	Sparkle V	Sparkle_V_sprout	Sparkle V
Kennex	MD7053G	MD7053G	MD7053G
Ketablet	Ketablet	TR10CS1_6	TR10CS1
Kiano	Slim_Tab_8	Slim_Tab_8	Slim_Tab_8
Kobo	Arc 10HD	macallan	arc 10HD
Kobo	Arc 7	lbp8	arc 7
Kobo	Arc 7HD	cardhu	arc 7HD
Kobo	Kobo Arc	zeus	Arc
Kobo	Kobo Vox	pegasus	Vox

Supported Devices

Kodak	SP4	SP4	SP4
Kyocera		SCP-8600	Zio
Kyocera		WX06K	WX06K
Kyocera	Brigadier	E6782	E6782
Kyocera	DIGNO	KYI11	ISW11K
Kyocera	DIGNO	KYL22	KYL22
Kyocera	DIGNO Dual	WX04K	WX04K
Kyocera	DIGNO R	202K	202K
Kyocera	DIGNO S	KYL21	KYL21
Kyocera	DIGNO T	302KC	302KC
Kyocera	DM015K	DM015K	DM015K
Kyocera	DuraForce	E6560	KYOCERA-E6560
Kyocera	DuraForce	E6560C	E6560C
Kyocera	DuraForce	E6560L	E6560L
Kyocera	DuraForce	E6762	USCC-E6762
Kyocera	Echo	KSP8000	KSP8000
Kyocera	Echo	M9300	M9300
Kyocera	Event	C5133	Event
Kyocera	HONEY BEE	101K	101K
Kyocera	Honeybee Touch	201K	201K
Kyocera	Hydro	C5170	C5170
Kyocera	Hydro	C5171	Hydro
Kyocera	Hydro EDGE	C5215	C5215
Kyocera	Hydro Elite	C6750	C6750
Kyocera	Hydro ICON	C6730	C6730
Kyocera	Hydro LIFE	C6530	C6530
Kyocera	Hydro LIFE	C6530N	C6530N
Kyocera	Hydro PLUS	C5171R	Hydro
Kyocera	Hydro PLUS	C5171R	Hydro_PLUS
Kyocera	Hydro VIBE	C6725	C6725

Supported Devices

Kyocera	Hydro XTRM	C6522	C6522
Kyocera	Hydro XTRM	C6522N	C6522N
Kyocera	Hydro XTRM	C6721	USCC-C6721
Kyocera	KC-01	KC-01	KC-01
Kyocera	LUCE	KCP01K	KCP01K
Kyocera	Milano	C5120	C5120
Kyocera	Milano	C5121	C5121
Kyocera	Rise	C5155	C5155
Kyocera	Rise	C5156	Rise
Kyocera	TORQUE	SKT01	SKT01
Kyocera	TORQUE G01	KYY24	KYY24
Kyocera	Torque	E6710	Torque
Kyocera	TorqueXT	E6715	E6715
Kyocera	URBANO L01	KYY21	KYY21
Kyocera	URBANO L02	KYY22	KYY22
Kyocera	URBANO L03	KYY23	KYY23
Kyocera	URBANO PROGRESSO	KYY04	URBANO PROGRESSO
Kyocera	URBANO V01	KYV31	KYV31
Kyocera	WX10K	WX10K	WX10K
Kyocera	Zio	SCP-8600	Zio
Kyocera	miraie	KYL23	KYL23
Kyocera	zio	msm7627_kb60	Zio
Kyocera	zio	msm7627_surf	Zio
Kyocera	zio	pls8600	Zio
Kyowon	All&G PAD	mypad2	KA-E410W
LGE		AS855	LG-AS855
LGE		LGP970	LG-P970
LGE		US855	USCC-US855
LGE		alessi	LG-E720
LGE		alessi	LG-E720b

Supported Devices

LGE		alohag_302-220	LG-C710h
LGE		black	LG-KU5900
LGE		bproj_214-07	LG-P970
LGE		bproj_222-88	LG-P970
LGE		bproj_226-10	LG-P970
LGE		bproj_228-03	LG-P970
LGE		bproj_231-01	LG-P970
LGE		bproj_232-05	LG-P970
LGE		bproj_234-33	LG-P970
LGE		bproj_260-03	LG-P970
LGE		bproj_454-xxx	LG-P970
LGE		bproj_530-XXX	LG-P970
LGE		bproj_BAL-xxx	LG-P970
LGE		bproj_OPEN-CN	LG-P970
LGE		bproj_VDF-XXX	LG-P970
LGE		cosmo_268-06	LG-P920
LGE		cosmo_302-720	LG-P925g
LGE		cosmo_454-XXX	LG-P920
LGE		cosmo_466-92	LG-P920
LGE		cosmo_505-XXX	LG-P920
LGE		cosmo_515-XXX	LG-P920
LGE		cosmo_525-01	LG-P920
LGE		cosmo_525-05	LG-P920
LGE		cosmo_724-02	LG-P920h
LGE		cosmo_724-05	LG-P920h
LGE		cosmo_724-xxx	LG-P920h
LGE		cosmo_BAL-XXX	LG-P920
LGE		cosmo_CIS-XXX	LG-P920
LGE		cosmo_ESA-XXX	LG-P920
LGE		cosmo_H3G-XXX	LG-P920

Supported Devices

LGE		cosmo_MOR-XXX	LG-P920
LGE		cosmo_OPEN-CN	LG-P920
LGE		cosmo_OPT-XXX	LG-P920
LGE		cosmo_TMO-XXX	LG-P920
LGE		cosmo_VDF-XXX	LG-P920
LGE		cosmo_tcl-mx	LG-P920h
LGE		cosmo_viv-br	LG-P920h
LGE		cx2	LG-P720
LGE		cx2	LG-P720h
LGE		cx2	LG-P725
LGE		e510_724-XX	LG-E510f
LGE		envt2	USCC-US760
LGE		envt2	VS761
LGE		envt2	enV Pro
LGE		envt2	enV Touch2
LGE		gelato_262-xx	LG-P690
LGE		gelato_425-02	LG-P690f
LGE		gelato_460-xx	LG-P690
LGE		gelato_460-xx	LG-P693
LGE		gelato_are-xx	LG-P690
LGE		gelato_bal-xx	LG-P690
LGE		gelato_hkg-xx	LG-P690
LGE		gelato_mor-xx	LG-P690
LGE		gelato_nfc_234-10	LG-P692
LGE		gelato_nfc_530-24	LG-P692
LGE		gelato_nfc_tim-it	LG-P692
LGE		gelato_ngr-xx	LG-P690
LGE		gelato_sgp-xx	LG-P690
LGE		gelato_tmb-sk	LG-P690
LGE		gelato_tur-xx	LG-P690

Supported Devices

LGE		gelato_win-it	LG-P690
LGE		gelatods_bal-xxx	LG-P698
LGE		gelatods_ngr-xxx	LG-P698
LGE		gelatods_open-xx	LG-P698
LGE		gelatods_tha-xxx	LG-P698f
LGE		hub	LG-LU3000
LGE		ku9500	KU9500
LGE		l1e	LG-P875
LGE		l95g	LG-L95G
LGE		ls700	LG-LS700
LGE		lu2300	LU2300
LGE		lu3100	LG-LU3100
LGE		msm8660_surf	LG-LU6200
LGE		p2	LG-P940h
LGE		p925g	LG-P925g
LGE		p940	LG-P940
LGE		p990_208-10	LG-P990
LGE		p990_214-01	LG-P990
LGE		p990_219-10	LG-P990
LGE		p990_226-01	LG-P990
LGE		p990_228-01	LG-P990
LGE		p990_234-xx	LG-P990
LGE		p990_262-02	LG-P990
LGE		p990_454-xxx	LG-P990
LGE		p990_466-92	LG-P990
LGE		p990_466-xxx	LG-P990
LGE		p990_505-xxx	LG-P990
LGE		p990_525-01	LG-P990
LGE		p990_525-05	LG-P990
LGE		p990_BAL-xxx	LG-P990

Supported Devices

LGE		p990_esa-xxx	LG-P990
LGE		p990h	LG-P990h
LGE		p990h_334-020	LG-P990h
LGE		p990h_716-10	LG-P990h
LGE		p990h_722-34	LG-P990h
LGE		p990h_724-05	LG-P990h
LGE		p990h_730-01	LG-P990h
LGE		p990h_730-03	LG-P990h
LGE		p990h_CTM-xxx	LG-P990h
LGE		p990h_SSV-xxx	LG-P990h
LGE		p993	LG-P993
LGE		star	LG-P990hN
LGE		univa_228-01	LG-E510
LGE		univa_454-xx	LG-E510
LGE		univa_525-01	LG-E510
LGE		univa_525-05	LG-E510
LGE		univa_722-34	LG-E510g
LGE		univa_bal-xxx	LG-E510
LGE		univa_neu-xx	LG-E510
LGE		univa_open_cn	LG-E510
LGE		univa_tha-xx	LG-E510f
LGE		univa_tmo-gr	LG-E510
LGE		univa_vdf-es	LG-E510
LGE		v900aus	LG-V900
LGE		v901twm	LG-V901
LGE		x2_450-08	LG-KU8800
LGE		x3	LG-P880
LGE	070 touch	w3voip	LG-FL40L
LGE	Ally	aloha	AS740
LGE	Ally	aloha	Ally

Supported Devices

LGE	Ally	aloha	Aloha
LGE	Ally	aloha	US740
LGE	Android TV	cosmo	LG Google TV
LGE	Android TV	eden	LG Android TV V4
LGE	Android TV	eden	LG Google TV G3 KR
LGE	Android TV G3	eden	LG Google TV G3
LGE	Enact	fx3q	VS890 4G
LGE	Escape	l1a	LG-P870
LGE	Eve	EVE	GW620
LGE	Eve	EVE	LG GW620
LGE	Eve	EVE	LG GW620F
LGE	Eve	EVE	LG GW620R
LGE	Eve	EVE	LG GW620g
LGE	Eve	EVE	LG KH5200
LGE	Eve	EVE	LG-GW620
LGE	Eve	EVE	LG-KH5200
LGE	F60	e2	LG-D390
LGE	F60	e2	LG-D390AR
LGE	F60	e2ds	LG-D392
LGE	F60	e2n	LG-D390n
LGE	F60	e2nac	LG-D393
LGE	F60	e2nam	LGMS395
LGE	F60	e2nas	LGLS660
LGE	F60	e2nav	VS810PP
LGE	G Pad 10.1	e9wifi	LG-V700
LGE	G Pad 10.1	e9wifin	LG-V700n
LGE	G Pad 10.1 LTE	e9lte	LG-VK700
LGE	G Pad 10.1 LTE	e9lte	VK700
LGE	G Pad 7.0	e7wifi	LG-V400
LGE	G Pad 7.0	e7wifi	LG-V400Y1

Supported Devices

LGE	G Pad 7.0 LTE	e7lte	LG-V410
LGE	G Pad 7.0 LTE	e7lte	LGUK410
LGE	G Pad 8.0	e8wifi	LG-V480
LGE	G Pro Lite	luv90ds	LG-D685
LGE	G Pro Lite	luv90ds	LG-D686
LGE	G Pro Lite	luv90nfc	LG-D683
LGE	G Pro Lite	luv90nfc	LG-D684
LGE	G Pro Lite	luv90ss	LG-D680
LGE	G Pro Lite	luv90ss	LG-D681
LGE	G Pro Lite	luv90ss	LG-D682
LGE	G Pro Lite	luv90ss	LG-D682TR
LGE	G Pro2	b1	LG-F350K
LGE	G Pro2	b1	LG-F350L
LGE	G Pro2	b1	LG-F350S
LGE	G Pro2	b1w	LG-D838
LGE	G Vista	b2l	LG-D631
LGE	G Vista	b2lds	LG-D690
LGE	G Vista	x10	VS880
LGE	G Watch	dory	G Watch
LGE	G pad 8.0	e8wifi	LG-V480
LGE	G pad 8.0 LTE	e8lte	LG-V490
LGE	G2 MINI	g2m	LG-D620
LGE	G2 MINI	g2mds	LG-D618
LGE	G2 MINI	g2mss	LG-D610
LGE	G2 MINI	g2mss	LG-D610AR
LGE	G2 MINI	g2mss	LG-D610TR
LGE	G2 MINI	g2mv	LG-D625
LGE	G2 mini 4G LTE	g2mv	LG-D625
LGE	G3 Beat	jagdsnm	LG-D726
LGE	G3 Beat	jagdsnm	LG-D728

Supported Devices

LGE	G3 Beat	jagdsnm	LG-D729
LGE	G3 Beat	jagn	LG-F470K
LGE	G3 Beat	jagn	LG-F470L
LGE	G3 Beat	jagn	LG-F470S
LGE	G3 Beat	jagnm	LG-D722J
LGE	G3 S	jag3gds	LG-D724
LGE	G3 S	jag3gss	LG-D723
LGE	G3 S	jagnm	LG-D722
LGE	G3 S	jagnm	LG-D722AR
LGE	G3 S	jagnm	LG-D725PR
LGE	G3 Screen	liger	LG-F490L
LGE	G3 Stylus	b2ldsn	LG-D690n
LGE	G3 Stylus	b2lss	LG-D693
LGE	G3 Stylus	b2lss	LG-D693AR
LGE	G3 Stylus	b2lss	LG-D693TR
LGE	G3 Stylus	b2lssn	LG-D693n
LGE	G3 Vigor	jagc	LGLS885
LGE	G3 Vigor	jagnm	LG-D725
LGE	GA7800	eden	LG Android TV V4
LGE	GPAD 7.0 LTE	e7lte	VK410
LGE	Gpad 7.0	e7wifi	LG-V400
LGE	Gx2	b2ln	LG-F430L
LGE	Intuition	batman_vzw	VS950 4G
LGE	L Bello	luv80ds	LG-D335
LGE	L Bello	luv80ds	LG-D335E
LGE	L Bello	luv80ds	LG-D337
LGE	L Fino	l70p	LG-D290
LGE	L Fino	l70p	LG-D290AR
LGE	L Fino	l70pds	LG-D295
LGE	L Fino	l70pn	LG-D290

Supported Devices

LGE	L-01F	g2	L-01F
LGE	L20	luv20ds	LG-D105
LGE	L20	luv20ss	LG-D100
LGE	L20	luv20ss	LG-D100AR
LGE	L20	luv20ts	LG-D107
LGE	L30 Sporty	luv30ds	LG-D125
LGE	L30 Sporty	luv30ss	LG-D120
LGE	L30 Sporty	luv30ss	LG-D120AR
LGE	L45	lo_2	LG-X130g
LGE	L45	lo_2_ds	LG-X132
LGE	L50 Sporty	luv50ds	LG-D221
LGE	L50 Sporty	luv50ds	LG-D227
LGE	L50 Sporty	luv50ss	LG-D213
LGE	L50 Sporty	luv50ss	LG-D213AR
LGE	L50 Sporty	luv50ssn	LG-D213
LGE	L60	lo_1	LG-X135
LGE	L60	lo_1	LG-X137
LGE	L60	lo_1	LG-X140
LGE	L60	lo_1	LG-X145
LGE	L60	lo_1	LG-X147
LGE	L65	w55	LG-D280
LGE	L65	w55ds	LG-D285
LGE	L65	w55n	LG-D280
LGE	L7 II	vee7e	LG-P712
LGE	L7 II	vee7e	LG-P714
LGE	L7 II Dual	vee7ds	LG-P716
LGE	L70	w5	LG-D320
LGE	L70	w5	LG-D320AR
LGE	L70	w5	LGAS323
LGE	L70	w5c	LGLS620

Supported Devices

LGE	L70	w5ds	LG-D325
LGE	L70	w5n	LG-D320
LGE	L70	w5n	LG-D329
LGE	L70	w5ts	LG-D340f8
LGE	L70 CDMA	w5c	LGL41C
LGE	L90	w7	LG-D400
LGE	L90	w7	LG-D405
LGE	L90	w7	LG-D415
LGE	L90	w7ds	LG-D410
LGE	L90	w7n	LG-D400
LGE	L90	w7n	LG-D405
LGE	L90 Dual	w7dsn	LG-D410
LGE	LBello	luv80ss	LG-D331
LGE	LBello	luv80ss	LG-D331AR
LGE	LG Connect 4G	cayman	LG-MS840
LGE	LG DOUBLEPLAY	lgc729	LG-C729
LGE	LG Enlighten	VS700	LG-VS700
LGE	LG Enlighten	VS700	LG-VS700PP
LGE	LG Esteem	MS910	LG-MS910
LGE	LG F70	f70	LGL31L
LGE	LG F70	f70n	LG-D315
LGE	LG F70	f70n	LG-D315I
LGE	LG F70	f70n	LG-F370K
LGE	LG F70	f70n	LG-F370L
LGE	LG F70	f70n	LG-F370S
LGE	LG G Flex	zee	LG-D950
LGE	LG G Flex	zee	LG-D950G
LGE	LG G Flex	zee	LG-D951
LGE	LG G Flex	zee	LG-D955
LGE	LG G Flex	zee	LG-D956

Supported Devices

LGE	LG G Flex	zee	LG-D958
LGE	LG G Flex	zee	LG-D959
LGE	LG G Flex	zee	LG-F340K
LGE	LG G Flex	zee	LG-F340L
LGE	LG G Flex	zee	LG-F340S
LGE	LG G Flex	zee	LG-LS995
LGE	LG G Flex	zee	LGL23
LGE	LG G Pad 8.0 LTE	e8lte	LG-P490L
LGE	LG G Pad 8.3	awifi	LG-V500
LGE	LG G Pad 8.3 Google Play Edition	palman	LG-V510
LGE	LG G Pad 8.3 LTE	altev	VK810 4G
LGE	LG G Pad 8.3 homeBoy	awifi070u	LG-V507L
LGE	LG G2	g2	LG-D800
LGE	LG G2	g2	LG-D801
LGE	LG G2	g2	LG-D802
LGE	LG G2	g2	LG-D802T
LGE	LG G2	g2	LG-D802TR
LGE	LG G2	g2	LG-D803
LGE	LG G2	g2	LG-D805
LGE	LG G2	g2	LG-D806
LGE	LG G2	g2	LG-F320K
LGE	LG G2	g2	LG-F320L
LGE	LG G2	g2	LG-F320S
LGE	LG G2	g2	LG-LS980
LGE	LG G2	g2	VS980 4G
LGE	LG G3	g3	AS985
LGE	LG G3	g3	LG-AS990
LGE	LG G3	g3	LG-D850
LGE	LG G3	g3	LG-D851
LGE	LG G3	g3	LG-D852

Supported Devices

LGE	LG G3	g3	LG-D852G
LGE	LG G3	g3	LG-D855
LGE	LG G3	g3	LG-D856
LGE	LG G3	g3	LG-D857
LGE	LG G3	g3	LG-D858
LGE	LG G3	g3	LG-D858HK
LGE	LG G3	g3	LG-D859
LGE	LG G3	g3	LG-F400K
LGE	LG G3	g3	LG-F400L
LGE	LG G3	g3	LG-F400S
LGE	LG G3	g3	LGL24
LGE	LG G3	g3	LGLS990
LGE	LG G3	g3	LGUS990
LGE	LG G3	g3	LGV31
LGE	LG G3	g3	VS985 4G
LGE	LG G3 A	tigers	LG-F410S
LGE	LG G3 Cat.6	tiger6	LG-F460K
LGE	LG G3 Cat.6	tiger6	LG-F460L
LGE	LG G3 Cat.6	tiger6	LG-F460S
LGE	LG Gx	omega	LG-F310L
LGE	LG Gx	omegar	LG-F310LR
LGE	LG L39C	l4ij_cdma	LGL39C
LGE	LG L80 Dual	w6ds	LG-D380
LGE	LG L80 Dual	w6ds	LG-D385
LGE	LG L80 Single	w6	LG-D370
LGE	LG L80 Single	w6	LG-D373
LGE	LG L80 Single	w6	LG-D375
LGE	LG L80 Single	w6	LG-D375AR
LGE	LG Lucid	cayman	VS840 4G
LGE	LG Lucid	cayman	VS840PP

Supported Devices

LGE	LG Lucid 2	l1v	VS870 4G
LGE	LG Lucid 3	x5	VS876
LGE	LG Mach	l2s	LG-LS860
LGE	LG Motion 4G	l0	LG-MS770
LGE	LG OPTIMUS M+	m3_mpcs_us	LG-MS695
LGE	LG OPTIMUS ZIP	lg175c	LGL75C
LGE	LG Optimus 3D	cosmopolitan	LG-P920
LGE	LG Optimus 3D	cosmopolitan	LG-P925g
LGE	LG Optimus 3D	cosmopolitan	LG-SU760
LGE	LG Optimus ELITE	m3s	LG-VM696
LGE	LG Optimus Elite	m3s	LG Optimus Elite
LGE	LG Optimus Elite	m3s	LG-LS696
LGE	LG Optimus F3Q	fx3q	LG-D520
LGE	LG Optimus F7	fx1	LG-AS780
LGE	LG Optimus F7	fx1	LG-LG870
LGE	LG Optimus F7	fx1	LG-US780
LGE	LG Optimus G	geeb	LG-E970
LGE	LG Optimus G	geeb	LG-E971
LGE	LG Optimus G	geeb	LG-E973
LGE	LG Optimus G	geehdc	L-01E
LGE	LG Optimus G	geehdc	LGL21
LGE	LG Optimus G	geehrc	LG-E975
LGE	LG Optimus G	geehrc	LG-E975K
LGE	LG Optimus G	geehrc	LG-E975T
LGE	LG Optimus G	geehrc	LG-E976
LGE	LG Optimus G	geehrc	LG-E977
LGE	LG Optimus G	geehrc	LG-E987
LGE	LG Optimus G	geehrc	LG-F180K
LGE	LG Optimus G	geehrc	LG-F180S
LGE	LG Optimus G	geehrc4g	LG-F180L

Supported Devices

LGE	LG Optimus G	geehrc4g	LG-LS970
LGE	LG Optimus G Pro	geefhd	LG-E980
LGE	LG Optimus G Pro	geefhd	LG-E980h
LGE	LG Optimus G Pro	geefhd	LG-E981h
LGE	LG Optimus G Pro	geefhd	LG-E986
LGE	LG Optimus G Pro	geefhd	LG-E988
LGE	LG Optimus G Pro	geefhd	LG-E989
LGE	LG Optimus G Pro	geefhd	LG-F240K
LGE	LG Optimus G Pro	geefhd	LG-F240S
LGE	LG Optimus G Pro	geefhd4g	LG-F240L
LGE	LG Optimus HUB	univa_222-01	LG-E510
LGE	LG Optimus HUB	univa_arb-xx	LG-E510
LGE	LG Optimus HUB	univa_cis-xxx	LG-E510
LGE	LG Optimus HUB	univa_esa-xx	LG-E510
LGE	LG Optimus HUB	univa_eur-xx	LG-E510
LGE	LG Optimus HUB	univa_open-eu	LG-E510
LGE	LG Optimus HUB	univa_tur-xx	LG-E510
LGE	LG Optimus L1II	v1	LG-E410
LGE	LG Optimus L1II	v1	LG-E410B
LGE	LG Optimus L1II	v1	LG-E410c
LGE	LG Optimus L1II	v1	LG-E410f
LGE	LG Optimus L1II	v1	LG-E410g
LGE	LG Optimus L1II	v1	LG-E410i
LGE	LG Optimus L1II	v1	LG-E411f
LGE	LG Optimus L1II	v1	LG-E411g
LGE	LG Optimus L1II	v1ds	LG-E415f
LGE	LG Optimus L1II	v1ds	LG-E415g
LGE	LG Optimus L1II	v1ds	LG-E420
LGE	LG Optimus L1II	v1ds	LG-E420f
LGE	LG Optimus L1II	v1ts	LG-E475f

Supported Devices

LGE	LG Optimus L3	e0	LG-E400
LGE	LG Optimus L3	e0	LG-E400R
LGE	LG Optimus L3	e0	LG-E400b
LGE	LG Optimus L3	e0	LG-E400f
LGE	LG Optimus L3	e0	LG-E400g
LGE	LG Optimus L3	e0	LG-L38C
LGE	LG Optimus L3	e0	LGL35G
LGE	LG Optimus L3	e0_open_eur	LG-E400
LGE	LG Optimus L3 Dual	e1	LG-E405
LGE	LG Optimus L3 Dual	e1	LG-E405f
LGE	LG Optimus L3 II	vee3ds	LG-E435
LGE	LG Optimus L3 II	vee3ds	LG-E435f
LGE	LG Optimus L3 II	vee3ds	LG-E435g
LGE	LG Optimus L3 II	vee3ds	LG-E435k
LGE	LG Optimus L3 II	vee3e	LG-E425
LGE	LG Optimus L3 II	vee3e	LG-E425c
LGE	LG Optimus L3 II	vee3e	LG-E425f
LGE	LG Optimus L3 II	vee3e	LG-E425g
LGE	LG Optimus L3 II	vee3e	LG-E425j
LGE	LG Optimus L3 II	vee3e	LG-E430
LGE	LG Optimus L3 II	vee3e	LG-E431g
LGE	LG Optimus L4 II	vee4ss	LG-E440
LGE	LG Optimus L4 II	vee4ss	LG-E440f
LGE	LG Optimus L4 II	vee4ss	LG-E440g
LGE	LG Optimus L4 II	vee4ss	LG-E465f
LGE	LG Optimus L4 II	vee4ss	LG-E465g
LGE	LG Optimus L4 II Dual	vee4ds	LG-E445
LGE	LG Optimus L4 II Dual	vee4ds	LG-E467f
LGE	LG Optimus L4 II Tri	vee4ts	LG-E470f
LGE	LG Optimus L5 Dual	m4ds	LG-E615

Supported Devices

LGE	LG Optimus L5 Dual	m4ds	LG-E615f
LGE	LG Optimus L5 II	vee5ds	LG-E455
LGE	LG Optimus L5 II	vee5ds	LG-E455f
LGE	LG Optimus L5 II	vee5ds	LG-E455g
LGE	LG Optimus L5 II	vee5nfc	LG-E460
LGE	LG Optimus L5 II	vee5nfc	LG-E460f
LGE	LG Optimus L5 II	vee5ss	LG-E450
LGE	LG Optimus L5 II	vee5ss	LG-E450B
LGE	LG Optimus L5 II	vee5ss	LG-E450f
LGE	LG Optimus L5 II	vee5ss	LG-E450g
LGE	LG Optimus L5 II	vee5ss	LG-E450j
LGE	LG Optimus L5 II	vee5ss	LG-E451g
LGE	LG Optimus L5 II	vee5ss	LG-E460
LGE	LG Optimus L7	u0	LG-P700
LGE	LG Optimus L7	u0	LG-P705
LGE	LG Optimus L7	u0	LG-P705f
LGE	LG Optimus L7	u0	LG-P705g
LGE	LG Optimus L7	u0	LG-P708g
LGE	LG Optimus L7	u0	LG-T280
LGE	LG Optimus L7	u0	LGL96G
LGE	LG Optimus L7	vee7ds	LG-P715
LGE	LG Optimus L7 II	vee7e	LG-P710
LGE	LG Optimus L7 II	vee7e	LG-P712
LGE	LG Optimus L7 II	vee7e	LG-P713
LGE	LG Optimus L7 II	vee7e	LG-P713GO
LGE	LG Optimus L7 II	vee7e	LG-P713TR
LGE	LG Optimus L7 II	vee7e	LG-P714
LGE	LG Optimus L70	w5	LG-D321
LGE	LG Optimus L70	w5	LGMS323
LGE	LG Optimus L7II	vee7ds	LG-P715

Supported Devices

LGE	LG Optimus L7II	vee7ds	LG-P716
LGE	LG Optimus L9	u2	LG-D700
LGE	LG Optimus L9	u2	LG-P760
LGE	LG Optimus L9	u2	LG-P765
LGE	LG Optimus L9	u2	LG-P768
LGE	LG Optimus L9	u2	LG-P769
LGE	LG Optimus L9	u2	LG-P778
LGE	LG Optimus L9	u2	LGMS769
LGE	LG Optimus L9 (NFC)	u2	LG-P760
LGE	LG Optimus L9 II	I9ii	LG-D605
LGE	LG Optimus LTE Tag	cayman	LG-AS840
LGE	LG Optimus LTE Tag	cayman	LG-F120K
LGE	LG Optimus LTE Tag	cayman	LG-F120L
LGE	LG Optimus LTE Tag	cayman	LG-F120S
LGE	LG Optimus LTE Tag	lge_120_kt	LG-F120K
LGE	LG Optimus LTE Tag	lge_120_skt	LG-F120S
LGE	LG Optimus LTE3	fx1sk	LG-F260S
LGE	LG Optimus One	thunderg	LG-P500
LGE	LG Optimus One	thunderg	LG-P500h
LGE	LG Optimus One	thunderg	LG-P503
LGE	LG Optimus One	thunderg	LG-P504
LGE	LG Optimus One	thunderg	LG-P505
LGE	LG Optimus One	thunderg	LG-P505CH
LGE	LG Optimus One	thunderg	LG-P505R
LGE	LG Optimus One	thunderg	LG-P506
LGE	LG Optimus One	thunderg	LG-P509
LGE	LG Optimus Regard	I0	LG-LW770
LGE	LG Optimus Select	u0_cdma	LG-AS730
LGE	LG Optimus Zone 2	w3c	VS415PP
LGE	LG Pecan	pecan	LG-P350

Supported Devices

LGE	LG Pecan	pecan	LG-P350f
LGE	LG Pecan	pecan	LG-P350g
LGE	LG Revolution	bryce	VS910 4G
LGE	LG Spectrum	VS920	VS920 4G
LGE	LG Thrill 4G	cosmopolitan	LG-P925
LGE	LG Venice	u0_cdma	LG-LG730
LGE	LG Viper 4G LTE	cayman	LG-LS840
LGE	LG Volt	x5	LGLS740
LGE	LG optimus LTE2	d1lkt	LG-F160K
LGE	LG optimus LTE2	d1lsk	LG-F160S
LGE	LG optimus LTE2	d1lu	LG-F160L
LGE	LG optimus LTE2	d1lu	LG-F160LV
LGE	LG optimus it L-05D	l_dcm	L-05D
LGE	LG optimus it L-05E	L05E	L-05E
LGE	LG-AS876	x5	AS876
LGE	LG-D150	w35	LG-D150
LGE	LG-D157f	w35ds	LG-D157f
LGE	LG-E985T	gvarfhd	LG-E985
LGE	LG-E985T	gvarfhd	LG-E985T
LGE	LGL22	g2	LGL22
LGE	Marquee	L-07C	L-07C
LGE	Marquee	LG855	LG-LG855
LGE	Marquee	LS855	LG-LS855
LGE	Marquee	bproj_CIS-xxx	LG-P970
LGE	My touch 4G	e739	LG-E739
LGE	Nexus 4	mako	Nexus 4
LGE	Nexus 5	hammerhead	Nexus 5
LGE	Optiimus Black	bproj_208-01	LG-P970
LGE	Optimus EX	x2	LG-SU880
LGE	Optimus LTE	l1a	LG-P870

Supported Devices

LGE	Optimus 2	as680	LG-AS680
LGE	Optimus 2X	p990	LG-P990
LGE	Optimus 2X	p990	LG-P990H
LGE	Optimus 2X	p990	LG-P990h
LGE	Optimus 2X	p990_262-xx	LG-P990
LGE	Optimus 2X	p990_CIS-xxx	LG-P990
LGE	Optimus 2X	p990_EUR-xx	LG-P990
LGE	Optimus 2X	p990hN	LG-P990hN
LGE	Optimus 2X	p999	LG-P999
LGE	Optimus 2X	star	LG-P990
LGE	Optimus 2X	star	LG-SU660
LGE	Optimus 2X	star_450-05	LG-SU660
LGE	Optimus 2X	su660	LG-SU660
LGE	Optimus 3D	cosmo_450-05	LG-SU760
LGE	Optimus 3D	cosmo_EUR-XXX	LG-P920
LGE	Optimus 3D	cosmo_MEA-XXX	LG-P920
LGE	Optimus 3D	p920	LG-P920
LGE	Optimus 3D	p920	LG-P920h
LGE	Optimus 3D	su760	LG-SU760
LGE	Optimus 3D Cube	cx2	LG-SU870
LGE	Optimus 3D MAX	cx2	LG-P720h
LGE	Optimus 3D MAX	cx2	LG-P725
LGE	Optimus 3D MAX	cx2	LG-SU870
LGE	Optimus 4X HD	x3	LG-P880
LGE	Optimus 4X HD	x3	LG-P880g
LGE	Optimus Big	justin	LG-LU6800
LGE	Optimus Big	lu6800	LG-LU6800
LGE	Optimus Black	LGL85C	LGL85C
LGE	Optimus Black	black	LG-KU5900
LGE	Optimus Black	blackg	LG-P970

Supported Devices

LGE	Optimus Black	blackg	LG-P970h
LGE	Optimus Black	bproj_214-03	LG-P970
LGE	Optimus Black	bproj_262-XXX	LG-P970
LGE	Optimus Black	bproj_302-220	LG-P970g
LGE	Optimus Black	bproj_334-020	LG-P970h
LGE	Optimus Black	bproj_724-xxx	LG-P970h
LGE	Optimus Black	bproj_ARE-XXX	LG-P970
LGE	Optimus Black	bproj_EUR-XXX	LG-P970
LGE	Optimus Black	bproj_sea-xxx	LG-P970
LGE	Optimus Black	ku5900	LG-KU5900
LGE	Optimus Black	lgp970	LG-P970
LGE	Optimus Black	lgp970	LG-P970g
LGE	Optimus Black	lgp970	LG-P970h
LGE	Optimus Chat	hazel	LG-C550
LGE	Optimus Chat	hazel	LG-C555
LGE	Optimus Core	u0_cdma	LGL86C
LGE	Optimus EX	x2	IS11LG
LGE	Optimus EX	x2_450-05	LG-SU880
LGE	Optimus Exceed 2	w5c	LG-VS450PP
LGE	Optimus F3	fx3	LG-LS720
LGE	Optimus F3	fx3	LG-P655H
LGE	Optimus F3	fx3	LG-P655K
LGE	Optimus F3	fx3	LG-P659
LGE	Optimus F3	fx3	LG-P659H
LGE	Optimus F3	fx3	LGL25L
LGE	Optimus F3	fx3	LGMS659
LGE	Optimus F5	l1e	LG-P870h
LGE	Optimus F5	l1e	LG-P875
LGE	Optimus F5	l1e	LG-P875h
LGE	Optimus F5	l1v	AS870 4G

Supported Devices

LGE	Optimus F6	f6	LG-D500
LGE	Optimus F6	f6	LG-D505
LGE	Optimus F6	f6	LGMS500
LGE	Optimus Fuel	w3c	LGL34C
LGE	Optimus G Pro	geevl04e	L-04E
LGE	Optimus GJ	geehdc	LG-E975w
LGE	Optimus GK	gvfhd	LG-F220K
LGE	Optimus Hub	lgc800	LG-C800
LGE	Optimus Hub	lgc800g	LG-C800G
LGE	Optimus Hub	univa_214-04	LG-E510
LGE	Optimus Hub	univa_724-05	LG-E510f
LGE	Optimus Hub	univa_730-01	LG-E510g
LGE	Optimus Hub	univa_730-03	LG-E510g
LGE	Optimus Hub	univa_740-01	LG-E510g
LGE	Optimus Hub	univa_clr-br	LG-E510f
LGE	Optimus Hub	univa_ctm-xxx	LG-E510g
LGE	Optimus Hub	univa_ent-cl	LG-E510g
LGE	Optimus Hub	univa_open-br	LG-E510f
LGE	Optimus Hub	univa_open-de	LG-E510
LGE	Optimus Hub	univa_ssv-xxx	LG-E510g
LGE	Optimus Hub	univa_tcl-mx	LG-E510f
LGE	Optimus Hub	univa_tlf-es	LG-E510
LGE	Optimus Hub	univa_ufn-mx	LG-E510g
LGE	Optimus Hub	univa_usc-mx	LG-E510g
LGE	Optimus Hub	univa_viv-br	LG-E510f
LGE	Optimus L40	w3	LG-D160
LGE	Optimus L40	w3	LG-D165
LGE	Optimus L40	w3	LG-D165AR
LGE	Optimus L40	w3ds	LG-D170
LGE	Optimus L40	w3ds	LG-D175f

Supported Devices

LGE	Optimus L40	w3ts	LG-D180f
LGE	Optimus L5	m4	LG-E610
LGE	Optimus L5	m4	LG-E610v
LGE	Optimus L5	m4	LG-E612
LGE	Optimus L5	m4	LG-E612f
LGE	Optimus L5	m4	LG-E612g
LGE	Optimus L5	m4	LG-E617G
LGE	Optimus L5	m4	LG-L40G
LGE	Optimus L7II	vee7ds	LG-P716
LGE	Optimus LIFE	l1_dcm	L-02E
LGE	Optimus LTE	i_dcm	L-01D
LGE	Optimus LTE	i_skt	LG-SU640
LGE	Optimus LTE	i_u	LG-LU6200
LGE	Optimus LTE	iproj	LG-P936
LGE	Optimus LTE	lgp930	LG-P930
LGE	Optimus LTE	lgp935	LG-P935
LGE	Optimus Mach	LU3000	LG-LU3000
LGE	Optimus Mach	hub	LG-LU3000
LGE	Optimus Mach	lu3000	LG-LU3000
LGE	Optimus Net	gelato_302-610	LG-P690b
LGE	Optimus Net	gelato_cis-xx	LG-P690
LGE	Optimus Net	gelato_sea-xx	LG-P690
LGE	Optimus Net	lgl45c	LGL45C
LGE	Optimus Net Dual	gelatods_are-xxx	LG-P698
LGE	Optimus Net Dual	gelatods_cis-xxx	LG-P698
LGE	Optimus Net Dual	gelatods_ind-xxx	LG-P698
LGE	Optimus Net Dual	gelatods_open-br	LG-P698f
LGE	Optimus Net Dual	gelatods_sea-xxx	LG-P698
LGE	Optimus One	ku3700	LG-KU3700
LGE	Optimus One	lu3700	LG-LU3700

Supported Devices

LGE	Optimus One	su370	LG-SU370
LGE	Optimus One	thunder_kor-05	LG-SU370
LGE	Optimus One	thunder_kor-08	LG-KU3700
LGE	Optimus One	thunder_kor-08	LG-LU3700
LGE	Optimus One	thunderc	LG-CX670
LGE	Optimus One	thunderc	LG-LW690
LGE	Optimus One	thunderc	LG-MS690
LGE	Optimus One	thunderc	LG-US670
LGE	Optimus One	thunderc	LS670
LGE	Optimus One	thunderc	VM670
LGE	Optimus One	thunderc	Vortex
LGE	Optimus One	thunderc	thunderc
LGE	Optimus PAD LTE	express	LG-LU8300
LGE	Optimus Pad	I06c	L-06C
LGE	Optimus Pad	v900	LG-V900
LGE	Optimus Pad	v900asia	LG-V900
LGE	Optimus Pad	v901ar	LG-V901
LGE	Optimus Pad	v901kr	LG-V901
LGE	Optimus Pad	v901tr	LG-V901
LGE	Optimus Pad	v905r	LG-V905R
LGE	Optimus Pad	v909	LG-V909
LGE	Optimus Pad	v909mkt	LG-V909
LGE	Optimus Plus	m3_acg_us	LG-AS695
LGE	Optimus Pro	muscat	LG-C660
LGE	Optimus Pro	muscat	LG-C660R
LGE	Optimus Pro	muscat	LG-C660h
LGE	Optimus Q	lg155c	LGL55C
LGE	Optimus Q2	bssq	LG-LU6500
LGE	Optimus Q2	bssq_450-06	LG-LU6500
LGE	Optimus Slider	VM701	LG-VM701

Supported Devices

LGE	Optimus Sol	victor	LG-E730
LGE	Optimus Sol	victor	LG-E730f
LGE	Optimus Spirit	gelato_505-01	LG-P690f
LGE	Optimus Spirit	gelato_eur-xx	LG-P690
LGE	Optimus Vu	325	LG-F100L
LGE	Optimus Vu	batman	LG-F100L
LGE	Optimus Vu	batman	LG-F100S
LGE	Optimus Vu	batman_dcm	L-06DJOJO
LGE	Optimus Vu	batman_lgu	LG-F100L
LGE	Optimus Vu	batman_skt	LG-F100S
LGE	Optimus Vu	lge_325_skt	LG-F100S
LGE	Optimus Vu	vu10	LG-P895
LGE	Optimus Vu	vu10	LG-P895qb
LGE	Optimus Vu2	vu2kt	LG-F200K
LGE	Optimus Vu2	vu2sk	LG-F200S
LGE	Optimus Vu2	vu2u	LG-F200L
LGE	Optimus Vu2	vu2u	LG-F200LS
LGE	Optimus Vu:	batman_dcm	L-06D
LGE	Optimus Z	su950	SU950
LGE	Optimus Zone	e0v	LG-VS410PP
LGE	Optimus chat	elini	L-04C
LGE	PRADA 3.0	p2	L-02D
LGE	PRADA 3.0	p2	LG-KU5400
LGE	PRADA 3.0	p2	LG-LU5400
LGE	PRADA 3.0	p2	LG-P940
LGE	PRADA 3.0	p2	LG-P940h
LGE	PRADA 3.0	p2	LG-SU540
LGE	PecanV	pecanV	LG-P355
LGE	Shine Plus with Google	alohag	LG-C710h
LGE	Smart Dios V8700	SE_TF	ref_SCTF

Supported Devices

LGE	Spectrum	i_vzw	VS920 4G
LGE	Spectrum 2	d1lv	VS930 4G
LGE	Spirit 4G	l1m	LG-MS870
LGE	Splendor	u0_cdma	LG-US730
LGE	Swift	swift	GT540
LGE	Swift	swift	GT540GO
LGE	Swift	swift	GT540R
LGE	Swift	swift	GT540f
LGE	Thrill 4G	cosmo_310-410	LG-P925
LGE	Thrill 4G	p925	LG-P925
LGE	VU3	vu3	LG-F300K
LGE	VU3	vu3	LG-F300L
LGE	VU3	vu3	LG-F300S
LGE	Wine Smart	vfp	LG-D486
LGE	Wine Smart	vfp	LG-F480K
LGE	Wine Smart	vfp	LG-F480L
LGE	Wine Smart	vfp	LG-F480S
LGU+	LAP250U	hg2	LAP250U
LGU+	ST940I-UP	tvq2	ST940I-UP
LGUplus	TV G	smartbox	TI320-DU
LIAONING YIYATONG	DISNEY_Tablet_PC	DISNEY_Tablet_PC	DS2310-70LP
LIAONING YIYATONG	IRULU_MID	IRULU_MID	X10
LINSAY	LINSAY F-7HD2CORE / F-7HD4CORE / F-10HD2CORE / F-10XHD4CORE	F-7HD2CORE	LINSAY F-7HD2CORE/F-7HD4CORE/F-10HD2CORE/F-10XHD4CORE
LT	LT610	LT610	LT610
LT	W2	EG606_YE	W2
LUVO	LUVO 001	luvo_001	Luvo 001
LUVO	LUVO-001L	LUVO-001L	LUVO 001L
LUXYA	LUXYA MID704DC Tablet / Bitmore Tab770	MY7317P	MID704DC

Supported Devices

Lanix	ILIUM PAD E10Si	iLium_Pad_E10Si_1	ILIUM PAD E10Si
Lava	XOLO LT900	LT900	LT900
Lazer	Lazer MD1005 Tablet	MD1005	MD1005
Lazer	Lazer MY1306P	MY1306P	MY1306P
Lazer	Lazer X4508	X4508	X4508
Lazer	MID9526CM	MID9526CM	S952
Lazer	MW-7615P	MW-7615P	MW-7615P
Lazer	MW6617	MW6617	MW6617
Le Pan	Le Pan TC1010	FG6A-LP	Le Pan TC1010
Le Pan	Le Pan TC1020	FG6Q	Le Pan TC1020
Le Pan	Le Pan TC802A	UY8	Le Pan TC802A
Lenovo		18382AU	ThinkPad Tablet
Lenovo		A1_07	A1_07
Lenovo		A2109A	IdeaTabA2109A
Lenovo		A2207A-H	IdeaTabA2207A-H
Lenovo		A278t	Lenovo A278t
Lenovo		A288t	Lenovo A288t
Lenovo		A298t	Lenovo A298t
Lenovo		A30t	A30t
Lenovo		A530_msm7627a_alps	Lenovo A530
Lenovo		A560e_msm7627a	LNV-Lenovo_A560e
Lenovo		A580	Lenovo A580
Lenovo		A600e_msm8625	LNV-Lenovo A600e
Lenovo		A60plus	Lenovo A60+
Lenovo		A630	Lenovo A630
Lenovo		A660	Lenovo A660
Lenovo		A668t	Lenovo A668t
Lenovo		A690	Lenovo A690
Lenovo		A700e	Lenovo A700e
Lenovo		A710e_msm7627a	Lenovo A710e

Supported Devices

Lenovo		A780_msm7627a	Lenovo A780
Lenovo		A789	Lenovo A789
Lenovo		A798t	Lenovo A798t
Lenovo		A800	Lenovo A800
Lenovo		Android	Lenovo A60+
Lenovo		K1	K1
Lenovo		K2110A-F	IdeaTab K2110A-F
Lenovo		LIFETAB_S9512	LIFETAB_S9512
Lenovo		Lenovo_S2	Lenovo S2-38AH0
Lenovo		MD_LIFETAB_P9516	MD_LIFETAB_P9516
Lenovo		P700i	Lenovo P700i
Lenovo		P770	Lenovo P770
Lenovo		S2005A-H	S2005A-H
Lenovo		S2109A	IdeaTabS2109A-F
Lenovo		S560	Lenovo S560
Lenovo		S880i	Lenovo S880i
Lenovo		S890	Lenovo S890
Lenovo		S899t	Lenovo S899t
Lenovo		S920_ROW	Lenovo S920
Lenovo		S920_ROW	Lenovo S920_ROW
Lenovo		SmartTabII7	SmartTabII7
Lenovo		T702T	A66t
Lenovo		a2_3g_data	IdeaTab A2107A-H
Lenovo		a2_wifi	IdeaTab A2107A-F
Lenovo		a2_wifi_row	IdeaTab A2107A-F
Lenovo		a326	Lenovo A326
Lenovo		a360	Lenovo A360
Lenovo		a370	Lenovo A370
Lenovo		a500plus	Lenovo A500+
Lenovo		a520_gray	Lenovo A520GRAY

Supported Devices

Lenovo		a59wg	Lenovo A500
Lenovo		a59wg	Lenovo A500+
Lenovo		a60_campus	Lenovo A60
Lenovo		a60id_tel	Lenovo A60
Lenovo		a60os	Lenovo A60
Lenovo		a60tw	Lenovo A60
Lenovo		a65	Lenovo A65
Lenovo		a65_ph_id_vn	Lenovo A65
Lenovo		a65cu	Lenovo A65
Lenovo		amazon_w	Lenovo A1-32AB0
Lenovo		apollo_td	Lenovo S2-38AT0
Lenovo		apollo_wg	Lenovo S2-38AH0
Lenovo		apollohd_w	Lenovo K2
Lenovo		apollozero_w	Lenovo S760
Lenovo		aruba	Lenovo A765e
Lenovo		austin	Lenovo A300
Lenovo		ideatv_S31	ideatv S31
Lenovo		lenovo13_td	Lenovo A366t
Lenovo		lenovo15_td_ics	Lenovo A698t
Lenovo		lenovo73_cu	Lenovo A60
Lenovo		lenovo73_gb	Lenovo A520
Lenovo		lenovo73_gb	Lenovo P70
Lenovo		lenovo75_a2_att_ics	A2107A-H
Lenovo		lenovo75_a2_ics	IdeaTab A2107A-H
Lenovo		lenovo75_cu_gb	Lenovo A750
Lenovo		lenovo75_cu_ics	Lenovo A750
Lenovo		mfld_pr2	Lenovo K800
Lenovo		mi_350	Spice Mi-350
Lenovo		msm7627_ea95	Lenovo A390e
Lenovo		msm7627_surf	A68e

Supported Devices

Lenovo		msm7627_surf	Lenovo A68e
Lenovo		msm7627a	LVN-Lenovo A790e
Lenovo		msm7627a_ha99	Lenovo A780
Lenovo		msm8660_surf	IdeaTab S2007A-F
Lenovo		msm8660_surf	IdeaTab S2007A-H
Lenovo		msm8660_surf	IdeaTab S2010A-D
Lenovo		msm8660_surf	IdeaTab S2010A-F
Lenovo		msm8660_surf	IdeaTab S2010A-H
Lenovo		msm8960	IdeaTabS2110AF
Lenovo		msm8960	IdeaTabS2110AH
Lenovo		msm8960	SmartTabI10
Lenovo		p700	Lenovo P700
Lenovo		p700_ph	Lenovo P700
Lenovo		s880	Lenovo S880
Lenovo		s880_row	Lenovo S880
Lenovo		sanpaolo	IdeaTabV2007A
Lenovo		santiago	IdeaTabV2010A
Lenovo		santiago	IdeaTabV2010A-W
Lenovo		sicily	Lenovo S696
Lenovo		stuttgart_row	Lenovo K860
Lenovo		ventana	K1
Lenovo	60K72	ideatv_K72	ideatv K72
Lenovo	A10	A10	IdeaPadA10
Lenovo	A1000	A1000F	IdeaTabA1000-F
Lenovo	A1000-G	A1000G	IdeaTabA1000-G
Lenovo	A1000L	A1000LF	IdeaTabA1000L-F
Lenovo	A208t	A208t	Lenovo A208t
Lenovo	A2107A	A2107A-H	A2107A-H
Lenovo	A218t	A218t	Lenovo A218t
Lenovo	A269	A269	Lenovo A269

Supported Devices

Lenovo	A269i	A269i	Lenovo A269i
Lenovo	A278t	A278t	Lenovo A278t
Lenovo	A3000	A3000	Lenovo A3000-H
Lenovo	A305E	A305e	LNV-Lenovo A305e
Lenovo	A305E	A305e	Lenovo A305e
Lenovo	A308t	A308t	Lenovo A308t
Lenovo	A318t	A318t	Lenovo A318t
Lenovo	A369	A369	Lenovo A369
Lenovo	A369i	A369i	Lenovo A369i
Lenovo	A370e	A370e	LNV-Lenovo A370e
Lenovo	A375e	A375e	LNV-Lenovo A375e
Lenovo	A376	A376	Lenovo A376
Lenovo	A378t	A378t	Lenovo A378t
Lenovo	A390	A390	Lenovo A390_ROW
Lenovo	A390t	A390t	Lenovo A390t
Lenovo	A398t	A398t	Lenovo A398t
Lenovo	A516	A516	Lenovo A516
Lenovo	A516	A516_ROW	Lenovo A516
Lenovo	A630	A630e	LNV-Lenovo A630e
Lenovo	A656	A656	Lenovo A656
Lenovo	A658T	A658t	Lenovo A658t
Lenovo	A670t	A670t	Lenovo A670t
Lenovo	A678t	A678t	Lenovo A678t
Lenovo	A706	armani	Lenovo A706
Lenovo	A706_ROW	armani_row	Lenovo A706_ROW
Lenovo	A720e	andorrap	Lenovo A720e
Lenovo	A750e	athenae	Lenovo A750e
Lenovo	A760	audi	Lenovo A760
Lenovo	A766	A766	Lenovo A766
Lenovo	A770e	athenaep	Lenovo A770e

Supported Devices

Lenovo	A820	A820	Lenovo A820
Lenovo	A820e	andorra	Lenovo A820e
Lenovo	A830	A830	Lenovo A830
Lenovo	A850	A850	Lenovo A850
Lenovo	A850	A850_ROW	Lenovo A850
Lenovo	A860e	artini	Lenovo A860e
Lenovo	B6000-F	B6000	Lenovo B6000-F
Lenovo	B6000-H	B6000	Lenovo B6000-H
Lenovo	B6000-HV	B6000	Lenovo B6000-HV
Lenovo	B8000-F	B8000	Lenovo B8000-F
Lenovo	B8000-H	B8000	Lenovo B8000-H
Lenovo	E4002	E4002	MEDION E4002
Lenovo	EveryPad	A3000	EveryPad
Lenovo	EveryPad	A3000	IdeaTab A3000-F
Lenovo	IdeaTV	msm8660_surf	ideatv K91
Lenovo	IdeaTab A1000	A1000LF	LenovoA1000L-F
Lenovo	IdeaTab A1010	A1010T	IdeaTabA1010-T
Lenovo	IdeaTab A1020	A1020T	IdeaTabA1020-T
Lenovo	IdeaTab A3000	A3000	IdeaTab A3000-H
Lenovo	IdeaTab A3000	A3000	Vodafone Smart Tab III 7
Lenovo	IdeaTab A5000	A5000E	IdeaTabA5000-E
Lenovo	IdeaTab S6000	S6000	IdeaTab S6000-F
Lenovo	IdeaTab S6000	S6000	IdeaTab S6000-H
Lenovo	IdeaTab S6000	S6000	Vodafone Smart Tab III 10
Lenovo	Indigo	Indigo	ThinkPad Tablet
Lenovo	K1	K1	K1
Lenovo	K800	K800	Lenovo K800
Lenovo	K900	K900	Lenovo K900
Lenovo	K900	K900_ROW	Lenovo K900_ROW
Lenovo	LIFETAB E10310	LIFETAB_E10310	LIFETAB_E10310

Supported Devices

Lenovo	LIFETAB E7310	LIFETAB_E7310	LIFETAB_E7310
Lenovo	LIFETAB E7310	LIFETAB_E7310	LIFETAB_E7312
Lenovo	Lenovo	A708t	Lenovo A708t
Lenovo	Lenovo	A880	Lenovo A880
Lenovo	Lenovo TAB 2 A7-30HC	A7-30HC	Lenovo TAB 2 A7-30HC
Lenovo	Lenovo X2	X2-AP	Lenovo X2-AP
Lenovo	Lenovo A2105	Lenovo_A2105	Lenovo_A2105
Lenovo	Lenovo A228t	A228t	Lenovo A228t
Lenovo	Lenovo A238t	A238t	Lenovo A238t
Lenovo	Lenovo A300t	A300t	Lenovo A300t
Lenovo	Lenovo A316	A316	Lenovo A316
Lenovo	Lenovo A316i	A316i	Lenovo A316i
Lenovo	Lenovo A319	A319	Lenovo A319
Lenovo	Lenovo A320t	A320t	Lenovo A320t
Lenovo	Lenovo A328	A328	Lenovo A328
Lenovo	Lenovo A328t	A328t	Lenovo A328t
Lenovo	Lenovo A3300	A3300-GV	LenovoA3300-GV
Lenovo	Lenovo A3300	A3300-H	LenovoA3300-H
Lenovo	Lenovo A3300	A3300-HV	LenovoA3300-HV
Lenovo	Lenovo A3300	A3300-T	Lenovo A3300-T
Lenovo	Lenovo A3300-GV	A3300-GV	LenovoA3300-GV
Lenovo	Lenovo A3300-HV	A3300-HV	Lenovo A3300-HV
Lenovo	Lenovo A330e	A330e	Lenovo A330e
Lenovo	Lenovo A338t	A338t	Lenovo A338t
Lenovo	Lenovo A3500	A3500HV	Lenovo A3500-HV
Lenovo	Lenovo A3500-F	A3500F	EveryPad2
Lenovo	Lenovo A3500-F	A3500F	Lenovo A3500-F
Lenovo	Lenovo A3500-FL	A3500FL	Lenovo A3500-FL
Lenovo	Lenovo A3500-H	A3500H	Lenovo A3500-H
Lenovo	Lenovo A355e	A355e	Lenovo A355e

Supported Devices

Lenovo	Lenovo A358t	A358t	Lenovo A358t
Lenovo	Lenovo A3600-D	A3600-d	Lenovo A3600-d
Lenovo	Lenovo A360e	A360e	Lenovo A360e
Lenovo	Lenovo A360t	A360t	Lenovo A360t
Lenovo	Lenovo A368t	A368t	Lenovo A368t
Lenovo	Lenovo A3800-D	A3800-d	Lenovo A3800-d
Lenovo	Lenovo A380e	A380e	LNV-Lenovo A380e
Lenovo	Lenovo A380t	A380t	Lenovo A380t
Lenovo	Lenovo A385e	A385e	LNV-Lenovo A385e
Lenovo	Lenovo A388t	A388t	Lenovo A388t
Lenovo	Lenovo A390	A390	Lenovo A390
Lenovo	Lenovo A395e	A395e	LNV-Lenovo A395e
Lenovo	Lenovo A396	A396	Lenovo A396
Lenovo	Lenovo A396	A396_TY	Lenovo A396_TY
Lenovo	Lenovo A398t+	A398tp	Lenovo A398t+
Lenovo	Lenovo A399	Aiken	Lenovo A399
Lenovo	Lenovo A5000	A5000	Lenovo A5000
Lenovo	Lenovo A505e	A505e	LNV-Lenovo A505e
Lenovo	Lenovo A516	A516_ROW	Lenovo A516
Lenovo	Lenovo A526	A526	Lenovo A526
Lenovo	Lenovo A529	A529	Lenovo A529
Lenovo	Lenovo A536	A536	Lenovo A536
Lenovo	Lenovo A5500-F	A5500-F	Lenovo A5500-F
Lenovo	Lenovo A5500-H	A5500-H	Lenovo A5500-H
Lenovo	Lenovo A5500-HV	A5500-HV	Lenovo A5500-HV
Lenovo	Lenovo A560	A560_msm8212	Lenovo A560
Lenovo	Lenovo A560	A560_msm8610	LNV-Lenovo A560
Lenovo	Lenovo A5800-D	A5800-D	Lenovo A5800-D
Lenovo	Lenovo A588t	LenovoA588t	LenovoA588t
Lenovo	Lenovo A6000	Kraft-A6000	Lenovo A6000

Supported Devices

Lenovo	Lenovo A606	A606	Lenovo A606
Lenovo	Lenovo A616	A616	Lenovo A616
Lenovo	Lenovo A628t	A628t	Lenovo A628t
Lenovo	Lenovo A680	A680	Lenovo A680
Lenovo	Lenovo A680	A680	Lenovo A680_ROW
Lenovo	Lenovo A688t	A688t	Lenovo A688t
Lenovo	Lenovo A690e	A690e	LNV-Lenovo A690e
Lenovo	Lenovo A7-30GC	A7-30GC	Lenovo TAB 2 A7-30GC
Lenovo	Lenovo A7-30H	A7-30H	Lenovo TAB 2 A7-30H
Lenovo	Lenovo A7-60HC	A760HC	Lenovo A7-60HC
Lenovo	Lenovo A7600-F	A7600-F	Lenovo A7600-F
Lenovo	Lenovo A7600-H	A7600-H	Lenovo A7600-H
Lenovo	Lenovo A7600-HV	A7600-HV	Lenovo A7600-HV
Lenovo	Lenovo A768t	airplayt	Lenovo A768t
Lenovo	Lenovo A780e	A780e	LNV-Lenovo A780e
Lenovo	Lenovo A785e	A785e	LNV-Lenovo A785e
Lenovo	Lenovo A788t	A788t	Lenovo A788t
Lenovo	Lenovo A805e	airplayep	Lenovo A805e
Lenovo	Lenovo A806	A806	Lenovo A806
Lenovo	Lenovo A808t	A808t	Lenovo A808t
Lenovo	Lenovo A808t-i	A808t-i	Lenovo A808t-i
Lenovo	Lenovo A816	airplayw	Lenovo A816
Lenovo	Lenovo A820t	A820t	Lenovo A820t
Lenovo	Lenovo A828	A858	Lenovo A858
Lenovo	Lenovo A828t	A828t	Lenovo A828t
Lenovo	Lenovo A850	A850	Lenovo A850
Lenovo	Lenovo A850+	A850p	Lenovo A850+
Lenovo	Lenovo A858t	A858t	Lenovo A858t
Lenovo	Lenovo A859	A859_ROW	Lenovo A859
Lenovo	Lenovo A889	A889	Lenovo A889

Supported Devices

Lenovo	Lenovo A890e	airbuse	Lenovo A890e
Lenovo	Lenovo A916	A916	Lenovo A916
Lenovo	Lenovo A936	A936	Lenovo A936
Lenovo	Lenovo B8080	B8080	Lenovo B8080-F
Lenovo	Lenovo B8080-H	B8080	Lenovo B8080-H
Lenovo	Lenovo B8080-HV	B8080	Lenovo B8080-HV
Lenovo	Lenovo K30-T	Kraft-T	Lenovo K30-T
Lenovo	Lenovo K30-TM	Kraft-TM	Lenovo K30-TM
Lenovo	Lenovo K30-W	Kraft-W	Lenovo K30-W
Lenovo	Lenovo K80M	K80M	Lenovo K80M
Lenovo	Lenovo K860	stuttgart	Lenovo K860
Lenovo	Lenovo K860i	K860i	Lenovo K860i
Lenovo	Lenovo K910	kiton	Lenovo K910
Lenovo	Lenovo K910L	K910L	Lenovo K910L
Lenovo	Lenovo K910e	kitone	LNV-Lenovo K910e
Lenovo	Lenovo K910e	kitone	Lenovo K910e
Lenovo	Lenovo K920/VIBE Z2	kingdom_row	Lenovo K920
Lenovo	Lenovo K920/VIBE Z2 Pro	kingdomt	Lenovo K920
Lenovo	Lenovo N300	Lindos2	Lenovo N300
Lenovo	Lenovo N308	SmartAIO	Lenovo N308
Lenovo	Lenovo P70	P70-A	Lenovo P70-A
Lenovo	Lenovo P70	P70-t	Lenovo P70-t
Lenovo	Lenovo P780	P780	Lenovo P780
Lenovo	Lenovo P90	P90	Lenovo P90
Lenovo	Lenovo S580	S580	Lenovo S580
Lenovo	Lenovo S60	sisleylt	Lenovo S60-t
Lenovo	Lenovo S60	sisleylw	Lenovo S60-w
Lenovo	Lenovo S650	S650	Lenovo S650
Lenovo	Lenovo S650_ROW	S650_ROW	Lenovo S650
Lenovo	Lenovo S658t	S658t	Lenovo S658t

Supported Devices

Lenovo	Lenovo S660	S660	Lenovo S660
Lenovo	Lenovo S668t	S668t	Lenovo S668t
Lenovo	Lenovo S810t	shellt	Lenovo S810t
Lenovo	Lenovo S820	S820	Lenovo S820
Lenovo	Lenovo S820	S820_AMX_ROW	Lenovo S820
Lenovo	Lenovo S850	S850	Lenovo S850
Lenovo	Lenovo S850t	S850t	Lenovo S850t
Lenovo	Lenovo S856	shellamx	Lenovo S856
Lenovo	Lenovo S856	shellr	Lenovo S856
Lenovo	Lenovo S856	shellr_s	Lenovo S856
Lenovo	Lenovo S856	shellw	Lenovo S856
Lenovo	Lenovo S858t	Selected	Lenovo S858t
Lenovo	Lenovo S860	S860	Lenovo S860
Lenovo	Lenovo S860e	shelle	Lenovo S860e
Lenovo	Lenovo S898t+	S898tp	Lenovo S898t+
Lenovo	Lenovo S90	sisleye	Lenovo S90-e
Lenovo	Lenovo S90-T	sisleyt	Lenovo S90-t
Lenovo	Lenovo S90-U	sisleyw	Lenovo S90-u
Lenovo	Lenovo S920	S920	Lenovo S920
Lenovo	Lenovo S930	S930	Lenovo S930
Lenovo	Lenovo S930_ROW	S930_ROW	Lenovo S930
Lenovo	Lenovo S938t	S938t	Lenovo S938t
Lenovo	Lenovo S939	S939	Lenovo S939
Lenovo	Lenovo S960	S960	Lenovo S960
Lenovo	Lenovo S960	S960_AMX_ROW	Lenovo S960
Lenovo	Lenovo S968t	S968t	Lenovo S968t
Lenovo	Lenovo TAB 2 A7-10F	Tab2A7-10F	Tab2A7-10F
Lenovo	Lenovo TAB 2 A7-30F	A7-30F	Lenovo TAB 2 A7-30F
Lenovo	Lenovo TAB 2 A7-30HC	A7-30HC	Lenovo 2 A7-30HC
Lenovo	Lenovo TAB 2 A7-30TC	A7-30TC	Lenovo 2 A7-30TC

Supported Devices

Lenovo	Lenovo TAB A10-80HC	A10_80HC	TAB A10-80HC
Lenovo	Lenovo TAB S8-50F	S8-50F	Lenovo TAB S8-50F
Lenovo	Lenovo TAB S8-50L	S8-50L	Lenovo TAB S8-50L
Lenovo	Lenovo TAB S8-50LC	S8-50LC	Lenovo S8-50LC
Lenovo	Lenovo TAB S8-50LC	S8-50LC	Lenovo TAB S8-50LC
Lenovo	Lenovo X2	X2-EU	Lenovo X2-EU
Lenovo	Lenovo X2-CU/VIBE X2	X2-CU	Lenovo X2-CU
Lenovo	Lenovo X2-TO/VIBE X2	X2-TO	Lenovo X2-TO
Lenovo	Lenovo X2-TR/VIBE X2	X2-TR	Lenovo X2-TR
Lenovo	Lenovo YOGA Tablet Pro-1050L/Yoga Tablet 2	YT2	YOGA Tablet 2-1050L
Lenovo	Lenovo YOGA Tablet Pro-1050LC/Yoga Tablet 2	YT2	YOGA Tablet 2-1050LC
Lenovo	Lenovo YOGA Tablet Pro-1380F/Yoga Tablet 2 Pro	YT2	YOGA Tablet 2 Pro-1380F
Lenovo	Lenovo YOGA Tablet Pro-1380L/Yoga Tablet 2 Pro	YT2	YOGA Tablet 2 Pro-1380L
Lenovo	Lenovo YOGA Tablet Pro-830L/Yoga Tablet 2	YT2	YOGA Tablet 2-830L
Lenovo	Lenovo YOGA Tablet Pro-830LC/Yoga Tablet 2	YT2	YOGA Tablet 2-830LC
Lenovo	Lenovo YogaTablet2 -1050F	YT2	YOGA Tablet 2-1050F
Lenovo	Lenovo YogaTbalet2-830F	YT2	YOGA Tablet 2-830F
Lenovo	Lenovo Z2	z2r	Lenovo Z2
Lenovo	Lenovo Z2	z2t	Lenovo Z2
Lenovo	Lenovo Z2w	z2w	Lenovo Z2w
Lenovo	LenovoTV 40S9;LenovoTV 50S9;AQUOS 40U1;AQUOS 50U1;AQUOS 58U1;AQUOS 60LX765A	jazz	AQUOS 58U1
Lenovo	LenovoTV 40S9;LenovoTV 50S9;AQUOS 40U1;AQUOS 50U1;AQUOS 58U1;AQUOS 60LX765A	jazz	AQUOS 60LX765A

Supported Devices

Lenovo	LenovoTV 40S9;LenovoTV 50S9;AQUOS 40U1;AQUOS 50U1\xef\xbc\x9bAQUOS 58U1; AQUOS 60LX765A	jazz	AQUOS 60UE20A
Lenovo	LenovoTV 40S9;LenovoTV 50S9;AQUOS 40U1;AQUOS 50U1\xef\xbc\x9bAQUOS 58U1; AQUOS 60LX765A	jazz	LenovoTV 40S9
Lenovo	LenovoTV 40S9;LenovoTV 50S9;AQUOS 40U1;AQUOS 50U1\xef\xbc\x9bAQUOS 58U1; AQUOS 60LX765A	jazz	LenovoTV 58S9
Lenovo	LenovoTV 50S52;AQUOS LCD-50S1A	bumblebee	AQUOS 50S1
Lenovo	LenovoTV 50S52;AQUOS LCD-50S1A	bumblebee	LenovoTV 50S52
Lenovo	Lenovo S960	S960_ROW	Lenovo S960
Lenovo	P780	P780	Lenovo P780
Lenovo	P780	P780_ROW	Lenovo P780
Lenovo	P780	P780_ROW	Lenovo P780_ROW
Lenovo	S5000	S5000	Lenovo S5000-F
Lenovo	S5000	S5000	Lenovo S5000-H
Lenovo	S6000L	S6000L	Lenovo S6000L-F
Lenovo	S61	ideatv_S61	ideatv S61
Lenovo	S680	seoul	Lenovo S680
Lenovo	S686	Alaska	Lenovo S686
Lenovo	S720	S720	Lenovo S720
Lenovo	S750	S750	Lenovo S750
Lenovo	S820	S820	Lenovo S820
Lenovo	S820	S820_ROW	Lenovo S820
Lenovo	S820	S820_ROW	Lenovo S820_ROW
Lenovo	S820e	applee	Lenovo S820e
Lenovo	S850e	sichuan	Lenovo S850e
Lenovo	S868	S868t	Lenovo S868t
Lenovo	S870e	S870e	LNV-Lenovo S870e

Supported Devices

Lenovo	S870e	S870e	Lenovo S870e
Lenovo	S898t	S898t	Lenovo S898t
Lenovo	S920	S920	Lenovo S920
Lenovo	S960	S960	Lenovo S960
Lenovo	ThinkVision28	ThinkVision28	ThinkVision28
Lenovo	ideatv S52	ideatv_S52	ideatv S52
Lenovo	ideatvK82 60LX750A 52LX750A 46LX750A 60LX850A 70LX850A 80LX850A	ideatv_K82	ideatv K82
Lexibook	MFC191	MFC191	S952
LifeWatch	LifeWatch V , FGL-00004	hp6577_cts	LifeWatch V
LinkNet	Smart Box HD	SH940C-LN	SH940C-LN
Listo	WEBPAD1002	Listo	WEBPAD1002
Logic Instrument	FieldBook E1	FieldBook_E1	FieldBook_E1
Logicom	E350	E350	E350
Logicom	E400	E400	E400
Logicom	LOGICOM E1052GP	E1052GP	E1052GP
Logicom	LOGICOM E852GP	E852GP	E852GP
Logicom	Logicom S450	S450	S450
Logicom	Logicom S504	S504	Connect 5
Logicom	Logicom S504	S504	S504
Logicom	S1052	S1052	S1052
Logicom	S732	rk3026	S732
Logicom	S7842	S7842	S7842
Logicom	S952	S952	S952
Logitech	Revue	ka	Revue
Lumigon	T2	msm7630_fw8911	T2
Lumigon	T2 HD	T2HD	T2HD
MAD CATZ	Mad Catz M.O.J.O.	mojo	Mad Catz M.O.J.O.
MG Series	Any 302	TR10CS1_15	TR10CS1
MG Series	Any 302	TR10CS2_3	TR10CS2

Supported Devices

MG series	Any 302	TR10CS2_2	TR10CS2
MG series	Any 303	TR10CD2_2	TR10CD2
MG series	Any 303	TR10CD2_3	TR10CD2
MPman	MPDC1006	MPDC1006	MPDC1006
MPman	MPDC706	MPDC706	MPDC706
MSI	Primo73	N71J	Primo73
MSI	Primo76	N728	Primo76
MSI	Primo81	N821	Primo 81
MSI	Primo81	N821	Primo81
MSI	Primo81	Primo81	Primo81
MTC	MTC 982	MTC_982	MTC 982
MTC	Vodafone Smart mini	Vodafone_875	MTC 970H
MTN	MTN-5982C3	MTN-TBW5982C3	MTN-TBW5982C3
MTN	MTN-8978P	MTN-8978P	MTN-8978P
MTN	MTN-S620	MTN-S620	MTN-S620
MTN	MTN-S720i	MTN-S720i	MTN-S720i
MTN-E70	MTN-E70	MTN-E70	MTN-E70
MTT	Master	Master	M.T.T. Master
MTT	Smart Fun	SmartFun	M.T.T. Smart Fun
Mach Speed	Infinity-10.1-v2	Infinity-101-v2	Infinity-10.1-v2
Mach Speed	xtreme	X_treme_Play_Tab	X-treme Play Tab
MachSpeed	MachSpeed Trio Stealth_10 Tablet	D_10AL	Trio Stealth_10
MachSpeed	MachSpeed Trio Stealth_8 Tablet	D_8AL	Trio Stealth_8
MachSpeed	MachSpeed Trio Stealth_9 Tablet	D_9AL	Trio Stealth_9
MachSpeed	MachSpeed TrioStealth-7	TrioStealth-7	TrioStealth-7
Mad Catz	Mad Catz M.O.J.O.	mojo	Mad Catz M.O.J.O.
Medion	LIFETAB E10316	LIFETAB_E10316	BOSCH_E10316
Medion	LIFETAB E10316	LIFETAB_E10316	LIFETAB_E10316
Medion	LIFETAB E10320	LIFETAB_E10320	LIFETAB_E10320

Supported Devices

Medion	LIFETAB E10320	LIFETAB_E10320	MICROSTAR_E10319
Medion	LIFETAB E7313	LIFETAB_E7313	LIFETAB_E7313
Medion	LIFETAB E7316	LIFETAB_E7316	LIFETAB_E7316
Medion	LIFETAB E7316	LIFETAB_E7316	LIFETAB_S7316
Medion	LIFETAB E732X	LIFETAB_E732X	LIFETAB_E732X
Medion	LIFETAB S1033X	LIFETAB_S1033X	LIFETAB_S1033X
Medion	LIFETAB S785X	LIFETAB_S785X	LIFETAB_S785X
Medion	Lifetab P9514	LIFETAB_P9514	LIFETAB_P9514
Medion	MEDION E4502	E4502	MEDION E4502
Medion	P4501	P4501	P4501
Medion	microstar E10319	E10319	E10319
MegaFon	MFLogin3T	MFLogin3T	MFLogin3T
MegaFon	MFLoginPh	MFLoginPh	MFLoginPh
MegaFon	MS4B	Viper_LTE	ALCATEL ONE TOUCH 7030R
MegaFon	MS4B	Viper_LTE	ALCATEL ONE TOUCH 7030Y
MegaFon	MS4B	Viper_LTE	MS4B
MegaFon	MegaFon MT3A	MT3A	MT3A
Megahouse	CP-D403	CP-D403	CP-D403
Mexico SEP tender	TR10CS1	TR10CS1_7	TR10CS1
Mexico SEP tender	TR10CS1	TR10CS1_8	TR10CS1
Micromax	A110	s9081	Micromax A110
Micromax	A111	A111	A111
Micromax	A116	A116	A116
Micromax	A240	A240	A240
Micromax	A27	A27	A27
Micromax	A44	tinnoes13_s7050	A44
Micromax	A45	tinnoes73_s8030_2g	A45
Micromax	A50	kpt73_gb	Micromax A50
Micromax	A54	A54	A54
Micromax	A56	A56	Micromax A56

Supported Devices

Micromax	A57	A57	A57
Micromax	A57	A57	Micromax A57
Micromax	A72	A72	Micromax A72
Micromax	A73	A73	A73
Micromax	A73	A73	Micromax A73
Micromax	A75	A75	A75
Micromax	A78	Micromax	A78
Micromax	A84	A84	A84
Micromax	A87	A87	A87
Micromax	A87	A87	Micromax A87
Micromax	A88	A88	A88
Micromax	A89	A89	A89
Micromax	A91	A91	A91
Micromax	A91	A91	Micromax A91
Micromax	BOLT	A068	A068
Micromax	BOLT	A069	Micromax A069
Micromax	BOLT	A24	Micromax A24
Micromax	BOLT	A34	Micromax A34
Micromax	BOLT	A67	Micromax A67
Micromax	BOLT	A69	Micromax A69
Micromax	BOLT	A69_IN	Micromax A69
Micromax	Bolt	A066	Micromax A066
Micromax	Bolt	A067	Micromax A067
Micromax	Bolt	AD4500	Micromax AD4500
Micromax	CANVAS 2 COLOURS	A120	Micromax A120
Micromax	CANVAS 2 PLUS	A110Q	A110Q
Micromax	CANVAS 2 PLUS	s9086b	Micromax A110Q
Micromax	CANVAS 4	A210	A210
Micromax	CANVAS 4	s9111b	A210
Micromax	CANVAS BEAT	A114R	Micromax A114R

Supported Devices

Micromax	CANVAS BLAZE	MT500	MT500
Micromax	CANVAS DOODLE 3	MicromaxA102	Micromax A102
Micromax	CANVAS DUET	AE90	Micromax AE90
Micromax	CANVAS DUET 2	EG111	Micromax EG111
Micromax	CANVAS ELANZA 2	A121	Micromax A121
Micromax	CANVAS ENGAGE	A091	Micromax A091
Micromax	CANVAS ENTICE	A105	Micromax A105
Micromax	CANVAS GOLD	A300	Micromax A300
Micromax	CANVAS KNIGHT	A350	Micromax A350
Micromax	CANVAS KNIGHT	s9320ae	Micromax A350
Micromax	CANVAS MAGNUS	s9203	Micromax A117
Micromax	CANVAS POWER	A96	Micromax A96
Micromax	CANVAS TUBE	A118R	Micromax A118R
Micromax	CANVAS TURBO	A250	A250
Micromax	CANVAS TURBO	s9311	A250
Micromax	CANVAS TURBO MINI	s8513a	Micromax A200
Micromax	CANVAS UNITE 2	A106	Micromax A106
Micromax	Canvas 4+	A315	Micromax A315
Micromax	Canvas A1	AQ4501_sprout	Micromax AQ4501
Micromax	Canvas Fire	A093	Micromax A093
Micromax	Canvas Fire	A104	Micromax A104
Micromax	Canvas HD Plus	A190	Micromax A190
Micromax	Canvas Knight Cameo	A290	Micromax A290
Micromax	Canvas L	A108	Micromax A108
Micromax	Canvas Nitro	A310	Micromax A310
Micromax	Canvas Nitro	A311	Micromax A311
Micromax	Canvas XL2	A109	Micromax A109
Micromax	MICROMAX MAD	A94	Micromax A94
Micromax	MICROMAX UNITE	A092	Micromax A092
Micromax	Micromax Bolt	A064	Micromax A064

Supported Devices

Micromax	Micromax Bolt	A065	Micromax A065
Micromax	Micromax Bolt	A082	Micromax A082
Micromax	P275	P275	P275
Micromax	P300	crane-M701C_mmx	P300
MiiA	MiiA	TA10CA1_2	TA10CA1
MiiA	MiiA MT-733G	MT-733G	MT-733G
MobiWire	Cygnus	Cygnus45	Cygnus
MobiWire	Cygnus	Cygnus45	Cygnus45
Mobily	MDB342X	qnbml	MDB342X
Mobiwire	Ahiga	Ahiga	Ahiga
Mobiwire	Cygnus mini	Cygnus_mini	Cygnus mini
Mobiwire	Cygnus mini	Cygnus_mini	Cygnus_mini
Mobiwire	Pegasus	Pegasus	Pegasus
Mobiwire	VSN V.45	up06_h26_v45	V.45
Mohu	MH-CHANNELS	MH-CHANNELS	MH-CHANNELS
Monster	Monster M10	M10	M10
Motorola		A853	Milestone
Motorola		ArgonSpin	XT550
Motorola		Graham	MZ505
Motorola		TAHITI	MT620
Motorola		Triumph	MOTWX435KT
Motorola		XT311	XT311
Motorola		XT316	XT316
Motorola		XT317	XT317
Motorola		XT319	XT319
Motorola		XT530	XT530
Motorola		XT531	XT531
Motorola		XT532	XT532
Motorola		argonspin_umts	XT550
Motorola		cdma_kronos	MB612

Supported Devices

Motorola		cdma_pax	XT603
Motorola		cdma_solana	MILESTONE3
Motorola		cdma_spyder	DROID RAZR
Motorola		cdma_spyder	IS12M
Motorola		cdma_spyder	Motorola RAZR MAXX
Motorola		cdma_targa	DROID BIONIC
Motorola		cg_tita2	XT800+
Motorola		choi	XT711
Motorola		choles	XT701
Motorola		destino	i867
Motorola		dominoq_umts	XT316
Motorola		edison	MB865
Motorola		edison	ME865
Motorola		fawnridge	i940
Motorola		fleming	MZ607
Motorola		fleming	MZ608
Motorola		fleming	MZ609
Motorola		fleming	XOOM 2 ME
Motorola		graham_wifi	MZ505
Motorola		iDEN	Motorola_i1
Motorola		morr	MB200
Motorola		pasteur	MZ616
Motorola		pasteur	MZ617
Motorola		pasteur	XOOM 2
Motorola		qilin	XT806
Motorola		scorpion_mini_u	XT905
Motorola		smq_u	XT905
Motorola		swordfish	XT882
Motorola		ting_umts	XT560
Motorola		ttu_skt	XT800W

Supported Devices

Motorola		umts_begonia	MB610
Motorola		umts_begonia	MB611
Motorola		umts_elway	MB632
Motorola		umts_elway	ME632
Motorola		umts_hubble	MZ605
Motorola		umts_kobe	MB520
Motorola		umts_lucky	A1680
Motorola		umts_sage	MB508
Motorola		umts_solana	ME863
Motorola		umts_solana	XT860
Motorola		umts_spyder	XT910
Motorola		umts_spyder	XT910K
Motorola		umts_spyder	XT910S
Motorola		umts_venus2	XT610
Motorola		wifi_hubble	MZ604
Motorola		zepp	MB501
Motorola	Atrix	olympus	MB860
Motorola	Atrix	olympus	MB861
Motorola	Atrix	olympus	ME860
Motorola	Atrix HD	qinara	MB886
Motorola	Backflip	motus	MB300
Motorola	Backflip	motus	ME600
Motorola	CLIQ	morrison	MB200
Motorola	CLIQ	morrison	morrison
Motorola	Charm	umts_basil	MB502
Motorola	Citrus	cdma_ciena	WX442
Motorola	Citrus	cdma_ciena	WX445
Motorola	Citrus	cdma_ciena	XT301
Motorola	Cliq-XT	zeppelin	MB501
Motorola	Cliq-XT	zeppelin	ME501

Supported Devices

Motorola	DROID RAZR HD	vanquish	DROID RAZR HD
Motorola	DROID RAZR HD	vanquish_u	RAZR HD
Motorola	DROID RAZR HD	vanquish_u	XT925
Motorola	DROID RAZR M	scorpion_mini	XT907
Motorola	DROID RAZR i	smi	XT890
Motorola	DROID Turbo	quark	XT1254
Motorola	DROID4	cdma_maserati	DROID4
Motorola	Defy	umts_jordan	MB525
Motorola	Defy	umts_jordan	MB526
Motorola	Defy	umts_jordan	ME525
Motorola	Defy	umts_jordan	ME525+
Motorola	Defy	umts_jordan	unknown
Motorola	Defy Mini	TinBoost	XT320
Motorola	Defy Mini	TinBoost	XT321
Motorola	Defy Mini	tinboost_umts	XT320
Motorola	Defy Mini	tinboost_umts	XT321
Motorola	Defy Pro	XT560	XT560
Motorola	Devour	calgary	Devour
Motorola	Devour	calgary	calgary
Motorola	Droid	miler	A854
Motorola	Droid	sholes	Droid
Motorola	Droid	umts_sholes	A853
Motorola	Droid	umts_sholes	Milestone
Motorola	Droid	umts_sholes	XT701
Motorola	Droid	umts_sholes	XT702
Motorola	Droid	umts_sholes	XT720
Motorola	Droid	umts_sholes	umts
Motorola	Droid 3	cdma_solana	DROID3
Motorola	Droid 4	cdma_maserati	DROID4
Motorola	Droid Bionic	cdma_targa	DROID BIONIC

Supported Devices

Motorola	Droid II	cdma_droid2	A955
Motorola	Droid II	cdma_droid2	DROID2
Motorola	Droid II	cdma_droid2we	DROID2 GLOBAL
Motorola	Droid MAXX	obake-maxx	XT1080
Motorola	Droid Mini	obakem	XT1030
Motorola	Droid Pro	cdma_venus2	DROID PRO
Motorola	Droid Pro	cdma_venus2	DROID Pro
Motorola	Droid Pro	cdma_venus2	Milestone PLUS
Motorola	Droid Pro	cdma_venus2	XT610
Motorola	Droid RAZR	umts_spyder	XT910
Motorola	Droid Razr M	scorpion_mini_t	201M
Motorola	Droid Ultra	obake	XT1080
Motorola	Droid X	cdma_shadow	DROIDX
Motorola	Droid X	cdma_shadow	MB810
Motorola	Droid X	cdma_shadow	ME811
Motorola	Droid X	cdma_shadow	Milestone X
Motorola	Droid X	cdma_shadow	MotoroiX
Motorola	Droid X2	daytona	DROID X2
Motorola	Droid X2	daytona	Milestone X2
Motorola	Electrify M	solstice	XT901
Motorola	Flipout	umts_ruth	MB511
Motorola	Flipout	umts_ruth	ME511
Motorola	Flipout	umts_ruth	MotoMB511
Motorola	Glam XT800	titanium	XT800
Motorola	Iron Rock	umts_irock	XT627
Motorola	MOTO E	condor_cdma	XT1019
Motorola	MOTO E	condor_cdma	XT830C
Motorola	MOTO E	condor_umts	XT1021
Motorola	MOTO E	condor_umts	XT1023
Motorola	MOTO E	condor_umtsds	XT1022

Supported Devices

Motorola	MOTO G	falcon_umts	XT1002
Motorola	MOTO G	falcon_umts	XT1003
Motorola	MOTO G	falcon_umts	XT1032
Motorola	MOTO G	peregrine	XT1039
Motorola	MOTO G	peregrine	XT1042
Motorola	MOTO G	peregrine	XT1045
Motorola	MOTO G	titan_umts	XT1063
Motorola	MOTO G	titan_umts	XT1064
Motorola	MOTO G	titan_umtsds	XT1068
Motorola	MOTO G	titan_umtsds	titan_niibr_ds
Motorola	MOTO G LTE	peregrine	XT1039
Motorola	MOTO G LTE	peregrine	XT1040
Motorola	MOTO G LTE	peregrine	XT1045
Motorola	MOTO G w/4G LTE	peregrine	XT1039
Motorola	MOTO G w/4G LTE	peregrine	XT1040
Motorola	MOTO X	ghost	XT1053
Motorola	MOTO X	ghost	XT1058
Motorola	MOTO X	victara	XT1092
Motorola	MOTO X	victara	XT1093
Motorola	MOTO X	victara	XT1094
Motorola	MOTO X	victara	XT1095
Motorola	MOTO X	victara	XT1096
Motorola	MOTO X	victara	XT1097
Motorola	MOTOROLA ELECTRIFY 2	cdma_yangtze	XT881
Motorola	MOTOROLA RAZR HD	vanquish_u	RAZR HD
Motorola	MOTOROLA RAZR M	smq_t	201M
Motorola	MOTOROLA RAZR i	smi	XT890
Motorola	Master Touch	umts_primus	XT621
Motorola	Milestone2	umts_milestone2	A953
Motorola	Milestone2	umts_milestone2	ME722

Supported Devices

Motorola	Milestone2	umts_milestone2	MotoA953
Motorola	Moto 360	minnow	Moto 360
Motorola	Moto Defy XT	XT535	XT535
Motorola	Moto Defy XT	tinboostplus_cdma	XT555C
Motorola	Moto Defy XT	tinboostplus_cdma	XT556
Motorola	Moto Defy XT	tinboostplus_cdma	XT557
Motorola	Moto Defy XT	tinboostplus_umts	XT535
Motorola	Moto E	condor_cdma	XT1019
Motorola	Moto E	condor_udstv	XT1025
Motorola	Moto E	condor_umts	XT1021
Motorola	Moto E	condor_umts	XT1023
Motorola	Moto E	condor_umtsds	XT1022
Motorola	Moto G	falcon_cdma	XT1028
Motorola	Moto G	falcon_cdma	XT1031
Motorola	Moto G	falcon_cdma	XT937C
Motorola	Moto G	falcon_umts	XT1008
Motorola	Moto G	falcon_umts	XT1032
Motorola	Moto G	falcon_umts	XT1034
Motorola	Moto G	falcon_umts	XT939G
Motorola	Moto G	falcon_umtsds	XT1033
Motorola	Moto G	titan_udstv	XT1069
Motorola	Moto G	titan_udstv	titan_retbr_dstv
Motorola	Moto G	titan_umts	XT1063
Motorola	Moto G	titan_umts	XT1064
Motorola	Moto G	titan_umtsds	XT1068
Motorola	Moto G Google Play edition	falcon_umts	XT1032
Motorola	Moto G w/ 4G LTE	peregrine	XT1045
Motorola	Moto G w/4G LTE	peregrine	XT1040
Motorola	Moto MAXX	quark_umts	XT1225
Motorola	Moto X	ghost	XT1049

Supported Devices

Motorola	Moto X	ghost	XT1050
Motorola	Moto X	ghost	XT1052
Motorola	Moto X	ghost	XT1053
Motorola	Moto X	ghost	XT1055
Motorola	Moto X	ghost	XT1056
Motorola	Moto X	ghost	XT1058
Motorola	Moto X	ghost	XT1060
Motorola	Moto X	victara	XT1097
Motorola	Moto X	victara	XT1098
Motorola	Motoluxe	XT611	XT611
Motorola	Motoluxe	XT615	XT615
Motorola	Motoluxe	XT682	XT682
Motorola	Motoluxe	ironmax_umts	XT615
Motorola	Motoluxe	ironmax_umts	XT685
Motorola	Motoluxe	ironmaxct_cdma	Motorola MOT-XT681
Motorola	Motoluxe	ironmaxtv_umts	XT687
Motorola	Motoluxe	umts_irock	XT626
Motorola	Motoluxe	umts_irock	XT627
Motorola	Motoroi	sholest	Milestone XT720
Motorola	Motoroi	sholest	Motorola XT720
Motorola	Motoroi	sholest	XT720
Motorola	Motorola Atrix HD	qinara	MB886
Motorola	Motorola Master Touch	umts_primus	XT621
Motorola	Motorola Master Touch XT621	umts_primus	XT621
Motorola	Motorola Photon	asanti_c	XT897
Motorola	Motorola Photon	asanti_c	XT897S
Motorola	Motorola RAZR HD	vanquish	DROID RAZR HD
Motorola	Motorola RAZR M	smq	XT907
Motorola	Motorola Razr V	umts_yangtze	XT885
Motorola	Motorola Razr V	umts_yangtze	XT886

Supported Devices

Motorola	Motorola XOOM 2	fleming	MZ609
Motorola	Motorola XOOM 2	pasteur	MZ617
Motorola	Motosmart	XT389	XT389
Motorola	Motosmart	XT390	XT390
Motorola	Motosmart	argonmini_umts	XT389
Motorola	Motosmart	argonmini_umts	XT390
Motorola	Motosmart	silversmart_umts	XT303
Motorola	Motosmart	silversmart_umts	XT305
Motorola	Nexus 6	shamu	Nexus 6
Motorola	Opus One	rubicon	Motorola Titanium
Motorola	Opus One	rubicon	Titanium
Motorola	Photon 4G	sunfire	ISW11M
Motorola	Photon 4G	sunfire	MB855
Motorola	Photon 4G	sunfire	Motorola Electrify
Motorola	Quench XT3	XT502	Motorola-XT502
Motorola	RAZR D1	hawk35_umts	XT914
Motorola	RAZR D1	hawk35_umts	XT915
Motorola	RAZR D1	hawk35_umts	XT916
Motorola	RAZR D1	hawk35_umts	XT918
Motorola	RAZR D3	hawk40_umts	XT919
Motorola	RAZR D3	hawk40_umts	XT920
Motorola	Spice	sesame	XT300
Motorola	XOOM	stingray	Xoom
Motorola	XOOM	umts_everest	MZ601
Motorola	XOOM	umts_hubble	MZ601
Motorola	XOOM	umts_hubble	MZ605
Motorola	XOOM	wifi_hubble	MZ604
Motorola	XOOM	wifi_hubble	MZ606
Motorola	XOOM	wingray	Xoom
Motorola	XT605	umts_jorian	XT605

Supported Devices

Motorola	XT627	umts_irock	XT627
MotorolaSolutionsInc.	TC55	TC55	TC55
MotorolaSolutionsInc.	TC55CH	TC55CH	TC55CH
Multilaser	M7s Dual Core	NB116_NB117_NB118	M7s Dual ML03
My Go	GoTab GBT10	GBT10	GoTab_GBT10
NAXA	NAXA NID-7011	NID-7011	NID-7011
NAXA	NID_7010	NID_7010	NID_7010
NCREDIBLE	NV8-HD	NV8-HD	NV8
NEC	101T \xe3\x80\x80MEDIAS	NEC-101	NEC-101T
NEC	AGT10	AGT10	N8730-411
NEC	AGT10	AGT10	N8730-41101
NEC	AGT10	AGT10	N8730-41102
NEC	CASIO G\'zOne Commando 4G LTE	C811	C811 4G
NEC	Casio G\'zOne Commando	C771	C771
NEC	Disney Mobile on docomoN-03E	N-03E	N-03E
NEC	G\'z One IS11CA	IS11CA	IS11CA
NEC	G\'zOne TYPE-L CAL21	CAL21	CAL21
NEC	G\xe2\x80\x99zOne CA-201L	CA201L	CA-201L
NEC	LaVieTab PC-TE508S1W/LaVieTab PC-TE508S1L	PC-TE508S1_nec	LaVieTab PC-TE508S1
NEC	LaVieTab PC-TE510S1L	PC-TE510S1_nec	LaVieTab PC-TE510S1
NEC	LifeTouch B	LTB013	D000-000013-101
NEC	LifeTouch B	LTB018	D000-000018-001
NEC	LifeTouch B	LTB018	D000-000018-002
NEC	LifeTouch B	LTB018	D000-000018-003
NEC	LifeTouch B	LTB018	D000-000018-004
NEC	LifeTouch B	LTB018	D000-000018-101
NEC	LifeTouch B	LTB018	D000-000018-102
NEC	LifeTouch B	LTB018	D000-000018-104

Supported Devices

NEC	LifeTouch B	LTB019G	D000-000019-002
NEC	LifeTouch B	LTB019W	D000-000019-001
NEC	LifeTouch B	LTB028	LTB-HS
NEC	LifeTouch L	D000000023	LT-TLA
NEC	LifeTouch L	D000000035	NEC-STR
NEC	LifeTouch L	D000000039	NEC-STR
NEC	LifeTouch L	LTTLA16	LT-TLA
NEC	LifeTouch L	LTTLA32	LT-TLA
NEC	LifeTouch Note	D000000010N	D000-000010-N
NEC	LifeTouch Note	D000000011N	D000-000011-N
NEC	LifeTouch Note	LTNA7	LT-NA7
NEC	LifeTouch Note	LTNA7F	LT-NA7F
NEC	LifeTouch S	LifeTouch_D1	D000-000001-B01
NEC	LifeTouch S	LifeTouch_D1	D000-000001-B02
NEC	LifeTouch S	LifeTouch_D1	D000-000001-C01
NEC	LifeTouch S	LifeTouch_D1	D000-000001-K01
NEC	LifeTouch S	LifeTouch_D1	D000-000001-R01
NEC	LifeTouch S	LifeTouch_D1	D000-000001-R02
NEC	LifeTouch S	LifeTouch_D1	D000-000001-R03
NEC	LifeTouch S	LifeTouch_D1	D000-000001-R04
NEC	LifeTouch S	LifeTouch_D1	D000-000001-S00
NEC	LifeTouch S	LifeTouch_D1	D000-000001-S01
NEC	LifeTouch S	LifeTouch_D1	D000-000001-S05
NEC	LifeTouch S	LifeTouch_D1	D000-000001-S25
NEC	LifeTouch S	LifeTouch_D1	D000-000001-S85
NEC	LifeTouch S	LifeTouch_D7	D000-000007-D01
NEC	LifeTouch W	LT-W1_1	D000-000002-W01
NEC	LifeTouch W	LT-W1_2	D000-000002-W02
NEC	LifeTouch W	LifeTouch_W1	D000-000002-001
NEC	MEDIAS X N-06E	N-06E	N-06E

Supported Devices

NEC	MEDIAS BR IS11N	IS11N	IS11N
NEC	MEDIAS CH 101N	101N	101N
NEC	MEDIAS ES N-05D	N-05D	N-05D
NEC	MEDIAS LTE N-04D	N-04D	N-04D
NEC	MEDIAS N-04C	N-04C	N-04C
NEC	MEDIAS NE-202	NE-202	NE-202
NEC	MEDIAS NEC-101S	MAGNUM	NEC-101S
NEC	MEDIAS NEC-101S	NEC-101	NEC-101S
NEC	MEDIAS NEC-102	NEC-102	NEC-102
NEC	MEDIAS PP N-01D	N-01D	N-01D
NEC	MEDIAS TAB N-06D	N-06D	N-06D
NEC	MEDIAS TAB UL N-08D	N-08D	N-08D
NEC	MEDIAS U N-02E	N-02E	N-02E
NEC	MEDIAS U NE-103T	NE-103	NE-103T
NEC	MEDIAS W N-05E	N-05E	N-05E
NEC	MEDIAS WP N-06C	N-06C	N-06C
NEC	MEDIAS X N-04E	N-04E	N-04E
NEC	MEDIAS X N-07D	N-07D	N-07D
NEC	NE-201	NE-201	NEC-NE-201A1A
NEC	NEC909e	NEC909e	NEC909e
NEC	PC- TS507N1S	PC-TS507N1S	LaVieTab PC-TS507N1S
NEC	PC-508T1W	508T1W	PC-TS508T1W
NEC	PC-708T1W	708T1W	PC-TS708T1W
NEC	PC-TE307N1W	PC-TE307N1W	PC-TE307N1W
NEC	PC-TE510N1B	LaVieTab	LaVieTab PC-TE510N1B
NESO	NESO N810 i7	N810_i7_1	N810 i7
NGM	Dynamic Racing 3	NGM_Dynamic_Racing_3	Dynamic Racing 3
NGM	Forward_Prime	Forward_Prime	Forward_Prime
NGM	Infinity	Infinity	Infinity
NGM	NGM_Dynamic_Stylo	NGM_Dynamic_Stylo	NGM_Dynamic_Stylo

Supported Devices

NVidia	SHIELD Tablet	shieldtablet	SHIELD Tablet
NVidia	Shield	roth	SHIELD
NVidia	TegraNote	tegranote	Tegra Note 7
NVidia	TegraNote	tegranote	TegraNote-P1640
NVidia	TegraNote	tegranote	TegraNote-Premium
NVidia	TegraNote	tegranote7c	Tegra Note 7
NanoTech	Nuvola NP-1	nuvola	Nuvola NP-1
Ncredible	Ncredible NV8	NV8	NV8
Netgear	NeoTVPrime	NeoTV	GTV100
Next Learning	Nexttab N3	N3	N3
Nextbook	M-MP7NB3G	7_Plus_HD3G	M-MP7NB3G
Nextbook	NX700QC	nxm7100lvd_wm	NX700QC
Nextbook	NX785QC	nxm865lvd_wm	NX785QC
Nextbook	NX785QC8G	NXM865FD	NX785QC8G
Nextel	V.35	up11_vsn_h1_single	Nextel V.35
Nextel	V.45	H26-VSN	NII Nextel
Nextel	V.45	H26-VSN	V.45
Nikon	COOLPIX	S800c	COOLPIX S800c
Nikon	COOLPIX S810c	s810c	COOLPIX S810c
Nobis	NB07	NB07	NB07
Nobis	NB1022	RCT6203W46	NB1022
Nobis	NB7022S	NB7022S	NB7022S
Nobis	NB7850S	NB7850S	NB7850S
Nobis	Nobis NB09	M9025	NB09
Noblex	NBX-T1014N	TA10CA2	TA10CA2
Noblex	NBX-T7014	E270BSA	NBX-T7014
Nubia	NX401	NX40X	NX401
Nubia	NX501	NX501	NX501
Nubia	NX503A	NX503A	NX503A
Nuvision	TM1088	fiber-wifibt	CT1000

Supported Devices

Nuvision	TM1088	fiber-wifibt	Endeavour101
Nuvision	TM1088	fiber-wifibt	TM1088
Nuvision	TM1088	fiber-wifibt	WEBPAD1002
Nyx mobile	NOBA	NOBA	NOBA
OPPO	N1	N1	N1
OPPO	N1T	N1T	N1T
OPPO	N1W	N1W	N1W
OPPO	R1001	R1001	R1001
OPPO	R2001	R2001	R2001
OPPO	R2010	R2010	R2010
OPPO	R2017	R2017	R2017
OPPO	R6007	R6007	R6007
OPPO	R7007	R7007	R7007
OPPO	R8001	R8001	R8001
OPPO	R8006	R8006	R8006
OPPO	R8007	R8007	R8007
OPPO	R815	R815	R815
OPPO	R819	R819	R819
OPPO	R821	R821	R821
OPPO	R827	R827	R827
OPPO	R827T	R827T	R827T
OPPO	R829	R829	R829
OPPO	R829T	R829T	R829T
OPPO	R830	R830	R830
OPPO	R830S	R830S	R830S
OPPO	R831	R831	R831
OPPO	R831L	R831L	R831L
OPPO	R831S	R831S	R831S
OPPO	R831T	R831T	R831T
OPPO	R850	R850	R850

Supported Devices

OPPO	U707	U707	U707
OPPO	U708	U708	U708
OPPO	X9006	X9006	X9006
OPPO	X9007	X9007	X9007
OPPO	X9070	X9070	X9070
OPPO	X9076	X9076	X9076
OPPO	X9077	X9077	X9077
OPPO	X909	FIND5	X909
Odys	ODYS UNO X10	UNO_X10	UNO X10
Odys	ODYS UNO X8	UNO_X8	UNO_X8
Olivetti	Graphos A10	Graphos_A10	Graphos A10
Olivetti	OP110	OP110	OP110
OnePlus	OnePlus One	A0001	A0001
OnePlus	OnePlus One	A0001	One
OpenPeak		CIUS-7	CIUS-7
OpenPeak		CIUS-7-AT	CIUS-7-AT
OpenPeak		cius	cius
Oppo	1100	1100	1100
Oppo	1105	1105	1105
Oppo	1107	1107	1107
Oppo	3000	3000	3000
Oppo	3001	Mirror3	3001
Oppo	3005	3005	3005
Oppo	3006	Mirror3	3006
Oppo	3007	3007	3007
Oppo	3008	3008	3008
Oppo	N1	N1	N1
Oppo	N1 mimi	N1mini	N5111
Oppo	N1 mimi	N1mini	N5116
Oppo	N3	N3	N5206

Supported Devices

Oppo	N3	N3	N5207
Oppo	N5110	N5110	N5110
Oppo	N5117	N5117	N5117
Oppo	OPPO Find5	FIND5	X909
Oppo	OPPO Find5	FIND5	X909T
Oppo	OPPO Ulike2	Ulike2	U705T
Oppo	R1001	R1001	R1001
Oppo	R5	R5	R8106
Oppo	R5	R5	R8107
Oppo	R6006	R3	R6006
Oppo	R7005	R3	R7005
Oppo	R8000	R1S	R8000
Oppo	R809T	R809T	R809T
Oppo	R815T	R815T	R815T
Oppo	R815W	R815W	R815W
Oppo	R819T	R819T	R819T
Oppo	R820	R820	R820
Oppo	R8201	R1x	R8201
Oppo	R8206	R1x	R8206
Oppo	R8207	R1C	R8207
Oppo	R821T	R821T	R821T
Oppo	R823T	R823T	R823T
Oppo	R831K	R831K	R831K
Oppo	R833T	OPPO82_13067	R833T
Oppo	U3	U3	U3
Oppo	U707T	U707T	U707T
Oppo	Ulike2	U705W	U705W
Oppo	X9000	X9000	X9000
Oppo	X9077	FIND7	X9077
Opticon	H-27	H-27	H-27

Supported Devices

Orange	Luno	Luno	Luno
Orange	NOS Roya	Alto45	NOS Roya
Orange	Orange Nura	M812	Orange Nura
Orange	Orange Roya	Alto45	Orange Roya
Orange	Orange Zilo	Orange_Zilo	Zilo
Orange	idol S	Diablo_LTE	Orange Niva
Orbic	R370H	R370H	R370L
Panasonic		H580VT_A	JT-H580VT
Panasonic		H581VT_A	JT-H581VT
Panasonic		P-08D	P-08D
Panasonic		laputa	P-07C
Panasonic	003P	pana1	003P
Panasonic	101P	pana2_2s	101P
Panasonic	102P	pana2_4s	102P
Panasonic	48AX600C	mst918_4G	48AX600C
Panasonic	55AX600C	mst918_4k2k	55AX600C
Panasonic	AS650C	AS650C	AS650C
Panasonic	Altus 18	Altus18	Altus 18
Panasonic	Altus 24	Altus24	Altus 24
Panasonic	Boukenkun-reciever	VW_RCBKK1	VW_RCBKK1
Panasonic	EB-4063-X	EB-4063-X	EB-4063-X
Panasonic	ELUGA	pana2_4o	dL1
Panasonic	ELUGA P	P-03E	P-03E
Panasonic	ELUGA Power	P-07D	P-07D
Panasonic	ELUGA U	ELUGA_U	Panasonic ELUGA U
Panasonic	ELUGA V	P-06D	P-06D
Panasonic	ELUGA X	P-02E	P-02E
Panasonic	ELUGA dL1	pana2_4v	Panasonic_dL1
Panasonic	Eco11 v2	Eco11v2	Eco11 v2
Panasonic	Eco9 v1	Eco	Eco9 v1

Supported Devices

Panasonic	Eco9 v2	Ecov2	Eco9 v2
Panasonic	Elite 11	Elite11	Elite
Panasonic	Elite 11	Elite11	Elite 11
Panasonic	Elite 16	Elite16	Elite
Panasonic	FZ-A1	toughpad	FZ-A1B
Panasonic	FZ-B2	fz_b2bb	FZ-B2B
Panasonic	FZ-X1	FZ-X1	FZ-X1
Panasonic	FZ-X1	FZ-X1VU	FZ-X1
Panasonic	FZ-X1	FZ-X1VUC	FZ-X1
Panasonic	HDPSEB v2	HDPSEBv2	HD PSEB v2
Panasonic	JT-B1	B1	JT-B1
Panasonic	KX-PRXA10	KX-PRXA10	Panasonic KX-PRXA10
Panasonic	KX-PRXA15	KX-PRXA15	Panasonic KX-PRXA15
Panasonic	LUMIX CM1	DMC-CM1	DMC-CM1
Panasonic	P-01D	pana2_1	P-01D
Panasonic	P-02D	pana2_2	P-02D
Panasonic	P-04D	pana2_4d	P-04D
Panasonic	P-05D	pana2_4a	P-05D
Panasonic	P-07C	pana1	P-07C
Panasonic	Panasonic ELUGA A	ELUGA_A	Panasonic ELUGA A
Panasonic	Panasonic ELUGA I	ELUGA_I	Panasonic ELUGA I
Panasonic	Panasonic ELUGA S	ELUGA_S	Panasonic ELUGA S
Panasonic	Panasonic P11	P11	Panasonic P11
Panasonic	Panasonic P31	P31	Panasonic P31
Panasonic	Panasonic P41	P41	Panasonic P41
Panasonic	Panasonic P41 HD	P41HD	Panasonic P41HD
Panasonic	Panasonic P51	P51	Panasonic P51
Panasonic	Panasonic P55	P55	Panasonic P55
Panasonic	Panasonic P61	P61	Panasonic P61
Panasonic	Panasonic P61	P61	Panasonic_P61

Supported Devices

Panasonic	Panasonic P81	P81	Panasonic P81
Panasonic	Panasonic T11	T11	Panasonic T11
Panasonic	Panasonic T21	T21	Panasonic T21
Panasonic	Panasonic T31	T31	Panasonic T31
Panasonic	Panasonic T40	T40	Panasonic T40
Panasonic	Panasonic T41	T41	Panasonic T41
Panasonic	Panasonic T9	T9	Panasonic T9
Panasonic	SM17	SM17	Smart Monitor 17
Panasonic	SV-ME1000	K1	Panasonic SV-ME1000
Panasonic	SmartTVBox	C01AS	SMARTTVBOX
Panasonic	UN-MT300	A1	Panasonic UN-MT300
Panasonic	UN-W700	F1	Panasonic UN-W700
Panasonic	VTSH v1	VTSHv1	VTSH v1
Pantech	ADR910L	ADR910L	ADR910L
Pantech	ADR930L	ADR930L	ADR930L
Pantech	AT1	at1	IM-T100K
Pantech	Apache	ADR8995	ADR8995
Pantech	Burst	presto	PantechP9070
Pantech	Crossover	moon	PantechP8000
Pantech	EF33S	ef33s	IM-A760S
Pantech	EF34K	ef34k	IM-A770K
Pantech	EF35L	ef35l	IM-A780L
Pantech	Element	pororo	PantechP4100
Pantech	Flex	oscar	PantechP8010
Pantech	IM-810K	ef40k	IM-A810K
Pantech	IM-840SP	IM-A840SP	IM-A840SP
Pantech	IM-A730S	ef30s	IM-A730S
Pantech	IM-A740S	ef31s	IM-A740S
Pantech	IM-A760S	ef33s	IM-A760S
Pantech	IM-A770K	ef34k	IM-A770K

Supported Devices

Pantech	IM-A775C	ef34c	IM-A775C
Pantech	IM-A780L	ef35l	IM-A780L
Pantech	IM-A800S	ef39s	IM-A800S
Pantech	IM-A810K	ef40k	IM-A810K
Pantech	IM-A810S	ef40s	IM-A810S
Pantech	IM-A830K	ef45k	IM-A830K
Pantech	IM-A830KE	ef45kv	IM-A830KE
Pantech	IM-A830L	ef46l	IM-A830L
Pantech	IM-A830S	ef47s	IM-A830S
Pantech	IM-A840S	IM-A840S	IM-A840S
Pantech	IM-A850K	ef49k	IM-A850K
Pantech	IM-A850L	ef50l	IM-A850L
Pantech	IM-A850S	ef48s	IM-A850S
Pantech	IM-A860K	ef51k	IM-A860K
Pantech	IM-A860L	ef51l	IM-A860L
Pantech	IM-A860S	ef51s	IM-A860S
Pantech	IM-A870K	ef52k	IM-A870K
Pantech	IM-A870L	ef52l	IM-A870L
Pantech	IM-A870S	ef52s	IM-A870S
Pantech	IM-A880S	EF56S	IM-A880S
Pantech	IM-A910K	ef63k	IM-A910K
Pantech	IM-A910L	ef63l	IM-A910L
Pantech	IM-A910S	ef63s	IM-A910S
Pantech	IM-A920S	ef65s	IM-A920S
Pantech	Izar	sp33k	SKY IM-A630K
Pantech	MIRACH_J	mirachj	EIS01PT
Pantech	MIRACH_J	mirachj	IS11PT
Pantech	Mirach	ef13l	IM-A690L
Pantech	Mirach	ef13s	IM-A690S
Pantech	Mirach A	ef32k	IM-A750K

Supported Devices

Pantech	P9090	magnus	PantechP9090
Pantech	PLANET	mini	PLANET
Pantech	PTL21	maruko	PTL21
Pantech	Pocket	mini	PantechP9060
Pantech	SIRIUS \xce\xbb1	jmasai	IS06
Pantech	Sirius	ef10s	SKY IM-A600S
Pantech	VEGA RACER	ef34k	IM-A770K
Pantech	VEGA RACER	ef35l	IM-A780L
Pantech	VEGA Secret Note	EF59K	IM-A890K
Pantech	VEGA Secret Note	EF59L	IM-A890L
Pantech	VEGA Secret Note	EF59S	IM-A890S
Pantech	VEGA Secret UP	EF60S	IM-A900S
Pantech	VEGA Secret UP	EF61K	IM-A900K
Pantech	VEGA Secret UP	EF62L	IM-A900L
Pantech	VEGA Secret UP	ef60s	IM-A900S
Pantech	VEGA Secret UP	ef61k	IM-A900K
Pantech	VEGA Secret UP	ef62l	IM-A900L
Pantech	Vega	ef12s	SKY IM-A650S
Pantech	Vega LTE M	ef65l	IM-A820L
Pantech	Vega X	ef14l	IM-A720L
Pantech	Vega X	ef18k	IM-A710K
Pantech	ef14lv	ef14lv	IM-A725L
Partner	OT-310	OT-310	OT-310
Pegatron		Duke3G	Android Tablet PC
Pegatron		DukeWifi	Android Tablet PC
Pegatron		TabletPC	Android Tablet PC
Pegatron	MaxilQ	MaxilQ	MaxilQ
Pegatron	Olipad	OP111	chagall
Pegatron	chagall	chagall	Chagall 10.1 WiFi
Pegatron	chagall	chagall	E-Tab 4G

Supported Devices

Pegatron	chagall	chagall	chagall
Philips		Philips_GGC3	SA3CNT
Philips		Philips_PI5000	Philips_PI5000
Philips		SA2CNTxx	Philips GoGear Connect
Philips	HMP8100/93	HMP8100_ATV_93	HMP8100_ATV_93
Philips	HMP8100/98	HMP8100_ATV	HMP8100_ATV_INT
Philips	PHP-S221C4AFD	MMD_WW	G3SMNTS22
Philips	PHP-S231C4AFD	G3SMNTS23	G3SMNTS23
Philips	PI2000	PI2000	PI2000
Philips	PI2010	PI2010	PI2010
Philips	PI2011	PI2011	PI2011
Philips	PI3100/51	PI3100_51	PI3100
Philips	PI3100/58	PI3100_58	PI3100
Philips	PI3100/93	PI3100_93	PI3100-93
Philips	PI3100/98	PI3100_98	PI3100
Philips	PI3100Z3/93	PI3100Z3_93	PI3100Z3_93
Philips	PI3105	PI3105	PI3105
Philips	PI3106	PI3106	PI3106
Philips	PI3110	PI3110	PI3110
Philips	PI3205G	PI3205G_93	PI3205G
Philips	PI3210G	PI3210G	PI3210G
Philips	PI3900	T7p_Duo_93	PI3900-93
Philips	PI3900/51	PI3900_51	PI3900
Philips	PI3900/58	PI3900_58	PI3900
Philips	PI3900/98	PI3900_98	PI3900
Philips	PI3910	PI3910	PI3910
Philips	PI4010G	PI4010G	PI4010G
Philips	PI7100/93	PI7100_93	PI7100_93
Philips	Philips Android 2014	philipstv	AND1E
Philips	Philips W8510	Topaz	Philips W8510

Supported Devices

Philips	Philips_W3500	Philips_W3500	Philips_W3500
Philips	S221C3A	MMD_WW	G2SMNT
Philips	T8 PI7000	Tablet_8	PI7000
Philips	W337	W337	W337
Philips	W3568	Philips_W3568	Philips W3568
Philips	W3620	W3620	W3620
Philips	W6500	Philips_W6500_A	W6500
Philips	W6610	Marathon	Philips W6610
Philips	W6620	W6620	W6620
Philips	W8555	Pride	Philips W8555
Pioneer	PIONEER R1	RCK8726Y703H	R1
Polaris	polaris_Condroid_X7	polaris-Condroid_X7	Condroid_X7
Polaroid	A9x/PTAB935x	A9xPTAB935x	A9x/PTAB935x
Polaroid	Infinite	MID1324	MID 1324
Polaroid	MID4X07	RCT6773W22	MID4X07
Polaroid	MID4X10	RCT6203W46	MID4X10
Polaroid	P10/Q10/PTAB1040/PTAB1041	pq10-Polaroid	P10/Q10/PTAB1040/PTAB1041
Polaroid	P1001	P1001	P1001
Polaroid	P7/Q7/PTAB740/PTAB741	pq7-Polaroid	P7/Q7/PTAB740/PTAB741
Polaroid	P791	P791	P791
Polaroid	P9/Q9/PTAB940/PTAB941	pq9-Polaroid	P9/Q9/PTAB940/PTAB941
Polaroid	POLAROID A7_PTAB735	A7_PTAB735	HS-7DTB39
Polaroid	PRO5023PW	up06_h25_polaroid	PRO5023PW
Polaroid	PTAB1051-PTAB1055	RCT6203W46	PTAB1051_PTAB1055
Polaroid	Polaroid A/S10	wing-AS10	A/S10
Polaroid	Polaroid A/S7	wing-AS7	A/S7
Polaroid	Polaroid A/S8	wing-AS8	A/S8
Polaroid	Polaroid A7X_PTAB735X	PTAB735X	A7X_PTAB735X
Polaroid	Polaroid K7	PTAB782	K7/PTAB782
Polaroid	Polaroid MID1028	MID1028	MID1028

Supported Devices

Polaroid	Polaroid PTAB751	STJR76	PTAB751
Polaroid	Polaroid V7	nuclear-M7021	V7
Positivo	Positivo AB7	YPY_AB7D	YPY_AB7D
Positivo	Positivo AB7D	YPY_AB7DC	YPY_AB7DC
Positivo	Positivo Mini	mini	Positivo Mini
Positivo	Positivo Mini	mini	Positivo Mini TE
Positivo	Positivo S380	S380	S380
Positivo	Positivo S450	S450	S450
Positivo	Positivo SX1000	SX1000	Positivo SX1000
Positivo	Positivo T1060	t1060	T1060
Positivo	Positivo T701 TV	T701	T701
Positivo	Positivo T705	T705	T705
Positivo	Positivo T705	T705	T705K
Positivo	Positivo T710	T710	Positivo T710
Positivo	Positivo T750	t750	Positivo T750
Positivo	Positivo YPY AB7	YPY_AB7	Positivo Ypy AB7E
Positivo	Positivo YPY AB7	YPY_AB7	Positivo Ypy AB7EC
Positivo	Positivo YPY7 3G	TB07FTA	Positivo Ypy 7 - TB07FTA
Positivo	Positivo YPY7 3G	TB07FTA	Ypy 7 - TB07FTA
Positivo	Positivo YPY7 3G	YPY_07FTA	YPY_07FTA
Positivo	Positivo YPY7 wifi	TB07STA	Positivo Ypy 7 - TB07STA
Positivo	Positivo YPY7 wifi	TB07STA	Ypy 7 - TB07STA
Positivo	Positivo YPY7 wifi	YPY_07STA	YPY_07STA
Positivo	Positivo Ypy 07FTB	YPY_07FTB	POSITIVO TABLET YPY 07FTB PM BEL\xc3\x89M
Positivo	Positivo Ypy 07FTB	YPY_07FTB	YPY_07FTB
Positivo	Positivo Ypy 07FTBF	YPY_07FTBF	YPY_07FTBF
Positivo	Positivo Ypy 07STB	YPY_07STB	YPY_07STB
Positivo	Positivo Ypy 07STBF	YPY_07STBF	YPY_07STBF
Positivo	Positivo Ypy 10FTB	YPY_10FTB	YPY_10FTB

Supported Devices

Positivo	Positivo Ypy 10FTBF	YPY_10FTBF	YPY_10FTBF
Positivo	Positivo Ypy 10STB	YPY_10STB	YPY_10STB
Positivo	Positivo Ypy 10STBF	YPY_10STBF	YPY_10STBF
Positivo	Positivo Ypy AB10	YPY_AB10D	YPY_AB10D
Positivo	Positivo Ypy AB10D	YPY_AB10DC	YPY_AB10DC
Positivo	Positivo Ypy AB10E	YPY_AB10EC	Positivo Ypy AB10EC
Positivo	Positivo Ypy AB10H	YPY_AB10H	Positivo Ypy AB10H
Positivo	Positivo Ypy AB7F	YPY_AB7F	Positivo Ypy AB7F
Positivo	Positivo Ypy L700	YPY_L700	Positivo Ypy L700
Positivo	Positivo Ypy L700	YPY_L700	Positivo Ypy L700 Ed. Especial
Positivo	Positivo Ypy L700	YPY_L700	Positivo Ypy L700+
Positivo	Positivo Ypy S350p	YPY_S350	YPY_S350_PLUS
Positivo	Positivo Ypy S405	YPY_S405	YPY_S405
Positivo	Positivo Ypy TQ7	YPY_TQ7	YPY_TQ7
Positivo	Positivo mini I	mini_i	Positivo Mini I
Positivo	S440	S440	S440
Positivo	S480	S480	S480
Positivo	YPY 10 3G	YPY_10FTA	YPY_10FTA
Positivo	YPY S400	YPY_S400	YPY_S400
Positivo	Ypy	T701_AR	L701 TV
Positivo	Ypy	YPY_L700	Positivo BGH Ypy L700
Positivo	Ypy AB10DP	YPY_AB10DP	YPY_AB10DP
Positivo	Ypy AB10E	YPY_AB10E	Positivo Ypy AB10E
Positivo	Ypy AB7K	YPY_AB7K	YPY_AB7K
Positivo	Ypy Kids	YPY_L700	Positivo BGH Ypy L700 Kids
Positivo	Ypy Kids	YPY_L700	Positivo Ypy L700 Kids
Positivo	Ypy Kids	YPY_L700	Positivo Ypy L700+ Kids
Positivo	Ypy L1000	YPY_L1000	Positivo Ypy L1000
Positivo	Ypy L1000	YPY_L1000	Positivo Ypy L1000F
Positivo	Ypy L1050	YPY_L1050	Positivo Ypy L1050

Supported Devices

Positivo	Ypy L1050	YPY_L1050	Positivo Ypy L1050F
Positivo	Ypy L1050E	YPY_L1050E	Positivo Ypy L1050E
Positivo	Ypy Mini	mini	Positivo BGH Mini
Positivo	Ypy S350	YPY_S350	YPY_S350
Positivo	Ypy S450	YPY_S450	YPY_S450
Positivo	Ypy S460	YPY_S460	YPY_S460
Positivo	Ypy S500	YPY_S500	YPY_S500
Prestige	ELITE10Q	Elite10Q	Elite10Q
Prestige	ELITE7Q	Elite7Q	Elite7Q
Prestige	ELITE8Q	ELITE8Q	ELITE8Q
Prestige	ELITE8QS	Elite8QS	Elite8QS
Prestige	ELITE9Q	ELITE9Q	ELITE9Q
Prestige	PRO7DS	PRO7DS	PRO7DS
Prestige	PRO8D	PRO8D	PRO8D
Prestige	PRO9D	PRO9D	PRO9D
Prestige	Prestige 7G	Prestige-7G	Prestige 7G
Prestige	Prestige PRO10D	PRO10D	PRO10D
Prestigio	GV7790	GV7790	GV7790
Prestigio	MultiPad Thunder 7.0i	g01p	PMT3377_Wi
Prestigio	MultiPad Wize 3037 3G	PMT3038_3G	PMT3037_3G
Prestigio	MultiPad Wize 3038 3G	PMT3038_3G	PMT3038_3G
Prestigio	MultiPhone 5453 DUO	PSP5453DUO	PSP5453DUO
Prestigio	MultiPhone 5455 DUO	PSP5455DUO	PSP5455DUO
Prestigio	MultiPhone 5504 DUO	PSP5504DUO	PSP5504DUO
Prestigio	MultiPhone 5505 DUO	PSP5505DUO	PSP5505DUO
Prestigio	MultiPhone 5517 DUO	PSP5517DUO	PSP5517DUO
Prestigio	Multiphone 5508 DUO	PSP5508DUO	PSP5508DUO
Prestigio	PMT3008_Wi	PMT3008_Wi_C	PMT3008_Wi_C
Prestigio	PMT3047_3G	PMT3047_3G	PMT3047_3G
Prestigio	PMT3177_3G	PMT3177_3G	PMT3177_3G

Supported Devices

Prestigio	PMT3277_3G	PMT3277_3G	PMT3277_3G
Prestigio	PMT3287_3G	PMT3287_3G	PMT3287_3G
Prestigio	PMT3677_Wi	PMT3677	PMT3677_Wi
Prestigio	PMT5001_3G	PMT5001_3G	PMT5001_3G
Prestigio	PMT5002_Wi	PMT5002_Wi	PMT5002_Wi
Prestigio	PMT5008_3G	PMT5008_3G	PMT5008_3G
Prestigio	PMT5011_3G	PMT5001_3G	PMT5011_3G
Prestigio	PMT5018_3G	PMT5008_3G	PMT5018_3G
Prestigio	PMT5021_3G	PMT5001_3G	PMT5021_3G
Prestigio	PMT5287_4G	PMT5287_4G	PMT5287_4G
Prestigio	PMT5487_3G	PMT5487_3G	PMT5487_3G
Prestigio	PMT5777_3G	PMT5777_3G	PMT5777_3G
Prestigio	PMT5887_3G	PMT5887_3G	PMT5887_3G
Prestigio	PMT7177_3G	PMT7177_3G	PMT7177_3G
Prestigio	PMT7287_3G	PMT7287_3G	PMT7287_3G
Prestigio	PMT7787_3G	PMT7787_3G	PMT7787_3G
Prestigio	PSP3404DUO	PSP3404DUO	PSP3404DUO
Prestigio	PSP3405DUO	PSP3405DUO	PSP3405DUO
Prestigio	PSP3450DUO	PSP3450DUO	PSP3450DUO
Prestigio	PSP3502DUO	PSP3502DUO	PSP3502DUO
Prestigio	PSP5047DUO	MT6589	PSP5047DUO
Prestigio	PSP5454DUO	PSP5454DUO	PSP5454DUO
Prestigio	PSP5457DUO	MT6572	PSP5457DUO
Prestigio	PSP5507DUO	PSP5507DUO	PSP5507DUO
Prestigio	PSP5550DUO	PSP5550DUO	PSP5550DUO
Prestigio	Prestigio Grace	PSP7557	PSP7557
Prestigio	Prestigio MultiPad Wize 3009	PMT3009_Wi_C	PMT3009_Wi_C
Prestigio	Prestigio MultiPad Wize 3017	PMT3017_WI	PMT3017_WI
Prestigio	Prestigio MultiPad Wize 3018	PMT3018_WI	PMT3018_WI
Prestigio	Prestigio PMT5587_Wi	AML8726-MXS	PMT5587_Wi

Supported Devices

Prestigio	Prestigio PMT5877C	PMT5877C	PMT5877C
Prestigio	Prestigio PMT7077_3G	PMT7077_3G	PMT7077_3G
Prestigio	Prestigio PMT7287C3G	PMT7287C3G	PMT7287C3G
Prestigio	Prestigio PSP5307DUO	PSP5307DUO	PSP5307DUO
Proscan	PLT1077G(1GB/8GB)	PLT1077G	PLT1077G
Proscan	PLT7100G	PLT7100G	PLT7100G
Proscan	PLT7109G	PLT7109G	PLT7109G
Proscan	PLT7130G	PLT7130G	PLT7130G
Proscan	PLT7602G	PLT7602G	PLT7602G
Proscan	PLT7803G	PLT7803G	PLT7803G
Proscan	PLT7804G	PLT7804G	PLT7804G
Proscan	PLT8802G	PLT8802G	PLT8802G
Proscan	PLT9602G	PLT9602G	PLT9602G
Proscan	PLT9606G	PLT9606G	PLT9606G
Proscan	PLT9609G	PLT9609G	PLT9609G
Proscan	PROSCAN PLT8235G Tablet	MID807_K	PLT8235G
QLA	C600	GBC_bravo	C600
QOOQ	QOOQV3	QOOQ	QOOQ
Qilive	Q.3778	Q3778	Q.3778
Qilive	Qilive W55	W55	W55
Quanta		Nirvana_Tablet	Nirvana_Tablet
Quanta		infinity_g	INFINITY G NK2
Quanta		nk1	IGS-1000
Quanta		nk1	TA1013
Quanta		ventana	NK1_111018_002_HC
Quanta		ventana	Q10
Quanta	CT2200	CT2200	CT2200
Quanta	FT103	FT103	FT103
Quanta	True Beyond 4G	al7	TRUE BEYOND 4G
Quanta	VSD220	VSD220	VSD220

Supported Devices

RAINBOW	WIKO	s5501	RAINBOW
RCA	RCA DAA730R / RCA DAA738R	MD7081	DAA730R
RCA	RCA DAA730R / RCA DAA738R	MD7081	DAA738R
RCA	RCA RCS13101T	RCS13101T	RCS13101T
RCA	RCA RCT6077W2	RCT6077W2	RCT6077W2
RCA	RCA RCT6077W22	RCT6077W22	RCT6077W22
RCA	RCA RCT6272W23	RCT6272W23	RCT6272W23
RCA	RCA RCT6378W2	RCT6378W2	RCT6378W2
RCA	RCA RCT6691W3	RCT6691W3	RCT6691W3
RCA	RCT6002W46	RCT6002W46	RCT6002W46
RCA	RCT6103W46	RCT6103W46	RCT6103W46
RCA	RCT6203W46	RCT6203W46	RCT6203W46
RCA	RCT6273W26	RCT6273W26	RCT6273W26
RCA	RCT6293W23	RCT6293W23	RCT6293W23
RCA	RCT6573W23	RCT6573W23	RCT6573W23
RCA	RCT6672W23	RCT6672W23	RCT6672W23
RCA	RCT6773W22	RCT6773W22	RCT6773W22
REACH	Q882	Q882	Q882
Revtel	R45	Revel_R45	R45
SAKAISIO	SAKAISIO FP-U320-711-WIFI	U320-WF	FP-U320-711-WIFI
SAKAISIO	SAKAISIO FP-U320-711-WWAN	U320-3G	FP-U320-711-WWAN
SELECLINE	MID7526CM	MID7526CM	NID_7010
SELECLINE	MID_9526CM	MID_9526CM	S952
SENSEIT	SENSEIT L301	SENSEIT-L301	SENSEIT L301
SFR	SFR-G8800	stb_dvb_sfr	SFR-G8800
SFR	STARADDICT 4	staraddict4	STARADDICT 4
SFR	Star Shine II	up11_sfr_mensa	STARSHINE II
SFR	Star Trail 5	STARTRAIL5	STARTRAIL5
SFR	Star Trail III	mobiwire_startrail3	StarTrail III
SK Broadband	B tv smart	BHX-S100	BHX-S100

Supported Devices

SK Broadband	B tv smart	BKO-S200	BKO-S200
SK Telesys		K4	SK-S170
SK Telesys		msm8255_k5	SK-S150
SK Telesys		qsd8250_s1	SK-S100
SK Telesys	AN200	AN200	AN200
SK Telesys	Fly	htt77_ics2	Fly
SK Telesys	ITP-E410W	willow	ITP-E410W
SK Telesys	ITP-R208W	rk30sdk	ITP-R208W
SK Telesys	Ice-Phone Forever	z262_wvga_mge	Ice-Phone Forever
SK Telesys	K2401	K2401	S201
SK Telesys	S150	msm8255_k5	S150
SK Telesys	T720	T720	Clear
SK Telesys	UTA200	htt75_nand_6628_ics	UTA200
SK Telesys	icube-830	icube-830	icube-830
SKnetworks	EG68BE	EG668BE	EG668
SKnetworks	EG978TW	EG978TW	EG978
SKnetworks	EG980	eg980tw	EG980
SKnetworks	WA966	u966e_2	WA966
SKnetworks	WA978	u978e_1	WA978
SMARTAB	SMARTAB ST700	ST700	ST700
SOSMART	SOSMART T5	SOSMART_T5	SOSMART_T5
STOREX	eZee\Tab7Q11-M	Tab7Q11	Tab7Q11
STOREX	eZee\xe2\x80\x99Tab7D14-S	STOREX7526	NID_7010
Samsung		GT-I5510M	GT-I5510M
Samsung		GT-I5510T	GT-I5510T
Samsung		GT-I5800L	GT-I5800L
Samsung		GT-N7000B	GT-N7000B
Samsung		GT-P7300B	GT-P7300B
Samsung		GT-P7320T	GT-P7320T
Samsung		GT-P7500M	GT-P7500M

Supported Devices

Samsung		GT-P7500R	GT-P7500R
Samsung		GT-P7500V	GT-P7500V
Samsung		GT-S5698	GT-S5698
Samsung		GT-S5820	GT-S5820
Samsung		GT-S5830V	GT-S5830V
Samsung		SCH-I339	SCH-I339
Samsung		SCH-I405U	SCH-I405U
Samsung		SCH-I509U	SCH-I509U
Samsung		SCH-I519	SCH-I519
Samsung		SCH-I559	SCH-I559
Samsung		SCH-I559	SCH-i559
Samsung		SCH-I639	SCH-I639
Samsung		SCH-I659	SCH-I659
Samsung		SCH-I699	SCH-I699
Samsung		SCH-I779	SCH-I779
Samsung		SCH-I919U	SCH-I919U
Samsung		SCH-W899	SCH-W899
Samsung		SCH-W999	SCH-W999
Samsung		SCH-i809	SCH-i809
Samsung		SCH-i919	SCH-i919
Samsung		SGH-I987	SGH-I987
Samsung		SGH_T939	Behold II
Samsung		SHV-E150S	SHV-E150S
Samsung		SHW-M115S	SHW-M115S
Samsung		SHW-M135K	SHW-M135K
Samsung		SHW-M135L	SHW-M135L
Samsung		SHW-M340D	SHW-M340D
Samsung		SHW-M340K	SHW-M340K
Samsung		SHW-M460D	SHW-M460D
Samsung		amazingtrf	SGH-S730G

Supported Devices

Samsung		aruba3gchn	GT-I8262D
Samsung		d2vzw	SCH-I535PP
Samsung		espressoefcmcc	GT-P3108
Samsung		gd1ltekt	EK-KC120K
Samsung		godivaltevw	SCH-I425
Samsung		hllte	SM-N7505
Samsung		htdlte	SM-N9007
Samsung		ironcmcc	GT-B9388
Samsung		klteaio	SAMSUNG-SM-G900AZ
Samsung		kylepro	GT-S7580L
Samsung		loganrelte	GT-S7275Y
Samsung		lt03ltetmo	SM-P607T
Samsung		m0grandectc	SCH-W2013
Samsung		m0grandectc	SCH-W9913
Samsung		m2a3g	SM-C111
Samsung		m2altelgt	SM-C115L
Samsung		matisselteatt	SAMSUNG-SM-T537A
Samsung		matisselteusc	SM-T537R4
Samsung		matisseltevw	SM-T537V
Samsung		milletltevw	SM-T337V
Samsung		mondrianlte	SM-T325
Samsung		ms01lte	SM-G7105H
Samsung		p4noterfskt	SHW-M480S
Samsung		picassowifi	SM-T520
Samsung		q7lteskt	SM-T255S
Samsung		stunnerltespr	SPH-L500
Samsung		superiorchn	GT-I9260
Samsung		viennalteatt	SAMSUNG-SM-P907A
Samsung	Absolute	GT-B9120	GT-B9120
Samsung	Acclaim	SCH-R880	SCH-R880

Supported Devices

Samsung	Admire	SCH-R720	SCH-R720
Samsung	Amazing	amazingtrf	SGH-S730M
Samsung	Baffin	baffinltelgt	SHV-E270L
Samsung	Captivate Glide	SGH-I927	SAMSUNG-SGH-I927
Samsung	Captivate Glide	SGH-I927	SGH-I927
Samsung	China Telecom	kylevectc	SCH-I699I
Samsung	Conquer	SPH-D600	SPH-D600
Samsung	DoubleTime	SGH-I857	SAMSUNG-SGH-I857
Samsung	Droid Charge	SCH-I510	SCH-I510
Samsung	Europa	GT-I5500B	GT-I5500B
Samsung	Europa	GT-I5500L	GT-I5500L
Samsung	Europa	GT-I5500M	GT-I5500M
Samsung	Europa	GT-I5503T	GT-I5503T
Samsung	Europa	GT-I5510L	GT-I5510L
Samsung	Exhibit	SGH-T759	SGH-T759
Samsung	GALAXY Camera	gd1	EK-GC100
Samsung	Galaxy (China)	GT-B9062	GT-B9062
Samsung	Galaxy 070	hendrix	YP-GI2
Samsung	Galaxy A	archer	SHW-M100S
Samsung	Galaxy A	archer	archer
Samsung	Galaxy A3	a33g	SM-A300H
Samsung	Galaxy A3	a3lte	SM-A300F
Samsung	Galaxy A3	a3lte	SM-A300M
Samsung	Galaxy A3	a3ltechn	SM-A3000
Samsung	Galaxy A3	a3ltechn	SM-A300X
Samsung	Galaxy A3	a3ltectc	SM-A3009
Samsung	Galaxy A3	a3ltezh	SM-A3000
Samsung	Galaxy A3	a3ulte	SM-A300FU
Samsung	Galaxy A3	a3ulte	SM-A300XU
Samsung	Galaxy A5	a53g	SM-A500H

Supported Devices

Samsung	Galaxy A5	a5lte	SM-A500F
Samsung	Galaxy A5	a5lte	SM-A500G
Samsung	Galaxy A5	a5lte	SM-A500M
Samsung	Galaxy A5	a5ltechn	SM-A5000
Samsung	Galaxy A5	a5ltechn	SM-A500X
Samsung	Galaxy A5	a5lfectc	SM-A5009
Samsung	Galaxy A5	a5ltezh	SM-A5000
Samsung	Galaxy A5	a5ltezt	SM-A500YZ
Samsung	Galaxy A5	a5ultektt	SM-A500K
Samsung	Galaxy A5	a5ultelgt	SM-A500L
Samsung	Galaxy A5	a5ulteskt	SM-A500S
Samsung	Galaxy Ace	GT-S5830	GT-S5830
Samsung	Galaxy Ace	GT-S5830B	GT-S5830B
Samsung	Galaxy Ace	GT-S5830C	GT-S5830C
Samsung	Galaxy Ace	GT-S5830D	GT-S5830D
Samsung	Galaxy Ace	GT-S5830F	GT-S5830F
Samsung	Galaxy Ace	GT-S5830G	GT-S5830G
Samsung	Galaxy Ace	GT-S5830L	GT-S5830L
Samsung	Galaxy Ace	GT-S5830M	GT-S5830M
Samsung	Galaxy Ace	GT-S5830T	GT-S5830T
Samsung	Galaxy Ace	GT-S5830i	GT-S5830i
Samsung	Galaxy Ace	GT-S5831i	GT-S5831i
Samsung	Galaxy Ace	GT-S5838	GT-S5838
Samsung	Galaxy Ace	GT-S5839i	GT-S5839i
Samsung	Galaxy Ace	GT-S6358	GT-S6358
Samsung	Galaxy Ace	SCH-I619	SCH-I619
Samsung	Galaxy Ace	SHW-M240S	SHW-M240S
Samsung	Galaxy Ace	heatlte	SM-G357M
Samsung	Galaxy Ace 4	vivaltods5m	SM-G313HU
Samsung	Galaxy Ace 4	vivaltods5m	SM-G313HY

Supported Devices

Samsung	Galaxy Ace 4	vivaltods5m	SM-G313M
Samsung	Galaxy Ace 4	vivaltods5m	SM-G313MY
Samsung	Galaxy Ace 4 Lite	vivalto3g	SM-G313U
Samsung	Galaxy Ace Advance	GT-S6800	GT-S6800
Samsung	Galaxy Ace Duos	GT-S6352	GT-S6352
Samsung	Galaxy Ace Duos	GT-S6802	GT-S6802
Samsung	Galaxy Ace Duos	GT-S6802B	GT-S6802B
Samsung	Galaxy Ace Duos	SCH-I579	SCH-i579
Samsung	Galaxy Ace Duos	SCH-I589	SCH-I589
Samsung	Galaxy Ace Duos	SCH-I589	SCH-i589
Samsung	Galaxy Ace Duos	SCH-i579	SCH-i579
Samsung	Galaxy Ace Duos	SCH-i589	SCH-i589
Samsung	Galaxy Ace Plus	GT-S7500	GT-S7500
Samsung	Galaxy Ace Plus	GT-S7500L	GT-S7500L
Samsung	Galaxy Ace Plus	GT-S7500T	GT-S7500T
Samsung	Galaxy Ace Plus	GT-S7500W	GT-S7500W
Samsung	Galaxy Ace Plus	GT-S7508	GT-S7508
Samsung	Galaxy Ace Q	SGH-I827D	SGH-I827D
Samsung	Galaxy Ace Style	heat3gtfnvzw	SM-S765C
Samsung	Galaxy Ace Style	heat3gtfnvzw	SM-S766C
Samsung	Galaxy Ace Style	heatnfc3g	SM-G310HN
Samsung	Galaxy Ace Style	heatqlte	SM-G357FZ
Samsung	Galaxy Ace2	GT-I8160	GT-I8160
Samsung	Galaxy Ace2	GT-I8160L	GT-I8160L
Samsung	Galaxy Ace2	GT-I8160P	GT-I8160P
Samsung	Galaxy Ace2 X	kylesopen	GT-S7560
Samsung	Galaxy Ace2 X	kylesopen	GT-S7560M
Samsung	Galaxy Ace3	logan	GT-S7270
Samsung	Galaxy Ace3	logan	GT-S7270L
Samsung	Galaxy Ace3	logan	SCH-I679

Supported Devices

Samsung	Galaxy Ace3	logan3gcmcc	GT-S7278
Samsung	Galaxy Ace3	logands	GT-S7272
Samsung	Galaxy Ace3	loganlte	GT-S7275
Samsung	Galaxy Ace3	loganrelte	GT-S7275B
Samsung	Galaxy Ace3	loganrelte	GT-S7275R
Samsung	Galaxy Ace3	loganrelte	GT-S7275T
Samsung	Galaxy Ace3 Duos	loganlite3g	GT-S7272C
Samsung	Galaxy Ace3 Duos	loganu3gcmcc	GT-S7278U
Samsung	Galaxy Ace3 Duos TV	logandsdtv	GT-S7273T
Samsung	Galaxy Ace4	vivalto3g	SM-G313ML
Samsung	Galaxy Ace4	vivalto5mve3g	SM-G316M
Samsung	Galaxy Ace4	vivaltolte	SM-G313F
Samsung	Galaxy Ace4	vivaltolte	SM-G313MU
Samsung	Galaxy Ace4	vivaltonfc3g	SM-G313HN
Samsung	Galaxy Ace4 Lite	vivalto	SM-G3139D
Samsung	Galaxy Ace4 Lite	vivalto3g	SM-G313H
Samsung	Galaxy Admire	SCH-R820	SCH-R820
Samsung	Galaxy Admire 2	goghcri	SCH-R830C
Samsung	Galaxy Alpha	slte	SM-G850F
Samsung	Galaxy Alpha	slte	SM-G850FQ
Samsung	Galaxy Alpha	slte	SM-G850M
Samsung	Galaxy Alpha	slte	SM-G850X
Samsung	Galaxy Alpha	slte	SM-G850Y
Samsung	Galaxy Alpha	slteatt	SAMSUNG-SM-G850A
Samsung	Galaxy Alpha	sltecan	SM-G850W
Samsung	Galaxy Alpha	sltechn	SM-G8508S
Samsung	Galaxy Alpha	sltekt	SM-G850K
Samsung	Galaxy Alpha	sltelgt	SM-G850L
Samsung	Galaxy Alpha	slteskt	SM-G850S
Samsung	Galaxy Amp	kyleatt	SAMSUNG-SGH-I407

Supported Devices

Samsung	Galaxy Apollo	GT-I5800	GT-I5800
Samsung	Galaxy Apollo	GT-I5800	GT-I5800L
Samsung	Galaxy Apollo	GT-I5800D	GT-I5800D
Samsung	Galaxy Apollo	GT-I5801	GT-I5801
Samsung	Galaxy Appeal	SGH-I827	SAMSUNG-SGH-I827
Samsung	Galaxy Attain	SCH-R920	SCH-R920
Samsung	Galaxy Avant	afyonltetmo	SM-G386T
Samsung	Galaxy Axiom	infiniteusc	SCH-R830
Samsung	Galaxy Beam	GT-I8250	GT-I8250
Samsung	Galaxy Beam	GT-I8530	GT-I8530
Samsung	Galaxy Camera	gd1	EK-GC100
Samsung	Galaxy Camera	gd1att	SAMSUNG-EK-GC100
Samsung	Galaxy Camera	gd1can	EK-GC100
Samsung	Galaxy Camera	gd1ktt	EK-KC100K
Samsung	Galaxy Camera	gd1ltelgt	EK-KC120L
Samsung	Galaxy Camera	gd1lteskt	EK-KC120S
Samsung	Galaxy Camera	gd1ltevzw	EK-GC120
Samsung	Galaxy Camera	gd1skt	EK-KC100S
Samsung	Galaxy Camera	gd1wifi	EK-GC110
Samsung	Galaxy Camera	gd1wifiiny	EK-GC110
Samsung	Galaxy Camera	u0lte	EK-GN100
Samsung	Galaxy Camera	u0lte	EK-GN120
Samsung	Galaxy Camera 2	sf2wifi	EK-GC200
Samsung	Galaxy Centura	amazing3gtrf	SCH-S738C
Samsung	Galaxy Chat	zanin	GT-B5330
Samsung	Galaxy Chat	zanin	GT-B5330B
Samsung	Galaxy Chat	zanin	GT-B5330L
Samsung	Galaxy Core	afyonlteMetroPCS	SM-G386T1
Samsung	Galaxy Core	afyonltecan	SM-G386W
Samsung	Galaxy Core	arubaslim	GT-I8262

Supported Devices

Samsung	Galaxy Core	arubaslimss	GT-I8260
Samsung	Galaxy Core	arubaslimss	GT-I8260L
Samsung	Galaxy Core 2	kanas	SM-G355H
Samsung	Galaxy Core Advance	cane3g	GT-I8580
Samsung	Galaxy Core Advance	cane3gskt	SHW-M570S
Samsung	Galaxy Core LTE	afyonlte	SM-G386F
Samsung	Galaxy Core LTE	cs03lte	SM-G3518
Samsung	Galaxy Core Lite	victorlte	SM-G3586V
Samsung	Galaxy Core Lite	victorlte	SM-G3589W
Samsung	Galaxy Core Max	kleoslte	SM-G5108
Samsung	Galaxy Core Max Duos	kleoslte	SM-G5108Q
Samsung	Galaxy Core Plus	cs02	SM-G350
Samsung	Galaxy Core Plus	cs023g	SM-G3502
Samsung	Galaxy Core Plus	cs02ve3g	SM-G3502L
Samsung	Galaxy Core Plus	cs02ve3gdtv	SM-G3502T
Samsung	Galaxy Core Plus	cs02ve3gss	SM-G350L
Samsung	Galaxy Core Plus	cs02ve3gss	SM-G350M
Samsung	Galaxy Core Prime	core33g	SM-G360H
Samsung	Galaxy Core Prime	rossalte	SM-G3606
Samsung	Galaxy Core Prime	rossalte	SM-G3608
Samsung	Galaxy Core Prime	rossaltectc	SM-G3609
Samsung	Galaxy Core Safe	arubaslimss	GT-I8260E
Samsung	Galaxy Core Safe	arubaslimss	SHW-M580D
Samsung	Galaxy Core Safe	arubaslimss	SHW-M585D
Samsung	Galaxy Core2	kanas	SM-G355H
Samsung	Galaxy Core2	kanas	SM-G355HQ
Samsung	Galaxy Core2	kanas	SM-G355M
Samsung	Galaxy Core2	kanas3g	SM-G3556D
Samsung	Galaxy Core2	kanas3gcmcc	SM-G3558
Samsung	Galaxy Core2	kanas3gctc	SM-G3559

Supported Devices

Samsung	Galaxy Core2	kanas3gnfc	SM-G355HN
Samsung	Galaxy Discover	amazing3gcri	SCH-R740C
Samsung	Galaxy Discover	amazingtrfcd	SCH-S735C
Samsung	Galaxy Duos	aruba3gcmcc	GT-I8268
Samsung	Galaxy E7	e7lte	SM-E700M
Samsung	Galaxy Europa	GT-I5500	GT-I5500
Samsung	Galaxy Europa	GT-I5503	GT-I5503
Samsung	Galaxy Europa	GT-I5508	GT-I5508
Samsung	Galaxy Europa	GT-I5510	GT-I5510
Samsung	Galaxy Exhibit	codinaMetroPCS	SGH-T599N
Samsung	Galaxy Exhibit	codinatmo	SGH-T599
Samsung	Galaxy Exhibit	codinavid	SGH-T599V
Samsung	Galaxy Exhibit2	SGH-T679	SGH-T679
Samsung	Galaxy Exhilarate	SGH-I577	SAMSUNG-SGH-I577
Samsung	Galaxy Express	expressatt	SAMSUNG-SGH-I437
Samsung	Galaxy Express	expressatt	SAMSUNG-SGH-I437P
Samsung	Galaxy Express	expresslte	GT-I8730
Samsung	Galaxy Express	expresslte	GT-I8730T
Samsung	Galaxy Express	expresszigtteatt	SAMSUNG-SGH-I437Z
Samsung	Galaxy Express2	wilcoxlte	SM-G3815
Samsung	Galaxy Fame	SCH-I629	SCH-I629
Samsung	Galaxy Fame	nevis	GT-S6810
Samsung	Galaxy Fame	nevis	GT-S6810B
Samsung	Galaxy Fame	nevis	GT-S6810E
Samsung	Galaxy Fame	nevis	GT-S6810L
Samsung	Galaxy Fame	nevis3g	GT-S6812i
Samsung	Galaxy Fame	nevis3gcmcc	GT-S6818
Samsung	Galaxy Fame	nevis3gcmcc	GT-S6818V
Samsung	Galaxy Fame	nevisds	GT-S6812
Samsung	Galaxy Fame	nevisds	GT-S6812B

Supported Devices

Samsung	Galaxy Fame	nevisnvest	GT-S6790N
Samsung	Galaxy Fame	nevisp	GT-S6810M
Samsung	Galaxy Fame	nevisp	GT-S6810P
Samsung	Galaxy Fame	nevisvest	GT-S6790
Samsung	Galaxy Fame	nevisvest	GT-S6790E
Samsung	Galaxy Fame	nevisvest	GT-S6790L
Samsung	Galaxy Fame	nevisw	GT-S6812C
Samsung	Galaxy Fame Lite Duos	nevisw	GT-S6792L
Samsung	Galaxy Fit	GT-S5670	GT-S5670
Samsung	Galaxy Fit	GT-S5670B	GT-S5670B
Samsung	Galaxy Fit	GT-S5670L	GT-S5670L
Samsung	Galaxy Fresh	kylevest	GT-S7390
Samsung	Galaxy Fresh	kylevest	GT-S7390E
Samsung	Galaxy Fresh	kylevest	GT-S7390G
Samsung	Galaxy Gio	GT-S5660	GT-S5660
Samsung	Galaxy Gio	GT-S5660B	GT-S5660B
Samsung	Galaxy Gio	GT-S5660L	GT-S5660L
Samsung	Galaxy Gio	GT-S5660M	GT-S5660M
Samsung	Galaxy Gio	GT-S5660V	GT-S5660V
Samsung	Galaxy Gio	SCH-i569	SCH-i569
Samsung	Galaxy Gio	SHW-M290K	SHW-M290K
Samsung	Galaxy Gio	SHW-M290S	SHW-M290S
Samsung	Galaxy Golden	ks02lte	GT-I9230
Samsung	Galaxy Golden	ks02lte	GT-I9235
Samsung	Galaxy Golden	ks02ltekt	SHV-E400K
Samsung	Galaxy Golden	ks02lteskt	SHV-E400S
Samsung	Galaxy Golden 2	pateklte	SM-W2015
Samsung	Galaxy Grand	baffin3gduosctc	SCH-I879
Samsung	Galaxy Grand	baffincmcc	GT-I9128
Samsung	Galaxy Grand	baffincmcc	GT-I9128V

Supported Devices

Samsung	Galaxy Grand	baffinltektt	SHV-E270K
Samsung	Galaxy Grand	baffinlteskt	SHV-E270S
Samsung	Galaxy Grand	baffinrd	GT-I9118
Samsung	Galaxy Grand	baffinss	GT-I9080E
Samsung	Galaxy Grand	baffinss	GT-I9080L
Samsung	Galaxy Grand	baffinvekt	SHV-E275K
Samsung	Galaxy Grand	baffinveskt	SHV-E275S
Samsung	Galaxy Grand	baffinvetd3g	GT-I9128E
Samsung	Galaxy Grand	baffinvetd3g	GT-I9128I
Samsung	Galaxy Grand Duos	baffin	GT-I9082
Samsung	Galaxy Grand Duos	baffin	GT-I9082L
Samsung	Galaxy Grand Neo	baffinlite	GT-I9060
Samsung	Galaxy Grand Neo	baffinlite	GT-I9060L
Samsung	Galaxy Grand Neo	baffinlite	GT-I9082C
Samsung	Galaxy Grand Neo	baffinlitedtv	GT-I9063T
Samsung	Galaxy Grand Neo	baffinq3g	GT-I9168
Samsung	Galaxy Grand Neo	baffinq3g	GT-I9168I
Samsung	Galaxy Grand Neo Plus	grandneove3g	GT-I9060C
Samsung	Galaxy Grand Neo+	baffinq3gduosctc	SCH-I879E
Samsung	Galaxy Grand Prime	fortuna3g	SM-G530H
Samsung	Galaxy Grand Prime	fortuna3gdtv	SM-G530BT
Samsung	Galaxy Grand Prime	fortunalte	SM-G5306W
Samsung	Galaxy Grand Prime	fortunalte	SM-G5308W
Samsung	Galaxy Grand Prime	fortunalte	SM-G530F
Samsung	Galaxy Grand Prime	fortunalte	SM-G530M
Samsung	Galaxy Grand Prime	fortunaltectc	SM-G5309W
Samsung	Galaxy Grand Prime	fortunaltezh	SM-G5308W
Samsung	Galaxy Grand Prime	fortunaltezt	SM-G530Y
Samsung	Galaxy Grand duos	baffin	GT-I9082i
Samsung	Galaxy Grand-Max	grandmaxltekx	SM-G720N0

Supported Devices

Samsung	Galaxy Grand2	ms013g	SM-G7102
Samsung	Galaxy Grand2	ms013g	SM-G7106
Samsung	Galaxy Grand2	ms013g	SM-G7108
Samsung	Galaxy Grand2	ms013g	SM-G7109
Samsung	Galaxy Grand2	ms013gdtv	SM-G7102T
Samsung	Galaxy Grand2	ms013gss	SM-G710
Samsung	Galaxy Grand2	ms01lte	SM-G7105
Samsung	Galaxy Grand2	ms01lte	SM-G7105L
Samsung	Galaxy Grand2	ms01ltekt	SM-G710K
Samsung	Galaxy Grand2	ms01lteigt	SM-G710L
Samsung	Galaxy Grand2	ms01lteskt	SM-G710S
Samsung	Galaxy Indulge	SCH-R910	SCH-R910
Samsung	Galaxy Indulge	SCH-R915	SCH-R915
Samsung	Galaxy Infinite	infinite3gduosctc	SCH-I759
Samsung	Galaxy J	hltejs01tw	SGH-N075T
Samsung	Galaxy K	SHW-M130K	SHW-M130K
Samsung	Galaxy K Zoom	m2a3g	SM-C111M
Samsung	Galaxy K Zoom	m2alte	SM-C115
Samsung	Galaxy K Zoom	m2alte	SM-C115M
Samsung	Galaxy K Zoom	m2altecan	SM-C115W
Samsung	Galaxy M Pro2	lucas	GT-B7810
Samsung	Galaxy M Style	SHW-M340L	SHW-M340L
Samsung	Galaxy M Style	SHW-M340S	SHW-M340S
Samsung	Galaxy M Style	vastoicmcc	GT-I8258
Samsung	Galaxy Mega 2	mega23g	SM-G750H
Samsung	Galaxy Mega 5.8	crater	GT-I9152
Samsung	Galaxy Mega 5.8	crater3gctc	SCH-P709
Samsung	Galaxy Mega 5.8	craterss	GT-I9150
Samsung	Galaxy Mega 5.8	cratertd3g	GT-I9158
Samsung	Galaxy Mega 6.3	melius3g	GT-I9200

Supported Devices

Samsung	Galaxy Mega 6.3	melius3g	GT-I9208
Samsung	Galaxy Mega 6.3	melius3gduosctc	SCH-P729
Samsung	Galaxy Mega 6.3	meliuslte	GT-I9205
Samsung	Galaxy Mega 6.3	meliuslteMetroPCS	SGH-M819N
Samsung	Galaxy Mega 6.3	meliuslteatt	SAMSUNG-SGH-I527
Samsung	Galaxy Mega 6.3	meliusltecan	SGH-I527M
Samsung	Galaxy Mega 6.3	meliusltekt	SHV-E310K
Samsung	Galaxy Mega 6.3	meliuslteigt	SHV-E310L
Samsung	Galaxy Mega 6.3	meliuslteskt	SHV-E310S
Samsung	Galaxy Mega 6.3	meliusltespr	SPH-L600
Samsung	Galaxy Mega 6.3	meliuslteusc	SCH-R960
Samsung	Galaxy Mega Plus	craterq3g	GT-I9152P
Samsung	Galaxy Mega Plus	craterq3g	GT-I9158P
Samsung	Galaxy Mega Plus	megapluslte	GT-I9158V
Samsung	Galaxy Mega2	mega2lte	SM-G750F
Samsung	Galaxy Mega2	mega2lteatt	SAMSUNG-SM-G750A
Samsung	Galaxy Mega2	vasta3g	SM-G750H
Samsung	Galaxy Mega2	vastalte	SM-G7508Q
Samsung	Galaxy Mega2	vastaltezh	SM-G7508Q
Samsung	Galaxy Mini	GT-S5570	GT-S5570
Samsung	Galaxy Mini	GT-S5570B	GT-S5570B
Samsung	Galaxy Mini	GT-S5570I	GT-S5570I
Samsung	Galaxy Mini	GT-S5570L	GT-S5570L
Samsung	Galaxy Mini	GT-S5578	GT-S5578
Samsung	Galaxy Mini	SGH-T499	SGH-T499
Samsung	Galaxy Mini	SGH-T499V	SGH-T499V
Samsung	Galaxy Mini	SGH-T499Y	SGH-T499Y
Samsung	Galaxy Mini2	GT-S6500	GT-S6500
Samsung	Galaxy Mini2	GT-S6500D	GT-S6500D
Samsung	Galaxy Mini2	GT-S6500L	GT-S6500L

Supported Devices

Samsung	Galaxy Mini2	GT-S6500T	GT-S6500T
Samsung	Galaxy Music	ivoryss	GT-S6010
Samsung	Galaxy Music	ivoryss	GT-S6010L
Samsung	Galaxy Music Duos	ivory	GT-S6012
Samsung	Galaxy Music Duos	ivory	GT-S6012B
Samsung	Galaxy NX	u0lte	EK-GN120
Samsung	Galaxy NX	u0lte	EK-GN120A
Samsung	Galaxy NX	u0lteue	EK-GN120A
Samsung	Galaxy Neo	SHW-M220L	SHW-M220L
Samsung	Galaxy Nexus	maguro	Galaxy Nexus
Samsung	Galaxy Nexus	maguro	Galaxy X
Samsung	Galaxy Nexus	toro	Galaxy Nexus
Samsung	Galaxy Nexus	toroplus	Galaxy Nexus
Samsung	Galaxy Note	GT-I9220	GT-I9220
Samsung	Galaxy Note	GT-I9228	GT-I9228
Samsung	Galaxy Note	GT-N7000	GT-N7000
Samsung	Galaxy Note	GT-N7005	GT-N7005
Samsung	Galaxy Note	SC-05D	SC-05D
Samsung	Galaxy Note	SCH-i889	SCH-i889
Samsung	Galaxy Note	SGH-I717	SAMSUNG-SGH-I717
Samsung	Galaxy Note	SGH-I717	SGH-I717
Samsung	Galaxy Note	SGH-I717D	SGH-I717D
Samsung	Galaxy Note	SGH-I717M	SGH-I717M
Samsung	Galaxy Note	SGH-I717R	SGH-I717R
Samsung	Galaxy Note	SGH-T879	SGH-T879
Samsung	Galaxy Note	SHV-E160K	SHV-E160K
Samsung	Galaxy Note	SHV-E160L	SHV-E160L
Samsung	Galaxy Note	SHV-E160S	SHV-E160S
Samsung	Galaxy Note 10.1	lt033g	SM-P601
Samsung	Galaxy Note 10.1	lt033g	SM-P602

Supported Devices

Samsung	Galaxy Note 10.1	lt03ltekt	SM-P605K
Samsung	Galaxy Note 10.1	lt03lteigt	SM-P605L
Samsung	Galaxy Note 10.1	lt03lteskt	SM-P605S
Samsung	Galaxy Note 10.1	p4notelte	GT-N8020
Samsung	Galaxy Note 10.1	p4noteltekt	SHV-E230K
Samsung	Galaxy Note 10.1	p4notelteigt	SHV-E230L
Samsung	Galaxy Note 10.1	p4notelteskt	SHV-E230S
Samsung	Galaxy Note 10.1	p4noteltespr	SPH-P600
Samsung	Galaxy Note 10.1	p4notelteusc	SCH-I925U
Samsung	Galaxy Note 10.1	p4noteltevzw	SCH-I925
Samsung	Galaxy Note 10.1	p4noterf	GT-N8000
Samsung	Galaxy Note 10.1	p4noterf	GT-N8005
Samsung	Galaxy Note 10.1	p4noterfkt	SHW-M480K
Samsung	Galaxy Note 10.1	p4notewifi	GT-N8013
Samsung	Galaxy Note 10.1	p4notewifi43241any	SHW-M486W
Samsung	Galaxy Note 10.1	p4notewifiany	SHW-M480W
Samsung	Galaxy Note 10.1	p4notewifiktt	SHW-M485W
Samsung	Galaxy Note 10.1	p4notewifiww	GT-N8010
Samsung	Galaxy Note 10.1 2014 Edition	lt033g	SM-P601
Samsung	Galaxy Note 10.1 2014 Edition	lt03lte	SM-P605
Samsung	Galaxy Note 10.1 2014 Edition	lt03lte	SM-P605M
Samsung	Galaxy Note 10.1 2014 Edition	lt03ltevzw	SM-P605V
Samsung	Galaxy Note 10.1 2014 Edition	lt03wifi	SM-P600
Samsung	Galaxy Note 10.1 2014 Edition	lt03wifikx	SM-P600
Samsung	Galaxy Note 10.1 2014 Edition	lt03wifiue	SM-P600
Samsung	Galaxy Note 8	konalteatt	SAMSUNG-SGH-I467
Samsung	Galaxy Note 8.0	kona3g	GT-N5100
Samsung	Galaxy Note 8.0	kona3g	GT-N5105
Samsung	Galaxy Note 8.0	konalte	GT-N5120
Samsung	Galaxy Note 8.0	konaltecan	SGH-I467M

Supported Devices

Samsung	Galaxy Note 8.0	konawifi	GT-N5110
Samsung	Galaxy Note 8.0	konawifiary	SHW-M500W
Samsung	Galaxy Note Edge	SCL24	SCL24
Samsung	Galaxy Note Edge	tbeltekt	SM-N915K
Samsung	Galaxy Note Edge	tbeltelgt	SM-N915L
Samsung	Galaxy Note Edge	tbelteskt	SM-N915S
Samsung	Galaxy Note Edge	tblte	SM-N9150
Samsung	Galaxy Note Edge	tblte	SM-N915F
Samsung	Galaxy Note Edge	tblte	SM-N915FY
Samsung	Galaxy Note Edge	tblte	SM-N915G
Samsung	Galaxy Note Edge	tblte	SM-N915X
Samsung	Galaxy Note Edge	tblteatt	SAMSUNG-SM-N915A
Samsung	Galaxy Note Edge	tbltecan	SM-N915W8
Samsung	Galaxy Note Edge	tbltechn	SM-N9150
Samsung	Galaxy Note Edge	tbltespr	SM-N915P
Samsung	Galaxy Note Edge	tbltetmo	SM-N915T
Samsung	Galaxy Note Edge	tblteusc	SM-N915R4
Samsung	Galaxy Note Edge	tbltevw	SM-N915V
Samsung	Galaxy Note II	t0lteatt	SAMSUNG-SGH-I317
Samsung	Galaxy Note Pro 12.2	v1a3g	SM-P901
Samsung	Galaxy Note Pro 12.2	v1awifi	SM-P900
Samsung	Galaxy Note Pro 12.2	v1awifikx	SM-P900
Samsung	Galaxy Note Pro 12.2	viennalte	SM-P905
Samsung	Galaxy Note Pro 12.2	viennalte	SM-P905M
Samsung	Galaxy Note Pro 12.2	viennaltekx	SM-P905F0
Samsung	Galaxy Note Pro 12.2	viennaltevzw	SM-P905V
Samsung	Galaxy Note2	SC-02E	SC-02E
Samsung	Galaxy Note2	t03g	GT-N7100
Samsung	Galaxy Note2	t03g	GT-N7100T
Samsung	Galaxy Note2	t03gchn	GT-N7100

Supported Devices

Samsung	Galaxy Note2	t03gchnduos	GT-N7102
Samsung	Galaxy Note2	t03gchnduos	GT-N7102i
Samsung	Galaxy Note2	t03gcmcc	GT-N7108
Samsung	Galaxy Note2	t03gctc	SCH-N719
Samsung	Galaxy Note2	t03gcduos	GT-N7102
Samsung	Galaxy Note2	t03gcduos	GT-N7102i
Samsung	Galaxy Note2	t0lte	GT-N7105
Samsung	Galaxy Note2	t0lte	GT-N7105T
Samsung	Galaxy Note2	t0lteatt	SAMSUNG-SGH-I317
Samsung	Galaxy Note2	t0ltecan	SGH-I317M
Samsung	Galaxy Note2	t0ltecan	SGH-T889V
Samsung	Galaxy Note2	t0ltecmcc	GT-N7108D
Samsung	Galaxy Note2	t0litedcm	SC-02E
Samsung	Galaxy Note2	t0ltektt	SHV-E250K
Samsung	Galaxy Note2	t0lteigt	SHV-E250L
Samsung	Galaxy Note2	t0lteskt	SHV-E250S
Samsung	Galaxy Note2	t0ltespr	SPH-L900
Samsung	Galaxy Note2	t0ltetmo	SGH-T889
Samsung	Galaxy Note2	t0lteusc	SCH-R950
Samsung	Galaxy Note2	t0ltevzw	SCH-I605
Samsung	Galaxy Note3	SC-02F	SC-02F
Samsung	Galaxy Note3	SCL22	SCL22
Samsung	Galaxy Note3	ha3g	SM-N900
Samsung	Galaxy Note3	ha3g	SM-N9000Q
Samsung	Galaxy Note3	hlte	SM-N9005
Samsung	Galaxy Note3	hlte	SM-N9006
Samsung	Galaxy Note3	hlte	SM-N9007
Samsung	Galaxy Note3	hlte	SM-N9008V
Samsung	Galaxy Note3	hlte	SM-N9009
Samsung	Galaxy Note3	hlte	SM-N900U

Supported Devices

Samsung	Galaxy Note3	hlteatt	SAMSUNG-SM-N900A
Samsung	Galaxy Note3	hltecan	SM-N900W8
Samsung	Galaxy Note3	hltekt	SM-N900K
Samsung	Galaxy Note3	hltelgt	SM-N900L
Samsung	Galaxy Note3	hlteskt	SM-N900S
Samsung	Galaxy Note3	hltespr	SM-N900P
Samsung	Galaxy Note3	hltetmo	SM-N900T
Samsung	Galaxy Note3	hlteusc	SM-N900R4
Samsung	Galaxy Note3	hltevw	SM-N900V
Samsung	Galaxy Note3 Duos	hlte	SM-N9002
Samsung	Galaxy Note3 Duos	hlte	SM-N9008
Samsung	Galaxy Note3 Neo	frescoltekt	SM-N750K
Samsung	Galaxy Note3 Neo	frescoltelgt	SM-N750L
Samsung	Galaxy Note3 Neo	frescolteskt	SM-N750S
Samsung	Galaxy Note3 Neo	hl3g	SM-N750
Samsung	Galaxy Note3 Neo	hl3g	SM-N7500Q
Samsung	Galaxy Note3 Neo	hl3gds	SM-N7502
Samsung	Galaxy Note3 Neo	hlite	SM-N7505
Samsung	Galaxy Note3 Neo	hlite	SM-N7507
Samsung	Galaxy Note4	tre3g	SM-N910H
Samsung	Galaxy Note4	trelte	SM-N910C
Samsung	Galaxy Note4	treltekt	SM-N910K
Samsung	Galaxy Note4	treltelgt	SM-N910L
Samsung	Galaxy Note4	trelteskt	SM-N910S
Samsung	Galaxy Note4	trhplte	SM-N910U
Samsung	Galaxy Note4	trlte	SM-N910F
Samsung	Galaxy Note4	trlte	SM-N910G
Samsung	Galaxy Note4	trlte	SM-N910X
Samsung	Galaxy Note4	trlteatt	SAMSUNG-SM-N910A
Samsung	Galaxy Note4	trlteatt	SM-N910F

Supported Devices

Samsung	Galaxy Note4	trltecn	SM-N910W8
Samsung	Galaxy Note4	trltechn	SM-N9100
Samsung	Galaxy Note4	trltechn	SM-N9106W
Samsung	Galaxy Note4	trltechn	SM-N9108V
Samsung	Galaxy Note4	trltechn	SM-N9109W
Samsung	Galaxy Note4	trltechnzh	SM-N9100
Samsung	Galaxy Note4	trltespr	SM-N910P
Samsung	Galaxy Note4	trltetmo	SM-N910T
Samsung	Galaxy Note4	trlteusc	SM-N910R4
Samsung	Galaxy Note4	trltevw	SM-N910V
Samsung	Galaxy Player	YP-GB70	YP-GB70
Samsung	Galaxy Player 3.6	YP-GS1	YP-GS1
Samsung	Galaxy Player 4	YP-GB1	YP-GB1
Samsung	Galaxy Player 4.0	YP-G1	YP-G1
Samsung	Galaxy Player 4.2	YP-GI1	YP-GI1
Samsung	Galaxy Player 5	YP-G70	YP-G70
Samsung	Galaxy Player 5.8	harrison	YP-GP1
Samsung	Galaxy Player 5.8	harrisonkrkt	YP-GP1
Samsung	Galaxy Player 5.8	harrisonkrlgt	YP-GP1
Samsung	Galaxy Player 50	YP-G50	YP-G50
Samsung	Galaxy Pocket	GT-S5300	GT-S5300
Samsung	Galaxy Pocket	GT-S5300B	GT-S5300B
Samsung	Galaxy Pocket	GT-S5300L	GT-S5300L
Samsung	Galaxy Pocket	GT-S5302	GT-S5302
Samsung	Galaxy Pocket	GT-S5302B	GT-S5302B
Samsung	Galaxy Pocket	coriplus	GT-S5301
Samsung	Galaxy Pocket	coriplusds	GT-S5303
Samsung	Galaxy Pocket Neo	corsica	GT-S5312
Samsung	Galaxy Pocket Neo	corsica	GT-S5312B
Samsung	Galaxy Pocket Neo	corsica	GT-S5312L

Supported Devices

Samsung	Galaxy Pocket Neo	corsicass	GT-S5310
Samsung	Galaxy Pocket Neo	corsicass	GT-S5310B
Samsung	Galaxy Pocket Neo	corsicass	GT-S5310E
Samsung	Galaxy Pocket Neo	corsicass	GT-S5310G
Samsung	Galaxy Pocket Neo	corsicass	GT-S5310L
Samsung	Galaxy Pocket Neo	corsicass	GT-S5310T
Samsung	Galaxy Pocket Neo	corsicave3g	GT-S5310I
Samsung	Galaxy Pocket Neo	corsicave3g	GT-S5310N
Samsung	Galaxy Pocket Neo	corsicaveds3gvj	GT-S5312C
Samsung	Galaxy Pocket Neo	corsicaveds3gvj	GT-S5312M
Samsung	Galaxy Pocket Neo	d2aio	SAMSUNG-SGH-I747Z
Samsung	Galaxy Pocket Plus	coriplus	GT-S5301
Samsung	Galaxy Pocket Plus	coriplus	GT-S5301B
Samsung	Galaxy Pocket Plus	coriplus	GT-S5301L
Samsung	Galaxy Pocket SS	corsicave3g	GT-S5310C
Samsung	Galaxy Pocket SS	corsicave3g	GT-S5310M
Samsung	Galaxy Pocket2	pocket23g	SM-G110B
Samsung	Galaxy Pocket2	pocket23g	SM-G110M
Samsung	Galaxy Pocket2	pocket2ss3g	SM-G110H
Samsung	Galaxy Pop	superiorlteskt	SHV-E220S
Samsung	Galaxy Pop (CDMA)	SCH-i559	SCH-i559
Samsung	Galaxy Precedent	SCH-M828C	SCH-M828C
Samsung	Galaxy Premier	superior	GT-I9260
Samsung	Galaxy Premier	superiorcmcc	GT-I9268
Samsung	Galaxy Prevail	SPH-M820	SPH-M820-BST
Samsung	Galaxy Prevail2	raybst	SPH-M840
Samsung	Galaxy Pro	GT-B7510	GT-B7510
Samsung	Galaxy Pro	GT-B7510B	GT-B7510B
Samsung	Galaxy Pro	GT-B7510L	GT-B7510L
Samsung	Galaxy Proclaim	SCH-S720C	SCH-S720C

Supported Devices

Samsung	Galaxy Q	SGH-T589	SGH-T589
Samsung	Galaxy Q	SGH-T589R	SGH-T589R
Samsung	Galaxy Q	SGH-T589W	SGH-T589W
Samsung	Galaxy R-Style	jaguark	SHV-E170K
Samsung	Galaxy R-Style	jaguarl	SHV-E170L
Samsung	Galaxy R-Style	jaguars	SHV-E170S
Samsung	Galaxy Reverb	iconvmu	SPH-M950
Samsung	Galaxy Round	flteskt	SM-G910S
Samsung	Galaxy Rugby	comanchecan	SGH-I547C
Samsung	Galaxy Rugby Pro	comancheatt	SAMSUNG-SGH-I547
Samsung	Galaxy Rush	prevail2spr	SPH-M830
Samsung	Galaxy S	GT-I9000	GT-I9000
Samsung	Galaxy S	GT-I9000B	GT-I9000B
Samsung	Galaxy S	GT-I9000M	GT-I9000M
Samsung	Galaxy S	GT-I9000T	GT-I9000T
Samsung	Galaxy S	GT-I9003	GT-I9003
Samsung	Galaxy S	GT-I9003L	GT-I9003L
Samsung	Galaxy S	GT-I9008L	GT-I9008L
Samsung	Galaxy S	GT-I9010	GT-I9010
Samsung	Galaxy S	GT-I9018	GT-I9018
Samsung	Galaxy S	GT-I9050	GT-I9050
Samsung	Galaxy S	SC-02B	SC-02B
Samsung	Galaxy S	SCH-I500	SCH-I500
Samsung	Galaxy S	SCH-S950C	SCH-S950C
Samsung	Galaxy S	SCH-i909	SCH-i909
Samsung	Galaxy S	SGH-I897	SAMSUNG-SGH-I897
Samsung	Galaxy S	SGH-T959V	SGH-T959V
Samsung	Galaxy S	SGH-T959W	SGH-T959W
Samsung	Galaxy S	SHW-M110S	SHW-M110S
Samsung	Galaxy S	SHW-M190S	SHW-M190S

Supported Devices

Samsung	Galaxy S	SPH-D700	SPH-D700
Samsung	Galaxy S	loganlte	GT-S7275
Samsung	Galaxy S Advance	GT-I9070	GT-I9070
Samsung	Galaxy S Advance	GT-I9070P	GT-I9070P
Samsung	Galaxy S Aviator	SCH-R930	SCH-R930
Samsung	Galaxy S Blaze	SGH-T769	SGH-T769
Samsung	Galaxy S BlazeQ	apexqtmo	SGH-T699
Samsung	Galaxy S Captivate	SGH-I896	SAMSUNG-SGH-I896
Samsung	Galaxy S Captivate	SGH-I896	SGH-I896
Samsung	Galaxy S Continuum	SCH-I400	SCH-I400
Samsung	Galaxy S DUOS	kyleopen	GT-S7562
Samsung	Galaxy S DUOS	kyleopen	GT-S7562L
Samsung	Galaxy S Duos	kylechn	GT-S7562
Samsung	Galaxy S Duos	kyleopen	GT-S7562
Samsung	Galaxy S Duos	kyletdcmcc	GT-S7568
Samsung	Galaxy S Duos2	kyleprods	GT-S7582
Samsung	Galaxy S Duos2	kyleprods	GT-S7582L
Samsung	Galaxy S Duos3	vivalto3gvn	SM-G313HZ
Samsung	Galaxy S Epic	SPH-D700	SPH-D700
Samsung	Galaxy S Fascinate	SGH-T959P	SGH-T959P
Samsung	Galaxy S Glide	SGH-I927R	SAMSUNG-SGH-I927R
Samsung	Galaxy S Lightray	SCH-R940	SCH-R940
Samsung	Galaxy S Plus	GT-I9001	GT-I9001
Samsung	Galaxy S Stratosphere	SCH-I405	SCH-I405
Samsung	Galaxy S Vibrant	SGH-T959	SGH-T959
Samsung	Galaxy S Vibrant	SGH-T959D	SGH-T959D
Samsung	Galaxy S duos	kyleichn	GT-S7566
Samsung	Galaxy S2	GT-I9100	GT-I9100
Samsung	Galaxy S2	GT-I9100M	GT-I9100M
Samsung	Galaxy S2	GT-I9100P	GT-I9100P

Supported Devices

Samsung	Galaxy S2	GT-I9100T	GT-I9100T
Samsung	Galaxy S2	GT-I9103	GT-I9103
Samsung	Galaxy S2	GT-I9108	GT-I9108
Samsung	Galaxy S2	GT-I9210T	GT-I9210T
Samsung	Galaxy S2	SC-02C	SC-02C
Samsung	Galaxy S2	SCH-R760X	SCH-R760X
Samsung	Galaxy S2	SGH-I777	SAMSUNG-SGH-I777
Samsung	Galaxy S2	SGH-S959G	SGH-S959G
Samsung	Galaxy S2	SGH-T989	SGH-T989
Samsung	Galaxy S2	SHV-E110S	SHV-E110S
Samsung	Galaxy S2	SHW-M250K	SHW-M250K
Samsung	Galaxy S2	SHW-M250L	SHW-M250L
Samsung	Galaxy S2	SHW-M250S	SHW-M250S
Samsung	Galaxy S2	t1cmcc	GT-I9108
Samsung	Galaxy S2 Duos	SCH-i929	SCH-i929
Samsung	Galaxy S2 Duos TV	logandsdtv	GT-S7273T
Samsung	Galaxy S2 Epic	SCH-R760	SCH-R760
Samsung	Galaxy S2 Epic	SPH-D710	SPH-D710
Samsung	Galaxy S2 Epic	SPH-D710BST	SPH-D710BST
Samsung	Galaxy S2 Epic	SPH-D710VMUB	SPH-D710VMUB
Samsung	Galaxy S2 HD LTE	SGH-I757M	SGH-I757M
Samsung	Galaxy S2 HD LTE	SHV-E120K	SHV-E120K
Samsung	Galaxy S2 HD LTE	SHV-E120L	SHV-E120L
Samsung	Galaxy S2 HD LTE	SHV-E120S	SHV-E120S
Samsung	Galaxy S2 LTE	GT-I9210	GT-I9210
Samsung	Galaxy S2 LTE	SC-03D	SC-03D
Samsung	Galaxy S2 LTE	SGH-I727R	SGH-I727R
Samsung	Galaxy S2 Plus	GT-I9100G	GT-I9100G
Samsung	Galaxy S2 Plus	s2ve	GT-I9105
Samsung	Galaxy S2 Plus	s2vep	GT-I9105P

Supported Devices

Samsung	Galaxy S2 Skyrocket	SGH-I727	SAMSUNG-SGH-I727
Samsung	Galaxy S2 Skyrocket	SGH-I727	SGH-I727
Samsung	Galaxy S2 Wimax	ISW11SC	ISW11SC
Samsung	Galaxy S2 X	SGH-T989D	SGH-T989D
Samsung	Galaxy S3	SC-03E	SC-03E
Samsung	Galaxy S3	c1att	SGH-I748
Samsung	Galaxy S3	c1ktt	SHV-E210K
Samsung	Galaxy S3	c1lgt	SHV-E210L
Samsung	Galaxy S3	c1skt	SHV-E210S
Samsung	Galaxy S3	d2att	SAMSUNG-SGH-I747
Samsung	Galaxy S3	d2can	SGH-I747M
Samsung	Galaxy S3	d2can	SGH-T999V
Samsung	Galaxy S3	d2cri	SCH-R530C
Samsung	Galaxy S3	d2dcm	Gravity
Samsung	Galaxy S3	d2dcm	SC-06D
Samsung	Galaxy S3	d2lteMetroPCS	SGH-T999N
Samsung	Galaxy S3	d2lterefreshspr	SPH-L710T
Samsung	Galaxy S3	d2ltetmo	SGH-T999L
Samsung	Galaxy S3	d2mtr	SCH-R530M
Samsung	Galaxy S3	d2spi	SCH-L710
Samsung	Galaxy S3	d2spr	SPH-L710
Samsung	Galaxy S3	d2tfnspr	SCH-S960L
Samsung	Galaxy S3	d2tfnvzw	SCH-S968C
Samsung	Galaxy S3	d2tmo	SGH-T999
Samsung	Galaxy S3	d2usc	SCH-R530U
Samsung	Galaxy S3	d2vmu	SPH-L710
Samsung	Galaxy S3	d2vzw	SCH-I535
Samsung	Galaxy S3	d2xar	SCH-R530X
Samsung	Galaxy S3	m0	GT-I9300
Samsung	Galaxy S3	m0	GT-I9300T

Supported Devices

Samsung	Galaxy S3	m0apt	SCH-I939
Samsung	Galaxy S3	m0chn	GT-I9300
Samsung	Galaxy S3	m0cmcc	GT-I9308
Samsung	Galaxy S3	m0ctc	SCH-I939
Samsung	Galaxy S3	m0ctcduos	SCH-I939D
Samsung	Galaxy S3	m0skt	SHW-M440S
Samsung	Galaxy S3	m3	GT-I9305
Samsung	Galaxy S3	m3	GT-I9305N
Samsung	Galaxy S3	m3	GT-I9305T
Samsung	Galaxy S3	m3dcm	GravityQuad
Samsung	Galaxy S3	m3dcm	SC-03E
Samsung	Galaxy S3 Duos	arubaslim	GT-I8262B
Samsung	Galaxy S3 Mini	golden	GT-I8190
Samsung	Galaxy S3 Mini	golden	GT-I8190L
Samsung	Galaxy S3 Mini	golden	GT-I8190N
Samsung	Galaxy S3 Mini	golden	GT-I8190T
Samsung	Galaxy S3 Mini	goldenlteatt	SAMSUNG-SM-G730A
Samsung	Galaxy S3 Mini	goldenltebmc	SM-G730W8
Samsung	Galaxy S3 Mini	goldenltevzw	SM-G730V
Samsung	Galaxy S3 Mini	goldene3g	GT-I8200L
Samsung	Galaxy S3 Mini Value Edition	goldene3g	GT-I8200N
Samsung	Galaxy S3 Mini Value Edition	goldenvess3g	GT-I8200
Samsung	Galaxy S3 Mini Value Edition	goldenvess3g	GT-I8200Q
Samsung	Galaxy S3 Neo	s3ve3g	GT-I9300I
Samsung	Galaxy S3 Neo	s3ve3g	GT-I9301I
Samsung	Galaxy S3 Neo	s3ve3g	GT-I9301Q
Samsung	Galaxy S3 Neo	s3ve3gdd	GT-I9300I
Samsung	Galaxy S3 Neo	s3ve3gds	GT-I9300I
Samsung	Galaxy S3 Neo	s3ve3gdsdd	GT-I9300I
Samsung	Galaxy S3 Neo Plus	s3ve3g	GT-I9300I

Supported Devices

Samsung	Galaxy S3 Neo Plus	s3ve3g	GT-I9308I
Samsung	Galaxy S3 Progre	SCL21	SCL21
Samsung	Galaxy S3 Slim	wilcoxds	SM-G3812B
Samsung	Galaxy S4	SC-04E	SC-04E
Samsung	Galaxy S4	ja3g	GT-I9500
Samsung	Galaxy S4	ja3gduosctc	SCH-I959
Samsung	Galaxy S4	jaltekt	SHV-E300K
Samsung	Galaxy S4	jaltelgt	SHV-E300L
Samsung	Galaxy S4	jalteskt	SHV-E300S
Samsung	Galaxy S4	jflte	GT-I9505
Samsung	Galaxy S4	jflte	GT-I9508
Samsung	Galaxy S4	jflte	GT-I9508C
Samsung	Galaxy S4	jflteai	SAMSUNG-SGH-I337Z
Samsung	Galaxy S4	jflteatt	SAMSUNG-SGH-I337
Samsung	Galaxy S4	jfltecan	SGH-I337M
Samsung	Galaxy S4	jfltecan	SGH-M919V
Samsung	Galaxy S4	jfltecri	SCH-R970C
Samsung	Galaxy S4	jfltecs	SCH-R970X
Samsung	Galaxy S4	jfltelra	SCH-I545L
Samsung	Galaxy S4	jflterefreshspr	SPH-L720T
Samsung	Galaxy S4	jfltespr	SPH-L720
Samsung	Galaxy S4	jfltetfnatt	SM-S975L
Samsung	Galaxy S4	jfltetfntmo	SGH-S970G
Samsung	Galaxy S4	jfltetmo	SGH-M919
Samsung	Galaxy S4	jflteusc	SCH-R970
Samsung	Galaxy S4	jfltevw	SCH-I545
Samsung	Galaxy S4	jftdd	GT-I9507
Samsung	Galaxy S4	jftdd	GT-I9507V
Samsung	Galaxy S4	jfvelte	GT-I9515
Samsung	Galaxy S4	jfvelte	GT-I9515L

Supported Devices

Samsung	Galaxy S4	jfwifi	GT-I9505X
Samsung	Galaxy S4	ks01lte	GT-I9506
Samsung	Galaxy S4	ks01tekt	SHV-E330K
Samsung	Galaxy S4	ks01telgt	SHV-E330L
Samsung	Galaxy S4 Active	jactivelte	GT-I9295
Samsung	Galaxy S4 Active	jactivelteatt	SAMSUNG-SGH-I537
Samsung	Galaxy S4 Active	jactivelteatt	SGH-I537
Samsung	Galaxy S4 Active	jactivelteskt	SHV-E470S
Samsung	Galaxy S4 Duos	ja3gchnduos	GT-I9502
Samsung	Galaxy S4 Google Play Edition	jgedlte	GT-I9505G
Samsung	Galaxy S4 LTE-A	ks01lteskt	SHV-E330S
Samsung	Galaxy S4 Mini	serrano3g	GT-I9190
Samsung	Galaxy S4 Mini	serranods	GT-I9192
Samsung	Galaxy S4 Mini	serranolte	GT-I9195
Samsung	Galaxy S4 Mini	serranolte	GT-I9195L
Samsung	Galaxy S4 Mini	serranolte	GT-I9195T
Samsung	Galaxy S4 Mini	serranolte	GT-I9195X
Samsung	Galaxy S4 Mini	serranolte	GT-I9197
Samsung	Galaxy S4 Mini	serranoltebmc	SGH-I257M
Samsung	Galaxy S4 Mini	serranoltekt	SHV-E370K
Samsung	Galaxy S4 Mini	serranoltekx	SHV-E370D
Samsung	Galaxy S4 Mini	serranoltelra	SCH-I435L
Samsung	Galaxy S4 Mini	serranoltespr	SPH-L520
Samsung	Galaxy S4 Mini	serranolteusc	SCH-R890
Samsung	Galaxy S4 Mini	serranoltevw	SCH-I435
Samsung	Galaxy S4 Mini	serranovlteatt	SAMSUNG-SGH-I257
Samsung	Galaxy S4 Zoom	mproject3g	SM-C101
Samsung	Galaxy S4 Zoom	mprojectlteatt	SAMSUNG-SM-C105A
Samsung	Galaxy S4 Zoom	mprojecttelgt	SM-C105L
Samsung	Galaxy S4 Zoom	mprojectlteskt	SM-C105S

Supported Devices

Samsung	Galaxy S4 Zoom	mprojectqlte	SM-C105
Samsung	Galaxy S5	SCL23	SCL23
Samsung	Galaxy S5	k3g	SM-G900H
Samsung	Galaxy S5	klte	SM-G9008W
Samsung	Galaxy S5	klte	SM-G9009W
Samsung	Galaxy S5	klte	SM-G900F
Samsung	Galaxy S5	klte	SM-G900FQ
Samsung	Galaxy S5	klte	SM-G900I
Samsung	Galaxy S5	klte	SM-G900M
Samsung	Galaxy S5	klte	SM-G900MD
Samsung	Galaxy S5	klteMetroPCS	SM-G900T1
Samsung	Galaxy S5	klteacg	SM-G900R7
Samsung	Galaxy S5	klteatt	SAMSUNG-SM-G900A
Samsung	Galaxy S5	kltecan	SM-G900W8
Samsung	Galaxy S5	klteduoszn	SM-G9006W
Samsung	Galaxy S5	kltekt	SM-G900K
Samsung	Galaxy S5	kltelgt	SM-G900L
Samsung	Galaxy S5	kltelra	SM-G900R6
Samsung	Galaxy S5	klteskt	SM-G900S
Samsung	Galaxy S5	kltespr	SM-G900P
Samsung	Galaxy S5	kltetmo	SM-G900T
Samsung	Galaxy S5	klteusc	SM-G900R4
Samsung	Galaxy S5	kltevwz	SM-G900V
Samsung	Galaxy S5	kwifi	SM-G900X
Samsung	Galaxy S5	lentisltekt	SM-G906K
Samsung	Galaxy S5	lentisltelgt	SM-G906L
Samsung	Galaxy S5	lentislteskt	SM-G906S
Samsung	Galaxy S5 Active	klteactive	SM-G870F
Samsung	Galaxy S5 Active	klteattactive	SAMSUNG-SM-G870A
Samsung	Galaxy S5 Active	kltecanactive	SM-G870W

Supported Devices

Samsung	Galaxy S5 Dual SIM	klte	SM-G900FD
Samsung	Galaxy S5 Google Play Edition	kgedlte	SM-G900FG
Samsung	Galaxy S5 K Sport	kltesprsports	SM-G860P
Samsung	Galaxy S5 LTE-A	kccat6	SM-G901F
Samsung	Galaxy S5 Mini	kmini3g	SM-G800H
Samsung	Galaxy S5 Mini	kminilte	SM-G800F
Samsung	Galaxy S5 Mini	kminilte	SM-G800Y
Samsung	Galaxy S5 Mini	kminilteusc	SM-G800R4
Samsung	Galaxy S5 mini	kmini3g	SM-G800HQ
Samsung	Galaxy S5 mini	kminilte	SM-G800M
Samsung	Galaxy S5 mini	kminilteatt	SAMSUNG-SM-G800A
Samsung	Galaxy S5 mini	kminiwifi	SM-G800X
Samsung	Galaxy S5 mini LTE	kminilte	SM-G800Y
Samsung	Galaxy Spica	GT-I5700	GT-I5700
Samsung	Galaxy Spica	GT-I5700	GT-I5700L
Samsung	Galaxy Spica	GT-I5700	GT-I5700R
Samsung	Galaxy Spica	GT-I5700L	GT-I5700L
Samsung	Galaxy Spica	spica	GT-I5700
Samsung	Galaxy Spica	spica	GT-I5700L
Samsung	Galaxy Spica	spica	GT-I5700R
Samsung	Galaxy Spica	spica	GT-I5700
Samsung	Galaxy Star	mint	GT-S5282
Samsung	Galaxy Star	mintss	GT-S5280
Samsung	Galaxy Star Plus	logan2g	GT-S7262
Samsung	Galaxy Star Trios	mintts	GT-S5283B
Samsung	Galaxy Star2 Plus	higgs2g	SM-G350E
Samsung	Galaxy Stellar	jasperzw	SCH-I200
Samsung	Galaxy Stellar	jasperzw	SCH-I200PP
Samsung	Galaxy Style Duos	aruba3gduosctc	SCH-I829
Samsung	Galaxy Tab	GT-P1000	GT-P1000

Supported Devices

Samsung	Galaxy Tab	GT-P1000L	GT-P1000L
Samsung	Galaxy Tab	GT-P1000M	GT-P1000M
Samsung	Galaxy Tab	GT-P1000N	GT-P1000N
Samsung	Galaxy Tab	GT-P1000R	GT-P1000R
Samsung	Galaxy Tab	GT-P1000T	GT-P1000T
Samsung	Galaxy Tab	GT-P1010	GT-P1010
Samsung	Galaxy Tab	GT-P1013	GT-P1013
Samsung	Galaxy Tab	SC-01C	SC-01C
Samsung	Galaxy Tab	SCH-I800	SCH-I800
Samsung	Galaxy Tab	SGH-T849	SGH-T849
Samsung	Galaxy Tab	SHW-M180K	SHW-M180K
Samsung	Galaxy Tab	SHW-M180L	SHW-M180L
Samsung	Galaxy Tab	SHW-M180S	SHW-M180S
Samsung	Galaxy Tab	SHW-M180W	SHW-M180W
Samsung	Galaxy Tab	SMT-i9100	SMT-i9100
Samsung	Galaxy Tab 10.1	GT-P7500	GT-P7500
Samsung	Galaxy Tab 10.1	GT-P7500D	GT-P7500D
Samsung	Galaxy Tab 10.1	GT-P7503	GT-P7503
Samsung	Galaxy Tab 10.1	GT-P7510	GT-P7510
Samsung	Galaxy Tab 10.1	SC-01D	SC-01D
Samsung	Galaxy Tab 10.1	SCH-I905	SCH-I905
Samsung	Galaxy Tab 10.1	SGH-T859	SGH-T859
Samsung	Galaxy Tab 10.1	SHW-M300W	SHW-M300W
Samsung	Galaxy Tab 10.1	SHW-M380K	SHW-M380K
Samsung	Galaxy Tab 10.1	SHW-M380S	SHW-M380S
Samsung	Galaxy Tab 10.1	SHW-M380W	SHW-M380W
Samsung	Galaxy Tab 10.1 N	GT-P7501	GT-P7501
Samsung	Galaxy Tab 10.1 N	GT-P7511	GT-P7511
Samsung	Galaxy Tab 10.1 v	p3	GT-P7100
Samsung	Galaxy Tab 4 8.0	milletwifi	SM-T330X

Supported Devices

Samsung	Galaxy Tab 4 8.0	milletwifikx	SM-T330
Samsung	Galaxy Tab 4 Active	rubenslte	SM-T365
Samsung	Galaxy Tab 7.0	SPH-P100	SPH-P100
Samsung	Galaxy Tab 7.0 Plus	GT-P6200	GT-P6200
Samsung	Galaxy Tab 7.0 Plus	GT-P6200L	GT-P6200L
Samsung	Galaxy Tab 7.0 Plus	GT-P6201	GT-P6201
Samsung	Galaxy Tab 7.0 Plus	GT-P6210	GT-P6210
Samsung	Galaxy Tab 7.0 Plus	GT-P6211	GT-P6211
Samsung	Galaxy Tab 7.0 Plus	SC-02D	SC-02D
Samsung	Galaxy Tab 7.0 Plus	SGH-T869	SGH-T869
Samsung	Galaxy Tab 7.0 Plus	SHW-M430W	SHW-M430W
Samsung	Galaxy Tab 7.7	GT-P6800	GT-P6800
Samsung	Galaxy Tab 7.7	GT-P6810	GT-P6810
Samsung	Galaxy Tab 7.7	SCH-I815	SCH-I815
Samsung	Galaxy Tab 7.7 Plus	SC-01E	SC-01E
Samsung	Galaxy Tab 8.9	GT-P7300	GT-P7300
Samsung	Galaxy Tab 8.9	GT-P7310	GT-P7310
Samsung	Galaxy Tab 8.9	GT-P7320	GT-P7320
Samsung	Galaxy Tab 8.9	SCH-P739	SCH-P739
Samsung	Galaxy Tab 8.9	SGH-I957	SAMSUNG-SGH-I957
Samsung	Galaxy Tab 8.9	SGH-I957D	SAMSUNG-SGH-I957D
Samsung	Galaxy Tab 8.9	SGH-I957D	SGH-I957D
Samsung	Galaxy Tab 8.9	SGH-I957M	SAMSUNG-SGH-I957M
Samsung	Galaxy Tab 8.9	SGH-I957M	SGH-I957M
Samsung	Galaxy Tab 8.9	SGH-I957R	SAMSUNG-SGH-I957R
Samsung	Galaxy Tab 8.9	SGH-I957R	SGH-I957R
Samsung	Galaxy Tab 8.9	SHV-E140K	SHV-E140K
Samsung	Galaxy Tab 8.9	SHV-E140L	SHV-E140L
Samsung	Galaxy Tab 8.9	SHV-E140S	SHV-E140S
Samsung	Galaxy Tab 8.9	SHW-M305W	SHW-M305W

Supported Devices

Samsung	Galaxy Tab Pro 10.1	picassolte	SM-T525
Samsung	Galaxy Tab Pro 10.1	picassowifi	SM-T520
Samsung	Galaxy Tab Pro 12.2	v2lte	SM-T905
Samsung	Galaxy Tab Pro 12.2	v2wifi	SM-T900
Samsung	Galaxy Tab Pro 12.2	v2wifi	SM-T900X
Samsung	Galaxy Tab Pro 8.4	mondrianlte	SM-T325
Samsung	Galaxy Tab Pro 8.4	mondrianwifi	SM-T320
Samsung	Galaxy Tab Pro 8.4	mondrianwifi	SM-T320X
Samsung	Galaxy Tab Pro 8.4	mondrianwifikk	SM-T320
Samsung	Galaxy Tab Pro 8.4	mondrianwifue	SM-T320
Samsung	Galaxy Tab Q	q7	SM-T2519
Samsung	Galaxy Tab S 10.5	chagallwifi	SM-T800
Samsung	Galaxy Tab S 8.4	SC-03G	SC-03G
Samsung	Galaxy Tab S 8.4	klimtlte	SM-T705
Samsung	Galaxy Tab S 8.4	klimtlte	SM-T705C
Samsung	Galaxy Tab S 8.4	klimtlte	SM-T705Y
Samsung	Galaxy Tab S 8.4	klimtltevzw	SM-T707V
Samsung	Galaxy Tab S 8.4	klimtwifi	SM-T700
Samsung	Galaxy Tab2 10.1	espresso10att	SAMSUNG-SGH-I497
Samsung	Galaxy Tab2 10.1	espresso10can	SGH-I497
Samsung	Galaxy Tab2 10.1	espresso10rf	GT-P5100
Samsung	Galaxy Tab2 10.1	espresso10spr	SPH-P500
Samsung	Galaxy Tab2 10.1	espresso10tmo	SGH-T779
Samsung	Galaxy Tab2 10.1	espresso10vzw	SCH-I915
Samsung	Galaxy Tab2 10.1	espresso10wifi	GT-P5110
Samsung	Galaxy Tab2 10.1	espresso10wifi	GT-P5113
Samsung	Galaxy Tab2 7.0	espressorf	GT-P3100
Samsung	Galaxy Tab2 7.0	espressorf	GT-P3100B
Samsung	Galaxy Tab2 7.0	espressorf	GT-P3105
Samsung	Galaxy Tab2 7.0	espressovzw	SCH-I705

Supported Devices

Samsung	Galaxy Tab2 7.0	espressovzw	SCH-i705
Samsung	Galaxy Tab2 7.0	espressowifi	GT-P3110
Samsung	Galaxy Tab2 7.0	espressowifi	GT-P3113
Samsung	Galaxy Tab3	lt01wifikx	SM-T310
Samsung	Galaxy Tab3 10.1	santos103g	GT-P5200
Samsung	Galaxy Tab3 10.1	santos10lte	GT-P5220
Samsung	Galaxy Tab3 10.1	santos10wifi	GT-P5210
Samsung	Galaxy Tab3 10.1	santos10wifi	GT-P5210XD1
Samsung	Galaxy Tab3 7.0	lt023g	SM-T211
Samsung	Galaxy Tab3 7.0	lt023g	SM-T212
Samsung	Galaxy Tab3 7.0	lt023gdtv	SM-T211M
Samsung	Galaxy Tab3 7.0	lt02lte	SM-T215
Samsung	Galaxy Tab3 7.0	lt02lteatt	SAMSUNG-SM-T217A
Samsung	Galaxy Tab3 7.0	lt02ltespr	SM-T217S
Samsung	Galaxy Tab3 7.0	lt02ltetmo	SM-T217T
Samsung	Galaxy Tab3 7.0	lt02wifi	SM-T210
Samsung	Galaxy Tab3 7.0	lt02wifi	SM-T210R
Samsung	Galaxy Tab3 7.0	lt02wifilgt	SM-T210L
Samsung	Galaxy Tab3 8.0	lt013g	SM-T311
Samsung	Galaxy Tab3 8.0	lt013g	SM-T312
Samsung	Galaxy Tab3 8.0	lt01lte	SM-T315
Samsung	Galaxy Tab3 8.0	lt01lte	SM-T315T
Samsung	Galaxy Tab3 8.0	lt01wifi	SM-T310
Samsung	Galaxy Tab3 8.0	lt01wifi	SM-T310X
Samsung	Galaxy Tab3 8.0	lt02lduwifi	SM-T210X
Samsung	Galaxy Tab3 Kids	lt02kidswifi	SM-T2105
Samsung	Galaxy Tab3 Lite	goya3g	SM-T111
Samsung	Galaxy Tab3 Lite	goya3g	SM-T111M
Samsung	Galaxy Tab3 Lite	goyawifi	SM-T110
Samsung	Galaxy Tab4	matissewifigoogle	SM-T530NN

Supported Devices

Samsung	Galaxy Tab4 10.0	matisse3g	SM-T531
Samsung	Galaxy Tab4 10.0	matisselte	SM-T535
Samsung	Galaxy Tab4 10.1	matissewifi	SM-T530
Samsung	Galaxy Tab4 10.1	matissewifi	SM-T530X
Samsung	Galaxy Tab4 10.1	matissewifikx	SM-T530
Samsung	Galaxy Tab4 10.1	matissewifiue	SM-T530NU
Samsung	Galaxy Tab4 7.0	403SC	403SC
Samsung	Galaxy Tab4 7.0	degas3g	SM-T231
Samsung	Galaxy Tab4 7.0	degas3g	SM-T232
Samsung	Galaxy Tab4 7.0	degaslte	SM-T235
Samsung	Galaxy Tab4 7.0	degaslte	SM-T235Y
Samsung	Galaxy Tab4 7.0	degasltespr	SM-T237P
Samsung	Galaxy Tab4 7.0	degasltevzw	SM-T237V
Samsung	Galaxy Tab4 7.0	degaswifi	SM-T230
Samsung	Galaxy Tab4 7.0	degaswifi	SM-T230X
Samsung	Galaxy Tab4 7.0	degaswifidtv	SM-T230NT
Samsung	Galaxy Tab4 7.0	degaswifiopenbnn	SM-T230NU
Samsung	Galaxy Tab4 7.0	degaswifiue	SM-T230NU
Samsung	Galaxy Tab4 8.0	millet3g	SM-T331
Samsung	Galaxy Tab4 8.0	milletlte	SM-T335
Samsung	Galaxy Tab4 8.0	milletlteatt	SAMSUNG-SM-T337A
Samsung	Galaxy Tab4 8.0	milletltektt	SM-T335K
Samsung	Galaxy Tab4 8.0	milletltelgt	SM-T335L
Samsung	Galaxy Tab4 8.0	milletltetmo	SM-T337T
Samsung	Galaxy Tab4 8.0	milletwifi	SM-T330
Samsung	Galaxy Tab4 8.0	milletwifiue	SM-T330NU
Samsung	Galaxy Tab4 Active	rubenslte	SM-T365M
Samsung	Galaxy Tab4 Active	rubenswifi	SM-T360
Samsung	Galaxy Tab4 Nook 10.1	matissewifiopenbnn	SM-T530NU
Samsung	Galaxy TabS 10.5	SCT21	SCT21

Supported Devices

Samsung	Galaxy TabS 10.5	chagallhktekt	SM-T805K
Samsung	Galaxy TabS 10.5	chagallhltelgt	SM-T805L
Samsung	Galaxy TabS 10.5	chagallhteskt	SM-T805S
Samsung	Galaxy TabS 10.5	chagalllte	SM-T805
Samsung	Galaxy TabS 10.5	chagalllte	SM-T805M
Samsung	Galaxy TabS 10.5	chagalllte	SM-T805Y
Samsung	Galaxy TabS 10.5	chagalllteatt	SAMSUNG-SM-T807A
Samsung	Galaxy TabS 10.5	chagallltecan	SM-T805W
Samsung	Galaxy TabS 10.5	chagallltespr	SM-T807P
Samsung	Galaxy TabS 10.5	chagallltetmo	SM-T807T
Samsung	Galaxy TabS 10.5	chagalllteusc	SM-T807R4
Samsung	Galaxy TabS 10.5	chagallltevzw	SM-T807V
Samsung	Galaxy TabS 10.5	chagallwifi	SM-T800
Samsung	Galaxy TabS 10.5	chagallwifi	SM-T800X
Samsung	Galaxy TabS 10.5	chagallwifikx	SM-T800
Samsung	Galaxy TabS 8.4	klimtlte	SM-T705
Samsung	Galaxy TabS 8.4	klimtlte	SM-T705M
Samsung	Galaxy TabS 8.4	klimtlteatt	SAMSUNG-SM-T707A
Samsung	Galaxy TabS 8.4	klimtltecan	SM-T705W
Samsung	Galaxy TabS 8.4	klimtwifi	SM-T700
Samsung	Galaxy TabS 8.4	klimtwifikx	SM-T700
Samsung	Galaxy Tap Pro 10.1	picassolte	SM-T525
Samsung	Galaxy Tap Pro 8.4	mondrianwifi	SM-T320
Samsung	Galaxy Trend	kyleve	GT-S7392
Samsung	Galaxy Trend	kyleve	GT-S7392L
Samsung	Galaxy Trend	kyleve3gcmcc	GT-S7568I
Samsung	Galaxy Trend Duos	kyleichn	GT-S7562i
Samsung	Galaxy Trend Duos	kylepluschn	GT-S7572
Samsung	Galaxy Trend Duos	kyleve	GT-S7390
Samsung	Galaxy Trend Duos	kyleve	GT-S7392

Supported Devices

Samsung	Galaxy Trend Duos	kyleve	GT-S7562C
Samsung	Galaxy Trend Lite	kylevess	GT-S7390
Samsung	Galaxy Trend Lite	kylevess	GT-S7390L
Samsung	Galaxy Trend Plus	kylepro	GT-S7580
Samsung	Galaxy Trend Plus	kylepro	GT-S7580E
Samsung	Galaxy Trend Plus	kylepro	GT-S7580L
Samsung	Galaxy Trend2	garda3gcmcc	GT-S7898
Samsung	Galaxy Trend2	gardave3gcmcc	GT-S7898I
Samsung	Galaxy Trend2	kyleplusctc	SCH-I739
Samsung	Galaxy Trend3	cs023g	SM-G3502U
Samsung	Galaxy Trend3	cs02cmcc	SM-G3508
Samsung	Galaxy Trend3	cs02ctc	SM-G3509
Samsung	Galaxy Trend3	cs02ve	SM-G3508I
Samsung	Galaxy Trend3	cs02ve3g	SM-G3502C
Samsung	Galaxy Trend3	cs02ve3g	SM-G3502I
Samsung	Galaxy Trend3	cs02ve3g	SM-G3508J
Samsung	Galaxy Trend3	cs02ve3g	SM-G3509I
Samsung	Galaxy U	SHW-M130L	SHW-M130L
Samsung	Galaxy Victory	goghspr	SPH-L300
Samsung	Galaxy Victory	goghvmu	SPH-L300
Samsung	Galaxy W	GT-I8150	GT-I8150
Samsung	Galaxy W	GT-I8150B	GT-I8150B
Samsung	Galaxy W	GT-I8150T	GT-I8150T
Samsung	Galaxy W	SGH-T679M	SGH-T679M
Samsung	Galaxy Win	delos3gcmcc	GT-I8558
Samsung	Galaxy Win	delos3gduosctc	SCH-I869
Samsung	Galaxy Win	delos3geur	GT-I8552
Samsung	Galaxy Win	delos3geur	GT-I8552B
Samsung	Galaxy Win	delos3gss	GT-I8550E
Samsung	Galaxy Win	delosltelgt	SHV-E500L

Supported Devices

Samsung	Galaxy Win	deloslteskt	SHV-E500S
Samsung	Galaxy Win Duos	delos3gchn	GT-I8552
Samsung	Galaxy Win Pro	wilcox3g	SM-G3818
Samsung	Galaxy Win Pro	wilcoxctc	SM-G3819
Samsung	Galaxy Win Pro	wilcoxctc	SM-G3819D
Samsung	Galaxy Win Pro	wilcoxds	SM-G3812
Samsung	Galaxy Xcover	GT-S5690	GT-S5690
Samsung	Galaxy Xcover	GT-S5690L	GT-S5690L
Samsung	Galaxy Xcover	GT-S5690M	GT-S5690M
Samsung	Galaxy Xcover	GT-S5690R	GT-S5690R
Samsung	Galaxy Xcover2	skomer	GT-S7710
Samsung	Galaxy Xcover2	skomer	GT-S7710L
Samsung	Galaxy Y	GT-S5360	GT-S5360
Samsung	Galaxy Y	GT-S5360B	GT-S5360B
Samsung	Galaxy Y	GT-S5360L	GT-S5360L
Samsung	Galaxy Y	GT-S5360T	GT-S5360T
Samsung	Galaxy Y	GT-S5363	GT-S5363
Samsung	Galaxy Y	GT-S5368	GT-S5368
Samsung	Galaxy Y	GT-S5369	GT-S5369
Samsung	Galaxy Y	SCH-I509	SCH-I509
Samsung	Galaxy Y	SCH-i509	SCH-i509
Samsung	Galaxy Y Duos	GT-S6102	GT-S6102
Samsung	Galaxy Y Duos	GT-S6102B	GT-S6102B
Samsung	Galaxy Y Duos	GT-S6102E	GT-S6102E
Samsung	Galaxy Y Plus	coriplusds	GT-S5303
Samsung	Galaxy Y Plus	coriplusds	GT-S5303B
Samsung	Galaxy Y Pop	GT-S6108	GT-S6108
Samsung	Galaxy Y Pro	GT-B5510	GT-B5510
Samsung	Galaxy Y Pro	GT-B5510B	GT-B5510B
Samsung	Galaxy Y Pro	GT-B5510L	GT-B5510L

Supported Devices

Samsung	Galaxy Y Pro Duos	GT-B5512	GT-B5512
Samsung	Galaxy Y Pro Duos	GT-B5512B	GT-B5512B
Samsung	Galaxy Y TV	GT-S5367	GT-S5367
Samsung	Galaxy Young	roy	GT-S6312
Samsung	Galaxy Young	roydtv	GT-S6313T
Samsung	Galaxy Young	royss	GT-S6310
Samsung	Galaxy Young	royss	GT-S6310B
Samsung	Galaxy Young	royss	GT-S6310L
Samsung	Galaxy Young	royss	GT-S6310T
Samsung	Galaxy Young	royssdtv	GT-S6313T
Samsung	Galaxy Young	royssnfc	GT-S6310N
Samsung	Galaxy Young2	young23g	SM-G130H
Samsung	Galaxy Young2	young23g	SM-G130M
Samsung	Galaxy Young2	young23g	SM-G130U
Samsung	Galaxy Young2	young23gdtv	SM-G130BT
Samsung	Galaxy Young2	young2ds2g	SM-G130E
Samsung	Galaxy Young2	young2nfc3g	SM-G130HN
Samsung	Galaxy player 70 Plus	YP-GB70D	YP-GB70D
Samsung	Galaxy win	delos3gss	GT-I8550L
Samsung	Garda	gardalteMetroPCS	SGH-T399N
Samsung	Gear Live	sprat	Gear Live
Samsung	Gem	SCH-I100	SCH-I100
Samsung	Hennessy	hennessy3gduosctc	SCH-W789
Samsung	Homesync	spcwifi	GT-B9150
Samsung	IceTouch	gokey	YP-GH1
Samsung	Illusion	SCH-I110	SCH-I110
Samsung	Infuse	SGH-I997	SAMSUNG-SGH-I997
Samsung	Infuse	SGH-I997R	SAMSUNG-SGH-I997R
Samsung	Moment	SPH-M900	SPH-M900
Samsung	Montblanc	montblanc3gctc	SM-W2014

Supported Devices

Samsung	Nexus 10	manta	Nexus 10
Samsung	Nexus S	crespo	Nexus S
Samsung	Nexus S	crespo4g	Nexus S 4G
Samsung	ProXpress M4580	fiber-athena	samsung-printer-tablet
Samsung	Replenish	SPH-M580	SPH-M580
Samsung	Replenish	SPH-M580BST	SPH-M580BST
Samsung	Repp	SCH-R680	SCH-R680
Samsung	Roy VE DTV	royssvedtv	GT-S6293T
Samsung	Roy VE DTV	royvedtv	GT-S6293T
Samsung	Rugby Smart	SGH-I847	SAMSUNG-SGH-I847
Samsung	SC-01F	SC-01F	SC-01F
Samsung	SC-01G	SC-01G	SC-01G
Samsung	SC-02G	SC-02G	SC-02G
Samsung	SC-04F	SC-04F	SC-04F
Samsung	Samsung Galaxy S4	jflteMetroPCS	SGH-M919N
Samsung	Samsung Galaxy S4 Zoom	mprojectltekt	SM-C105K
Samsung	Samsung Galaxy Stratosphere2	aegis2vzw	SCH-I415
Samsung	Samsung Garda	gardaltetmo	SGH-T399
Samsung	Samsung Homesync	spcwifi	GT-B9150
Samsung	Samsung Homesync	spcwifiany	GT-B9150
Samsung	Sidekick	SGH-T839	SGH-T839
Samsung	Transfix	SCH-R730	SCH-R730
Samsung	Transform	SPH-M920	SPH-M920
Samsung	Transform Ultra	SPH-M930	SPH-M930
Samsung	Transform Ultra	SPH-M930BST	SPH-M930BST
Samsung	VinsQ	SPH-M910	SPH-M910
Samsung	VinsQ(M910)	SPH-M910	SPH-M910
Samsung	olleh	ik1	SMT-E5015
Sanyo	Benesse	31TL04	31TL04
Sanyo	Benesse	40TL04	40TL04

Supported Devices

Sanyo	Benesse	41EA04	41EA04
Sanyo	CEA1	CEA1	CEA1
Sanyo	CEA3	CEA3	CEA3
Sharp		SH7218T	SH7218T
Sharp		SH8268U	SH8268U
Sharp		SH8288U	SH8288U
Sharp		SH8298U	SH8298U
Sharp		msm7627_surf	SH8118U
Sharp	306SH	SG306SH	306SH
Sharp	401SH	SG401SH	401SH
Sharp	A01SH	A01SH	A01SH
Sharp	ADS1	ADS1	SHARP-ADS1
Sharp	AQUOS CRYSTAL X	SG402SH	402SH
Sharp	AQUOS PAD SHT22	SHT22	SHT22
Sharp	AQUOS PAD SH-06F	SH-06F	SH-06F
Sharp	AQUOS PAD SH-08E	SH-08E	SH-08E
Sharp	AQUOS PAD SHT21	SHT21	SHT21
Sharp	AQUOS PHONE SERIE SHL22	SHL22	SHL22
Sharp	AQUOS PHONE SERIE SHL23	SHL23	SHL23
Sharp	AQUOS PHONE SERIE mini SHL24	SHL24	SHL24
Sharp	AQUOS PHONE CL IS17SH	SHI17	IS17SH
Sharp	AQUOS PHONE EX SH-02F	SH-02F	SH-02F
Sharp	AQUOS PHONE EX SH-04E	SH04E	SH-04E
Sharp	AQUOS PHONE IS11SH	SHI11	IS11SH
Sharp	AQUOS PHONE IS12SH	SHI12	IS12SH
Sharp	AQUOS PHONE IS13SH	SHI13	IS13SH
Sharp	AQUOS PHONE IS14SH	SHI14	IS14SH
Sharp	AQUOS PHONE SERIE ISW16SH	SHI16	ISW16SH
Sharp	AQUOS PHONE SERIE SHL21	SHL21	SHL21

Supported Devices

Sharp	AQUOS PHONE SH-01D	SH01D	SH-01D
Sharp	AQUOS PHONE SH-06D	SH06D	SH-06D
Sharp	AQUOS PHONE SH-12C	SH12C	SH-12C
Sharp	AQUOS PHONE SH90B	SH90B	SH90B
Sharp	AQUOS PHONE SL IS15SH	SHI15	IS15SH
Sharp	AQUOS PHONE SoftBank 102SH II	SBM102SH2	SBM102SH2
Sharp	AQUOS PHONE SoftBank 006SH	SBM006SH	SBM006SH
Sharp	AQUOS PHONE SoftBank 102SH	SBM102SH	SBM102SH
Sharp	AQUOS PHONE SoftBank 103SH	SBM103SH	SBM103SH
Sharp	AQUOS PHONE SoftBank 104SH	SBM104SH	SBM104SH
Sharp	AQUOS PHONE THE HYBRID SoftBank 007SH	SBM007SH	SBM007SH
Sharp	AQUOS PHONE THE HYBRID SoftBank 007SH J	SBM007SHJ	SBM007SHJ
Sharp	AQUOS PHONE THE HYBRID SoftBank 101SH	SBM101SH	SBM101SH
Sharp	AQUOS PHONE THE PREMIUM SoftBank 009SH	SBM009SH	SBM009SH
Sharp	AQUOS PHONE WX05SH	WX05SH	WX05SH
Sharp	AQUOS PHONE Xx 206SH	SBM206SH	SBM206SH
Sharp	AQUOS PHONE Xx 302SH	SBM302SH	SBM302SH
Sharp	AQUOS PHONE Xx SoftBank 106SH	SBM106SH	SBM106SH
Sharp	AQUOS PHONE Xx mini 303SH	SBM303SH	SBM303SH
Sharp	AQUOS PHONE ZETA SH-01F	SH-01F	SH-01F
Sharp	AQUOS PHONE ZETA SH-02E	SH02E	SH-02E
Sharp	AQUOS PHONE ZETA SH-06E	SH-06E	SH-06E
Sharp	AQUOS PHONE ZETA SH-09D	SH09D	SH-09D
Sharp	AQUOS PHONE es WX04SH	WX04SH	WX04SH
Sharp	AQUOS PHONE f SH-13C	SH13C	SH-13C
Sharp	AQUOS PHONE si SH-01E	SH01E	SH-01E
Sharp	AQUOS PHONE si SH-07E	SH-07E	SH-07E

Supported Devices

Sharp	AQUOS PHONE slider SH-02D	SH02D	SH-02D
Sharp	AQUOS PHONE ss 205SH	SBM205SH	SBM205SH
Sharp	AQUOS PHONE st SH-07D	SH07D	SH-07D
Sharp	AQUOS PHONE sv SH-10D	SH10D	SH-10D
Sharp	AQUOS SERIE SHL25	SHL25	SHL25
Sharp	AQUOS SH-M01	SH-M01	SH-M01
Sharp	AQUOS Xx 304SH	SG304SH	304SH
Sharp	AQUOS ZETA SH-01G	SH-01G	SH-01G
Sharp	AQUOS ZETA SH-04F	SH-04F	SH-04F
Sharp	DM009SH	DM009SH	DM009SH
Sharp	DM010SH	DM010SH	DM010SH
Sharp	DM011SH	DM011SH	DM011SH
Sharp	DM012SH	DM012SH	DM012SH
Sharp	DM013SH	DM013SH	DM013SH
Sharp	DM016SH	DM016SH	DM016SH
Sharp	Disney Mobile DM014SH	DM014SH	DM014SH
Sharp	Disney Mobile on docomo SH-02G	SH-02G	SH-02G
Sharp	Disney Mobile on docomo SH-05F	SH-05F	SH-05F
Sharp	EB-A71GJ	EB-A71GJ	EB-A71GJ
Sharp	EB-WX1GJ/EB-W51GJ	Galapagos	EB-W51GJ
Sharp	EB-WX1GJ/EB-W51GJ	Galapagos	EB-WX1GJ
Sharp	GALAPAGOS SoftBank 003SH	SBM003SH	SBM003SH
Sharp	GALAPAGOS SoftBank 005SH	SBM005SH	SBM005SH
Sharp	INFOBAR A01	SHX11	INFOBAR A01
Sharp	INFOBAR C01	SHX12	INFOBAR C01
Sharp	IS01	SHI01	IS01
Sharp	IS03	SHI03	IS03
Sharp	IS05	SHI05	IS05
Sharp	LC-42LE860M	LC-42LE860M	LC-42LE860M

Supported Devices

Sharp	LC-50LE860M	LC-50LE860M	LC-50LE860M
Sharp	LC-55LE860M	LC-55LE860M	LC-55LE860M
Sharp	LC-A11A	a11a	LC-A11A
Sharp	LC-LX565H	lx565h	LC-LX565H
Sharp	LCD-LX460A	lx460a	LCD-LX460A
Sharp	LCD-LX560A	lx560a	LCD-LX560A
Sharp	LCD-LX565A	msd818sharp	LCD-LX565A
Sharp	LCD-V3A	v3a	LCD-V3A
Sharp	LYNX 3D SH-03C	SH03C	SH-03C
Sharp	LYNX SH-10B	SH10B	SH-10B
Sharp	PANTONE 5 SoftBank 107SH	SBM107SH	SBM107SH
Sharp	PANTONE 6 SoftBank 200SH	SBM200SH	SBM200SH
Sharp	Q-pot.Phone SH-04D	SH04D	SH-04D
Sharp	RW107	RW107	RW107
Sharp	SBM204SH	SBM204SH	SBM204SH
Sharp	SC-S01	scallop	SC-S01
Sharp	SH-01E Vivienne Westwood	SH01EVW	SH-01EVW
Sharp	SH-01F DRAGON QUEST	SH-01FDQ	SH-01FDQ
Sharp	SH-03F	SH03F	SH-03F
Sharp	SH-05E	SH05E	SH-05E
Sharp	SH-06D NERV	SH06DNERV	SH-06DNERV
Sharp	SH80F	SH80F	SH80F
Sharp	SH8118U	msm7627	SH8118U
Sharp	SH8128U	msm7627	SH8128U
Sharp	SH8188U	SH8188U	SH8188U
Sharp	SoftBank 007SH KT	SBM007SHK	SBM007SHK
Sharp	SoftBank 107SH B	SBM107SHB	SBM107SHB
Sharp	SoftBank 305SH	SG305SH	305SH
Sharp	SoftBank AQUOS PHONE Xx 203SH	SBM203SH	SBM203SH

Supported Devices

Sharp	Yahoo! Phone SoftBank 009SH Y	SBM009SHY	SBM009SHY
SiAL	Bic camera	Si01BB	Si01BB
SiAL	Si01BE	Si01BE	Si01BE
Sico SmartPhone	SSR1-5-8M	GBC_bravo	SSR1-5-8M
Sico SmartPhone	SSR1-5-8M	GBC_bravo	sico pro
Siragon	Siragon SP-5000	SP-5000	Siragon SP-5000
Smartab	Smartab SRF79	SRF79	SRF79
Smartab	Smartab STJR76	STJR76	STJR76
Smartfren	AD688G	AD688G	Smartfren Andromax AD688G
Smartfren	AD689G	AD689G	Smartfren Andromax AD689G
Smartfren	Andromax AD687G	AD687G	Andromax AD687G
Smartfren	EG680	eg680	EG680
Smartfren	NEWAD688G	NEWAD688G	Smartfren Andromax AD688G
Smartfren	Smartfren Andromax AD682H	AD682H	Smartfren Andromax AD682H
Sonim	Ex-Handy 09	XP6700Z1	Ex-Handy 09
Sonim	Smart-Ex 01	XP7700Z1	Smart-Ex 01
Sonim	XP6	XP6700	XP6700
Sonim	XP7	XP7700	XP7700
Sony		C5503	C5503
Sony		C6616	C6616
Sony		SGP312	SGP312
Sony		ST21i	ST21i
Sony		ST23i	ST23i
Sony		ST26i	ST26i
Sony		nbx02	Sony Tablet P
Sony	BRAVIA Smart Stick	NSZGU1	NSZ-GU1
Sony	Internet TV	asura	Internet TV
Sony	Internet TV	eagle	Internet TV Box
Sony	NSZGS7	NSZGS7	NSZ-GS7/GX70
Sony	NW-F800	icx1227	WALKMAN

Supported Devices

Sony	NW-F880 Series	icx1237	WALKMAN
Sony	NW-Z1000	icx1216	NW-Z1000Series
Sony	NW-ZX1	icx1240	WALKMAN
Sony	NWZ-Z1000	icx1216	NWZ-Z1000Series
Sony	SmartWatch 3	tetra	SmartWatch 3
Sony	Sony	D2302	D2302
Sony	Sony Ericsson Live with Walkman	WT19a	WT19a
Sony	Sony Ericsson Live with Walkman	WT19i	WT19i
Sony	Sony Smartphone Z Ultra Google Play edition	C6806	C6806_GPe
Sony	Sony Tablet S	nbx03	Sony Tablet S
Sony	Tablet P	nbx02	Sony Tablet P
Sony	Tablet S	nbx03	Sony Tablet S
Sony	Xperia E1 dual	D2114	D2114
Sony	Xperia A	SO-04E	SO-04E
Sony	Xperia A2	SO-04F	SO-04F
Sony	Xperia C	C2304	C2304
Sony	Xperia C	C2305	C2305
Sony	Xperia C3	D2533	D2533
Sony	Xperia C3 Dual	D2502	D2502
Sony	Xperia E	C1504	C1504
Sony	Xperia E	C1505	C1505
Sony	Xperia E dual	C1604	C1604
Sony	Xperia E dual	C1605	C1605
Sony	Xperia E1	D2004	D2004
Sony	Xperia E1	D2005	D2005
Sony	Xperia E1	D2114	D2114
Sony	Xperia E1 Dual	D2104	D2104
Sony	Xperia E1 Dual	D2105	D2105
Sony	Xperia E1 dual	D2104	D2104

Supported Devices

Sony	Xperia E1 dual	D2105	D2105
Sony	Xperia E3	D2202	D2202
Sony	Xperia E3	D2203	D2203
Sony	Xperia E3	D2206	D2206
Sony	Xperia E3	D2243	D2243
Sony	Xperia E3 Dual	D2212	D2212
Sony	Xperia Go	ST27a	ST27a
Sony	Xperia Go	ST27i	ST27i
Sony	Xperia J	ST26a	ST26a
Sony	Xperia J	ST26i	ST26i
Sony	Xperia L	C2104	C2104
Sony	Xperia L	C2105	C2105
Sony	Xperia M	C1904	C1904
Sony	Xperia M	C1905	C1905
Sony	Xperia M dual	C2004	C2004
Sony	Xperia M dual	C2005	C2005
Sony	Xperia M2	D2303	D2303
Sony	Xperia M2	D2305	D2305
Sony	Xperia M2	D2306	D2306
Sony	Xperia M2 Aqua	D2403	D2403
Sony	Xperia M2 Aqua	D2406	D2406
Sony	Xperia M2 dual	D2302	D2302
Sony	Xperia Miro	ST23i	ST23i
Sony	Xperia P	LT22i	LT22i
Sony	Xperia PLAY	R800a	R800a
Sony	Xperia PLAY	R800i	R800i
Sony	Xperia S	LT26i	LT26i
Sony	Xperia SL	LT26ii	LT26ii
Sony	Xperia SP	C5302	C5302
Sony	Xperia SP	C5303	C5303

Supported Devices

Sony	Xperia SP	C5306	C5306
Sony	Xperia SP	M35h	M35h
Sony	Xperia SP	M35t	M35t
Sony	Xperia T	LT30a	LT30a
Sony	Xperia T	LT30p	LT30p
Sony	Xperia T2 Ultra	D5303	D5303
Sony	Xperia T2 Ultra	D5306	D5306
Sony	Xperia T2 Ultra	D5316	D5316
Sony	Xperia T2 Ultra	D5316N	D5316N
Sony	Xperia T2 Ultra	D5322	D5322
Sony	Xperia T2 Ultra dual	D5322	D5322
Sony	Xperia T3	D5102	D5102
Sony	Xperia T3	D5103	D5103
Sony	Xperia T3	D5106	D5106
Sony	Xperia TX	LT29i	LT29i
Sony	Xperia Tablet S	txs03	SGPT12
Sony	Xperia Tablet S	txs03	SGPT13
Sony	Xperia Tablet Z	SGP311	SGP311
Sony	Xperia Tablet Z	SGP312	SGP312
Sony	Xperia Tablet Z	SGP321	SGP321
Sony	Xperia Tablet Z	SGP351	SGP351
Sony	Xperia Tipo	ST21i	ST21i
Sony	Xperia Tipo	ST21i2	ST21i2
Sony	Xperia U	ST25a	ST25a
Sony	Xperia U	ST25i	ST25i
Sony	Xperia V	LT25i	LT25i
Sony	Xperia Z	C6602	C6602
Sony	Xperia Z	C6603	C6603
Sony	Xperia Z	C6606	C6606
Sony	Xperia Z	C6616	C6616

Supported Devices

Sony	Xperia Z	L36h	L36h
Sony	Xperia Z	SO-02E	SO-02E
Sony	Xperia Z Ultra	C6802	C6802
Sony	Xperia Z Ultra	C6806	C6806
Sony	Xperia Z Ultra	C6833	C6833
Sony	Xperia Z Ultra	C6843	C6843
Sony	Xperia Z Ultra	SGP412	SGP412
Sony	Xperia Z Ultra	SOL24	SOL24
Sony	Xperia Z Ultra	XL39h	XL39h
Sony	Xperia Z1	C6902	C6902
Sony	Xperia Z1	C6903	C6903
Sony	Xperia Z1	C6906	C6906
Sony	Xperia Z1	C6916	C6916
Sony	Xperia Z1	C6943	C6943
Sony	Xperia Z1	L39h	L39h
Sony	Xperia Z1	L39t	L39t
Sony	Xperia Z1	L39u	L39u
Sony	Xperia Z1	SO-01F	SO-01F
Sony	Xperia Z1	SOL23	SOL23
Sony	Xperia Z1 Compact	D5503	D5503
Sony	Xperia Z1 Compact	M51w	M51w
Sony	Xperia Z1f	SO-02F	SO-02F
Sony	Xperia Z2	D6502	D6502
Sony	Xperia Z2	D6503	D6503
Sony	Xperia Z2	D6543	D6543
Sony	Xperia Z2	SO-03F	SO-03F
Sony	Xperia Z2 Tablet	SGP511	SGP511
Sony	Xperia Z2 Tablet	SGP512	SGP512
Sony	Xperia Z2 Tablet	SGP521	SGP521
Sony	Xperia Z2 Tablet	SGP551	SGP551

Supported Devices

Sony	Xperia Z2 Tablet	SGP561	SGP561
Sony	Xperia Z2 Tablet	SO-05F	SO-05F
Sony	Xperia Z2 Tablet	SOT21	SOT21
Sony	Xperia Z2a	D6563	D6563
Sony	Xperia Z3	401SO	401SO
Sony	Xperia Z3	D6603	D6603
Sony	Xperia Z3	D6616	D6616
Sony	Xperia Z3	D6643	D6643
Sony	Xperia Z3	D6653	D6653
Sony	Xperia Z3	SO-01G	SO-01G
Sony	Xperia Z3	SOL26	SOL26
Sony	Xperia Z3 Compact	D5803	D5803
Sony	Xperia Z3 Compact	D5833	D5833
Sony	Xperia Z3 Compact	SO-02G	SO-02G
Sony	Xperia Z3 Dual	D6633	D6633
Sony	Xperia Z3 Tablet Compact	SGP611	SGP611
Sony	Xperia Z3 Tablet Compact	SGP612	SGP612
Sony	Xperia Z3 Tablet Compact	SGP621	SGP621
Sony	Xperia Z3 Tablet Compact	SGP641	SGP641
Sony	Xperia Z3v	D6708	D6708
Sony	Xperia ZL	C6502	C6502
Sony	Xperia ZL	C6503	C6503
Sony	Xperia ZL	C6506	C6506
Sony	Xperia ZL	L35h	L35h
Sony	Xperia ZL2	SOL25	SOL25
Sony	Xperia ZR	C5306	C5306
Sony	Xperia ZR	C5502	C5502
Sony	Xperia ZR	C5503	C5503
Sony	Xperia acro HD	SO-03D	SO-03D
Sony	Xperia acro S	LT26w	LT26w

Supported Devices

Sony	Xperia active	ST17i	ST17i
Sony	Xperia arc S	LT18i	LT18i
Sony	Xperia go	ST27i	ST27i
Sony	Xperia ion	LT28h	LT28h
Sony	Xperia ion	LT28i	LT28i
Sony	Xperia mini pro	SK17a	SK17a
Sony	Xperia miro	ST23a	ST23a
Sony	Xperia miro	ST23i	ST23i
Sony	Xperia neo L	MT25i	MT25i
Sony	Xperia pro	MK16i	MK16i
Sony	Xperia ray	ST18i	ST18i
Sony	Xperia sola	MT27i	MT27i
Sony	Xperia tipo	ST21a	ST21a
Sony	Xperia tipo dual	ST21a2	ST21a2
Sony Ericsson		LT15a	LT15a
Sony Ericsson		LT18i	LT18i
Sony Ericsson		LT22i	LT22i
Sony Ericsson		LT26i	LT26i
Sony Ericsson		LT28h	LT28h
Sony Ericsson		LT28i	LT28i
Sony Ericsson		MK16a	MK16a
Sony Ericsson		MK16i	MK16i
Sony Ericsson		MT11i	MT11i
Sony Ericsson		MT15i	MT15i
Sony Ericsson		MT27i	MT27i
Sony Ericsson		R800x	R800x
Sony Ericsson		SK17i	SK17i
Sony Ericsson		ST15i	ST15i
Sony Ericsson		ST17i	ST17i
Sony Ericsson		ST18i	ST18i

Supported Devices

Sony Ericsson		WT18i	WT18i
Sony Ericsson		WT19a	WT19a
Sony Ericsson		WT19i	WT19i
Sony Ericsson	Live with Walkman	WT19a	WT19a
Sony Ericsson	Live with Walkman	WT19i	WT19i
Sony Ericsson	Live with Walkman(TM)	WT19a	WT19a
Sony Ericsson	X10 Xperia Mini	robyn	E10i
Sony Ericsson	Xperia A	SO-04E	SO-04E
Sony Ericsson	Xperia AX	SO-01E	SO-01E
Sony Ericsson	Xperia Acro	IS11S	IS11S
Sony Ericsson	Xperia Acro	SO-02C	SO-02C
Sony Ericsson	Xperia Arc	LT15i	LT15i
Sony Ericsson	Xperia Arc	SO-01C	SO-01C
Sony Ericsson	Xperia C	S39h	S39h
Sony Ericsson	Xperia GX	SO-04D	SO-04D
Sony Ericsson	Xperia Go	ST27a	ST27a
Sony Ericsson	Xperia Go	ST27i	ST27i
Sony Ericsson	Xperia J	ST26i	ST26i
Sony Ericsson	Xperia Neo	MT15i	MT15i
Sony Ericsson	Xperia P	LT22i	LT22i
Sony Ericsson	Xperia PLAY	R800a	R800a
Sony Ericsson	Xperia PLAY	R800at	R800at
Sony Ericsson	Xperia PLAY	R800i	R800i
Sony Ericsson	Xperia PLAY	R800x	R800x
Sony Ericsson	Xperia PLAY	SO-01D	SO-01D
Sony Ericsson	Xperia Play	R800i	R800i
Sony Ericsson	Xperia Play	Zeus	Zeus
Sony Ericsson	Xperia S	LT26i	LT26i
Sony Ericsson	Xperia S	SO-02D	SO-02D
Sony Ericsson	Xperia SL	LT26ii	LT26ii

Supported Devices

Sony Ericsson	Xperia SP	M35c	M35c
Sony Ericsson	Xperia SX	SO-05D	SO-05D
Sony Ericsson	Xperia T	LT30a	LT30a
Sony Ericsson	Xperia T	LT30at	LT30at
Sony Ericsson	Xperia T	LT30p	LT30p
Sony Ericsson	Xperia TX	LT29i	LT29i
Sony Ericsson	Xperia Tablet Z	SGP311	SGP311
Sony Ericsson	Xperia Tablet Z	SGP321	SGP321
Sony Ericsson	Xperia Tablet Z	SGP341	SGP341
Sony Ericsson	Xperia Tablet Z	SO-03E	SO-03E
Sony Ericsson	Xperia U	ST25i	ST25i
Sony Ericsson	Xperia UL	SOL22	SOL22
Sony Ericsson	Xperia V	LT25c	LT25c
Sony Ericsson	Xperia V	LT25i	LT25i
Sony Ericsson	Xperia VL	SOL21	SOL21
Sony Ericsson	Xperia X10	SO-01B	SO-01B
Sony Ericsson	Xperia X10	SonyEricssonSO-01B	SO-01B
Sony Ericsson	Xperia X10	SonyEricssonX10iv	X10i
Sony Ericsson	Xperia X10	X10a	X10a
Sony Ericsson	Xperia X10	X10i	X10i
Sony Ericsson	Xperia X10 Mini	E10i	E10i
Sony Ericsson	Xperia X10 Mini	SonyEricssonE10i	E10i
Sony Ericsson	Xperia X10 Mini Pro	U20i	U20i
Sony Ericsson	Xperia X10 mini	SonyEricssonE10a	E10a
Sony Ericsson	Xperia X10 mini pro	SonyEricssonU20a	U20a
Sony Ericsson	Xperia X8	E15i	E15i
Sony Ericsson	Xperia Z	SO-02E	SO-02E
Sony Ericsson	Xperia Z Ultra	C6806	C6806
Sony Ericsson	Xperia Z1	C6903	C6903
Sony Ericsson	Xperia Z1	C6906	C6906

Supported Devices

Sony Ericsson	Xperia Z1	C6943	C6943
Sony Ericsson	Xperia acro HD	IS12S	IS12S
Sony Ericsson	Xperia acro S	LT26w	LT26w
Sony Ericsson	Xperia active	ST17i	ST17i
Sony Ericsson	Xperia arc	LT15a	LT15a
Sony Ericsson	Xperia arc	LT15i	LT15i
Sony Ericsson	Xperia arc S	LT18a	LT18a
Sony Ericsson	Xperia arc S	LT18i	LT18i
Sony Ericsson	Xperia go	ST27i	ST27i
Sony Ericsson	Xperia ion	LT28at	LT28at
Sony Ericsson	Xperia ion	LT28h	LT28h
Sony Ericsson	Xperia ion	LT28i	LT28i
Sony Ericsson	Xperia live	WT19a	WT19a
Sony Ericsson	Xperia mini	S51SE	S51SE
Sony Ericsson	Xperia mini	ST15a	ST15a
Sony Ericsson	Xperia mini	ST15i	ST15i
Sony Ericsson	Xperia mini pro	SK17a	SK17a
Sony Ericsson	Xperia mini pro	SK17i	SK17i
Sony Ericsson	Xperia miro	ST23i	ST23i
Sony Ericsson	Xperia neo	MT15a	MT15a
Sony Ericsson	Xperia neo	MT15i	MT15i
Sony Ericsson	Xperia neo L	MT25i	MT25i
Sony Ericsson	Xperia neo V	MT11a	MT11a
Sony Ericsson	Xperia neo V	MT11i	MT11i
Sony Ericsson	Xperia pro	MK16a	MK16a
Sony Ericsson	Xperia pro	MK16i	MK16i
Sony Ericsson	Xperia ray	SO-03C	SO-03C
Sony Ericsson	Xperia ray	ST18a	ST18a
Sony Ericsson	Xperia ray	ST18i	ST18i
Sony Ericsson	Xperia sola	MT27i	MT27i

Supported Devices

Sony Ericsson	Xperia tipo	ST21i	ST21i
Sony Ericsson	Xperia tipo dual	ST21i2	ST21i2
Sophix_Digix	TAB-750_G	TAB-750_G	TAB-750_G
Spice	Dream Uno	Mi-498_sprout	Spice Mi-498
Spice	Dream Uno	Mi-498_sprout	Spice Mi-498H
Spice	Smart Flo Mi-449	SpiceMi449	SpiceMi-449
Spice	Smart Flo Mi-449	hongyu72_wet_jb3	SpiceMi-449
Spice	Stellar Mi-438	Spice	MI-438
Spice	Stellar Mi-506	SpiceMi506	Spice Mi-506
Storex	eZeeTab10D12-S	eZeeTab10D12-S	eZeeTab10D12-S
Storex	eZeeTab7D15-M	eZeeTab7D15-M	eZeeTab7D15-M
Sugar	Sugar	s9121	SUGAR
Sumitomo Electric Networks		dhe1100	Hikari-iFrame/WDPF-703SE
TA71CA5_JP	JP SA COUTO, S.A. _MG070A2T	TA71CA5_1	TA71CA5
TCL	L55E6700UDS	movo_la	movo_la
TCL	LE50UHDE5692G	movo	movo
TCT (Alcatel)		A556C	A556C
TCT (Alcatel)		A919_gsm	TCL A919
TCT (Alcatel)		ASB-D_T918	ASB-D T918
TCT (Alcatel)		B-GriffinPlus_TD	ASB-D T918
TCT (Alcatel)		BASE_Varia_gsm	BASE_Varia
TCT (Alcatel)		E928_TD	TCL E928
TCT (Alcatel)		Griffin_TD	TCL E928
TCT (Alcatel)		MOVE_gsm	MOVE
TCT (Alcatel)		MTC-962_gsm	MTC-962
TCT (Alcatel)		Martini	one touch 906
TCT (Alcatel)		MegaFon_SP-A10	MegaFon_SP-A10
TCT (Alcatel)		ONE_TOUCH_928D_gsm	ALCATEL ONE TOUCH 928D
TCT (Alcatel)		ONE_TOUCH_983A_gsm	ALCATEL_one_touch_983A
TCT (Alcatel)		ONE_TOUCH_983M_gsm	ONE TOUCH 983M

Supported Devices

TCT (Alcatel)		OP070	OP070
TCT (Alcatel)		OT-906	ALCATEL_one_touch_906
TCT (Alcatel)		OT-906	ALCATEL_one_touch_906Y
TCT (Alcatel)		OT-913D	ALCATEL_one_touch_913D
TCT (Alcatel)		OT-976	ALCATEL_one_touch_976
TCT (Alcatel)		OT-978	ALCATEL_one_touch_978
TCT (Alcatel)		OT-979	ALCATEL_one_touch_979
TCT (Alcatel)		OT-979	ALCATEL_one_touch_979_HelloKitty
TCT (Alcatel)		OT-980A_gsm	Alcatel OT-980A
TCT (Alcatel)		OT-980_gsm	Alcatel OT-980
TCT (Alcatel)		OT-980_gsm	Alcatel OT-980A
TCT (Alcatel)		OT-980_gsm	Alcatel OT-981A
TCT (Alcatel)		OT-981A_gsm	Alcatel OT-981A
TCT (Alcatel)		OT-981_gsm	Alcatel OT-981A
TCT (Alcatel)		OT_918_gsm	ALCATEL OT 918
TCT (Alcatel)		OT_919_HelloKitty_gsm	ALCATEL OT 919 HelloKitty
TCT (Alcatel)		OT_919_gsm	ALCATEL OT 919
TCT (Alcatel)		OT_990M_gsm	ALCATEL_OT_990M
TCT (Alcatel)		RASPG3201_umts	RASPG3201
TCT (Alcatel)		RPSPG3201_umts	RPSPG3201
TCT (Alcatel)		SmartIII4	Vodafone 975N
TCT (Alcatel)		T20	one touch T20
TCT (Alcatel)		T60	onetouch T60
TCT (Alcatel)		TCL-A909_A909_gsm	TCL A909
TCT (Alcatel)		TCL-S806	TCL-S806
TCT (Alcatel)		TCL_890D_gsm	TCL A890 2SIM
TCT (Alcatel)		TCL_A510	TCL A510
TCT (Alcatel)		TCL_A510	TCL_A510
TCT (Alcatel)		TCL_A919_umts	TCL A919
TCT (Alcatel)		TCL_A919_umts	TCL_W969

Supported Devices

TCT (Alcatel)		TCL_A966_gsm	TCL A966
TCT (Alcatel)		TCL_A968	TCL A968
TCT (Alcatel)		TCL_A980_gsm	TCL A980
TCT (Alcatel)		TCL_A986_gsm	TCL A986
TCT (Alcatel)		TCL_A988_gsm	TCL_A988
TCT (Alcatel)		TCL_A998_gsm	TCL A998
TCT (Alcatel)		TCL_C990_Plus_cdma	TCL C990+
TCT (Alcatel)		TCL_D515_cdma	TCL D515
TCT (Alcatel)		TCL_D662_cdma	TCL D662
TCT (Alcatel)		TCL_S800_GSM	TCL S800
TCT (Alcatel)		TCL_W939_gsm	TCL_W939
TCT (Alcatel)		TCL_W969_gsm	TCL W969
TCT (Alcatel)		Vancouver_gsm	Vancouver_Orange
TCT (Alcatel)		mercury	I-L1
TCT (Alcatel)		move_2_gsm	move 2
TCT (Alcatel)		msm7627_ffa	Alcatel OT-980
TCT (Alcatel)		msm7627_ffa	Alcatel OT-980A
TCT (Alcatel)		one_touch_890D_gsm	ALCATEL one touch 890D
TCT (Alcatel)		one_touch_890_gsm	ALCATEL_one_touch_890
TCT (Alcatel)		one_touch_890_gsm	Vip_MiniDroid
TCT (Alcatel)		one_touch_891_gsm	ALCATEL_one_touch_891
TCT (Alcatel)		one_touch_908A_gsm	ALCATEL_one_touch_908A
TCT (Alcatel)		one_touch_908F_gsm	ALCATEL_one_touch_908F
TCT (Alcatel)		one_touch_908F_gsm	ALCATEL_one_touch_908F_Orange
TCT (Alcatel)		one_touch_908F_gsm	Alcatel_one_touch_908F
TCT (Alcatel)		one_touch_908F_gsm	Alcatel_one_touch_908F_Orange
TCT (Alcatel)		one_touch_908M_gsm	ALCATEL_one_touch_908M
TCT (Alcatel)		one_touch_908S_gsm	ALCATEL_one_touch_908S
TCT (Alcatel)		one_touch_908_gsm	ALCATEL ONE TOUCH 908
TCT (Alcatel)		one_touch_909A_gsm	ALCATEL_one_touch_909A

Supported Devices

TCT (Alcatel)		one_touch_909B_cdma	ALCATEL_one_touch_909B
TCT (Alcatel)		one_touch_909B_cdma	USCC_ALCATEL_one_touch_909B
TCT (Alcatel)		one_touch_909S_gsm	ALCATEL_one_touch_909S
TCT (Alcatel)		one_touch_910A_gsm	ALCATEL_one_touch_910A
TCT (Alcatel)		one_touch_910_gsm	ALCATEL_one_touch_910
TCT (Alcatel)		one_touch_916A_gsm	ALCATEL ONE TOUCH 916A
TCT (Alcatel)		one_touch_916D_gsm	ALCATEL ONE TOUCH 916D
TCT (Alcatel)		one_touch_916_gsm	ALCATEL ONE TOUCH 916
TCT (Alcatel)		one_touch_918M_gsm	ALCATEL_ONE_TOUCH_918M
TCT (Alcatel)		one_touch_918M_umts	ALCATEL_one_touch_918M
TCT (Alcatel)		one_touch_918N_umts	ALCATEL_one_touch_918N
TCT (Alcatel)		one_touch_918_gsm	ALCATEL ONE TOUCH 918
TCT (Alcatel)		one_touch_985_gsm	ALCATEL ONE TOUCH 985
TCT (Alcatel)		one_touch_985_gsm	Telenor Smart
TCT (Alcatel)		one_touch_988_cdma	ALCATEL_one_touch_988
TCT (Alcatel)		one_touch_988_cdma	USCC_ALCATEL_one_touch_988
TCT (Alcatel)		one_touch_990A_gsm	ALCATEL ONE TOUCH 990A
TCT (Alcatel)		one_touch_990A_gsm	ALCATEL_one_touch_990A
TCT (Alcatel)		one_touch_990C_cdma	ALCATEL one touch 990C
TCT (Alcatel)		one_touch_990_gsm	ALCATEL ONE TOUCH 990
TCT (Alcatel)		one_touch_990_gsm	Alcatel one touch 990 Orange
TCT (Alcatel)		one_touch_990_gsm	Telenor_OneTouch
TCT (Alcatel)		one_touch_991S_gsm	ALCATEL ONE TOUCH 991S
TCT (Alcatel)		one_touch_993D_gsm	ALCATEL ONE TOUCH 993D
TCT (Alcatel)		one_touch_995A_gsm	ALCATEL_one_touch_995A
TCT (Alcatel)		one_touch_995C_cdma	one touch 995C+
TCT (Alcatel)		one_touch_996_gsm	Orange_infinity_996
TCT (Alcatel)	5038D	SOUL45_GSM	5038D
TCT (Alcatel)	6010A	Miata_3G	6016A
TCT (Alcatel)	6014X	Miata_3G	6014X

Supported Devices

TCT (Alcatel)	6016D	Miata_3G	6016D
TCT (Alcatel)	6016E	Miata_3G	6016E
TCT (Alcatel)	6016X	Miata_3G	6016X
TCT (Alcatel)	6037B	Eclipse	6037B
TCT (Alcatel)	6037K	Eclipse	6037K
TCT (Alcatel)	6037Y	Eclipse	6037Y
TCT (Alcatel)	6042D	CROSSAPAC	6042D
TCT (Alcatel)	6043A	DIABLOXPLUS	6043A
TCT (Alcatel)	6043D	DIABLOXPLUS	6043D
TCT (Alcatel)	7040N	Yaris5TMO	7040N
TCT (Alcatel)	7040R	Yaris5TMO	7040R
TCT (Alcatel)	7040T	Yaris5TMO	7040T
TCT (Alcatel)	7045Y	RIO5	7045Y
TCT (Alcatel)	730U	Rio5C	J730U
TCT (Alcatel)	8030Y	HERO2	8030Y
TCT (Alcatel)	9005X	PIXO8_3G	9005X
TCT (Alcatel)	A851L	Viper_gsm	Alcatel 7030L
TCT (Alcatel)	A851L	Viper_gsm	Alcatel A851L
TCT (Alcatel)	ALCATEL 4015T	Yaris35_GSM	ALCATEL 4015T
TCT (Alcatel)	ALCATEL A564C	Yaris5NA	ALCATEL A564C
TCT (Alcatel)	ALCATEL ONE TOUCH 4005D	Beetle_Lite_Edge_GSM	ALCATEL ONE TOUCH 4005D
TCT (Alcatel)	ALCATEL ONE TOUCH 4005D	Beetle_Lite_Edge_GSM	ALCATEL_ONE_TOUCH_4005D
TCT (Alcatel)	ALCATEL ONE TOUCH 4010X	Beetle_Lite_GSM	ALCATEL ONE TOUCH 4010A
TCT (Alcatel)	ALCATEL ONE TOUCH 4010X	Beetle_Lite_GSM	ALCATEL ONE TOUCH 4010D
TCT (Alcatel)	ALCATEL ONE TOUCH 4010X	Beetle_Lite_GSM	ALCATEL ONE TOUCH 4010E
TCT (Alcatel)	ALCATEL ONE TOUCH 4010X	Beetle_Lite_GSM	ALCATEL ONE TOUCH 4010X
TCT (Alcatel)	ALCATEL ONE TOUCH 4010X	Beetle_Lite_GSM	TCL_J210
TCT (Alcatel)	ALCATEL ONE TOUCH 4010X	Beetle_Lite_GSM	Telenor Smart 2
TCT (Alcatel)	ALCATEL ONE TOUCH 4030X	Beetle_GSM	ALCATEL ONE TOUCH 4029A
TCT (Alcatel)	ALCATEL ONE TOUCH 4030X	Beetle_GSM	ALCATEL ONE TOUCH 4030D

Supported Devices

TCT (Alcatel)	ALCATEL ONE TOUCH 4030X	Beetle_GSM	ALCATEL ONE TOUCH 4030E
TCT (Alcatel)	ALCATEL ONE TOUCH 4030X	Beetle_GSM	ALCATEL ONE TOUCH 4030X
TCT (Alcatel)	ALCATEL ONE TOUCH 4030X	Beetle_GSM	ALCATEL ONE TOUCH 4030Y
TCT (Alcatel)	ALCATEL ONE TOUCH 4030X	Beetle_GSM	ALCATEL ONE TOUCH 4030Y_orange
TCT (Alcatel)	ALCATEL ONE TOUCH 4030X	Beetle_GSM	Infinity POP
TCT (Alcatel)	ALCATEL ONE TOUCH 4030X	Beetle_GSM	Orange Runo
TCT (Alcatel)	ALCATEL ONE TOUCH 4037N	SOUL4NA	ALCATEL ONE TOUCH 4037N
TCT (Alcatel)	ALCATEL ONE TOUCH 4037N	SOUL4NA	ALCATEL ONE TOUCH 4037T
TCT (Alcatel)	ALCATEL ONE TOUCH 5020D	Megane_GSM	ALCATEL ONE TOUCH 5020A
TCT (Alcatel)	ALCATEL ONE TOUCH 5020D	Megane_GSM	ALCATEL ONE TOUCH 5020D
TCT (Alcatel)	ALCATEL ONE TOUCH 5020D	Megane_GSM	ALCATEL ONE TOUCH 5020E
TCT (Alcatel)	ALCATEL ONE TOUCH 5020D	Megane_GSM	ALCATEL ONE TOUCH 5020T
TCT (Alcatel)	ALCATEL ONE TOUCH 5020D	Megane_GSM	ALCATEL ONE TOUCH 5020W
TCT (Alcatel)	ALCATEL ONE TOUCH 5020D	Megane_GSM	ALCATEL ONE TOUCH 5020X
TCT (Alcatel)	ALCATEL ONE TOUCH 5020D	Megane_GSM	ALCATEL ONE TOUCH 5021E
TCT (Alcatel)	ALCATEL ONE TOUCH 5020D	Megane_GSM	ALCATEL_ONE_TOUCH_5020D_Orange
TCT (Alcatel)	ALCATEL ONE TOUCH 5020D	Megane_GSM	ALCATEL_ONE_TOUCH_5020X_Orange
TCT (Alcatel)	ALCATEL ONE TOUCH 5020D	Megane_GSM	AURUS III
TCT (Alcatel)	ALCATEL ONE TOUCH 5020D	Megane_GSM	MTC 972
TCT (Alcatel)	ALCATEL ONE TOUCH 5020D	Megane_GSM	Orange Kivo
TCT (Alcatel)	ALCATEL ONE TOUCH 5020D	Megane_GSM	Telenor Smart Pro 2
TCT (Alcatel)	ALCATEL ONE TOUCH 5020N	Megane	ALCATEL ONE TOUCH 5020N
TCT (Alcatel)	ALCATEL ONE TOUCH 5035D	Camry_GSM	ALCATEL ONE TOUCH 5035A
TCT (Alcatel)	ALCATEL ONE TOUCH 5035D	Camry_GSM	ALCATEL ONE TOUCH 5035D
TCT (Alcatel)	ALCATEL ONE TOUCH 5035D	Camry_GSM	ALCATEL ONE TOUCH 5035E
TCT (Alcatel)	ALCATEL ONE TOUCH 5035D	Camry_GSM	ALCATEL ONE TOUCH 5035X
TCT (Alcatel)	ALCATEL ONE TOUCH 5035D	Camry_GSM	TCL J610
TCT (Alcatel)	ALCATEL ONE TOUCH 5035D	Camry_GSM	TCL S810
TCT (Alcatel)	ALCATEL ONE TOUCH 5036A	YarisL_GSM	ALCATEL ONE TOUCH 5036A
TCT (Alcatel)	ALCATEL ONE TOUCH 5036D	YarisL_GSM	ALCATEL ONE TOUCH 5036D

Supported Devices

TCT (Alcatel)	ALCATEL ONE TOUCH 5036D	YarisL_GSM	ONE TOUCH 5036X
TCT (Alcatel)	ALCATEL ONE TOUCH 5036F	YarisL_GSM	ALCATEL ONE TOUCH 5036F
TCT (Alcatel)	ALCATEL ONE TOUCH 5036X	YarisL_GSM	ALCATEL ONE TOUCH 5036X
TCT (Alcatel)	ALCATEL ONE TOUCH 5037E	YarisL_GSM	ALCATEL ONE TOUCH 5037E
TCT (Alcatel)	ALCATEL ONE TOUCH 601	Telsa	ALCATEL ONE TOUCH 6010
TCT (Alcatel)	ALCATEL ONE TOUCH 6010A	Telsa	ALCATEL ONE TOUCH 6010A
TCT (Alcatel)	ALCATEL ONE TOUCH 6010D	Telsa	ALCATEL ONE TOUCH 6010D
TCT (Alcatel)	ALCATEL ONE TOUCH 6010X	Telsa	ALCATEL ONE TOUCH 6010
TCT (Alcatel)	ALCATEL ONE TOUCH 6010X	Telsa	ALCATEL ONE TOUCH 6010D
TCT (Alcatel)	ALCATEL ONE TOUCH 6010X	Telsa	ALCATEL ONE TOUCH 6010X
TCT (Alcatel)	ALCATEL ONE TOUCH 6010X	Telsa	ALCATEL ONE TOUCH 6010X-orange
TCT (Alcatel)	ALCATEL ONE TOUCH 6010X	Telsa	TCL S520
TCT (Alcatel)	ALCATEL ONE TOUCH 6030A	Diablo	ALCATEL ONE TOUCH 6030A
TCT (Alcatel)	ALCATEL ONE TOUCH 6030D	Diablo	ALCATEL ONE TOUCH 6030D
TCT (Alcatel)	ALCATEL ONE TOUCH 6030N	Diablo	ALCATEL ONE TOUCH 6030N
TCT (Alcatel)	ALCATEL ONE TOUCH 6030X	Diablo	ALCATEL ONE TOUCH 6030A
TCT (Alcatel)	ALCATEL ONE TOUCH 6030X	Diablo	ALCATEL ONE TOUCH 6030D
TCT (Alcatel)	ALCATEL ONE TOUCH 6030X	Diablo	ALCATEL ONE TOUCH 6030X
TCT (Alcatel)	ALCATEL ONE TOUCH 6030X	Diablo	ALCATEL ONE TOUCH 6030X-orange
TCT (Alcatel)	ALCATEL ONE TOUCH 6030X	Diablo	ALCATEL_ONE_TOUCH_6030X_Orange
TCT (Alcatel)	ALCATEL ONE TOUCH 6030X	Diablo	Optimus_San_Remo
TCT (Alcatel)	ALCATEL ONE TOUCH 6030X	Diablo	TCL S820
TCT (Alcatel)	ALCATEL ONE TOUCH 6030X-orange	Diablo	ALCATEL ONE TOUCH 6030X-orange
TCT (Alcatel)	ALCATEL ONE TOUCH 6032	Alpha	ALCATEL ONE TOUCH 6032
TCT (Alcatel)	ALCATEL ONE TOUCH 6032A	Alpha	ALCATEL ONE TOUCH 6032A
TCT (Alcatel)	ALCATEL ONE TOUCH 6032X	Alpha	ALCATEL ONE TOUCH 6032X
TCT (Alcatel)	ALCATEL ONE TOUCH 6033A	DiabloHD	ALCATEL ONE TOUCH 6033A
TCT (Alcatel)	ALCATEL ONE TOUCH 6033M	DiabloHD	ALCATEL ONE TOUCH 6033M
TCT (Alcatel)	ALCATEL ONE TOUCH 6033X	DiabloHD	ALCATEL ONE TOUCH 6033M

Supported Devices

TCT (Alcatel)	ALCATEL ONE TOUCH 6033X	DiabloHD	ALCATEL ONE TOUCH 6033X
TCT (Alcatel)	ALCATEL ONE TOUCH 6033X	DiabloHD	TCL S850
TCT (Alcatel)	ALCATEL ONE TOUCH 6037B	Eclipse	ALCATEL ONE TOUCH 6037B
TCT (Alcatel)	ALCATEL ONE TOUCH 6040A	DIABLOX	ALCATEL ONE TOUCH 6040A
TCT (Alcatel)	ALCATEL ONE TOUCH 6040D	DIABLOX	ALCATEL ONE TOUCH 6040D
TCT (Alcatel)	ALCATEL ONE TOUCH 6040D	DIABLOX	TCL S950
TCT (Alcatel)	ALCATEL ONE TOUCH 6040E	DIABLOX	ALCATEL ONE TOUCH 6040E
TCT (Alcatel)	ALCATEL ONE TOUCH 6040X	DIABLOX	ALCATEL ONE TOUCH 6040X
TCT (Alcatel)	ALCATEL ONE TOUCH 7024W	Rav4	ALCATEL ONE TOUCH 7024R
TCT (Alcatel)	ALCATEL ONE TOUCH 7024W	Rav4	ALCATEL ONE TOUCH 7024W
TCT (Alcatel)	ALCATEL ONE TOUCH 7024W	Rav4	ALCATEL ONE TOUCH FIERCE
TCT (Alcatel)	ALCATEL ONE TOUCH 7025D	Rav4	ALCATEL ONE TOUCH 7025D
TCT (Alcatel)	ALCATEL ONE TOUCH 7040A	YARISXL	ALCATEL ONE TOUCH 7040A
TCT (Alcatel)	ALCATEL ONE TOUCH 7040D	YARISXL	ALCATEL ONE TOUCH 7040D
TCT (Alcatel)	ALCATEL ONE TOUCH 7040E	YARISXL	ALCATEL ONE TOUCH 7040E
TCT (Alcatel)	ALCATEL ONE TOUCH 7040K	YARISXL	ALCATEL ONE TOUCH 7040K
TCT (Alcatel)	ALCATEL ONE TOUCH 7040X	YARISXL	ALCATEL ONE TOUCH 7040X
TCT (Alcatel)	ALCATEL ONE TOUCH 7041D	YARISXL	ALCATEL ONE TOUCH 7041D
TCT (Alcatel)	ALCATEL ONE TOUCH 7041X	YARISXL	ALCATEL ONE TOUCH 7041X
TCT (Alcatel)	ALCATEL ONE TOUCH 7042D	YARISXL	ALCATEL ONE TOUCH 7042D
TCT (Alcatel)	ALCATEL ONE TOUCH 7047D	YARIS_55	ALCATEL ONE TOUCH 7047D
TCT (Alcatel)	ALCATEL ONE TOUCH 7047E	YARIS_55	ALCATEL ONE TOUCH 7047E
TCT (Alcatel)	ALCATEL ONE TOUCH 8008D	Scribe5HD	ALCATEL ONE TOUCH 8008D
TCT (Alcatel)	ALCATEL ONE TOUCH 8008D	Scribe5HD	ALCATEL ONE TOUCH 8008X
TCT (Alcatel)	ALCATEL ONE TOUCH 8008D	Scribe5HD	Orange Infinity 8008X
TCT (Alcatel)	ALCATEL ONE TOUCH 8020A	SCRIBEPRO	ALCATEL ONE TOUCH 8020A
TCT (Alcatel)	ALCATEL ONE TOUCH 8020D	SCRIBEPRO	ALCATEL ONE TOUCH 8020D
TCT (Alcatel)	ALCATEL ONE TOUCH 8020E	SCRIBEPRO	ALCATEL ONE TOUCH 8020E
TCT (Alcatel)	ALCATEL ONE TOUCH 8020X	SCRIBEPRO	ALCATEL ONE TOUCH 8020X
TCT (Alcatel)	ALCATEL ONE TOUCH 903	one_touch_903A_gsm	ALCATEL_ONE_TOUCH_903

Supported Devices

TCT (Alcatel)	ALCATEL ONE TOUCH 903	one_touch_903A_gsm	ALCATEL_one_touch_903
TCT (Alcatel)	ALCATEL ONE TOUCH 903	one_touch_903D_gsm	ALCATEL ONE TOUCH 903D
TCT (Alcatel)	ALCATEL ONE TOUCH 903	one_touch_903_gsm	ALCATEL ONE TOUCH 903
TCT (Alcatel)	ALCATEL ONE TOUCH 903	one_touch_903_gsm	ALCATEL_ONE_TOUCH_903
TCT (Alcatel)	ALCATEL ONE TOUCH 903A	one_touch_903A_gsm	ALCATEL ONE TOUCH 903A
TCT (Alcatel)	ALCATEL ONE TOUCH 903D	one_touch_903D_gsm	ALCATEL ONE TOUCH 903D
TCT (Alcatel)	ALCATEL ONE TOUCH 918	one_touch_918_gsm	ALCATEL ONE TOUCH 918
TCT (Alcatel)	ALCATEL ONE TOUCH 918	one_touch_918_gsm	ALCATEL one touch 918
TCT (Alcatel)	ALCATEL ONE TOUCH 918	one_touch_918_gsm	ALCATEL_one_touch_918
TCT (Alcatel)	ALCATEL ONE TOUCH 918	one_touch_918_gsm	Alcatel_one_touch_918_Orange
TCT (Alcatel)	ALCATEL ONE TOUCH 918A	one_touch_918A_gsm	ALCATEL ONE TOUCH 918A
TCT (Alcatel)	ALCATEL ONE TOUCH 918A	one_touch_918A_gsm	ALCATEL_one_touch_918A
TCT (Alcatel)	ALCATEL ONE TOUCH 918D	ONE_TOUCH_918D_umts	ALCATEL ONE TOUCH 918D
TCT (Alcatel)	ALCATEL ONE TOUCH 918D	one_touch_918D_gsm	ALCATEL ONE TOUCH 918D
TCT (Alcatel)	ALCATEL ONE TOUCH 918N	ONE_TOUCH_918N_umts	ALCATEL ONE TOUCH 918N
TCT (Alcatel)	ALCATEL ONE TOUCH 918N	one_touch_918N_gsm	ALCATEL ONE TOUCH 918N
TCT (Alcatel)	ALCATEL ONE TOUCH 918S	one_touch_918S_gsm	ALCATEL ONE TOUCH 918S
TCT (Alcatel)	ALCATEL ONE TOUCH 922	one_touch_922_gsm	ALCATEL ONE TOUCH 922
TCT (Alcatel)	ALCATEL ONE TOUCH 930D	OT-930	ALCATEL ONE TOUCH 930D
TCT (Alcatel)	ALCATEL ONE TOUCH 930D	OT-930	ALCATEL ONE TOUCH 930N
TCT (Alcatel)	ALCATEL ONE TOUCH 985	one_touch_985_gsm	ALCATEL ONE TOUCH 985
TCT (Alcatel)	ALCATEL ONE TOUCH 985	one_touch_985_gsm	ALCATEL_ONE_TOUCH_985
TCT (Alcatel)	ALCATEL ONE TOUCH 985	one_touch_985_gsm	ALCATEL_one_touch_985
TCT (Alcatel)	ALCATEL ONE TOUCH 985	one_touch_985_gsm	Telenor_One_Touch_C
TCT (Alcatel)	ALCATEL ONE TOUCH 985D	one_touch_985D_gsm	ALCATEL ONE TOUCH 985D
TCT (Alcatel)	ALCATEL ONE TOUCH 985N	one_touch_985N_gsm	ALCATEL ONE TOUCH 985N
TCT (Alcatel)	ALCATEL ONE TOUCH 991	ONE_TOUCH_991D_gsm	ALCATEL ONE TOUCH 991D
TCT (Alcatel)	ALCATEL ONE TOUCH 991	ONE_TOUCH_991_gsm	ALCATEL ONE TOUCH 991
TCT (Alcatel)	ALCATEL ONE TOUCH 991	ONE_TOUCH_991_gsm	ALCATEL_one_touch_991
TCT (Alcatel)	ALCATEL ONE TOUCH 991	ONE_TOUCH_991_gsm	Telenor_Smart_Pro

Supported Devices

TCT (Alcatel)	ALCATEL ONE TOUCH 991	one_touch_991_gsm	ALCATEL ONE TOUCH 991
TCT (Alcatel)	ALCATEL ONE TOUCH 991A	ONE_TOUCH_991A_gsm	ALCATEL ONE TOUCH 991A
TCT (Alcatel)	ALCATEL ONE TOUCH 991D	ONE_TOUCH_991D_gsm	ALCATEL ONE TOUCH 991D
TCT (Alcatel)	ALCATEL ONE TOUCH 991D	one_touch_991D_gsm	ALCATEL ONE TOUCH 991D
TCT (Alcatel)	ALCATEL ONE TOUCH 991T	one_touch_991T_gsm	ALCATEL ONE TOUCH 991T
TCT (Alcatel)	ALCATEL ONE TOUCH 992D	Martell_lite_GSM	ALCATEL ONE TOUCH 992
TCT (Alcatel)	ALCATEL ONE TOUCH 992D	Martell_lite_GSM	ALCATEL ONE TOUCH 992D
TCT (Alcatel)	ALCATEL ONE TOUCH 992D	Martell_lite_GSM	TCL S500
TCT (Alcatel)	ALCATEL ONE TOUCH 992D	Martell_lite_GSM	TCL S600
TCT (Alcatel)	ALCATEL ONE TOUCH 995	one_touch_995_gsm	ALCATEL_one_touch_995
TCT (Alcatel)	ALCATEL ONE TOUCH 995	one_touch_995_gsm	Optimus_Madrid
TCT (Alcatel)	ALCATEL ONE TOUCH 995	one_touch_995_gsm	Telenor_Smart_HD
TCT (Alcatel)	ALCATEL ONE TOUCH 995A	one_touch_995_gsm	ALCATEL_one_touch_995A
TCT (Alcatel)	ALCATEL ONE TOUCH 997D	Martell_GSM	ALCATEL ONE TOUCH 997
TCT (Alcatel)	ALCATEL ONE TOUCH 997D	Martell_GSM	ALCATEL ONE TOUCH 997D
TCT (Alcatel)	ALCATEL ONE TOUCH 997D	Martell_GSM	BASE_Lutea_3
TCT (Alcatel)	ALCATEL ONE TOUCH 997D	Martell_GSM	TCL S710
TCT (Alcatel)	ALCATEL ONE TOUCH 997D	Martell_GSM	TCL S800
TCT (Alcatel)	ALCATEL ONE TOUCH D668	DANIEL	ALCATEL ONE TOUCH D668
TCT (Alcatel)	ALCATEL ONE TOUCH D668	DANIEL	TCL D668
TCT (Alcatel)	ALCATEL ONE TOUCH D668	DANIEL	TCL-D668
TCT (Alcatel)	ALCATEL ONE TOUCH Fierce	Rav4	ALCATEL ONE TOUCH 7024N
TCT (Alcatel)	ALCATEL ONE TOUCH Fierce	Rav4	ALCATEL ONE TOUCH 7024W
TCT (Alcatel)	ALCATEL ONE TOUCH Fierce	Rav4	ALCATEL ONE TOUCH Fierce
TCT (Alcatel)	ALCATEL ONE TOUCH P310A	POP7	ALCATEL ONE TOUCH P310A
TCT (Alcatel)	ALCATEL ONE TOUCH P320A	POP8	ALCATEL ONE TOUCH P320A
TCT (Alcatel)	ALCATEL ONE TOUCH P321	POP8	ALCATEL ONE TOUCH P321
TCT (Alcatel)	ALCATEL ONE TOUCH918N	one_touch_918_gsm	ALCATEL ONE TOUCH 918N
TCT (Alcatel)	ALCATEL ONETOUCH 4037R	SOUL4NA	ALCATEL ONE TOUCH 4037R
TCT (Alcatel)	ALCATEL ONETOUCH 4037R	SOUL4NA	ALCATEL ONETOUCH 4037R

Supported Devices

TCT (Alcatel)	ALCATEL ONETOUCH 6032	Alpha	ALCATEL ONETOUCH 6032
TCT (Alcatel)	ALCATEL ONETOUCH 6032A	Alpha	ALCATEL ONETOUCH 6032A
TCT (Alcatel)	ALCATEL ONETOUCH 6032X	Alpha	ALCATEL ONETOUCH 6032X
TCT (Alcatel)	ALCATEL ONETOUCH 6043D	DIABLOXPLUS	ALCATEL ONETOUCH 6043D
TCT (Alcatel)	ALCATEL ONETOUCH P310A	POP7	ALCATEL ONE TOUCH P310A
TCT (Alcatel)	ALCATEL ONETOUCH P310A	POP7	ALCATEL ONETOUCH P310A
TCT (Alcatel)	ALCATEL ONETOUCH POP D3	SOUL4NA	ALCATEL ONETOUCH POP D3
TCT (Alcatel)	ALCATEL one touch 986+	OT986	ALCATEL one touch 986+
TCT (Alcatel)	ALCATEL one touch 990C+	one_touch_990C_Plus_cdma	ALCATEL one touch 990C+
TCT (Alcatel)	ALCATEL one touch J320	Iris	ALCATEL one touch J320
TCT (Alcatel)	ALCATEL_ONE_TOUCH_5037A	YarisL_GSM	ALCATEL ONE TOUCH 5037A
TCT (Alcatel)	ALCATEL_ONE_TOUCH_5037X	YarisL_GSM	ALCATEL ONE TOUCH 5037X
TCT (Alcatel)	ALCATEL_ONE_TOUCH_6010X_Orange	ONE_TOUCH_6010X_gsm	ALCATEL_ONE_TOUCH_6010X_Orange
TCT (Alcatel)	ALCATEL_ONE_TOUCH_6030X_Orange	ONE_TOUCH_6030X_gsm	ALCATEL_ONE_TOUCH_6030X_Orange
TCT (Alcatel)	ALCATEL_ONE_TOUCH_7047A	YARIS_55	ALCATEL ONE TOUCH 7047A
TCT (Alcatel)	ALCATEL_ONE_TOUCH_903	one_touch_903A_gsm	ALCATEL_ONE_TOUCH_903
TCT (Alcatel)	ALCATEL_ONE_TOUCH_903	one_touch_903_gsm	ALCATEL_ONE_TOUCH_903
TCT (Alcatel)	ALCATEL_ONE_TOUCH_991_Orange	one_touch_991_gsm	ALCATEL_ONE_TOUCH_991_Orange
TCT (Alcatel)	ALCATEL_ONE_TOUCH_P310X	POP7	ALCATEL ONE TOUCH P310X
TCT (Alcatel)	ALCATEL_ONE_TOUCH_P320X	POP8	ALCATEL ONE TOUCH P320X
TCT (Alcatel)	ALCATEL_one_touch_918D	one_touch_918D_umts	ALCATEL_one_touch_918D
TCT (Alcatel)	ALCATEL_one_touch_991	ONE_TOUCH_991A_gsm	ALCATEL_one_touch_991
TCT (Alcatel)	ALCATEL_one_touch_991	one_touch_991_gsm	ALCATEL_one_touch_991
TCT (Alcatel)	ALCATEL_one_touch_995	one_touch_995_gsm	ALCATEL_one_touch_995
TCT (Alcatel)	ALCATEL_one_touch_995	one_touch_995_gsm	RPSPE4301
TCT (Alcatel)	ALCATEL_one_touch_995	one_touch_995_gsm	Telenor_One_Touch_S
TCT (Alcatel)	ALCATEL_one_touch_995	one_touch_995_gsm	Telenor_Smart_HD
TCT (Alcatel)	ALCATEL_one_touch_995A	one_touch_995_gsm	ALCATEL_one_touch_995A

Supported Devices

TCT (Alcatel)	ALCATEL_one_touch_995S	one_touch_995_gsm	ALCATEL_one_touch_995S
TCT (Alcatel)	ALOO 6032	Alpha	ALOO 6032
TCT (Alcatel)	ATEL ONE TOUCH 995	one_touch_995_gsm	ALCATEL_one_touch_995
TCT (Alcatel)	Alcatel one touch 985	one_touch_985A_gsm	ALCATEL_one_touch_985
TCT (Alcatel)	Alcatel_one_touch_918_Orange	one_touch_918_gsm	Alcatel_one_touch_918_Orange
TCT (Alcatel)	Boost View 5.0	YARISXL	Boost View 5.0
TCT (Alcatel)	D819	HERO8	D819
TCT (Alcatel)	D820	HERO8	D820
TCT (Alcatel)	D820X	HERO8	D820X
TCT (Alcatel)	DL900	YARISXL	DL900
TCT (Alcatel)	E500	X50D	E500
TCT (Alcatel)	EVO7	EVO7	MTC 1065
TCT (Alcatel)	EVO7	EVO7	onetouch EVO7
TCT (Alcatel)	EVO7	EVO7	starTIM tab 7
TCT (Alcatel)	Hero2C	Hero2C	7055A
TCT (Alcatel)	I216A	PIXI7	I216A
TCT (Alcatel)	I216X	PIXI7	I216X
TCT (Alcatel)	I220	PIXI8	I220
TCT (Alcatel)	I221	PIXI8	I221
TCT (Alcatel)	IDOL 2 S	EOS4G	6050Y
TCT (Alcatel)	IDOL 2 S	EOS4G	ALCATEL ONE TOUCH 6050Y
TCT (Alcatel)	IDOL 2 S	EOS4G	Idol2S_Orange
TCT (Alcatel)	IDOL 2 S	EOS_lte	6050A
TCT (Alcatel)	IDOL 2 S	EOS_lte	6050F
TCT (Alcatel)	IDOL 2 S	EOS_lte	6050W
TCT (Alcatel)	IDOL 2 S	EOS_lte	6050Y
TCT (Alcatel)	IDOL 2 S	EOS_lte	ALCATEL ONE TOUCH 6050Y
TCT (Alcatel)	IDOL 2 S	EOS_lte	ALCATEL ONETOUCH 6050A
TCT (Alcatel)	IDOL 2 S	EOS_lte	OWN S5030
TCT (Alcatel)	IDOL 2 S	EOS_lte	TCL S830U

Supported Devices

TCT (Alcatel)	IDOL 2 S	EOS_lte	TCL S838M
TCT (Alcatel)	Idol S	DiabloHD_LTE	ALCATEL ONE TOUCH 6035L
TCT (Alcatel)	Idol S	DiabloHD_LTE	BS472
TCT (Alcatel)	Idol S	DiabloHD_LTE	MTC 978
TCT (Alcatel)	Idol S	Diablo_LTE	ALCATEL ONE TOUCH 6034L
TCT (Alcatel)	Idol S	Diablo_LTE	ALCATEL ONE TOUCH 6034M
TCT (Alcatel)	Idol S	Diablo_LTE	ALCATEL ONE TOUCH 6034R
TCT (Alcatel)	Idol S	Diablo_LTE	ALCATEL ONE TOUCH 6034Y
TCT (Alcatel)	Idol S	Diablo_LTE	San Remo 4G
TCT (Alcatel)	Idol S	Diablo_LTE	TCL-S850L
TCT (Alcatel)	Idol X	DiabloHD_LTE	ALCATEL ONE TOUCH 6035R
TCT (Alcatel)	Idol2 MINI S	MIATA_lte	6036A
TCT (Alcatel)	Idol2 MINI S	MIATA_lte	6036X
TCT (Alcatel)	Idol2 MINI S	MIATA_lte	6036Y
TCT (Alcatel)	Juke-A554C	A554C	A554C
TCT (Alcatel)	M812C	M812	M812C
TCT (Alcatel)	MTC 960	MTC_960_gsm	MTC 960
TCT (Alcatel)	MTC 970	Beetle_GSM	MTC 970
TCT (Alcatel)	MTC975	Camry_GSM	MTC975
TCT (Alcatel)	MegaFon_SP-A10	one_touch_995_gsm	MegaFon_SP-A10
TCT (Alcatel)	Megafon Login	OT-930	MegaFon_SP-AI
TCT (Alcatel)	Moov2	move_2_gsm	move 2
TCT (Alcatel)	ONE TOUCH 4007X	Pixo_GSM	ONE TOUCH 4007A
TCT (Alcatel)	ONE TOUCH 4007X	Pixo_GSM	ONE TOUCH 4007D
TCT (Alcatel)	ONE TOUCH 4007X	Pixo_GSM	ONE TOUCH 4007E
TCT (Alcatel)	ONE TOUCH 4007X	Pixo_GSM	ONE TOUCH 4007X
TCT (Alcatel)	ONE TOUCH 4011X	BeetleliteJB	ONE TOUCH 4011X
TCT (Alcatel)	ONE TOUCH 4033X	Yaris_M_GSM	4032A
TCT (Alcatel)	ONE TOUCH 4033X	Yaris_M_GSM	4032D
TCT (Alcatel)	ONE TOUCH 4033X	Yaris_M_GSM	4032E

Supported Devices

TCT (Alcatel)	ONE TOUCH 4033X	Yaris_M_GSM	4032X
TCT (Alcatel)	ONE TOUCH 4033X	Yaris_M_GSM	4033L
TCT (Alcatel)	ONE TOUCH 4033X	Yaris_M_GSM	MS3B
TCT (Alcatel)	ONE TOUCH 4033X	Yaris_M_GSM	ONE TOUCH 4032A
TCT (Alcatel)	ONE TOUCH 4033X	Yaris_M_GSM	ONE TOUCH 4033A
TCT (Alcatel)	ONE TOUCH 4033X	Yaris_M_GSM	ONE TOUCH 4033D
TCT (Alcatel)	ONE TOUCH 4033X	Yaris_M_GSM	ONE TOUCH 4033E
TCT (Alcatel)	ONE TOUCH 4033X	Yaris_M_GSM	ONE TOUCH 4033X
TCT (Alcatel)	ONE TOUCH 4033X	Yaris_M_GSM	OWN S3010
TCT (Alcatel)	ONE TOUCH 4033X	Yaris_M_GSM	OWN S3010D
TCT (Alcatel)	ONE TOUCH 4033X	Yaris_M_GSM	TCLJ330
TCT (Alcatel)	ONE TOUCH 6012A	California_GSM	ONE TOUCH 6012A
TCT (Alcatel)	ONE TOUCH 6012D	California	ALCATEL ONE TOUCH 6012D
TCT (Alcatel)	ONE TOUCH 6012D	California	ALCATEL ONE TOUCH 6012X
TCT (Alcatel)	ONE TOUCH 6012D	California	Mobile Sosh
TCT (Alcatel)	ONE TOUCH 6012D	California	ONE TOUCH 6012A
TCT (Alcatel)	ONE TOUCH 6012D	California	ONE TOUCH 6012D
TCT (Alcatel)	ONE TOUCH 6012D	California	ONE TOUCH 6012E
TCT (Alcatel)	ONE TOUCH 6012D	California	ONE TOUCH 6012X
TCT (Alcatel)	ONE TOUCH 6012D	California	ONE TOUCH IDOL MINI
TCT (Alcatel)	ONE TOUCH 6012D	California	Orange Covo
TCT (Alcatel)	ONE TOUCH 6012D	California	Orange Hiro
TCT (Alcatel)	ONE TOUCH 6012X	California	ONE TOUCH 6012X
TCT (Alcatel)	ONE TOUCH 8020D	SCRIBEPRO	ONE TOUCH 8020D
TCT (Alcatel)	ONE TOUCH 983	ONE_TOUCH_983_gsm	ALCATEL_one_touch_983
TCT (Alcatel)	ONE TOUCH 983	ONE_TOUCH_983_gsm	ONE TOUCH 983
TCT (Alcatel)	ONE TOUCH 983	ONE_TOUCH_983_gsm	VALENCIA
TCT (Alcatel)	ONE TOUCH 983	one_touch_983_gsm	ALCATEL_one_touch_983
TCT (Alcatel)	ONE TOUCH C505C	ONE_TOUCH_C505C_cdma	ONE TOUCH C505C
TCT (Alcatel)	ONE TOUCH EVO7HD	E710	MTC 1078

Supported Devices

TCT (Alcatel)	ONE TOUCH EVO7HD	E710	ONE TOUCH E710
TCT (Alcatel)	ONE TOUCH EVO7HD	E710	ONE TOUCH EVO7HD
TCT (Alcatel)	ONE TOUCH EVO8HD	E720	ONE TOUCH EVO7HD
TCT (Alcatel)	ONE TOUCH EVO8HD	E720	ONE TOUCH EVO8HD
TCT (Alcatel)	ONE TOUCH SCRIBE 5	Scribe5_gsm	ALCATEL ONE TOUCH 8000A
TCT (Alcatel)	ONE TOUCH SCRIBE 5	Scribe5_gsm	ALCATEL ONE TOUCH 8000D
TCT (Alcatel)	ONE TOUCH SCRIBE 5	Scribe5_gsm	TCL Y710
TCT (Alcatel)	ONE TOUCH T10	GR-TB7	GR-TB7
TCT (Alcatel)	ONE TOUCH TAB 7	T011	ONE TOUCH TAB 7
TCT (Alcatel)	ONE TOUCH TAB 7	T011	TCL TAB 7
TCT (Alcatel)	ONE TOUCH TAB 7HD	T016	ONE TOUCH TAB 7HD
TCT (Alcatel)	ONE TOUCH TAB 8HD	T021	ONE TOUCH TAB 8HD
TCT (Alcatel)	ONE TOUCH Ultra 960c	Alltel	ONE_TOUCH_960C
TCT (Alcatel)	ONE TOUCH Ultra 960c	ONE_TOUCH_960C	ADR3010
TCT (Alcatel)	ONE TOUCH Ultra 960c	ONE_TOUCH_960C	ONE TOUCH 960C
TCT (Alcatel)	ONE TOUCH Ultra 960c	RadioShack	ADR3010
TCT (Alcatel)	ONE TOUCH Ultra 960c	nTelos	ONE_TOUCH_960C
TCT (Alcatel)	ONE TOUCH Ultra 960c	vulcan	ONE_TOUCH_960C
TCT (Alcatel)	ONE_TOUCH_P310A	POP7	ONE TOUCH P310A
TCT (Alcatel)	ONE_TOUCH_P310X	POP7	ALCATEL ONE TOUCH P310X
TCT (Alcatel)	ONT TOUCH 4015X	Yaris35_GSM	4016D
TCT (Alcatel)	ONT TOUCH 4015X	Yaris35_GSM	ONE TOUCH 4015A
TCT (Alcatel)	ONT TOUCH 4015X	Yaris35_GSM	ONE TOUCH 4015D
TCT (Alcatel)	ONT TOUCH 4015X	Yaris35_GSM	ONE TOUCH 4015N
TCT (Alcatel)	ONT TOUCH 4015X	Yaris35_GSM	ONE TOUCH 4015X
TCT (Alcatel)	ONT TOUCH 4015X	Yaris35_GSM	ONE TOUCH 4015X-orange
TCT (Alcatel)	ONT TOUCH 4015X	Yaris35_GSM	ONE TOUCH 4016A
TCT (Alcatel)	ONT TOUCH 4015X	Yaris35_GSM	Orange Yomi
TCT (Alcatel)	OT-990C	OT-990C_cdma	OT-990C
TCT (Alcatel)	OWN S4010	Telsa	OWN S4010

Supported Devices

TCT (Alcatel)	OWN S5010	DiabloHD	OWN S5010
TCT (Alcatel)	OWN_S4025	YARIS_55	OWN_S4025
TCT (Alcatel)	One Touch 890D	one_touch_890D_gsm	ALCATEL one touch 890D
TCT (Alcatel)	One Touch 906	one_touch_906_gsm	ALCATEL_one_touch_906Y
TCT (Alcatel)	One Touch 908	one_touch_908_gsm	ALCATEL ONE TOUCH 908
TCT (Alcatel)	One Touch 908	one_touch_908_gsm	ALCATEL_one_touch_908
TCT (Alcatel)	One Touch 908	one_touch_908_gsm	Alcatel_one_touch_908F_Orange
TCT (Alcatel)	One Touch 990	one_touch_990_gsm	ALCATEL ONE TOUCH 990
TCT (Alcatel)	One Touch 990	one_touch_990_gsm	ALCATEL one touch 990
TCT (Alcatel)	One Touch 990	one_touch_990_gsm	ALCATEL_one_touch_990
TCT (Alcatel)	One Touch 990	one_touch_990_gsm	Alcatel one touch 908F Orange
TCT (Alcatel)	One Touch 990	one_touch_990_gsm	Alcatel one touch 990 Orange
TCT (Alcatel)	One Touch 990	one_touch_990_gsm	Los Angeles
TCT (Alcatel)	One Touch 990	one_touch_990_gsm	TCL A990
TCT (Alcatel)	One Touch 990	one_touch_990_gsm	TCL ONE TOUCH 990
TCT (Alcatel)	One Touch 990	one_touch_990_gsm	Telenor_OneTouch
TCT (Alcatel)	One Touch 990	one_touch_990_gsm	Vodafone 958
TCT (Alcatel)	One Touch 990A	one_touch_990A_gsm	ALCATEL_one_touch_990A
TCT (Alcatel)	One Touch 990S	one_touch_990S_gsm	ALCATEL_one_touch_990S
TCT (Alcatel)	One Touch 990S	one_touch_990S_gsm	Alcatel one touch 990S
TCT (Alcatel)	Orange_Sego	Orange_Sego	Orange_Sego
TCT (Alcatel)	P330X	Pop7_LTE	P330X
TCT (Alcatel)	P330X_orange	Pop7_LTE	P330X_orange
TCT (Alcatel)	P350X	POP8_LTE	P350X
TCT (Alcatel)	P688L	Rio5C	TCL-P688L
TCT (Alcatel)	P688L	Rio5C	TOM007
TCT (Alcatel)	PIXI3(3.5)	PIXI3_35	4009D
TCT (Alcatel)	PIXI3(3.5)	PIXI3_35	4009E
TCT (Alcatel)	POP 2	Alto45	5042A
TCT (Alcatel)	POP 2	Alto45	5042D

Supported Devices

TCT (Alcatel)	POP 2	Alto45	5042X
TCT (Alcatel)	POP S3	RIO4G_TF	ALCATEL A845L
TCT (Alcatel)	POP S3	RIO_4G	5050A
TCT (Alcatel)	POP S3	RIO_4G	5050S
TCT (Alcatel)	POP S3	RIO_4G	5050X
TCT (Alcatel)	POP S3	RIO_4G	5050Y
TCT (Alcatel)	POP S3	RIO_4G	ALCATEL ONETOUCH 5050X
TCT (Alcatel)	POP S3	RIO_4G	Siru
TCT (Alcatel)	POP S9	RIO6_lte	7050Y
TCT (Alcatel)	POP S9	RIO6_lte	ALCATEL A995L
TCT (Alcatel)	POP S9	RIO6_lte	STARXTREM II
TCT (Alcatel)	POP S9	RIO6_lte	Smartphone Android by SFR STARXTREM II
TCT (Alcatel)	PandA_m14	YARIS_55	PandA_m14
TCT (Alcatel)	Pixo 7	PIXO7	I211
TCT (Alcatel)	Pixo 7	PIXO7	I212
TCT (Alcatel)	Pixo 7	PIXO7	I213
TCT (Alcatel)	SOUL 4.5	SOUL45_GSM	5038X
TCT (Alcatel)	Smartphone Android by SFR STARADDICT II	one_touch_996_gsm	Smartphone Android by SFR STARADDICT II
TCT (Alcatel)	Smartphone Android by SFR STARADDICT II	one_touch_996_gsm	Smartphone_Android_by_SFR_STARADDICT_II
TCT (Alcatel)	Soul 3.5	SOUL35	4018A
TCT (Alcatel)	Soul 3.5	SOUL35	4018D
TCT (Alcatel)	Soul 3.5	SOUL35	4018E
TCT (Alcatel)	Soul 3.5	SOUL35	4018F
TCT (Alcatel)	Soul 3.5	SOUL35	4018M
TCT (Alcatel)	Soul 3.5	SOUL35	4018X
TCT (Alcatel)	Soul 3.5	SOUL35	T4018
TCT (Alcatel)	Soul 4	SOUL4	4035A
TCT (Alcatel)	Soul 4	SOUL4	4035D
TCT (Alcatel)	Soul 4	SOUL4	4035X

Supported Devices

TCT (Alcatel)	Soul 4	SOUL4	4035X_Orange
TCT (Alcatel)	Soul 4	SOUL4	4035Y
TCT (Alcatel)	Soul 4	SOUL4	4036E
TCT (Alcatel)	Soul 4.5	SOUL45_GSM	5038A
TCT (Alcatel)	Soul 4.5	SOUL45_GSM	5038E
TCT (Alcatel)	Soul 4.5	SOUL45_GSM	D45
TCT (Alcatel)	T10	T10	one touch T10
TCT (Alcatel)	TAB 7 DUAL CORE	T015	TAB 7 DUAL CORE
TCT (Alcatel)	TAB 7 DUAL CORE	T017	TAB 7 DUAL CORE
TCT (Alcatel)	TCL 736L	Rio5C	TCL-J736L
TCT (Alcatel)	TCL 738M	Rio5C	TCL J738M
TCT (Alcatel)	TCL A506	TCL_A506	TCL A506
TCT (Alcatel)	TCL A865	TCL_A865	TCL A865
TCT (Alcatel)	TCL A988	one_touch_993D_gsm	ALCATEL ONE TOUCH 993D
TCT (Alcatel)	TCL A988	one_touch_993_gsm	ALCATEL ONE TOUCH 993
TCT (Alcatel)	TCL A988	one_touch_993_gsm	MTC_968
TCT (Alcatel)	TCL C995	TCL_C995_cdma	TCL C995
TCT (Alcatel)	TCL D35	SOUL35	TCL D35
TCT (Alcatel)	TCL D40 DUAL	D40	TCL D40 DUAL
TCT (Alcatel)	TCL D662	TCL_D662_cdma	TCL D662
TCT (Alcatel)	TCL D706	EG502	TCL D706
TCT (Alcatel)	TCL D768	EG501	TCL D768
TCT (Alcatel)	TCL D920	TCL_D920	TCL D920
TCT (Alcatel)	TCL D920	TCL_D920	TCL-D920
TCT (Alcatel)	TCL DL750	SOUL4	DL750
TCT (Alcatel)	TCL H900M	HERO2	TCL H900M
TCT (Alcatel)	TCL J210C	TCL_J210C_cdma	TCL J210C
TCT (Alcatel)	TCL J210C	TCL_J210C_cdma	TCL-J210C
TCT (Alcatel)	TCL J300	Megane	ALCATEL ONE TOUCH 5020T
TCT (Alcatel)	TCL J300	Megane	TCL J300

Supported Devices

TCT (Alcatel)	TCL J310	MeganeB	TCL J310
TCT (Alcatel)	TCL J320	Iris	TCL J320
TCT (Alcatel)	TCL J320C	Daniel_lite	TCL J320C
TCT (Alcatel)	TCL J320T	IrisTD	TCL J320T
TCT (Alcatel)	TCL J600T	Iris2TD	TCL J600T
TCT (Alcatel)	TCL J620	md501	TCL J620
TCT (Alcatel)	TCL J630	Iris2PlusUMTS	J630
TCT (Alcatel)	TCL J630T	Iris2PlusTD	TCL J630T
TCT (Alcatel)	TCL J720	YARISXL	TCL J720
TCT (Alcatel)	TCL J726T	YARISXL	TCL J726T
TCT (Alcatel)	TCL J900	Camry2	TCL J900
TCT (Alcatel)	TCL J900T	Camry2_TD	TCL J900T
TCT (Alcatel)	TCL J920	YARIS_55	TCL J920
TCT (Alcatel)	TCL J926T	YARIS_55	TCL J926T
TCT (Alcatel)	TCL J928	Prius	TCL J928
TCT (Alcatel)	TCL J929L	Diablo_LTE	TCL-J929L
TCT (Alcatel)	TCL J938M	RIO55_LTE	TCL J938M
TCT (Alcatel)	TCL M2M	CROSS2	TCL M2M
TCT (Alcatel)	TCL M2U	CROSS2	TCL M2U
TCT (Alcatel)	TCL P301C	Cooper_40	TCL P301C
TCT (Alcatel)	TCL P301M	TCL_P301M	TCL P301M
TCT (Alcatel)	TCL P331M	TCL_P331M	TCL P331M
TCT (Alcatel)	TCL P360W	Focus5_CU	TCL P360W
TCT (Alcatel)	TCL P606	Rav4_GSM	TCL P600
TCT (Alcatel)	TCL P606	Rav4_GSM	TCL P606
TCT (Alcatel)	TCL P606	Rav4_GSM	TCL P606T
TCT (Alcatel)	TCL P631M	Civic_X	TCL P631M
TCT (Alcatel)	TCL P728M	CROSS_LTE	TCL P728M
TCT (Alcatel)	TCL S300T	TCLS300T	TCL S300T
TCT (Alcatel)	TCL S500	TCL_S500_GSM	TCL S500

Supported Devices

TCT (Alcatel)	TCL S520	TCL_S520_GSM	TCL S520
TCT (Alcatel)	TCL S530T	California	TCL S530T
TCT (Alcatel)	TCL S600	TCL_S600_GSM	TCL S600
TCT (Alcatel)	TCL S700	TCLS700	TCL S700
TCT (Alcatel)	TCL S700T	TCLS700T	TCL S700T
TCT (Alcatel)	TCL S720	Cross55	TCL S720
TCT (Alcatel)	TCL S720T	Cross55	TCL S720T
TCT (Alcatel)	TCL S725T	Cross55_TD_Plus	TCL_S725T
TCT (Alcatel)	TCL S820	Diablo	TCL S820
TCT (Alcatel)	TCL S850	DiabloHD	TCL S850
TCT (Alcatel)	TCL S860	Alpha	TCL S860
TCT (Alcatel)	TCL S900	S900	TCL S900
TCT (Alcatel)	TCL S950	DIABLOX	TCL S950
TCT (Alcatel)	TCL S950T	DIABLOX	TCL S950T
TCT (Alcatel)	TCL S960	DIABLOXPLUS	TCL S960
TCT (Alcatel)	TCL S960T	DIABLOXPLUS	TCL S960T
TCT (Alcatel)	TCL Y900	Scribe5HD_GSM	TCL Y900
TCT (Alcatel)	TCL Y910	SCRIBEPRO	TCL Y910
TCT (Alcatel)	TCL Y910T	SCRIBEPRO	TCL Y910T
TCT (Alcatel)	TCL i718M	EOS2	TCL i718M
TCT (Alcatel)	TCL-J320D	Daniel_lite_2S	TCL-J320D
TCT (Alcatel)	TCL-J900C	TCL_J900C	TCL-J900C
TCT (Alcatel)	TCL-P306C	Ford50	TCL-P306C
TCT (Alcatel)	TCL_6110A	Telsa	TCL 6110A
TCT (Alcatel)	TCL_6110A	Telsa	TCL_6110A
TCT (Alcatel)	TCL_J636D	msm7627a_a5y_j636d	TCL_J636D
TCT (Alcatel)	TCL_J706T	Focus_L	TCL_J706T
TCT (Alcatel)	TCL_U980	TCL_U980	TCL_U980
TCT (Alcatel)	Telenor_Smart	one_touch_985_gsm	Telenor_Smart
TCT (Alcatel)	VF 860	Vodafone_Smart_II_gsm	Vodafone Smart II

Supported Devices

TCT (Alcatel)	VF685	VF685	VF685
TCT (Alcatel)	Vodafone 785	Vodafone_785	MTC 982
TCT (Alcatel)	Vodafone 785	Vodafone_785	Vodafone 785
TCT (Alcatel)	Vodafone 861	one_touch_922_gsm	ALCATEL ONE TOUCH 922
TCT (Alcatel)	Vodafone 861	one_touch_922_gsm	Vodafone 861
TCT (Alcatel)	Vodafone 985N	Vodafone985N	Vodafone 985N
TCT (Alcatel)	Vodafone Smart III	Vodafone_975	Vodafone 975
TCT (Alcatel)	Vodafone Smart III (with NFC)	Vodafone_975N	Vodafone 975N
TCT (Alcatel)	Vodafone Smart Tab 4	Vodafone_Smart_Tab_4	Vodafone Smart Tab 4
TCT (Alcatel)	Vodafone_Smart_Tab_3G	Vodafone_Smart_Tab_3G	Vodafone Smart Tab 3G
TCT (Alcatel)	Vodafone_Smart_Tab_4G	Vodafone_Smart_Tab_4G	Vodafone Smart Tab 4G
TCT (Alcatel)	X35E	X35E	X35E
TCT (Alcatel)	X50D	X50D	X50D
TCT (Alcatel)	freebit Panda_m14	YARIS_55	freebit Panda_m14
TCT (Alcatel)	one touch 995C+	one_touch_995C_cdma	one touch 995C+
TCT (Alcatel)	one touch D920	one_touch_D920	ALCATEL one touch D920
TCT (Alcatel)	one touch D920	one_touch_D920	one touch D920
TCT (Alcatel)	one_touch_D920_ALIQ	one_touch_D920	one touch D920
TCT (Alcatel)	tmn smarta8	ONE_TOUCH_991D_gsm	moche smart a8
TCT (Alcatel)	tmn smarta8	ONE_TOUCH_991D_gsm	tmn smart a8
THTF	TSINGHUA TONGFANG CO., LTD.	TR10CD1_3	TR10CD1
TMAX	TMAX TM9S775	MID908A-K	TM9S775
TPS	SMART Sprint	SMARTSprint	SMART Sprint
TSUNAMi	Tablet Tsunami TSTA080D1	MG080D1T	MG080D1T
TUNTUN English	DREAM PAD	delight	ITP-R408W
TUPAD	TU7_58212_18222	TU7_58212	TU7_18222
Taiwan Mobile	Amazing X3	TX3	Amazing X3
TaiwanMobile	A6S	A6S	A6S
TaiwanMobile	Amazing A8	D78	Amazing A8

Supported Devices

TaiwanMobile	TaiwanMobile A5C	A5C	A5C
TaiwanMobile	TaiwanMobile A6S	A6S	A6S
Technicolor		omap4_WT3	T-Hub2
Techno	H5S	up09_tecno_h5s	TECNO H5S
Techno	H7S	qp16_tecno_h7s	H7S
Techno	M3	up11_tecno_m3s	TECNO M3S
Techno	P5	up08_tecno_p5s	TECNO P5S
Techno	TECNO-A7S	TECNO-A7S	TECNO-A7S
Tecno	RACE Blot2	Infinix_X454	Infinix X454
Tecno	TECNO-M6S	g335_b1	TECNO-M6S
Tele2	Tele2fon V4	Tele2fon_v4	Tele2fon v4
Tele2	Tele2fon V5	Tele2fon_v5	Tele2fon v5
Teleepoch		MaxBravo	PMI920
Teleepoch		U670C	U670C
Teleepoch		chaser-921	Chaser
Teleepoch	Essentiel B SmartTab 1002	T9660R	SmartTAB 1002
Teleepoch	U675	U675	U675
Teleepoch	UMX U680C	U680C	U680C
Telefunken	VP73_Telefunken	Telefunken	VP73_Telefunken
Tesco	Hudl 2	HTF8A4	Hudl 2
Tesco	Hudl HT7S3	ht7s3	Hudl HT7S3
Tesco	Hudl HT7S3	ht7s3	hudl ht7s3
Tesco	W032I_C3	w032i_c3	W032I_C3
Tesco	hudl 2	HTF8A4	Hudl 2
Thomson	THOMSON PRIMO7 Tablet	PRIMO7	PRIMO7
Thomson	THOMSON PRIMO8 Tablet	AMLMY8306P	PRIMO8
Thomson	TLink 455	TLINK455	TLINK455
Tinhvan	TA80TA1	TA80TA1_1	TA80TA1
Tonino Lamborghini	Antares	TL66	TL66
Tonino Lamborghini	Antares	TL_Antares	Antares

Supported Devices

Toshiba		WDPF-703TI	Hikari-iFrame/WDPF-703TI
Toshiba		tosebook01	DB50
Toshiba		tostab05	AT200
Toshiba		tostabg1	LT170
Toshiba	A204	tos14ast10	A204
Toshiba	AT10-A/AT15-A (Japan: AT503)	tostab12BL	AT10-A
Toshiba	AT10-A/AT15-A (Japan: AT503)	tostab12BL	AT502
Toshiba	AT10-A/AT15-A (Japan: AT503)	tostab12BL	AT503
Toshiba	AT10-A/AT15-A (Japan: AT503)	tostab12BL	AT503_HEMS
Toshiba	AT100	tostab03	AT100
Toshiba	AT100	tostab03	Tostab03
Toshiba	AT10LE-A/AT15LE-A/AT10PE-A/AT15PE-A (Japan: AT703)	tostab12BA	AT10LE-A
Toshiba	AT10LE-A/AT15LE-A/AT10PE-A/AT15PE-A (Japan: AT703)	tostab12BA	AT10PE-A
Toshiba	AT10LE-A/AT15LE-A/AT10PE-A/AT15PE-A (Japan: AT703)	tostab12BA	AT702
Toshiba	AT10LE-A/AT15LE-A/AT10PE-A/AT15PE-A (Japan: AT703)	tostab12BA	AT703
Toshiba	AT400	tostab12AL	AT300SE
Toshiba	AT400	tostab12AL	AT400
Toshiba	AT7-A	tost7t	AT374
Toshiba	AT7-A	tost7t	AT7-A
Toshiba	AT7-B	tos13t7gt	AT374
Toshiba	AT7-B	tos13t7gt	AT7-B
Toshiba	AT7-C	tos14riy20	A17
Toshiba	AT7-C	tos14riy20	AT7-C
Toshiba	JP:REGZA Tablet AT570 Others:TOSHIBA AT270	tostab11BS	AT270
Toshiba	JP:REGZA Tablet AT570 Others:TOSHIBA AT270	tostab11BS	AT470
Toshiba	JP:REGZA Tablet AT570 Others:TOSHIBA AT270	tostab11BS	AT570

Supported Devices

Toshiba	JPN:REGZA Tablet AT500 Other countries:TOSHIBA AT300	tostab11BA	AT300
Toshiba	JPN:REGZA Tablet AT500 Other countries:TOSHIBA AT300	tostab11BA	AT500
Toshiba	JPN:REGZA Tablet AT500 Other countries:TOSHIBA AT300	tostab11BA	AT500a
Toshiba	JPN:REGZA Tablet AT830 Other countries:TOSHIBA AT330	tostab11BT	AT330
Toshiba	JPN:REGZA Tablet AT830 Other countries:TOSHIBA AT330	tostab11BT	AT830
Toshiba	L4300	I4300	I4300
Toshiba	L5450/L5400	tostv14rtk1	I5400
Toshiba	L5450/L5400	tostv14rtk1	I5450
Toshiba	L5450/L5400	tostv14rtk2	I5400
Toshiba	L5450/L5400	tostv14rtk2	I5450
Toshiba	L5450C	I5450	I3453
Toshiba	L5450C	I5450	I5450
Toshiba	L9450	I9450	I9450
Toshiba	TOSHIBA STB10	TOSPASB	TOSPASB
Toshiba	Thrive 7	tostab04	AT1S0
Toshiba	tt300/tt301/tt302	Mozart	Mozart
Toughshield	R200	R200	R200
Toughshield	T700_TABLET	T700_TABLET	T700
TrekStor	TrekStor torino tab 7	tolino7	tolino tab 7
TrekStor	TrekStor torino tab 8.9	tolino89	tolino tab 8.9
Trekstor	SurfTab ST70204-3	TREKM7100KLD	SurfTab ST70204-3
Trekstor	SurfTab xintron i 7.0	st70408_4_coho	st70408_4_coho
Trekstor	tolino tab 8	tolino8	tolino tab 8
Trio	TRIO-7.85	astar-y3	TRIO-7.85
Trio	Trio 7.85 vQ	Trio-785-vQ	Trio 7.85 vQ
Trio	Trio AXS 3G	Trio_AXS_3G	Trio AXS 3G
Trio	Trio MINI	Trio-MINI	Trio MINI

Supported Devices

Trio	Trio MST711	nuclear-MST711	MST711
Trio	Trio-Stealth G4 7	Trio-Stealth-G4-7	Trio-Stealth-G4-7
Trio	Trio-Stealth-G4-101	Trio-Stealth-G4-101	Trio-Stealth G4 10.1
Trio	Trio-Stealth-G4-7.85	Trio-Stealth-G4-785	Trio-Stealth-G4-7.85
Tunisie Telecom	Star Trail by TT	startrail3_tt	StarTrail TT
Turk Telekom	Turk Telekom E4	722T	E4
U606	Hisense	U606	STARSHINE III
U688	Hisense	U688	HS-U688
VENSTAR	VENSTAR2050	VENSTAR2050	VENSTAR2050
VF	Vodafone Smart mini	Vodafone_875	Vodafone 875
VIBE Z	K910	kitonw	Lenovo K910
VSN	V.35	up11_h1_vsn	V.35
Venturer	i7	RCT6773W22	i7
Verizon Wireless	Ellipsis 7	QMV7A	QMV7A
Verizon Wireless	Ellipsis 7	QMV7A	QMV7B
Verizon Wireless	Ellipsis 7 (QMV7A)	QMV7A	QMV7A
Verizon Wireless	Ellipsis 7 (QMV7B)	QMV7A	QMV7B
Verizon Wireless	Ellipsis 8	QTAQZ3	QTAQZ3
Verssed	FW8977-ED	FW8977-ED	FW8977-ED
Vertu	Aster	alexa	Aster
Vertu	Constellation V	gambit	Constellation V
Vertu	Signature Touch	odin	Signature Touch
Vertu	VERTU Ti	hermione	VERTU Ti
Vestel	VP100+	ephesus	10.1Myros
Vestel	VP100+	ephesus	VP100+
Vestel	VP73	wing-ibt	VP73
Vestel	VP73	wing-ibt	VP73_Hyundai
Vestel	VP73	wing-ibt	VP73_Myros
Vestel	VP73	wing-ibt	VP73_Vox
Vestel	VP73	wing-ibt	VP73_le

Supported Devices

Vestel	VP74	wifionly-gms	VP74
Vestel	VP74	wifionly-gms	VP74-Celcus
Vestel	VP74	wifionly-gms	VP74-Finlux
Vestel	VP74	wifionly-gms	VP74-Orava
Vestel	VP74	wifionly-gms	VP74-Telefunken
Vestel	VP74	wifionly-gms	VP74-Vox
Vestel	VSP145M	VSP145M	VSP145M
Vestel	VSP250g	VSP250g	VSP250g
Vestel	VSP250s	VSP250s	VSP250s
Vestel	VSP355g	g55	VSP355g
Vestel	VSP355s	s55	VSP355s
ViewSonic		v350	ViewSonic-V350
ViewSonic		viewpad4	ViewSonic-ViewPad4
ViewSonic		viewpad7	ViewPad7
ViewSonic		viewpad7x	ViewPad7X
ViewSonic		viewpad7x	ViewPad7x
ViewSonic	VSD221	VSD221	VSD221
ViewSonic	VSD231	VSD231-VSA	VSD231
ViewSonic	VSD241 Smart Display	VSD241	VSD241
Vizio	StreamPlayer	VAP430	VAP430
Vizio, Inc.	VTAB1008	VTAB1008	VTAB1008
Vulcan	TA10TA2	TA10TA2_1	TA10TA2
Vulcan	TA71CA1	TA71CA1	TA71CA1
Vulcan	TA71CA2	TA71CA2_1	TA71CA2
W.e.	WETAB700DG	WETAB700DG	WETAB700DG
W.e.	WeTab1004B	WeTab1004B	WeTab1004B
WACOM	Cintiq Companion Hybrid 13HD	CintiqCompanionHybrid13HD	Cintiq Companion Hybrid 13HD
WIKO	Barry	s7811	BARRY
WIKO	CINK SLIM 2	s8074	CINK SLIM 2
WIKO	DARKFULL	s9311	DARKFULL

Supported Devices

WIKO	DARKFULL	s9311	Dream
WIKO	DARKNIGHT	s9203	DARKNIGHT
WIKO	DARKNIGHT	s9203	X-tremer
WIKO	HIGHWAY	s9320	HIGHWAY
WIKO	IGGY	s7521	Cynus F4
WIKO	IGGY	s7521	Golf
WIKO	IGGY	s7521	IGGY
WeTek	Play	Play	Play
Welgate	WA-U420D	WA-U420D	WA-U420D
Wenu	Kate	Wenu	Kate
Wiko	BLOOM	s4700	BLOOM
Wiko	GETAWAY	s8812	GETAWAY
Wiko	GOA	s3511	GOA
Wiko	HIGHWAY SIGNS	s4750	HIGHWAY SIGNS
Wiko	KITE	l4020	KITE
Wiko	LENNY	s5201ap	LENNY
Wiko	RAINBOW	s5501	RAINBOW
Wiko	RAINBOW 4G	l5503	RAINBOW 4G
Wiko	SLIDE	s8321	SLIDE
Wiko	SUNSET	s4011	SUNSET
Wintec	T730	T730	Clear
Wintec	T730	T730	T730
Wintec	T750	T750	Clear
Wistron	W1011A	w1011a	W1011A
Xiaomi	China	HM2013023	2013023
Xiaomi	China	braveheart	MiTV
Xiaomi	China	casablanca	MiBOX1S
Xiaomi	HM 1SC	armani	HM 1AC
Xiaomi	HM 1SC	armani	HM 1SC
Xiaomi	HM 1SC	armani	HM 1SW

Supported Devices

Xiaomi	HM 1SLTETD	HM2014501	2014501
Xiaomi	HM 1STD	HM2014011	2014011
Xiaomi	HM 2LTE-CMCC	HM2014813	2014813
Xiaomi	HM 2LTE-CT	HM2014812	2014812
Xiaomi	HM 2LTE-CU	HM2014811	2014811
Xiaomi	HM NOTE 1LTETD	dior	HM NOTE 1LTE
Xiaomi	HM NOTE 1LTETD	dior	HM NOTE 1LTETD
Xiaomi	HM NOTE 1LTETD	dior	HM NOTE 1LTEW
Xiaomi	HM NOTE 1TD	lcsh92_wet_tdd	HM NOTE 1TD
Xiaomi	HM NOTE 1W	lcsh92_wet_jb9	HM NOTE 1W
Xiaomi	Hong Mi	HM2013022	2013022
Xiaomi	MI 2A	taurus	MI 2A
Xiaomi	MI 2S	aries	MI 2
Xiaomi	MI 2S	aries	MI 2S
Xiaomi	MI 3W	cancro	MI 3W
Xiaomi	MI 4LTE	cancro	MI 4LTE
Xiaomi	MI 4LTE-CT	cancro	MI 4LTE
Xiaomi	MI PAD	mocha	MI PAD
Xiaomi	Mi 3	pisces	MI 3
Xiaomi	MiBOX2	dredd	MiBOX2
Xiaomi	MiTV2	entrapment	MiTV2
Xplore_Technologies	RangerX	iX101T1	iX101T1
Xplore_Technologies	RangerX	iX101T1_2G	iX101T1-2G
Yota Devices	YotaPhone2	yotaphone2	YD201
YotaPhone	YotaPhone C9660	yotaphone	C9660
ZTE		BUL_P726G	ZTE-RACER
ZTE		D930	D930
ZTE		Grand-S	ZTE Grand S
ZTE		N720	N720
ZTE		N720_Micromax	Micromax A60

Supported Devices

ZTE		N721	N721
ZTE		N721	ZTE-U N721
ZTE		N721	ZTE_U N721
ZTE		N8010_CT	ZXY-ZTE_N8010
ZTE		N8010_CT_BL	ZXY-ZTE_N8010
ZTE		N8300_CT	ZXY-ZTE N8300
ZTE		NX501	NX501
ZTE		P117A11	ZTE U807
ZTE		P117A13	ZTE U807N
ZTE		P117A20qHD	ZTE U817
ZTE		P117A30	ZTE U935
ZTE		P117T21	ZTE U960E
ZTE		P188T10	ZTE U956
ZTE		P188T20	ZTE U819
ZTE		P253A20	ZTE V768
ZTE		P722G	ZTE-U X876
ZTE		P726CU	ZTE-U X850
ZTE		P726G	ZTE-LINK
ZTE		P726G	ZTE-RACER
ZTE		P726G	ZTE-WAVE
ZTE		P726N	soft stone
ZTE		P726N	soft-stone
ZTE		P726VV	ZTE-U X850
ZTE		P727A	VF945
ZTE		P729B	Orange Tactile internet 2
ZTE		P729C	ZTE-BLADE
ZTE		P810A10	ZTE U880s2
ZTE		P810A20	ZTE U887
ZTE		P810T01	ZTE U791
ZTE		P810T01	ZTE U791(OPEN)

Supported Devices

ZTE		P810T02	ZTE U793
ZTE		P825T10	ZTE U808
ZTE		P825T10	ZTE U808(OPEN)
ZTE		QB7211	QB7211
ZTE		QB7211	STARTEXT II
ZTE		T77	T77
ZTE		T9	ZTE-T T9
ZTE		TWM_P726G	Taiwan Mobile T2
ZTE		U788	ZTE U788
ZTE		U790	ZTE U790
ZTE		U795	ZTE U795
ZTE		U805	ZTE-T U805
ZTE		U812	ZTE-T U812
ZTE		U830	ZTE-T U830
ZTE		U880E	ZTE U880E
ZTE		U880F1	ZTE U880F1
ZTE		U880s	ZTE U880s
ZTE		U885	ZTE U885
ZTE		U930HD	ZTE U930HD
ZTE		U960s	ZTE-T U960s
ZTE		U960s2	ZTE U960s2
ZTE		U960s3	ZTE U960s3
ZTE		V6020_Claro	V6020_Claro
ZTE		V66	V66
ZTE		V68	V68
ZTE		V71A	STARTAB
ZTE		V71A	V71B
ZTE		V768	ZTE V768
ZTE		V8100_Z55	V8100_Z55
ZTE		V8200_EE_UK	V8200_EE_UK

Supported Devices

ZTE		V8200_OSK	V8200-Memphis-orange-Slovakia
ZTE		V8300_Z39	V8300_Z39
ZTE		V857	ZTE-U V857
ZTE		V875m	ZTE-U V875m
ZTE		X500	X500
ZTE		X500	X500_USA_General
ZTE		X500MMB	ZTE-C X500
ZTE		ZTE-Grand-S	ZTE Grand S
ZTE		ZTE-N5	ZTE N5
ZTE		ZTE-N807	ZTE N807
ZTE		ZTE-N880F	ZTE N880F
ZTE		ZTE-N881E	ZTE N881E
ZTE		ZTE-N881F	ZTE N881F
ZTE		ZTE-N980	ZTE N980
ZTE		ZTE-N988	ZTE N988
ZTE		ZTE-U-V889F	ZTE-U V889F
ZTE		ZTE-V72A	V72A
ZTE		ZTE-V889F	ZTE V889F
ZTE		ZTE-V955	ZTE V955
ZTE		ZTE-V956	ZTE V956
ZTE		ZTE-V988	ZTE Grand S
ZTE		ZTE-V988	ZTE V988
ZTE		amigo	Android Edition Starnaute
ZTE		arthur	N860
ZTE		atlas40	Acqua
ZTE		atlas40	BLADE III
ZTE		atlas40	MEDION LIFE P4012
ZTE		atlas40	N880E
ZTE		atlas40	ZTE G882
ZTE		atlas40	ZTE N880E

Supported Devices

ZTE		atlas40	ZTE N881D
ZTE		atlas40	ZTE N882E
ZTE		atlas40	ZTE R22
ZTE		atlas40	ZTE T22
ZTE		atlas40	ZTE V880E
ZTE		atlas40	ZTE V889D
ZTE		banana	ZTE-C N780
ZTE		blade	MegaFon SP-A5
ZTE		blade	V880
ZTE		blade	ZTE Libra
ZTE		blade	ZTE-BLADE
ZTE		blade2	ATLAS W
ZTE		blade2	BLADEII
ZTE		blade2	Blade S
ZTE		blade2	San Francisco II
ZTE		bladeplus	008Z
ZTE		bladeplus	V881
ZTE		bladeplus	ZTE V881
ZTE		bladeplus	ZTE-U V881
ZTE		cardhu	ZTE-T T98
ZTE		crane-zte7	K75
ZTE		dana	ZTE N970
ZTE		deepblue	ZTE N790
ZTE		deepblue	ZTE N790S
ZTE		enterprise	ZTE U5
ZTE		enterprise_HK	ZTE Grand Era
ZTE		enterprise_U950	ZTE U950
ZTE		enterprise_U985	ZTE U985
ZTE		enterprise_V985	ZTE V985
ZTE		frosty	ZTE T82

Supported Devices

ZTE		hct77_ics2	V865M
ZTE		hope	N855D
ZTE		hope	N855D_PERFECTUM
ZTE		hope	N855D_YM
ZTE		hope	ZTE N855
ZTE		hope	ZTE N855D
ZTE		hope	ZTE N855D+
ZTE		iliamna	ZTE T81
ZTE		joe	V871
ZTE		joe	Vodafone 945
ZTE		kiska	ZTE V9800
ZTE		mooncake2	MTS-SP102
ZTE		mooncake2	Mtag 281
ZTE		mooncake2	ZTE N660
ZTE		msm7627a	ZTE N880F
ZTE		msm7627a	ZTE V889F
ZTE		msm7627a	ZTE-U V889F
ZTE		msm7630_zteu960	ZTE U960D
ZTE		msm7630_zteu960	ZTE-T U960
ZTE		nice	A21plus
ZTE		nice	ICE
ZTE		nice	KIS II
ZTE		nice	Orange Zali
ZTE		nice	Turkcell Maxi Plus 5
ZTE		nice	V880S
ZTE		nice	ZTE Kis Pro
ZTE		okmok	ZTE V9500
ZTE		p173a10	ZTE-U V760
ZTE		r750	ZTE-C R750
ZTE		racer2	ARIZONA

Supported Devices

ZTE		racer2	Kyivstar Shine
ZTE		racer2	RACERII
ZTE		racer2	RacerII
ZTE		racer2	Turkcell T11
ZTE		racer2	ZTE-U V859
ZTE		roamer	ZTE Roamer
ZTE		roamer	ZTE roamer
ZTE		roamer	ZTE-C N760
ZTE		roamer2	Dubai
ZTE		roamer2	Dublin
ZTE		roamer2	N788_BASHA
ZTE		roamer2	Orange Dublin
ZTE		roamer2	V788D
ZTE		roamer2	ZTE N788
ZTE		roamer2	ZTE N789
ZTE		roamer2	ZTE V788D
ZTE		roundtop	ZTE V9800
ZTE		sailboat	ZTE V875
ZTE		sean	N850
ZTE		skate	KPN Smart 200
ZTE		skate	MEDION LIFE P4310
ZTE		skate	Monte Carlo
ZTE		skate	Optimus Monte Carlo
ZTE		skate	Orange Monte Carlo
ZTE		skate	ZTE N960
ZTE		skate	ZTE Skate
ZTE		skate	ZTE V960
ZTE		skate	ZTE-SKATE
ZTE		skate	ZTE-Skate
ZTE		skate	ZTE-U V960

Supported Devices

ZTE		skateplus	Skate4.3 H
ZTE		turies	Android Edition StarText
ZTE		turies	Vodafone Smart Chat
ZTE		turies	ZTE-Tureis
ZTE		v9plus	BASE Tab 7.1
ZTE		v9plus	Light Tab 2
ZTE		v9plus	Light Tab 2W
ZTE		v9plus	MegaFon V9+
ZTE		v9plus	TT102
ZTE		v9plus	Telenor Touch Pad
ZTE		v9plus	V9+
ZTE		v9plus	V9A
ZTE		v9plus	V9e+
ZTE		v9plus	ZTE V10
ZTE		v9plus	ZTE V9A
ZTE		ventana	ZTE U970
ZTE		ventana_U880F	ZTE U880F
ZTE		ventana_U930	ZTE U930
ZTE		warp2	N861
ZTE		whistler	STARADDICT II
ZTE		whistler	V961
ZTE		whistler	ZTE Grand X
ZTE		whistler	ZTE V970T
ZTE		whistler	ZTE-Mimosa X
ZTE		z788	ZTE U788+
ZTE		z795	ZTE U795+
ZTE		zte_v857	ZTE-U V857
ZTE	009Z	bladeplus	009Z
ZTE	009Z	bladeplus	ZTE V882
ZTE	009Z	bladeplus	ZTE V886J

Supported Devices

ZTE	A2	A2	A2
ZTE	Amazing A1	roamer2	Amazing A1
ZTE	Amazing P6	msm8226	Amazing P6
ZTE	Amazing X2	msm8226	Amazing X2
ZTE	Amazing p5_Lite	V77	Amazing p5_Lite
ZTE	Android edition by sfr STARADDICT	skate	Android edition by sfr STARADDICT
ZTE	Avea inTouch 2	atlas40	Avea inTouch 2
ZTE	Avea inTouch 4	msm8916_32	Avea inTouch 4
ZTE	Avea inTouch 4	msm8916_32	ZTE Blade V220
ZTE	BASE Lutea 2	skate	BASE Lutea 2
ZTE	BLADE III_IL	atlas40	BLADE III_IL
ZTE	Baker	ZTE-Baker	Baker
ZTE	Beeline E600	roamer2	Beeline E600
ZTE	Blade	blade	003Z
ZTE	Blade	blade	Android Edition StarTrail
ZTE	Blade	blade	BASE lutea
ZTE	Blade	blade	BLADE_N880
ZTE	Blade	blade	Beeline E400
ZTE	Blade	blade	Kyivstar Spark
ZTE	Blade	blade	MF8604
ZTE	Blade	blade	Movistar Prime
ZTE	Blade	blade	N880
ZTE	Blade	blade	Netphone 701
ZTE	Blade	blade	Optimus San Francisco
ZTE	Blade	blade	Orange San Francisco
ZTE	Blade	blade	Orange Tactile internet 2
ZTE	Blade	blade	RTK V8
ZTE	Blade	blade	San Francisco
ZTE	Blade	blade	V8502

Supported Devices

ZTE	Blade	blade	WayteQ Libra
ZTE	Blade	blade	XCD35
ZTE	Blade	blade	ZTE Libra
ZTE	Blade	blade	ZTE V880
ZTE	Blade	blade	ZTE-BLADE
ZTE	Blade	blade	ZTE-C N880S
ZTE	Blade	blade	ZTE-LIBRA
ZTE	Blade	blade	ZTE-Libra
ZTE	Blade	blade	ZTE-U V880
ZTE	Blade	blade	a5
ZTE	Blade Apex	coeus	Blade Apex
ZTE	Blade Apex2	msm8226	Blade Apex2
ZTE	Blade G LTE	oceanus	Blade G LTE
ZTE	Blade III	atlas40	Blade III
ZTE	Blade III	atlas40	Skate Pro
ZTE	Blade S	blade2	Blade S
ZTE	Bouygues Telecom Bs 351	nice	Bouygues Telecom Bs 351
ZTE	Bouygues Telecom Bs 402	P172G10	A4C
ZTE	Bouygues Telecom Bs 402	P172G10	Amazing A4C
ZTE	Bouygues Telecom Bs 402	P172G10	Bouygues Telecom Bs 402
ZTE	Bouygues Telecom Bs 402	P172G10	ZTE Blade Q Mini
ZTE	Cosmote Smart Share	nice	Cosmote Smart Share
ZTE	Cosmote Xplore	Cosmote	Cosmote Xplore
ZTE	Cosmote Xplore	Cosmote-Xplore	Cosmote Xplore
ZTE	Dialog Q143L	frosty	Dialog Q143L
ZTE	FT142D	msm8226	FT142D
ZTE	Grand Memo	prindle	Grand Memo
ZTE	Grand S Flex	iris	Grand S Flex
ZTE	Grand X	P175A20	Grand X
ZTE	Grand X	P175A20	Grand X(M)

Supported Devices

ZTE	Grand X	P175A20	ZTE Grand X Classic
ZTE	Grand X	P175A20	ZTE V970
ZTE	Grand X	P175A20	ZTE V970M
ZTE	Grand X	P175A20	ZTE-U V970M
ZTE	Grand X	P175A20	tmn smart a18
ZTE	Grand X In	mfld_pr2	Grand X In
ZTE	Grand X In	mfld_pr2	STARADDICT II Plus
ZTE	Grand X In	mfld_pr2	ZTE Grand X In
ZTE	Grand X Pro	P177A20	Blade Super
ZTE	Grand X Pro	P177A20	Grand X Pro
ZTE	Grand X Pro	P177A20	KPN Smart 300
ZTE	Infinity X^2 mini	msm8226	Infinity X^2 mini
ZTE	K97	K97	K97
ZTE	K97	K97	ZTE K97
ZTE	KIS	roamer2	KIS
ZTE	KIS PLUS	roamer2	KIS PLUS
ZTE	KPN Smart 400	msm8226	KPN Smart 400
ZTE	Karbonsn_A1	N721	Karbonsn_A1
ZTE	Kis T3	roamer2	Kis T3
ZTE	Leopard MF800	roamer2	Leopard MF800
ZTE	Light Tab 2	v9plus	Light Tab 2
ZTE	M8402	roamer2	M8402
ZTE	MEDION LIFE P4310	skate	MEDION LIFE P4310
ZTE	MEDION Smartphone LIFE E3501	roamer2	MEDION Smartphone LIFE E3501
ZTE	MF97A	MF97A	MF97A
ZTE	MF97W	MF97W	MF97W
ZTE	MS4A	kiska	MS4A
ZTE	MS4A	roundtop	MS4A
ZTE	Momodesign MD Droid	atlas40	Momodesign MD Droid

Supported Devices

ZTE	Movistar Express	QB7211	Movistar Express
ZTE	Movistar Motion	roamer2	Movistar Motion
ZTE	N720	N720	N720
ZTE	N720	N720	ZTE-U N720
ZTE	N720	N720	ZTE_U N720
ZTE	N762	roamer	N762
ZTE	N765_APT	N765	N765_APT
ZTE	N790	deepblue	N790
ZTE	N800	nex	N800
ZTE	N8000_USA_Cricket	N8000	N8000_USA_Cricket
ZTE	N8000_USA_RS	N8000	N8000_USA_RS
ZTE	N8000_WHITE_CKT	N8000	N8000_WHITE_CKT
ZTE	N8010_APT	N8010_APT	N8010_APT
ZTE	N810	fluid	N810
ZTE	N8300_Reliance	N8300_Reliance	N8300_Reliance
ZTE	N8303	roamer2	N8303
ZTE	N850	sean	N850
ZTE	N850L	seanplus	N850L
ZTE	N855D	hope	N855D
ZTE	N860	arthur	N860
ZTE	N860	arthur	Warp
ZTE	N861	warp2	N861
ZTE	N910	arthur4g	ZTE-N910
ZTE	N9100	hayes	N9100
ZTE	N9101	apollo	N9101
ZTE	N9130	speed	N9130
ZTE	N9180	N9180	N9180
ZTE	N918St	N918St	N918St
ZTE	N918St	N918St	ZTE N918St
ZTE	N9500	gordon	N9500

Supported Devices

ZTE	N9510	warplte	N9510
ZTE	N9515	warp4	N9515
ZTE	N9516	eridani	N9516
ZTE	N9520	stormer	N9520
ZTE	N958St	N958St	N958St
ZTE	N9810	quantum	N9810
ZTE	N986D	P188F10	N986+
ZTE	N986D	P188F10	N986D
ZTE	NE501J	NE501J	NE501J
ZTE	NE501J	NE501J	V5
ZTE	NE501J	NE501J	ZTE_V5
ZTE	NX402	NX40X	NX402
ZTE	NX403A	NX403A	NX403A
ZTE	NX404H	NX404H	NX404H
ZTE	NX405H	NX405H	NX405H
ZTE	NX406E	NX406E	NX406E
ZTE	NX40X	NX402	NX402
ZTE	NX40X_APT	NX40X	NX40X
ZTE	NX40X_APT	NX40X	NX40X_APT
ZTE	NX501	NX501	NX501
ZTE	NX501_APT	NX501	NX501_APT
ZTE	NX503A_Z4	NX503A_Z4	NX503A_Z4
ZTE	NX503J	NX503J	NX503J
ZTE	NX505J	NX505J	NX505J
ZTE	NX506J	NX506J	NX506J
ZTE	NX507J	NX507J	NX507H
ZTE	NX507J	NX507J	NX507J
ZTE	NX601J	NX601J	NX601J
ZTE	Optimus Barcelona	blade2	Optimus Barcelona
ZTE	Orange Hi 4G	Orange_Hi_4G	Orange Hi 4G

Supported Devices

ZTE	Orange Hi 4G	msm8226	Orange Hi 4G
ZTE	Orange Monte Carlo	skate	Orange Monte Carlo
ZTE	Orange Novi	oceanus	Orange Novi
ZTE	Orange Reyo	P172D10	Avea inTouch 3 Large
ZTE	Orange Reyo	P172D10	Blade Q Maxi
ZTE	Orange Reyo	P172D10	Orange Reyo
ZTE	Orange Reyo	P172D10	ZTE Blade Q Maxi
ZTE	Orange Rono	Vec4G	Orange Rono
ZTE	Orange Rono	msm8226	Orange Rono
ZTE	Orange Zali	nice	Orange Zali
ZTE	RACER III mini	roamer2	RACER III mini
ZTE	Racer	mooncake	Carl
ZTE	Racer	mooncake	MTC 916
ZTE	Racer	mooncake	MTS-SP100
ZTE	Racer	mooncake	Movistar Link
ZTE	Racer	mooncake	RTK D1
ZTE	Racer	mooncake	Racer
ZTE	Racer	mooncake	TaiWan Mobile T2
ZTE	Racer	mooncake	V8402
ZTE	Racer	mooncake	Vip Droid
ZTE	Racer	mooncake	XCD 28
ZTE	Racer	mooncake	ZTE X850
ZTE	Racer	mooncake	ZTE-C N600
ZTE	Racer	mooncake	ZTE-C N600+
ZTE	Racer	mooncake	ZTE-LINK
ZTE	Racer	mooncake	ZTE-RACER
ZTE	Racer	mooncake	ZTE-U V852
ZTE	Racer	mooncake	ZTE-U X850
ZTE	S8Q	MT8123	S8Q
ZTE	STARNAUTE II	V6600	STARNAUTE II

Supported Devices

ZTE	STARTRAIL 4	P172E10	Avea inTouch 3
ZTE	STARTRAIL 4	P172E10	STARTRAIL 4
ZTE	STARTRAIL 4	P172E10	ZTE Blade Q
ZTE	STARXTREM	prindle	STARXTREM
ZTE	Skate Pro	atlas40	Skate Pro
ZTE	SmartTab10	V11A	SmartTab10
ZTE	SmartTab7	V71A	SmartTab7
ZTE	Soshphone 4G	Vec4G	Soshphone 4G
ZTE	Soshphone 4G	msm8226	Soshphone 4G
ZTE	Spro 2	msm8974	MF97V
ZTE	T-Mobile Vivacity	blade2	T-Mobile Vivacity
ZTE	T3	skate	T3
ZTE	TQ150	QB7211	TQ150
ZTE	TURKCELL T40	TURKCELL-T40	TURKCELL T40
ZTE	TURKCELL T50	msm8226	TURKCELL T50
ZTE	TURKCELL T50	msm8226	TURKCELL TURBO T50
ZTE	Telenor Touch Plus	blade2	Telenor Touch Plus
ZTE	Turkcell Maxi Plus 5	nice	Turkcell Maxi Plus 5
ZTE	U880	U880	ZTE-T U880
ZTE	U9180	U9180	U9180
ZTE	U9180	U9180	ZTE U9180
ZTE	UZTE V790	roamer2	UZTE V790
ZTE	UZTE V817	ZTE-V956	UZTE V817
ZTE	Ultym 5.2	msm8916_32	Ultym 5.2
ZTE	V55	V55	V55
ZTE	V72C	v72c	V72C
ZTE	V72M	eos	V72M
ZTE	V8000_USA_Cricket	V8000	V8000_USA_Cricket
ZTE	V8110	V8110	V8110
ZTE	V8200plus	V8200plus	V8200plus

Supported Devices

ZTE	V8285	MT8382	V8285
ZTE	V8403	roamer2	V8403
ZTE	V8514	P821E10	V8514
ZTE	V865M	hct77_jb	V865M
ZTE	V9	v9	A100
ZTE	V9	v9	BASE Tab
ZTE	V9	v9	BLACK 03
ZTE	V9	v9	Beeline M2
ZTE	V9	v9	Light
ZTE	V9	v9	Light Tab
ZTE	V9	v9	MTC 1055
ZTE	V9	v9	One Pad
ZTE	V9	v9	RTK V9
ZTE	V9	v9	TO101
ZTE	V9	v9	TT101
ZTE	V9	v9	V9
ZTE	V9	v9	V9C
ZTE	V9	v9	V9c
ZTE	V9	v9	V9e
ZTE	V9	v9	myPad P2
ZTE	V9180	V9180	V9180
ZTE	V96A	V96A	V96A
ZTE	V9A	v9plus	Light Tab 2
ZTE	V9A	v9plus	V9A
ZTE	V9A	v9plus	ZTE V9A
ZTE	V9A	v9plus	my Pad P3
ZTE	V9A	v9plus	myPad P3
ZTE	V9S	V9S	V9S
ZTE	V9S	V9S	myPadP4
ZTE	Vip Racer III	atlas40	Vip Racer III

Supported Devices

ZTE	Vodafone Smart Chat	turies	Vodafone Smart Chat
ZTE	X500	X500	X500
ZTE	X501_USA_Cricket	X501	X501_USA_Cricket
ZTE	X501_USA_Cricket	X501	X501_USA_RS
ZTE	X501_USA_OM	X501	X501_USA_OM
ZTE	X9180	X9180	X9180
ZTE	Z660G	nice	Z660G
ZTE	Z665C	seanplus	Z665C
ZTE	Z667	demi	Z667
ZTE	Z667T	bonnie	Z667T
ZTE	Z730	ada	Z730
ZTE	Z740	metis	Z740
ZTE	Z740G	metis	Z740G
ZTE	Z750C	Z750C	Z750C
ZTE	Z752C	eros	Z752C
ZTE	Z753G	faerie	Z753G
ZTE	Z768G	Z768G	Z768G
ZTE	Z777	betty	Z777
ZTE	Z787	apus	Z787
ZTE	Z792	giant	Z792
ZTE	Z795G	ZTE-Z795G	Z795G
ZTE	Z796C	Z796C	Z796C
ZTE	Z797C	carol	Z797C
ZTE	Z826	herculis	Z826
ZTE	Z830	gruis	Z830
ZTE	Z930L	coeus	Z930L
ZTE	Z933	glaucus	Z933
ZTE	Z936L	gift	Z936L
ZTE	Z970	draconis	Z970
ZTE	Z980L	cygni	Z980L

Supported Devices

ZTE	Z987	cygni	Z987
ZTE	Z992	aviva	Z992
ZTE	Z993	aviva	Z993
ZTE	Z995	becky	Z995
ZTE	Z998	coeus	Z998
ZTE	ZTE A880	ZTE-A880	ZTE A880
ZTE	ZTE B790	roamer2	ZTE B790
ZTE	ZTE BLADE III	atlas40	Skate Pro
ZTE	ZTE BLADE III	atlas40	ZTE BLADE III
ZTE	ZTE BLADE III	atlas40	ZTE Blade III
ZTE	ZTE Blade Apex	oceanus	ZTE Blade Apex
ZTE	ZTE Blade Apex2	msm8226	ZTE Blade Apex2
ZTE	ZTE Blade C370	ZTE_Blade_C370	ZTE Blade C370
ZTE	ZTE Blade G	ZTE-Blade-G	ZTE Blade G
ZTE	ZTE Blade G LTE	coeus	ZTE Blade G LTE
ZTE	ZTE Blade G Lux	P172F10	Blade G Lux
ZTE	ZTE Blade G Lux	P172F10	DIGICEL DL800
ZTE	ZTE Blade G Lux	P172F10	Orange Tado
ZTE	ZTE Blade G Lux	P172F10	ZTE Blade G Lux
ZTE	ZTE Blade G Lux	P172F10	ZTE Kis3 max
ZTE	ZTE Blade G Lux	P172F10	ZTE V830W
ZTE	ZTE Blade HN	ZTE_Blade_HN	ZTE Blade HN
ZTE	ZTE Blade III	atlas40	ZTE Blade III
ZTE	ZTE Blade III Pro	Blade-III-Pro	ZTE Blade III Pro
ZTE	ZTE Blade L2	P182A10	BGH Joy Smart AXS
ZTE	ZTE Blade L2	P182A10	BGH Joy Smart AXS D
ZTE	ZTE Blade L2	P182A10	Blade L2
ZTE	ZTE Blade L2	P182A10	MEO Smart A75
ZTE	ZTE Blade L2	P182A10	ZTE Blade L2
ZTE	ZTE Blade Q Mini	P172G10_UK_VIRGIN	ZTE Blade Q Mini

Supported Devices

ZTE	ZTE Blade V	ZTE-Blade-V	Vodafone Blade V
ZTE	ZTE Blade V	ZTE-Blade-V	ZTE Blade V
ZTE	ZTE Blade V2	msm8916_32	ZTE Blade V2
ZTE	ZTE Blade VEC	P692S20_Q82	ZTE Blade VEC
ZTE	ZTE Blade Vec	P692S20_Q82	Blade Vec
ZTE	ZTE Blade Vec	P692S20_Q82	ZTE Blade Vec
ZTE	ZTE Blade Vec	P692S20_Q82	ZTE Geek 2
ZTE	ZTE Blade Vec 4G	msm8226	ZTE Blade Vec 4G
ZTE	ZTE Blade Vec Pro	P692S20_M92	ZTE Blade Vec Pro
ZTE	ZTE G601U	P172E02	ZTE G601U
ZTE	ZTE G717C	P692N30	ZTE G717C
ZTE	ZTE G718C	ZTE-G718C	ZTE G718C
ZTE	ZTE G719C	ZTE-G719C	ZTE G719C
ZTE	ZTE G720C	ZTE-G720C	ZTE G720C
ZTE	ZTE G720T	P839T30	ZTE G720T
ZTE	ZTE G720T	V_P839T30	ZTE G720T
ZTE	ZTE GEEK II 4G	msm8226	ZTE GEEK II 4G
ZTE	ZTE GEEK II Pro	ztexasp92_wet_jb9	ZTE GEEK II Pro
ZTE	ZTE GEEK II Pro	ztexasp92_wet_jb9	ZTE M1001
ZTE	ZTE Geek	redhookbay	ZTE Geek
ZTE	ZTE Geek 2 LTE	msm8226	ZTE Geek 2 LTE
ZTE	ZTE Geek 2 pro	P692S20_M92	ZTE Geek 2 pro
ZTE	ZTE Grand Era	enterprise_RU	ZTE Grand Era
ZTE	ZTE Grand Memo LTE	Grand-Memo	ZTE Grand Memo
ZTE	ZTE Grand Memo LTE	Grand-Memo	ZTE Grand Memo LTE
ZTE	ZTE Grand S Flex	iris	ZTE Grand S Flex
ZTE	ZTE Grand S II	P541T50	ZTE Grand S II
ZTE	ZTE Grand S II	P541T50	ZTE S221
ZTE	ZTE Grand S II	P897A21	ZTE Grand S II
ZTE	ZTE Grand S II LTE	msm8974	ZTE Grand S II LTE

Supported Devices

ZTE	ZTE Grand X 2	P682F06	Amazing A7
ZTE	ZTE Grand X 2	P682F06	ZTE Grand X 2
ZTE	ZTE Grand X 2	P682F06	ZTE V968
ZTE	ZTE Grand X 2	P682F06	ZTE V969
ZTE	ZTE Grand X Quad Lite	P188F07	Amazing A6
ZTE	ZTE Grand X Quad Lite	P188F07	V8602
ZTE	ZTE Grand X Quad Lite	P188F07	ZTE Grand X Quad Lite
ZTE	ZTE Grand X Quad Lite	P188F07	ZTE Grand X2
ZTE	ZTE Grand X Quad Lite	P188F07	ZTE Skate 2
ZTE	ZTE Grand X Quad Lite	P188F07	ZTE V967S
ZTE	ZTE Grand X2 In	redhookbay	Grand X2 In
ZTE	ZTE Grand X2 In	redhookbay	ZTE Grand X2 In
ZTE	ZTE Kis 3	ZTE-P821E10	MEO SMART A16
ZTE	ZTE Kis 3	ZTE-P821E10	MEO Smart A16
ZTE	ZTE Kis 3	ZTE-P821E10	MOCHE SMART A16
ZTE	ZTE Kis 3	ZTE-P821E10	ZTE Kis 3
ZTE	ZTE Kis 3	ZTE-P821E10	ZTE V811
ZTE	ZTE Kis Lite	roamer2	ZTE Kis Lite
ZTE	ZTE Kis Pro	nice	Optimus Zali
ZTE	ZTE Kis Pro	nice	ZTE Kis Pro
ZTE	ZTE Kis Q	P172D02	ZTE Kis Q
ZTE	ZTE LEO M1	V883M	V883M
ZTE	ZTE LEO M1	V883M	ZTE LEO M1
ZTE	ZTE LEO S1	V972M	V972M
ZTE	ZTE LEO S1	V972M	ZTE LEO S1
ZTE	ZTE LEO S2	V982M_Z64	ZTE LEO S2
ZTE	ZTE M901C	P692N60	ZTE M901C
ZTE	ZTE N5L	prmthus	ZTE N5L
ZTE	ZTE N5S	P189F10	ZTE N5S
ZTE	ZTE N795	deepblue	ZTE N795

Supported Devices

ZTE	ZTE N798	atlas40	ZTE N798
ZTE	ZTE N798+	ZTE_N798	ZTE N798+
ZTE	ZTE N798+	ZTE_N798P	ZTE N798+
ZTE	ZTE N799D	ZTE-N799D	N799D
ZTE	ZTE N799D	ZTE-N799D	ZTE N799D
ZTE	ZTE N818	ZTE-N818	N818
ZTE	ZTE N818	ZTE-N818	ZTE N818
ZTE	ZTE N880E	atlas40	ZTE N880E
ZTE	ZTE N880G	ZTE-N880G	ZTE N880G
ZTE	ZTE N900	ZTE-N900	ZTE N900
ZTE	ZTE N900D	ZTE-N900D	ZTE N900D
ZTE	ZTE N909	ZTE-N909	ZTE N909
ZTE	ZTE N909D	ZTE-N909D	ZTE N909D
ZTE	ZTE N9120	elden	ZTE N9120
ZTE	ZTE N919	ZTE-N919	ZTE N919
ZTE	ZTE N919D	ZTE-N919D	N919D
ZTE	ZTE N919D	ZTE-N919D	ZTE N919D
ZTE	ZTE N983	P177F03	ZTE N983
ZTE	ZTE N9835	chovar	N9835
ZTE	ZTE N9835	chovar	ZTE N9835
ZTE	ZTE N986	P188F02	N986
ZTE	ZTE N986	P188F02	ZTE N986
ZTE	ZTE Q101T	P810T10	ZTE Q101T
ZTE	ZTE Q201T	P172T24	ZTE Q201T
ZTE	ZTE Q2S-C	P826N50	ZTE Q2S-C
ZTE	ZTE Q2S-T	P826T50	ZTE Q2S-T
ZTE	ZTE Q301C	APT_TW_P810N30	ZTE Q301C
ZTE	ZTE Q301C	P810N30	ZTE Q301C
ZTE	ZTE Q301T	P172T33	ZTE Q301T
ZTE	ZTE Q501T	P172T31	ZTE Q501T

Supported Devices

ZTE	ZTE Q501U	P172F04	ZTE Q501U
ZTE	ZTE Q503U	P682V53	ZTE Q503U
ZTE	ZTE Q505T	P826T20	ZTE Q505T
ZTE	ZTE Q507T	P682T20	ZTE Q507T
ZTE	ZTE Q508U	P816V50	ZTE Q508U
ZTE	ZTE Q509T	P632T31	Amazing X5
ZTE	ZTE Q509T	P632T31	ZTE Q509T
ZTE	ZTE Q7	CMCC_P839V50	ZTE Q7
ZTE	ZTE Q7	P839V50	ZTE Q7
ZTE	ZTE Q705U	P682V60	ZTE Q705U
ZTE	ZTE Q801T	P181L30	ZTE Q801T
ZTE	ZTE Q801U	P826V30	ZTE Q801U
ZTE	ZTE Q802C	ZTE-Q802C	ZTE Q802C
ZTE	ZTE Q802D	ZTE-Q802D	ZTE Q802D
ZTE	ZTE Q802T	P826T30	ZTE Q802T
ZTE	ZTE Q805T	P120T55	ZTE Q805T
ZTE	ZTE R83	demeter	ZTE R83
ZTE	ZTE S118	P189S10	Grand S Lite
ZTE	ZTE S118	P189S10	ZTE S118
ZTE	ZTE S2004	msm8974	ZTE S2004
ZTE	ZTE S2005	msm8974	ZTE S2005
ZTE	ZTE STAR	msm8226	ZTE GEEK II Pro 4G
ZTE	ZTE STAR	msm8226	ZTE S2002
ZTE	ZTE STAR	msm8226	ZTE STAR
ZTE	ZTE STAR	msm8226	ZTE Star 1
ZTE	ZTE Skate	skate	ZTE Skate
ZTE	ZTE Switch X1	deepblue	ZTE Switch X1
ZTE	ZTE Switch X1	deepblue	ZTE V796
ZTE	ZTE T12	P173A30T	ZTE T12
ZTE	ZTE T28	bluetick	ZTE T28

Supported Devices

ZTE	ZTE T28	bluetick	ZTE T28 Prepaid
ZTE	ZTE T60	turies	ZTE T60
ZTE	ZTE T760	P173A10T	ZTE T760
ZTE	ZTE T790	roamer2	ZTE T790
ZTE	ZTE T792	ZTE-T792	ZTE T792
ZTE	ZTE T80	msm8226	ZTE T80
ZTE	ZTE T81	iliamna	ZTE T81
ZTE	ZTE T82	frosty	ZTE T82
ZTE	ZTE T83	demeter	ZTE T83
ZTE	ZTE T86	msm8226	Amazing X1
ZTE	ZTE T86	msm8226	ZTE T86
ZTE	ZTE T88	msm8226	ZTE T88
ZTE	ZTE U5S	P188T51	ZTE U5S
ZTE	ZTE U809	P172T11	ZTE U809
ZTE	ZTE U816	P988T20	ZTE U816
ZTE	ZTE U817	P117A20	ZTE U817
ZTE	ZTE U818	P172T21	ZTE U818
ZTE	ZTE U879	P172T30	ZTE U879
ZTE	ZTE U889	P183T30	ZTE U889
ZTE	ZTE U968	P682T51	ZTE U968
ZTE	ZTE U969	P682T50	ZTE U969
ZTE	ZTE U9815	P945T20	ZTE U9815
ZTE	ZTE U988S	pluto	ZTE U988S
ZTE	ZTE V5S	P189F13	ZTE Grand Memo lite
ZTE	ZTE V5S	P189F13	ZTE V5S
ZTE	ZTE V70	ZTE-V70	ZTE V70
ZTE	ZTE V7073	V7073	ZTE V7073
ZTE	ZTE V72	V72	MT7A
ZTE	ZTE V72	V72	ZTE V72
ZTE	ZTE V72	V72	myPad P4 Lite

Supported Devices

ZTE	ZTE V768	V768	ZTE V768
ZTE	ZTE V769M	V769M	V769M
ZTE	ZTE V769M	V769M	ZTE LEO Q2
ZTE	ZTE V769M	V769M	ZTE V769M
ZTE	ZTE V779M	ZTEV779M	ZTE V779M
ZTE	ZTE V790	roamer2	ZTE V790
ZTE	ZTE V791	P175A40	V791
ZTE	ZTE V791	P175A40	ZTE V791
ZTE	ZTE V792C	P810D01	ZTE V792C
ZTE	ZTE V793	P175A60	Amazing A3
ZTE	ZTE V793	P175A60	Cellcom 4G
ZTE	ZTE V793	P175A60	M9000
ZTE	ZTE V793	P175A60	Telcel T20
ZTE	ZTE V793	P175A60	ZTE KIS Flex
ZTE	ZTE V793	P175A60	ZTE V793
ZTE	ZTE V793	P175A60	tmn smart a6
ZTE	ZTE V795	P172D01	V795(A3S)
ZTE	ZTE V795	P172D01	ZTE B795
ZTE	ZTE V795	P172D01	ZTE KIS II
ZTE	ZTE V795	P172D01	ZTE KIS II PRO
ZTE	ZTE V795	P172D01	ZTE Kis II
ZTE	ZTE V795	P172D01	ZTE V795
ZTE	ZTE V797	P172D03	VIETTEL V8411
ZTE	ZTE V797	P172D03	ZTE V797
ZTE	ZTE V807	P177E01	Amazing A4
ZTE	ZTE V807	P177E01	Beeline E700
ZTE	ZTE V807	P177E01	Leopard MF900
ZTE	ZTE V807	P177E01	UZTE V807
ZTE	ZTE V807	P177E01	V8501
ZTE	ZTE V807	P177E01	ZTE BLADE C

Supported Devices

ZTE	ZTE V807	P177E01	ZTE V807
ZTE	ZTE V807	P177E01	ZTE V889S
ZTE	ZTE V808	P172E01	UZTE V808
ZTE	ZTE V808	P172E01	ZTE V808
ZTE	ZTE V809	P172A10	ZTE Blade C2
ZTE	ZTE V809	P172A10	ZTE T809
ZTE	ZTE V809	P172A10	ZTE V809
ZTE	ZTE V809	P172A10	meo smart a12
ZTE	ZTE V811	ZTE-V811	Beeline Smart2
ZTE	ZTE V811	ZTE-V811	ZTE V811
ZTE	ZTE V811C	P810E01	ZTE V811C
ZTE	ZTE V811W	P821E10	ZTE V811
ZTE	ZTE V811W	P821E10	ZTE V811W
ZTE	ZTE V813W	P172B20	ZTE Blade C2 Plus
ZTE	ZTE V813W	P172B20	ZTE V813W
ZTE	ZTE V815W	P172R10	Amazing A4S
ZTE	ZTE V815W	P172R10	B8405
ZTE	ZTE V815W	P172R10	KIS II Max
ZTE	ZTE V815W	P172R10	SMART Start
ZTE	ZTE V815W	P172R10	UZTE GRAND V7
ZTE	ZTE V815W	P172R10	ZTE Blade Buzz
ZTE	ZTE V815W	P172R10	ZTE Kis II Max
ZTE	ZTE V815W	P172R10	ZTE Maxx
ZTE	ZTE V815W	P172R10	ZTE T815
ZTE	ZTE V815W	P172R10	ZTE V815W
ZTE	ZTE V815W	P172R10	ZTE V816W
ZTE	ZTE V817	ZTE-V817	V817
ZTE	ZTE V817	ZTE-V817	ZTE V817
ZTE	ZTE V817	ZTE-V956	ZTE V817
ZTE	ZTE V818	P172F01	ZTE Blade 2

Supported Devices

ZTE	ZTE V818	P172F01	ZTE V818
ZTE	ZTE V829	P172A30	Blade G Pro
ZTE	ZTE V829	P172A30	V8507
ZTE	ZTE V829	P172A30	ZTE Blade G Plus
ZTE	ZTE V829	P172A30	ZTE Blade G Pro
ZTE	ZTE V829	P172A30	ZTE V829
ZTE	ZTE V879	P172F02	ZTE V879
ZTE	ZTE V880E	atlas40	ZTE V880E
ZTE	ZTE V880G	ZTE-V880G	ZTE V880G
ZTE	ZTE V887	P177A10	ZTE Blade L
ZTE	ZTE V887	P177A10	ZTE V887
ZTE	ZTE V887	P177A10	tmn smart a20
ZTE	ZTE V889D	atlas40	ZTE V889D
ZTE	ZTE V889M	P175A10	UZTE V889M
ZTE	ZTE V889M	P175A10	ZTE V889M
ZTE	ZTE V891	P986E01	ZTE V891
ZTE	ZTE V956	ZTE-V956	ZTE V956
ZTE	ZTE V965	P188F03	ZTE Blade G2
ZTE	ZTE V965	P188F03	ZTE R880H
ZTE	ZTE V965	P188F03	ZTE V880H
ZTE	ZTE V965	P188F03	ZTE V965
ZTE	ZTE V969	P682F01	ZTE V969
ZTE	ZTE V970	whistler	UZTE V970
ZTE	ZTE V970	whistler	ZTE V970
ZTE	ZTE V975	redhookbay	V975
ZTE	ZTE V975	redhookbay	ZTE Geek
ZTE	ZTE V975	redhookbay	ZTE V975
ZTE	ZTE V9800	kiska	ZTE V9800
ZTE	ZTE V9820	ZTE-V9820	ZTE V9820
ZTE	ZTE V983	P177A30	ZTE V983

Supported Devices

ZTE	ZTE V987	P188F04	UZTE GRAND X Quad
ZTE	ZTE V987	P188F04	ZTE Grand X
ZTE	ZTE V987	P188F04	ZTE V987
ZTE	ZTE V993W	ZTE_V993W	ZTE V993W
ZTE	ZTE V9A	v9plus	ZTE V9A
ZTE	ZTE Z932L	warplte	Z932L
ZTE	ZTE Z932L	warplte	ZTE Z932L
ZTE	ZTE-BLADE	blade	ZTE-BLADE
ZTE	ZTE-N910	arthur4g	ZTE-N910
ZTE	ZTE-SKATE	skate	ZTE-SKATE
ZTE	ZTE-U N721	N721	ZTE-U N721
ZTE	ZTE-U V760	ztenj73_gb	MD Smart
ZTE	ZTE-U V760	ztenj73_gb	Telenor Touch Mini
ZTE	ZTE-U V760	ztenj73_gb	ZTE-U V760
ZTE	ZTE-U V760	ztenj73_gb	ZTE-U V856
ZTE	ZTE-U V760	ztenj73_gb	ZTE-U V857
ZTE	ZTE-U V760	ztenj73_gb	moii E598
ZTE	ZTE-V6500	V6500	Etisalat Smartphone
ZTE	ZTE-V6500	V6500	ZTE-V6500
ZTE	ZTE-V856	zte_v856	ZTE-V856
ZTE	ZTE-X500	X500	ZTE-X500
ZTE	ZTE-Z990	roamer	ZTE-Z990
ZTE	ZTE-Z990G	roamer	ZTE-Z990G
ZTE	ZTE_LEO_Q1	hct72_wet_jb3	V765M
ZTE	ZTE_LEO_Q1	hct72_wet_jb3	ZTE LEO Q1
ZTE	ZTE_LEO_Q1	hct72_wet_jb3	ZTE V765M
ZTE	ZTE_LEO_Q1	hct72_wet_jb3	ZTE_CLARO_Q1
ZTE	ZTE_LEO_Q1	hct72_wet_jb3	ZTE_LEO_Q1
ZTE	ZTE_LEO_Q1	hct72_wet_jb3	mobifone M9001
ZTE	ZTE_N9511	hera	ZTE_N9511

Supported Devices

ZTE	ZTE_Q701C	ZTE-Q701C	ZTE Q701C
ZTE	ZTE_Q801C	ZTE-Q801C	ZTE Q801C
ZTE	ZTE_Q801L	ZTE-Q801L	ZTE Q801L
ZTE	ZXY-ZTE_N8010	N8010_YM	ZXY-ZTE_N8010
ZTE	ZXY-ZTE_V6700	V6700	ZTE V6700
ZTE	ZXY-ZTE_V6700	V6700	ZXY-ZTE_V6700
ZTE	blade S	blade2	Blade S
ZTE	myPad P5	K78	Amazing_P5
ZTE	myPad P5	K78	myPad P5
ZTE	nubia Z5	NX501	nubia Z5
ZTE	tmn smart a15	atlas40	tmn smart a15
ZTE	tmn smart a60	kiska	tmn smart a60
ZTE	tmn smart a7	sailboat	tmn smart a7
Zeki	TBDG734	TBDG734	TBDG734
Zeki	TBQG1084	TBQG1084	TBQG1084
Zeki	TBQG855	TBQG855	TBQG855
Zeki	Zeki TBDG1073	TBDG1073	TBDG1073
Zeki	Zeki TBDG874 Tablet	TBDG874B	TBDG874
Zeki	Zeki TBQC1063B	TBQC1063B	TBQC1063
Zeki	Zeki TBQG774	TBQG774	TBQG774
Zeki	Zeki TBQG884	TBQG884	TBQG884
Zilo	Zilo	Zilo	Zilo
bq	Aquaris E10	Aquaris_E10	Aquaris E10
bq	Aquaris E10 3G	Aquaris_E10_3G	Aquaris E10 3G
bq	Aquaris E4	Aquaris_E4	Aquaris E4
bq	Aquaris E4.5	Aquaris_E45	Aquaris E4.5
bq	Aquaris E5	Aquaris_E5	Aquaris E5
bq	Aquaris E5 FHD	Aquaris_E5_FHD	Aquaris E5 FHD
bq	Aquaris E5 HD	Aquaris_E5_HD	Aquaris E5 HD
bq	Aquaris E6	Aquaris_E6	Aquaris E6

Supported Devices

bq	Edison 3	Edison_3	Edison 3
bq	Edison_3_mini	Edison_3_mini	Edison 3 mini
bq	bq Edison 3 3G	Edison_3_3G	Edison 3 3G
essentielb	Essentielb- Black Diamond	bird77_a_cu_ics2	Essentielb-Black Diamond
essentielb	Pyxis	pyxis_boulanger	Essentielb-Pixis
essentielb	essentielb ST7001 Tablet	ST7001	ST7001
geanee	FXC-5A	FXC-5A	FXC-5A
harris	RF-3590-RT	msm8660_cougar	Harris 12131-1000
hisense	lt971	LT971	LT971
i-Buddie	TA10CA1	TA10CA1	TA10CA1
i-Buddie	TA10CA2	TA10CA2	TA10CA2
i-Buddie	TA10CA3	TA10CA3	TA10CA3
i-Buddie	TA10CA4	TA10CA4	TA10CA4
i-Buddie	TA71CA1	TA71CA1	TA71CA1
i-Buddie	TA71CA5	TA71CA5	TA71CA5
i-Buddie	TA80CA1	TA80CA1	TA80CA1
i-Buddie	TM75A-V2	TM75A-V2	TM75A-V2
i-Buddie	TR10CD1	TR10CD1_2	TR10CD1
i-Buddie	TR10CD1	TR10CD1_4	TR10CD1
i-Buddie	TR10CD1_P	TR10CD1	TR10CD1
i-Buddie	TR10CS1	TR10CS1_12	TR10CS1
i-Buddie	TR10CS1	TR10CS1_2	TR10CS1
i-Buddie	TR10CS1_P	TR10CS1	TR10CS1
i-mobile	IQX KEN	IQX_KEN	IQX KEN
i-mobile	i-mobile i-note WiFi 1.1	M1703	i-mobile M1703
iDea USA	CT8	CT8	CT8
iDeaUSA	iDeaUSA CT10	CT10	CT10
iDeaUSA	iDeaUSA CT7	CT7	CT7
iRiver		smdkc110	ILT-MX100
iRiver	DMT580D	m805_892x	DDA800R

Supported Devices

iRiver	DMT580D	m805_892x	DMT580D
iRiver	DMT580D	m805_892x	MIT700
iRiver	MM3202	mm3201	MM-3201
iRiver	MM3202	mm3201	MM-3202
iRiver	ULALA	msm7627a_sku3	I-K1
iRiver	WOW Tab+(ITQ1000)	itq1000	ITQ1000
iRiver	WPT005	wikipad	WPT005
iRiver	Wow TAB +	itq701	ITQ701
iRiver	Wow(Window of the world)	itq700	ITQ700
iRiver	Wow(Window of the world)	itq700	YBMK01
iView	776TPCIII	776TPCIII	776TPCIII
iView	iView 778TPC	778TPC	778TPC
iView	iView 788TPCII	iView_788TPCII	788TPCII
iView	iView 920TPC	920TPC	920TPC
iView	iView SupraPad i700	g01i	i700
iView	iView SupraPad i785Q	anchor	i785Q
mobicel	Retro	Retro	Retro
mobistel	Cynus T6	Cynus_T6	Cynus T6
myPhone	CUBE	myphone_cube	myPhone Cube
nabi	nabi 2 Tablet	mt799	NABI2-NV7A
nabi	nabi 2S Tablet	nabi2S	SNB02-NV7A
nabi	nabi Big Tab HD\“ 20"	DMTAB-NV20A	DMTAB-NV20A
nabi	nabi Big Tab HD\“ 24"	DMTAB-NV24A	DMTAB-NV24A
nabi	nabi DreamTab HD8 Tablet	DMTAB	DMTAB-IN08A
nabi	nabi DreamTab HD8 Tablet	t8400n	DMTAB-NV08B
oioo	oioo Model 2	wecct	Model 2
oioo	oioo Model 3	wecct3	Model 3
pendo	PNDPP44QC10	PNDPP44QC10	PNDPP44QC10
pendo	PNDPP44QC7	PNDPP44QC7	PNDPP44QC7
sugar_aums	QPOINT	QPI-1	QPI-1

Supported Devices

tecmobile	OmnisOne	OmnisOne	Omnis One
ucall	EASY1	EASY1	EASY1