

# ILLUMINATE YOUR PANEL

**REPLACE THE SHOULDER LIGHTS WITH  
FUNCTIONAL LEDS AND SHROUDS THAT PROVIDE  
10 TIMES THE LIGHT AT 1/10TH THE POWER**



## FEATURE

- DIMMABLE \*
- .04 AMPS EACH
- 26,280 HOURS LIFE
- RED LIGHT (633 nm)
- EASY INSTALLATION
- ONLY LOG BOOK ENTRY REQ'D
- DOESN'T GET HOT

**GO FROM THIS**

**TO**

**THIS**



**For Purchase Contact:  
Short Wing Piper Club Store  
<http://www.shortwingpiperclub.org/>**

**KIT INCLUDES :  
- 2 LED LIGHTS  
- 2 SHROUDS**

**TOM ANDERSON  
5401 Crooked Tree Dr.  
Mason, Ohio 45040  
PHONE: 513-398-2656  
[LIGHTKIT@CINCI.RR.COM](mailto:LIGHTKIT@CINCI.RR.COM)**


\* Requires at least 1 incandescent in the dimming circuit

## Light Kit Installation Instructions


1. Remove Grimes lens holder from the light socket. It just snaps off.



2. Remove the bulb from the socket by pushing in and turning the bulb counter clockwise.
3. Rotate the socket so that it points toward the front of the plane and insert the LED bulb into the light socket and turn clockwise to lock it in.



4. Install the shroud on the socket and snap into position



5. Installation is complete. Check to make sure the light illuminates and dims with the panel rheostat. Make an entry in you log book of the installation and noting that this is a minor alteration.