

UK USER GUIDE AIR COOLER

WARNINGS

- Do not carry the air cooler when filled with water. Some water may remain in the unit even if the tank is empty.
- Use only clean water. If needed, use distilled water.
- The air cooler works best in non-polluted areas. Large dust/dirt particles may reduce the lifetime of the unit.
- We recommend to use the air cooler only in dry locations. If used in a moist area or environment, take care not to get water on the external parts of the product.
- If a leak or spill occurs on the surface of the device, unplug the air cooler and let it dry for 24 hours. Then, use as normal.
- Do not place in direct sunlight for extended periods of time.
- Before not using the air cooler for an extended period of time, empty the water tank, turn the unit on, and set to the highest fan speed for at least 4 hours. This will dry out the filter and the inside of the air cooler.
- Only use the original power cord supplied in package.
- Do not touch the power supply or power cord with wet hands.
- Unplug the air cooler when cleaning, removing/replacing filter or moving the device.
- For the best results, place the air cooler on a higher surface like a table or countertop.
- Do not place the air cooler near a heater or any electrical equipment.

- Do not place the device in passageways or high traffic areas where there is a possibility of tripping or knocking it over.
- Do not allow any foreign objects inside air cooler.
- Do not place items on top of the air cooler.
- Do not block the front and back grills of the device.
- Do not turn the device upside down.
- Do not submerge the air cooler under water or in other liquids.
- Do not place the air cooler near open flames or fire sources.
- The device can be switched off completely only when disconnected from the power supply.
- The manufacturer does not bear any responsibility for any damage from failure to comply with this product guide.
- A replaceable water filter is designed specifically for this product. If your cartridge has been broken or damaged, you can purchase a replacement.
- For domestic use only


TIPS

- Place the air cooler on a raised surface such as a table, desk or counter top. This is the best way to cool your personal area faster.
- Try to stay within a few feet of the air cooler. You'll feel the most benefit when sitting directly in front of it.

SETUP

1. Place the air cooler on a flat surface.
2. Open the lid of the water tank and fill with water. We recommend a pitcher or measuring cup.
3. Plug USB power adapter into an outlet. Then, insert the larger USB end of the cable into the adapter and

the smaller end into the power port on the back of the air cooler. You can also connect the USB plug with a computer.



USAGE

1. Press power button to power on Air Cooler. (fig. 1)
2. Press the (fig. 4) button to turn on the LED light. The light has 8 different colors: color changing, light green, orange, purple, green, blue, red and white. Press the button once to turn on the lights, and the color of the light switches automatically. Press twice to keep the fixed display color. Then each button is pressed to adjust the color until the light is turned off.
3. Press (fig. 3) button to turn on the water diffuser.
4. Press (fig. 2) button to set the speed of the air conditioner; low, medium or high. The indicator above the button shows the speed.

NOTE: We recommend running Air Cooler on HIGH mode for at least 5 minutes before powering off to allow for drying.

MAINTENANCE

We recommend cleaning the water tank and inside of the unit once weekly. Use only a non-abrasive cloth and mild dish soap when needed.

THE ENVIRONMENT

When this product reaches the end of its useful life, hand it in at a collection point for the recycling of electric and electronic equipment. Please refer to the symbols on the

product, the users instructions or the packaging. Contact your municipality for the address of the appropriate collection point in your neighbourhood.

SPECIFICATIONS

Dimension	16 x 16 x 16 cm
Water tank capacity	260 ml / 8.8 fl.oz
Power supply	USB, 5VDC / 1A

NL GEBRUIKERSHANDLEIDING LUCHTKOELER

WAARSCHUWINGEN

- Verplaats de luchtkoeler niet als deze gevuld is met water. Er kan wat water in het apparaat terecht komen, zelfs als de tank leeg is.
- Gebruik alleen schoon water. Gebruik indien nodig gedestilleerd water.
- De luchtkoeler werkt het beste in schone omgeving. Grote hoeveelheden stof/vuildeeltjes kunnen de levensduur van het apparaat verkorten.
- We raden aan om de luchtkoeler alleen in een droge omgeving te gebruiken. Zorg er bij gebruik in een vochtige ruimte of omgeving voor dat geen water op het product terecht komt.
- Als er een lek of lekkage optreedt aan het oppervlak van het apparaat, trek dan de stekker uit het stopcontact en laat de luchtkoeler 24 uur drogen. Gebruik daarna zoals gewoonlijk.
- Niet gedurende langere tijd in direct zonlicht plaatsen.
- Voordat u de luchtkoeler voor langere tijd niet gebruikt, moet u het waterreservoir legen, het apparaat inschakelen en