


Table Top and Glass Rack Assembly




RGR parts
4 1 1/4" #6 screws

RTT parts
3 1 1/4" #6 screws


Note: Glass rack, table top and individual racking all sold separately. Above elevation is for instructional purposes only.

1. Screw through glass rack into adjacent racks on either side using a 1 1/4" #6 screw



Glass rack will be flush with front spacer bars

2. Remove temporary 1x2 behind table top nosing



3. Screw up through top front spacer into table top using (3) 1 1/4" #6 screws.

