

HOW TO CHANGE THE TEMPERATURE





3. Press or lowers the temperature. Each press raises or lowers the temperature by 1°F (1°C)



The same setting is selected the next time simply by pressing 🥨