



## Cloud Portal Demo Instructions

The HiLIFE Portal is available for demonstration without registering an account. To demo the Portal, follow these steps:

1. Go to <https://hilifeportal.com>
2. Enter the username and password in the upper right corner of the home page:
  - Username/email: [demo@demo.com](mailto:demo@demo.com)
  - Password: 654321!

The screenshot shows the HiLIFE Portal home page. The page features the HiLIFE logo at the top left, the text "Powered by HIGHLIGHT Industries" in the center, and a photograph of a modern industrial building. In the upper right corner, a login form is highlighted with a red box. The login form includes a "LOGIN" button, a text input field for the username "demo@demo.com", a password input field with masked characters, and a "Sign In" button. Below the photograph, there is a paragraph of text describing the company's mission and services.

3. You will arrive at the Dashboard once logged in; from here you can view Data, Graphs, and Reports for a demo machine. Simply click through the tabs to view data as you would for your own HiLIFE system.

The first screenshot shows the HiLIFE Portal dashboard with a table of data for a specific machine. The table has columns for Date, Time, Actual %, Target %, Upper Limit %, Lower Limit %, Alarm, and Other. The data is as follows:

Date	Time	Actual %	Target %	Upper Limit %	Lower Limit %	Alarm	Other
11/22/2016	05:24:49 pm	288.03	200	253	207	Yes	All Data
11/22/2016	05:24:47 pm	243	200	253	207	No	All Data
11/22/2016	05:22:24 pm	243	200	253	207	No	All Data
11/22/2016	05:40:40 pm	243	200	253	207	No	All Data
11/22/2016	05:40:39 pm	243	200	253	207	No	All Data
11/22/2016	05:40:17 pm	243	200	253	207	No	All Data
11/22/2016	05:47:54 pm	243	200	253	207	No	All Data
11/22/2016	05:58:32 pm	243	200	253	207	No	All Data
11/28/2016	11:32:23 am	100	200	253	207	Yes	All Data
11/28/2016	11:25:30 am	200	200	253	207	Yes	All Data

The second screenshot shows a line graph titled "Unwind Length" for Machine 11112. The graph displays a fluctuating line representing the unwind length over time, with a green horizontal line indicating a target or average value. The x-axis is labeled "Date/Time Range" and the y-axis is labeled "Unwind Length".

The bottom screenshot shows the HiLIFE Portal dashboard with a navigation menu (DASHBOARD, DATA, GRAPHS, REPORTS, SUPPORT) and a "New Report" button. Below the button, there is a table with columns for Name, Frequency, Enabled, and Tasks. The table contains one entry:

Name	Frequency	Enabled	Tasks
Supervisory Summary	Daily	No	Edit Delete

The dashboard also shows a "Showing 1 to 1 of 1 entries" message at the bottom right.