



# USER MANUAL

**Model# BATC-002**




[www.Boshel.com](http://www.Boshel.com)



## PACKAGE INCLUDES:

- 1 x Remote
- 1 x Receiver
- 1 x Nylon Belt
- 1 x USB Charging Cable
- 1 x Charger
- 1 x Test Bulb
- 1 x User Manual
- 1 x Warranty information



- ① LCD Screen
- ② Static Shock Button
- ③ Vibration Button
- ④ Beep Button
- ⑤ Automation Button
- ⑥ Intensity Up/down Button
- ⑦ Channel Button
- ⑧ Universal Button
- ⑨ Power Button
- ⑩ Charging port
- ⑪ Power Button
- ⑫ DC-5V port



## DESCRIPTION:

- 1. LCD Screen:** The LCD Screen will display the training modes, the mode that is in use will flash. It will also display the levels, and battery indication. It will also display which channel you are currently using (this is for when you use this controller with 2 collars, however, only 1 is included in the package).
- 2. Static Shock Button:** By pressing the "*Static Shock*" button, the receiver will emit a shock.
- 3. Vibration Button:** By pressing the "*Vibration*" button, the receiver will vibrate.
- 4. Beep Button:** By pressing the "*Beep*" button, the receiver will emit a beep sound.
- 5. Automation Button:** By pressing the "*Automation*" button, the receiver will change to automatic mode.
- 6. Intensity - Up/down Buttons:** Selects the level of the beep, vibration and static Shock. It also Selects the sensitivity of automatic mode.
- 7. Channel Button:** Pressing the "1/2" button will shift channel between the first and second collar receiver. (only 1 included)
- 8. Universal Button:** Sends the signal from transmitter to receiver. (For example, when vibration mode is chosen, pressing the vibration or universal button can send out vibration signal.)
- 9. Turn on/off the transmitter:** Turn on/off the transmitter by pressing the "*Power*" button one time.
- 10. Charging port:** Insert charging cable (included) into charging port to charge the Transmitter.
- 11. Turn on/off the Receiver:** Turn on/off the receiver by pressing the "*Power*" button one time.
- 12. DV-5V hole:** Insert charging cable (included) into DC-5V port to charge the receiver.

### **FEATURES:**

- ▶ New ergonomic modern high-end design
- ▶ Easy-to-operate, user- friendly design
- ▶ Receiver is fully rainproof
- ▶ Rechargeable controller and receiver (recharger included)
- ▶ Could be used as an automatic bark collar when you choose auto mode
- ▶ Automatic intensity level is adjustable by 7 levels
- ▶ 3 training modes; Beep/Vibrate/Static shock
- ▶ The 3 training modes are adjustable by 7 levels
- ▶ Remote range up to 800 yards
- ▶ The system can be used for 2 receivers, (only 1 receiver included)
- ▶ LCD display
- ▶ Power saving design

## INSTRUCTIONS:

**Note:** *Please make sure the product is fully charged before using!*

### Charging the remote controller:

- 1) Connect the charger cable to the charging port.
- 2) Plug the charger into a standard outlet.
- 3) The battery icon on the LCD display will flash.
- 4) Charge the transmitter for about one hour for the first charge or until the battery icon stops flashing.

### Charging the receiver:

- 1) Connect the charger cable to the DC-5V port.
- 2) Plug the charger into a standard wall outlet.
- 3) The red light will flash on the receiver. (if it has no power, you might see a green light instead of the flashing red light)
- 4) Charge the receiver for about one hour for the first charge, or until the light indicates that charging is complete. (The red light will disappear)

### Pairing the remote controller and receiver

- 1) Turn on the remote controller (by pressing the "power" button).
- 2) Choose channel 1 for pairing (by pressing the  $\frac{1}{2}$  button).
- 3) Turn on the receiver (by pressing the "power" button)



4) Press the "Power" button on the receiver again.

5) The collar receiver will beep if connected successfully.

6) After a beep from the receiver, press the "Vibration button" within 30 seconds for pairing.

7) If the pairing was not successful, please repeat steps 3-6.

8) To match the second receiver, press the "1/2" button and select the second receiver and follow the same procedure. (second receiver not included)

### **Adjusting the level of the beep, vibration and shock:**

Press the "+" or "-" buttons to adjust the levels of beep, vibration and shock modes to get the perfect level that works best with your dog.

### **Using the training system in manual mode:**

Select the mode you would like to use on your dog by pressing the designated button, then every time you would like that the receiver should emit a beep/vibrate/shock, make sure it is in the right mode and level(as explained above) and press the "Arrow" button. Follow the same steps for testing the system before using it on your dog

- To test the shocking mode place the light bulb on the metal screws of the receiver, and follow the above instructions, the test bulb will turn red, that indicates that the receiver emitted a shock.



### **How to change to automatic mode:**

Press the "Automation" Button and the receiver will emit a "Beep Beep" sound which indicates that it is changed to automatic mode.

### How to test automation mode:

- 1) Connect the test bulb to the two metal screws on the receiver



- 2) Look for the test area on the receiver. (it says "TEST" and some lines in the sides, these lines are the test area)
- 3) Scratch on the test area on the receiver, the receiver will vibrate first and shock afterwards (when the light on the test bulb turns on, that means that the receiver is emitting a shock).

### Adjusting the receiver sensitivity under automatic mode:

After entering into the automation mode, press down the "+" or "-" button on the controller to adjust the sensitivity to the level that best suits your dog, then press the "Automation" button again.

### Adjusting the level of the vibration and shock under the automation mode:

Switch to the manual mode, press the "+" or "-" button to adjust to the level of vibration and shock that works best with your dog, then press the "Automation" button again to re-enter automatic mode.

**Note:** Under automation mode, in order to ensure the safety of the dog, the product will enter the protected mode after work for 5 times consecutively. When in protected mode, the product will not work no matter how the dog barks. It is required to wait for a few minutes or press the "Automation" button to activate the product.



### **Important Notes:**

1. For the safety of your pet, the maximum amount of time you can press the vibration or static shock to your pet continuously is 15 seconds (in manual mode). After this, the vibration or static shock will stop, and the button must be released and pressed again.
2. The transmitter will be changed to Standby Mode if there are no operations after 5 seconds. Press any button to take it out of the standby mode.
3. The receiver will be changed to Standby Mode if there are no operations for one minute. Any movements from the dog will activate the receiver.
4. In working mode, if you want to reconnect the receiver to the transmitter, simply press the "Power" button, there will be a beep sound indicating that it is ready to be matched.
5. The design of the receiver is waterproof on level IP7 which makes the receiver fully waterproof. However, make sure your dog does not swim with it for too long to ensure that the nylon collar stays in good condition.
6. In order for the receiver to be fully waterproof, the rubber cover has to be put in the right position. Failure to follow this step can break the receiver and may void the warranty.
7. In common, if the battery is full, the receiver can work for 5 days, and the transmitter 10 days.
8. The valid distance of the remote means the straight-line distance between the Transmitter and the Collar Receiver without obstacles in between. If there are interference signals or other disruptions, the actual remote control distance may vary.
9. Training sessions should be kept positive and short, 10-15 minutes for each session is recommended.
10. Presently, this product is the most effective and safest tool for training or barking prevention. When you follow the correct operational instructions, you can effectively train the pet without any problems.
11. Once your pet is well trained you probably wont have to use this product on a regular basis. However, You may need to reinforce training with the Receiver Collar from time to time.
12. The collar is adjustable from length 5.9"(15cm)to 19.6"(50cm)
13. Our Lithium battery can charge 2000 times for Remote Controller and Receiver Collar.

## **WARNINGS:**

- Make sure to read and follow the instructions carefully. It is important to use the collar correctly. Failure to do so may harm your pet.
- Do not use this product for your aggressive dog, or if your dog is prone to aggressive behavior. Aggressive dogs may cause damage to the people or things around. If you are unsure whether this product is appropriate for your dog, please consult your veterinarian or certified trainer.
- Make sure the collar is not too tight on your dog, wearing a tight collar may cause skin damage.
- Avoid wearing the collar on the dog for more than 12 hours per day.
- If possible, reposition the collar every 1 to 2 hours.
- Never connect a dog rope or leash hook to the collar, it will cause excessive pressure on the contact area. And may cause skin damage or potentially harm your pet.
- Wash the neck area of your dog and the contact area of the collar weekly with a damp cloth.
- Examine the contact area of dog daily, lest rash or sore appears.
- If you see unusual conditions on your pets neck, immediately discontinue to use the product for a few days. If the condition persists beyond 48 hours, consult your veterinarian for help. Once the skin recovers, check the skin condition of your pet frequently.

## **General Training Tips**

***The following tips will show you how to get the best performance out of your Dog Training Collar.***

- (1) Make training sessions short and positive (about 10-15 minutes for each session.) This will enable the dog to focus on the trainer.
- (2) Training one dog each time is recommended.
- (3) During the first initial training sessions, keep the dog in a familiar outdoor environment. Training in a place that the dog is not familiar with may make the dog become distracted.
- (4) Use a long leash fastened to a non-metallic collar to help the dog to learn.

Ensure that the additional collar and leash does not interfere with the Contact Points of the Collar Receiver. Do not use the remote training collar without a long leash unless your dog is fully trained.

(5) More success will occur by teaching the dog a command first before trying to reinforce the command with the Remote Transmitter.

(6) For basic obedience training, vibration is more useful.

(7) Issue one obedience command each time, this will reduce confusion and allow the dog to remain focused. Do not use the training system for commands that the dog has not learned.

(8) During training, look for all the positive changes in the dog's behavior and remember to encourage it promptly with ample praise and reward.

(9) Avoid over-correcting your dog. Use as less remote correction as possible during the training process.

(10) When the dog has become apparently perplexed, shift the focus of the training by drawing the dog's attention to a command they have been familiar with.

Example: Tell the dog to sit and give abundant praise and encouragement on successful completion of the sit command.

(11) Do not use the training system to correct or eliminate aggressive or biting behavior. When the dog is showing signs of aggressive behavior, contact a professional dog trainer in your local area immediately.

(12) Please keep in mind that training sessions should be kept short. Stop Training and play with the dog when the dog has made progress.

