



## MSH-RPTR-CC Quick Start Guide

The MSH-RPTR-CC connects directly to a computer to allow the user to interface to the Mesh Network devices on the BZSS network. This interface will allow the user to monitor and configure the BZSS devices and MSH-RPTR family products.

This apparatus is suitable for use in Class I, Division II, group: D-T4, or unclassified locations.



**WARNING: EXPLOSION HAZARD. DO NOT MOVE OR REPLACE COMPONENTS OR CONNECTORS WHILE THE CIRCUIT IS LIVE OR UNLESS THE AREA IS KNOWN TO BE FREE OF IGNITABLE CONCENTRATIONS.**



**WARNING: SUBSTITUTION OF THE COMPONENTS MAY IMPAIR SUITABILITY FOR DIVISION 2**

Full user's manual can be downloaded from  
<http://www.bzensors.com>